Alarm Help - MV SERIES -



ALARM ADDRESS	A23.2	ALARM NO.	2082
OP. MESSAGE	AXES ZERO POINT RETURN REQUESTED.		
Related Signal			
CAUSE	Each time, when machine power on , this prompt will show on the screen • (Except the axis with ABS. Linear scale)		
ACTION	1. Select Zero return mode. X Y 2. Select axis 3. Press zero return start button	Z 6.	