QUASER
we cut faster

ALARM ADDRESS	A12.6	ALARM NO.	1186
ALARM TEXT	NOW => ATC-ARM AT 0D		
Related Signal	Input: X0.4 ,X0.5 , X0.6 , X0.7 (MV154/154APC/MV204) , 　　　　X6.4 ,X6.5 ,X6.6 ,X6.7(184C) 。 　　　　ARM AT 0 Degree Position 。		
CAUSE	In ATC service mode, This is a prompt for operator 。		
ACTION			