
WARNING: DO NOT connect this thermostat to voltages higher than 24 Volt AC, such as: base-board heaters, line/high-voltage fan-coil, or systems with transformers providing higher than 24VAC. Improper use of this device can result in personal injury, and/or property damage.

- 1.Introduction: Fidure's A1-730 thermostat is an HVAC powered (24VAC) wireless thermostat designed for common heating ventilation and air-conditioning systems. The ZigBee wireless-controller allows the device to operate as a long-range ZigBee message repeating router.
- **2. Using the device:** Using the device and operating the onscreen menus is straight forward. The buttons are located on the right edge of the thermostat with the symbols shown below:



Use the Up and Down buttons to move the selector arrow, the Menu button to select/confirm an option and the Cancel button to cancel or go back without affecting change.

3. The menu system: The interface menu is activated via the Menu button. The pointer can be moved using the up/down buttons and selection is confirmed by the Menu button. The Cancel button allows the user to leave the menu without making any changes.

Main Menu

Hold Temperature Heat/Cool Mode Fan Control Options ▶ Settings

Schedule

4. ZigBee Network Commissioning:

Join a ZigBee HA 1.2 network using: menu -> Settings -> Network -> Join Network.

This also activates EZ-Mode network commissioning. The options on the network menu perform the following:

- · Open the network for other devices to join
- Show current network information
- Enable Identify Mode on the device
- Find and Bind to an identifying device supporting thermostat cluster client

Network

▶ Join Network (EZ-Mode) Network Info

Note on Joining: If more than one network is open at the time and the device has <u>just</u> joined one of them, choosing 'Leave Network' allows the device to automatically join another open network. This can be repeated until the correct network has been joined.

Network

▶ Leave Network Open Network (EZ-Mode) Network Info Identify (EZ-Mode) Find (EZ-Mode)

5. Mode of operation (Heat/Cool): To reach the Mode Menu, press the menu button and scroll down using the up/down buttons. Once the indicator arrow points to the "Heat/Cool Mode", press the menu button. The available options are:

Off: The thermostat will disengage from running the cooling or heating system and stop controlling the temperature. The device itself, will stay on.

Heat Only: The thermostat will only engage the heating system.

Cool Only: The thermostat will only engage the cooling system.

Auto Changeover: This mode is useful in climates where the daytime temperatures may be hot and night time cold, requiring heating for part of the day and cooling the other. In this mode, the thermostat will apply heating or cooling depending on the set-point temperatures programmed. Once the temperature falls below or exceeds the heat/cool set-points by~2°F (1°C), the thermostat will automatically changeover between heat and cool to accommodate the comfort settings.

6. Fan Control: In the **Automatic** setting option the air circulating fan will turn on automatically when the heating or cooling cycles start. In some cases it may be preferred to keep the fan **Always** on

Schedule

Select Schedule Type:

▶ Same For Everyday

Weekdays, Weekends

for continuous air circulation.

7. Schedule

Programming: The schedule menu can be accessed via menu-schedule. On this screen you can choose

the preferred schedule pattern. Selecting 'None' on this menu deletes the current schedule.

None

Custom

Once you have chosen the schedule type, the next screen allows you to program further details. You can navigate between day, interval, start time, and heat/cool settings. Switch between options using the Up/Down keys and select using the Menu button. The 'Next' option allows you to sequentially enter the schedule information. Changes are only saved once the Menu button is pressed while on the 'Done' option is selected.

Note: The scheduled program will only activate if the clock has been set either automatically via ZigBee time service, manually via the clock menu, or 15 minutes after power up.

nutes

Heat To: 16.0°C

Cool To: 23.5°C

Everyday

Schedule

At Time: 11: 30 PM

Next ↑↓ Done

Hold Temperature

Till Next Interval

Till Specified Time

Resume Schedule

Sleep

schedule with the following sequence:

Menu->Schedule>'Same For Everyday'>Menu->Up (Sleep),
then press and hold
the 'Menu' button until
the screen cycles to

'Done' and Main Screen is displayed.

7. Pausing Schedule / Hold Temperature: You can instruct the thermostat to hold the current set-point temperature for a period of time. Hold menu is available from Main menu and can be accessed by pressing the Menu button twice. The following options are available:

Creating a schedule quickly: You can create a default

▶ For Now

4 Hours

Hold For Now: Hold the current set-point temperature until instructed otherwise.

Hold For 4-hours Hold the current set-point for four hours.

Hold Till Next Interval: Hold current set-point until the beginning of the next scheduled interval.

Hold Till Specified Time (Vacation Mode): Hold current set-point until a specified time and date.

Resume Schedule: Resume following the schedule for setpoint temperature.

8. Options Menu:

Along with Time
Format and
Temperature Unit, the
following preferences
can be set through the
Options menu which is
accessible via Main

Options

24-Hour Time

Celsius Temperature
Peek at Next Schedule

Clock Auto-Adjust
Auto-Brightness

-Schedule Peek: Adjust the temperature in advance to start the next interval closer to set-point.

-Automatically Update the Clock if a ZigBee Time Server is available.

-Automatically adjust the thermostat backlight according to ambient light conditions.

9. System Setup: System setup Menu allows you to configure the thermostat to your existing Heating and Cooling system. It can be accessed via Main Menu -> Settings Menu -> Systems Setup.

System Setup

▶ System Type Heating Fan Control Heating Cycle Rate Auto Change-Over

System Type A1-730 Supports single stage cooling and heating, such as a combination air- conditioner/furnace or a heat pump. The System Type menu allows you to choose among: Cool only, Heat Only, Heat Only with Fan (for electric heat furnaces), Heat Pumps, as well as conventional Furnace and Air Conditioner set up (Heating and Cooling).

Heating Fan Control: In some systems it is required that the thermostat explicitly turn on the fan during heat cycles (e.g. some electric heat systems). This menu allows you to specify the

thermostat behavior and fan control during heat cycles.

Heating Fan Control

▶ Heating System Thermostat **Heating Cycle Rate:** Use this setting to match your heating/cooling system for best temperature control and life expectancy of your HVAC system. Below are the corresponding values for Cycles -per-Hour:

Heating Cycle Rate

▶ Gas/Oil Furnace Electric Furnace HighEfficiency Furnace Hot-water System Gas/Oil Steam, Gravity

- Gas/Oil Forced-Air Furnace (less than 90% efficiency) [5]
- Electric Heating Furnace [9]
- High Efficiency (more than 90% efficiency) Forced-Air type Furnace [3]
- Hot Water system [3]
- Gas/Oil, Steam and gravity system [1]

10. Setting the Clock: When there is no ZigBee Time Service available on the network, the thermostat clock can be manually set through the Settings -> Clock menu. Use the Up/ Down buttons to change the values and the Menu button to confirm and move to the next field.

Set Clock

▶02: 41 PM 2014- 11- 22 Done

Tamper Lock

11. Tamper Lock: In addition to the ZigBee (over the network) screen lock feature, the screen can be locked locally via the Tamper Lock screen (accessible through Main Menu -> Settings-> More -.> Tamper Lock).

Use the Up/Down buttons to adjust the values and Menu button to move to the next field/digit.

Important: Store or Remember the lock code you set. There

Menu to the

A Set Unlock Code:

b4 3 2 1

Activate

are no override codes or resets available to unlock a thermostat once it's been locked. ONLY the code use to activated the lock will unlock the thermostat.

Note: Tamper lock works independently of the Keypad Lock

available via the ZigBee network functions supported by some Home Automation Systems.

For further information visit **www.fidure.com** or email customer support at **support@fidure.com**.

For USA customers:



Declaration of Conformity

Trade Name: FIDURE

Model No.: A1730

Address: 3421 Yonge st.,

Toronto, ON Canada M4N 2N1

This device complies with Part15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

"WARNING: To satisfy FCC RF exposure requirements for mobile transmitting devices, a separation distance of 20cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operations at closer distances than this are not recommended."

Contains FCC ID:QPU3020

For Canadian Customers:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Contains transmitter module IC:4523A-SN3020

Limited Warranty Thermostat

Fidure Thermostat

IMPORTANT INFORMATION ABOUT YOUR RIGHTS AND OBLIGATIONS, AS WELL AS LIMITATIONS AND EXCLUSIONS THAT MAY APPLY TO YOU.

The disclaimers, exclusions, and limitations of liability under this Limited Warranty will not apply to the extent prohibited by applicable law. Please refer to the laws applicable in your jurisdiction.

1. WHAT THIS LIMITED WARRANTY COVERS; PERIOD OF COVERAGE

Fidure Corp. ("Fidure"), 3421 Yonge St. Ontario, Canada, warrants to the owner of the enclosed product that the product contained in this box ("Product") will be free from defects in materials and workmanship for a period of two (2) years (or one (1) year for Factory Refurbished Products) from the date of delivery following the original retail purchase (the "Warranty Period"). If the Product fails to conform to this Limited Warranty during the Warranty Period, Fidure will, at its sole discretion, either (a) repair or replace any defective Product or component; or (b) accept the return of the Product and refund the money actually paid by the original purchaser for the Product, Repair or replacement may be made with a new or refurbished product or components, at Fidure' sole discretion. If the Product or a component incorporated within it is no longer available. Fidure may replace the Product with a similar product of similar function, at Fidure' sole discretion. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been renaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of ninety (90) days from the date of delivery or the remaining Warranty Period This Limited Warranty is transferable from the original purchaser to subsequent owners, but the Warranty Period will not be extended in duration or expanded in coverage for any such transfer.

2. TOTAL SATISFACTION RETURN POLICY

If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition within thirty (30) days of the original purchase and receive a full refund.

3. WARRANTY CONDITIONS; HOW TO GET SERVICE IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY

Before being able to claim under this Limited Warranty, the owner of the Product must (a) notify Fidure of the intention to claim by visiting Fidure.com/support during the Warranty Period and providing a description of the alleged failure, and (b) comply with Fidure' return shipping instructions. Fidure will have no warranty obligations with respect to a returned Product if it determines, in its reasonable discretion after examination of the returned Product, that the Product is an Ineligible Product (defined below). Fidure will bear all costs of return shipping to owner and will reimburse any shipping costs incurred by the owner, except with respect to any Ineligible Product, for which owner will bear all shipping costs.

4. WHAT THIS LIMITED WARRANTY DOES NOT COVER

This warranty does not cover the following (collectively "ineligible Products"): Products marked as "sample" or sold "AS IS"; or Products that have been subject to: (a) modifications, alterations, tampering, or improper maintenance or repairs; (b) handling, storage, installation, testing, or use not in accordance with the User's Guide or other instructions provided by Fidure; (c) abuse or misuse of the Product; (d) breakdowns, fluctuations, or interruptions in electric power or the telecommunications

network; or (e) Acts of God, including lightning, flood, tornado, earthquake, or hurricane. This warranty does not cover consumable parts, including batteries, unless damage is due to defects in materials or workmanship of the Product, or software (even if packaged or sold with the product). Unauthorized use of the Product or software can impair the Product's performance and may invalidate this Limited Warranty.

5. DISCLAIMER OF WARRANTIES

EXCEPT AS STATED ABOVE IN THIS LIMITED WARRANTY, AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, FIDURE DISCLAIMS ALL EXPRESS, IMPLIED, AND STATUTORY WARRANTIES AND CONDITIONS WITH RESPECT TO THE PRODUCT, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, FIDURE ALSO LIMITS THE DURATION OF ANY IMPLIED WARRANTIES OR CONDITIONS TO THE DURATION OF THIS LIMITED WARRANTY.

6. LIMITATION OF DAMAGES

IN ADDITION TO THE ABOVE WARRANTY DISCLAIMERS, IN NO EVENT WILL FIDURE BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, EXEMPLARY, OR SPECIAL DAMAGES, INCLUDING ANY DAMAGES FOR LOST DATA OR LOST PROFITS, ARISING FROM OR RELATING TO THIS LIMITED WARRANTY OR THE PRODUCT, AND FIDURE' TOTAL CUMULATIVE LIABILITY ARISING FROM OR RELATED TO THIS LIMITED WARRANTY OR THE PRODUCT WILL NOT EXCEED THE AMOUNT ACTUALLY PAID FOR THE PRODUCT BY THE ORIGINAL PURCHASER.

7. LIMITATION OF LIABILITY

FIDURE AND FIDURE'S PARTNERS' ONLINE SERVICES ("SERVICES") PROVIDE YOU INFORMATION ("PRODUCT INFORMATION") REGARDING YOUR FIDURE PRODUCTS OR OTHER PERIPHERALS CONNECTED TO YOUR PRODUCTS ("PRODUCT PERIPHERALS"). THE TYPE OF PRODUCT PERIPHERALS THAT MAY BE CONNECTED TO YOUR PRODUCT MAY CHANGE FROM TIME TO TIME. WITHOUT LIMITING THE GENERALITY OF THE DISCLAIMERS ABOVE, ALL PRODUCT INFORMATION IS PROVIDED FOR YOUR CONVENIENCE, "AS IS", AND "AS AVAILABLE". FIDURE DOES NOT REPRESENT, WARRANT, OR GUARANTEE THAT PRODUCT INFORMATION WILL BE AVAILABLE ACCURATE OR RELIABLE OR THAT PRODUCT INFORMATION OR USE OF THE SERVICES OR PRODUCT WILL PROVIDE SAFETY IN YOUR HOME. YOU USE ALL PRODUCT INFORMATION, THE SERVICES, AND THE PRODUCT AT YOUR OWN DISCRETION AND RISK. YOU WILL BE SOLELY RESPONSIBLE FOR (AND FIDURE DISCLAIMS) ANY AND ALL LOSS, LIABILITY, OR DAMAGES, INCLUDING TO YOUR WIRING, FIXTURES, ELECTRICTY, HOME, PRODUCT, PRODUCT PERIPHERALS, COMPUTER, MOBILE DEVICE, AND ALL OTHER ITEMS AND PETS IN YOUR HOME. RESULTING FROM YOUR USE OF THE PRODUCT INFORMATION. SERVICES, OR PRODUCT. PRODUCT INFORMATION PROVIDED BY THE SERVICES IS NOT INTENDED AS A SUBSTITUTE FOR DIRECT MEANS OF OBTAINING THE INFORMATION. FOR EXAMPLE A NOTIFICATION PROVIDED THROUGH THE SERVICE IS NOT INTENDED. AS A SUBSTITUTE FOR AUDIBLE AND VISIBLE INDICATIONS IN THE HOME AND ON THE PRODUCT, NOR FOR A THIRD PARTY MONITORING SERVICE THAT MONITORS ALARM

8. VARIATIONS THAT MIGHT APPLY TO THIS LIMITED WARRANTY

Some jurisdictions do not allow limitations on how long an implied warranty lasts or exclusions/limitations on incidental or consequential damages, so some of the limitations set out above may not apply to you.