OPERATING INSTRUCTIONS

With the interface installed you can now view the TV picture on the move.



If you wish to de-activate the "video in motion" feature you may, by pressing and holding the RETURN button on the steering wheel for 3 seconds. Do the same to activate the "video in motion" feature.



VIMCANMER4

VIDEO IN MOTION MERCEDES S / CL 2006 on With TV Tuner

NAV TV (Europe) LTD



NAV TV (Europe) LTD

Distribution Centre Unit 21B Vale Business Park Llandow, Vale of Glamorgan CF71 7PF

Telephone: + 44 (0)8445 783 783 + 44 (0)1446 77 22 47 Fax:

technical@nav.tv

LOCATION & REMOVAL

Installation is made at the front of the vehicle at the CD changer

CL class;

First remove the vent trim below the screen, then remove the 1 screw that holds the trim, the trim will then pull. Then as S Class to remove the CD Changer unit.

S class;

To remove the unit you will first need to remove the trim and door by removing 4 screws, 2 at the top of the unit behind the small hinged flaps, and two behind the leather- trim panel (trim clips only to remove) with the door and trim removed to will see 4 screws securing the unit, see photos below;







INSTALLATION

Locate the 20 pin black plug that houses the fibre optic cables, remove the plug and slide out the insert as shown below.



TO REMOVE PINS PRESS THE SPRUNG TAB IN THE INSERT HOLES

Remove the YELLOW/WHITE cable (pin 1) and insert it into the YELLOW/WHITE male pin provided and insulate. Then insert the female YELLOW/WHITE pin provided into the black plug (pin1)

Next remove the YELLOW cable (pin 11) and insert it into the YELLOW male pin provided and insulate. Then insert the YELLOW female pin provided into the black plug (pin 11)

Connect the RED cable to 12v+ permanent, you may use the red/blue cable in pin 10.

Connect the PURPLE cable to 12v+ permanent, you may use the red/blue cable in pin 10.

Connect the BLACK cable to 12v– ground, you may use the brown cable in pin 20.

INSTALLATION

If you have connected the interface and now have no steering wheel controls, or you only have the Mercedes logo on screen, or the screen does not come on / go off with the key you have inserted the CAN HIGH and CAN LOW incorrectly, please check pin numbers given.