


10050	`O` RING	11962	SEAL, M14, BONDED	15395	CLIP, PIPE SUPPORT,
10053	`O` RING, 3/4" ID (9	11970	SETSCREW, M6 X 25	15396	CLIP, PIPE SUPPORT,
10149	OIL COOLER, EC100 (1	13050	ADAPTOR, 3/8" BSP MA	15398	CLIP
10151	TUBESTACK, 3", EC100	13062	ADAPTOR, 3/8" BSP MA	15400	CLIP, PIPE SUPPORT,
10153	END CAP, 1.1/4" OD,	13066	ADAPTOR, 3/8" BSP MA	15401	CLIP, PIPE SUPPORT,
10161	TUBESTACK, 3", EC120	13080	ADAPTOR, 1/4" BSP MA	15462	PIPE, 1.1/4" RAW WAT
10171	`O` RING	13081	ADAPTOR, 1/4" BSP MA	15485	PIPE, 1.1/4" RAW WAT
10179	SPACER, COOLER COUPL	13082	ADAPTOR, 1/4" BSP MA	16120	HOSE, 1.1/4" X 2.1/2
10183	`O` RING (OIL COOLER	13084	ADAPTOR, 1/4" BSP MA	16121	HOSE, 1.1/4" X 4.1/2
11036	BOLT, CENTRE (FUEL F	13085	ADAPTOR, M16 FEMALE	16122	HOSE, 1.3/4" X 2.1/2
11056	GASKET, THERMOSTAT H	13095	ADAPTOR 1/2" NPTF MA	16123	HOSE, 1.3/4" X 3.3/4
11057	ELEMENT, THERMOSTAT	13100	ADAPTOR, 1/2" BSP MA	16125	HOSE, 2" X 1.3/4", R
11060	`O` RING, THERMOSTAT	13102	ADAPTOR, 1/2" BSP MA	16126	HOSE, 1.3/4" X 90 DE
11062	CAPSCREW, M10 X 40,	13110	ADAPTOR, 1/2" BSP MA	16127	HOSE, 2" X 1.1/4", R
11066	END CAP, WITH DRAIN	13111	ADAPTOR, 1/2" BSP MA	16128	HOSE, 1.3/4" X 1.1/4
11068	SCREW, END COVER (SE	13150	ADAPTOR, 3/4" BSP MA	16131	HOSE, 3/4" X 2.1/2"
11069	SCREW, CAM, RAW WATE	13170	ADAPTOR, 1" BSP MALE	16132	HOSE, 1.1/4" X 90 DE
11070	CAM, RAW WATER PUMP	13184	ADAPTOR, 7/8" UNC MA	16140	HOSE, 5" I.D X 2.5" (
11074	NUT, RAW WATER PUMP	13745	HOSE END, 1/4" BSP F	16143	HOSE, 1.3/4" X 1.1/4
11083	HOUSING, BEARING	13750	HOSE, 3/8" ID, 1 WIR	16146	HOSE, 1.1/4" X 8" (S
11090	SHAFT, RAW WATER PUM	13760	HOSE, 1/2" ID, 1 WIR	16148	HOSE, 1.1/4" X 45 DE
11094	PUMP, 1" BSP, RAW WA	13780	HOSE END, 1/2" BSP F	16149	HOSE, 1.1/4" PIPE CL
11095	SEAL ASSEMBLY, SHAFT	13790	HOSE END, 3/8" BSP F	16150	CAP, BLANKING, 2" X
11164	CAPSCREW, M6 X 30, S	13791	HOSE END, 3/8" BSP F	16152	HOSE, 2" X 1.3/4", 9
11171	HOUSING, EC100, OIL	13800	HOSE END, 1/2" BSP F	16153	HOSE, 1.3/4" X 1.1/2
11175	RING, RETAINING	15010	SERVICE KIT, 1" RAW	16154	CAP, BLANKING, 1.5/8
11589	CAM, RAW WATER PUMP	15011	SERVICE KIT, 3/4" RA	16155	HOSE, 1.1/2" X 1.1/4
11611	HOSE ASSEMBLY (3/8,	15012	WEARPLATE (JABSCO 3/	16161	BELLOWS, EXHAUST, 5"
11623	COLLAR, THRUST	15013	END COVER (JABSCO 3/	16163	HOSE, 2" X 2.1/2" (S
11629	SEAL, SPLIT RING	15014	WEARPLATE (JABSCO 1"	16166	HOSE, 1.1/4" X 90 DE
11632	HOSE ASSEMBLY (3/8,	15015	END COVER (JABSCO 1"	17034	PIPE, INJECTION PUMP
11635	END COVER, WITH DRAI	15017	GEARWHEEL (JABSCO PU	17048	TURBOCHARGER (330)
11637	`O` RING	15019	GASKET, END COVER (J	17049	HOSE, 1.1/4" X 90 DE
11638	TUBESTACK	15021	IMPELLER (JABSCO 1")	17050	NUT, 1/4" OD PIPE
11728	SETSCREW, M12 X 25	15022	IMPELLER (JABSCO 3/4	17051	OLIVE, 1/4" OD PIPE
11800	HOSE, 3/8" ID, TEXTI	15023	GASKET, END COVER	17064	PIPE, 1.1/4" FLANGED
11855	ADAPTOR, 1/4" BSP MA	15071	ELBOW, 1" BSPT MALE	17085	HOSE ASSEMBLY (3/8,
11858	HOSE ASSEMBLY (1/4,	15074	SOCKET, BRASS, 1/4"	17086	PIPE, OIL DRAIN, TUR
11880	HOOD, SWITCH, WATERP	15228	PIPE, 1.1/4" FLANGED	17101	PIPE, 3/4" S.S INTER
11884	HOLDER, LAMP, RED LE	15229	PIPE, 1.1/4" FLANGED	17113	`O` RING, 2.48" ID X
11885	HOLDER, LAMP, YELLOW	15300	PIPE, 1.3/4", MANIFO	17114	OIL COOLER, EC120
11886	BULB, 12V, 1.2W (SIG	15334	(FLANGE, BRASS, STUB	17115	HOUSING, OIL COOLER,
11887	BULB, 24V, 1.2W (SIG	15373	PIPE, 1.1/4" S.S. RE	17166	SETSCREW, M12 X 35
11893	BOLT, 1/2" UNF X 6"	15378	PIPE, 1.1/4" S.S. RE	17206	COUPLING, FLEXIBLE,
11907	TAB HOUSING (180940-	15381	PIPE, REMOTE CLR TO	17225	HOSE ASSEMBLY (3/8,
11924	PULLEY, 125MM, SINGL	15385	TIE, 9MM X 275MM	17237	SWITCH, SINGLE POLE,

SABRE


PLANT & MARINE




Unit 1 Castle Street
Castlepark Industrial Estate
Ellon, Aberdeenshire
AB41 9RF, Scotland, UK
Tel: +44 (0)1224 877667
Email: sales@sabrepm.com
Web: sabrepm.com

17294	GASKET, TURBOCHARGER	18775	BELT, ALTERNATOR (EJ	19696	PIVOT, CONTROL CABLE
17320	GASKET, TURBOCHARGER	18788	CLAMP, VEE BAND (LEH	19720	AUDIBLE WARNING DEVI
17340	ELEMENT, AIR CLEANER	18789	GASKET, STEEL, EXHAU	19734	DAMPER DRIVE PLATE (
17361	STUD, M8 X 36, S.S.	18791	ELBOW 1" BSPT MALE X	19738	SOLENOID, STOP, 24V
17465	THERMOSTAT ASSEMBLY	18806	WASHER, M6, FLAT (BR	19739	RELAY, 12V (LEHMAN N
17505	MANIFOLD, EXHAUST	18876	OLIVE, 10MM OD PIPE	19740	RELAY, 24V (LEHMAN N
17506	PIPE, DRAIN WITH FLA	18891	PIPE, 1.1/4" FLANGED	19741	OIL COOLER (LEHMAN N
17508	SETSCREW, M8 X 25, S	18948	HOSE ASSEMBLY (1/2,	19744	SWITCH, PUSH BUTTON
17538	IMPELLER, COMPRESSOR	19002	ADAPTOR, 3/8" BSP MA	19745	SWITCH, SINGLE POLE
17547	BRACKET, PIPE SUPPOR	19009	NUT, M5, SELF LOCKIN	19747	HOSE, 1" ID, MOULDED
17582	PIPE, 1.1/4" S.S. WA	19061	AIR CLEANER	19764	CONNECTION KIT, GEAR
17617	ADJUSTER ARM (RAS)	19062	ELEMENT, AIR CLEANER	19793	TACHOMETER 0-4000 LE
17658	COMPLETE ON BOARD SP	19233	SCREW, END COVER, SE	19799	POSITIVE LOCK RECEPT
17929	BOLT, M16 X 50	19234	GASKET, END COVER	19820	STARTER, 24V, S115-2
17954	ADAPTOR 3/8" BSP MAL	19244	SEAL, SPLINE	19845	ADAPTOR, CONDUIT, 25
18013	TUBESTACK, INTERCOOL	19268	PUMP, 1" BSP, RAW WA	19848	MOUNT, ENCLOSURE BOX
18014	INTERCOOLER ASSEMBLY	19269	MOUNT, FLEXIBLE, ENG	19849	LOOM, ENGINE WIRING,
18015	INTERCOOLER ASSEMBLY	19272	SHAFT, RAW WATER PUM	19852	BRACKET, CONTROL BOX
18046	RELAY, 12V	19279	ALTERNATOR, 24V, A12	19863	BULB, RED, 24V
18047	RELAY, 24V	19302	MANIFOLD, EXHAUST 35	19875	MOUNT, FLEXIBLE, ENG
18060	SPACER, 11MM ID X 19	19377	WASHER, M20, SPRING	19879	ADAPTOR, EXHAUST, TU
18068	GEARBOX, MPM IRM 220	19394	PLUG, BLANKING, 10MM	19880	CONNECTOR, EXHAUST,
18153	'O' RING	19472	CLAMP, VEE BAND (LEH	19881	EXHAUST OUTLET, WATE
18154	OIL COOLER & FILTER,	19570	SCREW, M5 X 12, PAN	19884	JACKET, THERMAL, EXH
18155	OIL COOLER & FILTER,	19579	NUT, M6, SELF LOCKIN	19898	HOSE, 1.3/4" X 1.3/8
18158	HOUSING, ENGINE OIL	19582	FILTER, FUEL SEDIMEN	19899	HOSE, SUCTION, 25MM
18180	MOUNT, FLEXIBLE, ENG	19600	BELT (LEHMAN NO. 2B2	19901	OIL COOLER (LEHMAN N
18194	MOUNT, FLEXIBLE, ENG	19607	PUMP, 3/4" BSP, RAW	19904	HOSE, 1.3/4" X 90 DE
18357	TIE, 4.8MM X 190MM	19609	HOSE CLIP, SIZE 35,	19917	EXHAUST ELBOW, DRY,
18386	WASHER, M8, FLAT, BR	19610	HOSE, 1" X 3"	19933	HOSE, WIRE REINFORCE
18390	NUT, M8, BRASS	19617	HOSE, 1.3/4" ID, MET	19941	HOSE, WIRE REINFORCE
18408	TRANSDUCER, TACHO	19633	HEADER TANK ASSEMBLY	19945	HOSE, WIRE REINFORCE
18465	LOOM, INTERCONNECTIN	19634	CAP, PRESSURE, 7 PSI	19958	CLIP, PIPE SUPPORT,
18471	GASKET, CYLINDER HEA	19639	HOSE ASSEMBLY, HEADE	19959	CLIP, PIPE SUPPORT,
18520	HEADER TANK/HEAT EXC	19640	HOSE, 1" X 180 DEG E	20110	DAMPER DRIVE PLATE,
18591	RING, PISTON, UPPER	19643	GASKET, INNER, INLET	20300	COUPLING, PROP SHAFT
18592	RING, PISTON, LOWER	19644	GASKET, AIR CLEANER	20310	COUPLING, FLEXIBLE,
18593	RING, PISTON, OIL CO	19646	ELEMENT, AIR CLEANER	20311	COUPLING, GEARBOX (R
18607	ADAPTOR, 1/4" BSP MA	19650	FILTER, CARTRIDGE, O	20312	COUPLING, FLEXIBLE,
18621	HOSE END 1/4" BSP FE	19651	HOSE ASSEMBLY (LEHMA	20313	COUPLING, FLEXIBLE,
18622	HOSE END, 1/4" BSP F	19653	HOSE ASSEMBLY (LEHMA	21077	DAMPER DRIVE PLATE (
18706	INJECTOR	19654	BRACKET, OIL COOLER	21078	ADAPTOR HOUSING, PRM
18758	PIPE, LIFT PUMP TO F	19655	BRACKET, OIL COOLER	21080	COUPLING, PROP SHAFT
18760	HOSE CLIP, SIZE 50,	19656	ADAPTOR, 1/2" BSP MA	26164	BELT (LEHMAN NO 2B24
18761	LIFT PUMP, FUEL (A.C	19687	GASKET, END CAP (LEH	26169	SPRING (LEHMAN NO 2P
18773	NOZZLE ASSEMBLY	19688	ANODE, ZINC, ASSEMBL	26171	CONNECTOR, 3/4" BSPT


Perkins Sabre Marine Parts List
Contact us today for a quote.




26192	PRINTED CIRCUIT BOAR	27078	STUD AND NUT KIT, FL	33015	ADAPTOR, 1/4" BSP MA
26201	SCREW, M3 X 16, SLOT	27091	GEARBOX, PRM 750D, 2	33016	HOSE ASSEMBLY (3/8,
26213	FUSE, 5 AMP, INSTRUM	27100	GEARBOX, PRM 1000D,	33017	PIPE, 1.1/4", RAW WA
26240	HOUSING, 2 WAY, POSI	27105	DAMPER DRIVE PLATE,	33018	STRAINER, RAW WATER,
26241	MOUNT, FLEXIBLE, ENG	27113	CLIP, PIPE SUPPORT,	33019	HOSE, 1.3/4" X 90 DE
26263	CONNECTOR, TAB, FAST	27121	MOUNT, FLEXIBLE, ENG	33020	PIPE, 1.1/4", HEAT E
26264	BRACKET, GEAR CONTRO	27122	STUD AND NUT KIT, FL	33021	`O` RING (RAW WATER
26302	STARTER, 12V, S115-1	27125	TAP, DRAIN, METAL (S	33024	BRACKET, HEAT EXCHAN
26316	ELBOW, EXHAUST (SHIL	27127	WARNING LIGHT, LOW O	33027	GASKET, MANIFOLD, OU
26319	`O` RING	27128	WARNING LIGHT, HIGH	33029	NUT, M10, EXTENDED,
26363	HEATSHIELD, TURBOCHA	27129	WARNING LIGHT, CHARG	33030	CONNECTOR, LIQUID TI
26379	HOSE, 1.3/4" X 3.1/4	27169	INSULATOR, TERMINAL,	33035	BRACKET, REAR LIFTIN
26442	HOSE, SUCTION, WIRE	27170	INSULATOR, TERMINAL,	33036	SHIELD, WASTEGATE
26481	HOSE, 1" X 2"	27175	ALTERNATOR, 24V-110	33037	HEATSHIELD, TURBOCHA
26489	DAMPER DRIVE PLATE,	27177	DAMPER DRIVE PLATE,	33038	PIPE, OIL FEED, TURB
26501	HOSE ASSEMBLY (3/8,	27268	GEARBOX, PRM 750C, 1	33040	PIPE, OIL DRAIN, TUR
26530	PAINT, PERKINS PREST	27309	CAP, 31.8 MM, BLACK	33041	PIPE, DRAIN, WITH FL
26531	PAINT, TOUCH UP, PER	30004	TUBE, NYLON, 5/16"OD	33043	CAPSCREW, M12 X 20,
26620	HOSE ASSEMBLY (1/4,	30006	RESERVOIR, THERMOSTA	33044	PIPE, FUEL, LIFT PUM
26642	BAG, POLYTHENE SELF	30016	PIPE ASSEMBLY, THERM	33045	PIPE, BOOST CONTROL
26663	GASKET KIT, ENGINE O	30030	OLIVE, 3/16" OD PIPE	33046	PIPE, THERMOSTART
26667	CLIP, PIPE SUPPORT,	30031	NUT, MALE, 3/16" OD	33049	DUCT, INTERCOOLER TO
26685	LOOM, INTERCONNECTIN	30033	ADAPTOR, 3/16" ENOTS	33051	HOUSING, INTERCOOLER
26686	AIR CLEANER/SILENCER	30066	ELBOW, STEM, 3/16" O	33053	BUSH, RUBBER
26702	HOSE CLIP, SIZE 25,	30070	OLIVE, 3/8" (ENOTS)	33054	HOSE, 1" MOULDED
26756	BRACKET, GEAR CONTRO	30085	PLUG, 1/8" BSPT, SOC	33055	Pipe, 1"OD, crankcase
26774	STUD, M16, FLEXIBLE	30086	PLUG, 1/8" NPTF, SOC	33058	CONNECTOR, EXHAUST,
26787	MOUNT, FLEXIBLE, MET	30088	PLUG, 1/4" NPTF, SOC	33059	SPACER, 11MM ID X 14
26794	BELLOWS ASSEMBLY, EX	30089	PLUG, 1/4" BSPT (STE	33061	HOUSING, AIR CLEANER
26800	FLANGE, TABLE D 3" NO	30117	WASHER, 8MM (FUEL PI	33062	ELEMENT, AIR CLEANER
26804	GASKET, EXHAUST, 4"	30118	NUT, TUBING, 8MM BUN	33063	SUPPORT, AIR CLEANER
26807	FLANGE EXHAUST TABLE	30119	SLEEVE, 5/16" ID RUB	33064	HOSE, TURBO INTAKE
26821	HOSE ASSEMBLY (3/8,	30120	OLIVE, 5/16" OD PIPE	33065	GASKET, MANIFOLD, IN
26824	HOSE ASSEMBLY	30121	NUT, 5/16" OD PIPE	33066	CIRCLIP, THERMOSTAT
26832	HOSE ASSEMBLY, 2METR	30150	NUT, FEMALE, 3/16" O	33067	SPACER, THERMOSTAT
26833	HOSE ASSEMBLY, 1M, SED	30152	TUBING, PTFE 1/8" ID	33068	TURBOCHARGER
26834	HOSE ASSEMBLY (1/2,	31000	HOSE, 1 METRE X 5/1	33069	FLANGE, TURBO OIL FE
26835	THERMOSTART, 24V DE	33005	HOSE, 3/4" X 2" (TUR	33070	FLANGE, SECURING, IN
26871	HOSE, 1/4" ID X 0.87	33006	ADAPTOR, 3/8" BSP MA	33073	BRACKET, REAR MOUNTI
26874	ALTERNATOR, MOTOROLA	33008	`O` RING (INTERCOOLE	33074	SPACER, 10.5MM ID X
26901	TAP, BALL VALVE, 3/8	33009	PIPE, 1.3/4", MANIFO	33076	BRACKET, UPPER, HEAT
26902	CONNECTOR, 3/8" BSPT	33010	THERMOSTAT, 80 DEG C	33077	HOSE, 2" X 2.9/16"
26933	SCREW, M4 X 16, PAN	33011	HOUSING, THERMOSTAT	33078	WASHER, M8, FLAT (LA
27023	NYLON CONDUIT, HARNE	33012	BRACKET, SUPPORT (PI	33080	BRACKET, MOUNTING, G
27065	GASKET, MANIFOLD	33013	KIT, PIPE, 3 WAY CAS	33081	STUD, M10 X 24 NOMIN
27077	MOUNT, FLEXIBLE, ENG	33014	HOSE, 1" X 90 DEG	33083	CAPSCREW, M10 X 25,




33084	‘O’ RING (SUMP ADAPT	33180	LOOM, INTERCONNECTIN	33332	BRACKET, AUXILIARY A
33085	STUD, M16 X 30 NOMIN	33181	‘Y’ HARNESS	33333	BELT (A43)
33087	HOSE, 2" X 1.3/4", R	33182	HOSE ASSEMBLY (1/2,	33334	BELT (A49)
33088	HOSE, 1.3/4" X 2.1/2	33187	SEAL, SHAFT	33336	HOSE ASSEMBLY (1/2,
33089	HOSE, 2" X 1.3/4", R	33188	BEARING, RAW WATER P	33337	HOSE ASSEMBLY (1/2,
33090	HOSE, 3" X 2.1/2"	33189	RING, RETAINING	33338	ADPT PLATE, SAE 3 H/
33091	HOSE, 1.1/2" X 2.3/8	33190	GEAR, RAW WATER PUMP	33341	PIPE, 1.1/4", WATER
33092	HOSE, 2" X 3"	33191	SHAFT, RAW WATER PUM	33342	BELT GUARD, AUXILIAR
33093	HOSE, 2.1/8" X 2.1/2	33192	SERVICE KIT, RAW WAT	33343	HOSE ASSEMBLY (3/8,
33096	HOSE, 2" X 1.1/4", R	33194	THERMOSTART DROPPING	33344	HOSE ASSEMBLY (3/8,
33099	GASKET, EXHAUST, MAN	33202	BOLT, M8 X 35, S.S.	33345	BRACKET, SUPPORT (TU
33101	NUT, M8, EXTENDED (S	33204	BELT GUARD/LOOM COVE	33346	PIPE, DRAIN, WITH FL
33102	ELBOW, BLEED, HEADER	33206	FLANGE, WELD, EXHAUS	33347	PIPE, 1.1/4", GEARBO
33104	FLANGE, BY-PASS AND	33210	PLUG, BLANKING, 9.5M	33348	PIPE, 1.1/4", GEARBO
33106	ELBOW, BLEED, HEADER	33212	BADGE, HEADER TANK,	33349	PIPE, 1.1/4", HEAT E
33107	PIPE, 1.3/4" FLANGED	33214	CLAMPING RING, TAPPE	33350	BRACKET, MOUNTING, G
33110	HOSE, 1/4" ID X 0.13	33215	FLANGE, FILLER NECK	33351	OIL COOLER, GEARBOX
33111	HOSE, 1/4" ID X 0.86	33216	‘O’ RING (HEADER TAN	33352	CLAMP, GEARBOX OIL C
33118	SHIELD, WASTEGATE AC	33217	NECK, FILLER (PLATIN	33353	HOSE, 1.1/4" X 90 DE
33119	HOSE, 2" X 1.1/4", R	33224	ELBOW, 1.1/2" BSPT M	33354	PIPE, 1.1/4", INTERC
33120	ADAPTOR, POWER TAKE-	33225	CONNECTOR, 1.1/2" BS	33355	ELBOW, BLEED. (OLD
33121	PIPE, FLANGED, EXHAU	33227	SCREW, M4 X 16, CHEE	33356	HOSE, 1/4" ID X 0.43
33124	EXHAUST BELLOWS ASSE	33228	SCREW, M4 X 25, RECE	33357	HOSE ASSEMBLY (3/8,
33125	HOSE, 1.1/4" X 45 DE	33237	PIPE, 5/16" OD X 20	33358	HOSE ASSEMBLY (3/8,
33126	BOLT, M12 X 45 (10.9	33239	GEARBOX, HURTH HSW 6	33359	HOSE, 1" MOULDED
33128	PUMP, 1" BSP, BELT D	33241	ADAPTOR PLATE, SAE 3	33360	HEADER TANK ASSEMBLY
33129	PUMP, 1" BSP, BELT D	33242	DAMPER DRIVE PLATE,	33362	GEARBOX, HURTH HSW 6
33130	PUMP, 1.5" BSP, BELT	33244	MOUNT, FLEXIBLE	33365	BADGE, HEADER TANK,
33131	PUMP, 1.5" BSP, BELT	33258	PLUG, BLANKING, 1.1/	33371	HOSE, GEARBOX OIL CO
33132	PULLEY, 125MM, TRIPL	33277	ENGINE TURNING DEVIC	33372	HOSE, RAW WATER PUMP
33133	BUSH, TAPER LOCK, 2"	33279	HOSE ASSEMBLY (3/8,	33373	BRACKET, LOWER, HEAT
33136	COMPLETE ON BOARD SP	33281	ELEMENT, ENGINE BREA	33375	PIPE, 1" OD, CRANKCA
33137	SHIM, ADJUSTMENT, BI	33285	PIPE, 1.1/4", INTERC	33376	PLATE, SECURING, DIP
33138	HOSE, 2.1/8" X 1.1/4	33286	PIPE, 1.1/4", GEARBO	33377	BRACKET, SUPPORT
33141	ADAPTOR, 1/2" NPTF M	33314	BOLT, 3/8" UNF X 1.1	33378	GROMMET
33142	HOSE, 1.1/4" X 2.1/2	33315	HOSE ASSEMBLY (3/8,	33383	HOSE ASSEMBLY (3/8,
33143	OIL COOLER, GEARBOX	33317	BRACKET, GEAR CONTRO	33384	HOSE ASSEMBLY (3/8,
33144	PIPE, 1.1/4", RAW WA	33321	GEARBOX, HURTH HSW 6	33391	CLIP, PIPE SUPPORT,
33145	PIPE, 1.1/4", GEARBO	33323	HOSE CLIP, SIZE 100,	33392	PIPE, THERMOSTART
33147	PIPE, 1.1/4", INTERC	33324	HOSE, 1" ID X 90 DEG	33415	COVER, CYLINDER HEAD
33149	SENDER, TEMPERATURE,	33325	PIPE, 1.1/4", S.S. K	33421	HOSE, 1.3/4" X 2.1/8
33150	RESISTOR, DROPPING,	33326	PIPE, 1" S.S. 3 WAY,	33422	BRACKET, THERMOSTART
33173	CAPSCREW, M6 X 10, S	33327	PLUG, BLANKING, 1.3/	33423	RESISTOR, DROPPING,
33175	TUBESTACK, HEAT EXCH	33329	BELT (A47)	33426	COMPLETE ON BOARD SP
33177	END CAP (BLANKING WI	33330	INLET DUCT, NATURALL	33427	HOSE ASSEMBLY (3/8,
33179	LOOM, INTERCONNECTIN	33331	ELEMENT, AIR CLEANER	33428	HOSE ASSEMBLY (3/8,




33429	DAMPER DRIVE PLATE (	33542	MANIFOLD, EXHAUST (4	33691	HOSE, 3/8" ID X 0.40
33431	ADAPTOR HOUSING, PRM	33546	BRACKET, UPPER, BELT	33693	JACKET, THERMAL, EXH
33432	EXHAUST ELBOW, HIGH	33548	GASKET, EXHAUST, TUR	33694	JACKET, THERMAL, 90
33434	GASKET, EXHAUST	33550	AIR CLEANER ASSEMBLY	33696	`O` RING, TURBOCHARG
33435	EXHAUST BELLOWS ASSE	33551	PIPE, 1.3/4", MANIFO	33701	PIPE, 1.1/4", INTERC
33437	EXHAUST CONNECTOR, 9	33552	HOSE, BY-PASS, FRESH	33702	PIPE, 1.1/4", GEARBO
33439	FLANGE, EXHAUST, WEL	33553	FLANGE, BY-PASS, FRE	33706	EXHAUST OUTLET, WATE
33441	TUBE, EXTENDED DIPST	33559	INLET DUCT, TURBO TO	33708	ADAPTOR, 3/8" BSPT M
33442	SPACER, 10.5MM ID X	33560	HOSE, AIR INLET DUCT	33709	ELBOW, IRON, 3/8" BS
33443	HOSE, WIRE REINFORCE	33563	MANIFOLD, EXHAUST, C	33710	SOCKET, RELAY, WITH
33447	HOSE ASSEMBLY (1/2,	33564	BRACKET, SUPPORT, EX	33713	PIPE, INJECTOR, CYL
33450	EXHAUST OUTLET, MANI	33565	BRACKET, SUPPORT, MA	33717	DRAIN MANIFOLD ASSEM
33462	HOSE, 5/8" X 2.1/4"	33567	HEATSHIELD, TURBOCHA	33718	PIPE, DRAIN MANIFOLD
33463	HOSE CLIP, SIZE 8-16	33568	PAINT, AEROSOL SPRAY	33719	ALARM TANK ASSEMBLY
33464	HOSE, 3/8" ID X 0.48	33573	EXHAUST OUTLET, WATE	33724	PIPE KIT, FUEL INJ.
33467	HOSE, 1" X 5/8" REDU	33574	DAMPER DRIVE PLATE,	33745	PLUG, BLANKING, ROCK
33473	INSTALLATION DATA, P	33578	HOSE, 1.3/4" X 90 DE	33746	HEADER TANK ASSEMBLY
33487	BRACKET, MOUNTING, A	33585	TUBE, DIPSTICK	33761	WASHER, SEAL, COPPER
33489	SPACER, 8.5MM ID X 1	33586	JACKET, THERMAL, WAT	33762	MOUNTING KIT, ALARM
33492	HOSE ASSEMBLY (3/8,	33587	JACKET, THERMAL, EXH	33771	PIPE, 3 WAY CASTING,
33494	HOSE ASSEMBLY (3/8,	33588	JACKET, THERMAL, EXH	33773	DAMPER DRIVE PLATE,
33495	LOOM, ENGINE WIRING,	33589	DAMPER DRIVE PLATE,	33774	BONDING WIRE, RAW WA
33496	BRACKET, MOUNTING, L	33591	SPRING, SECURING, TH	33777	WASHER, M6, SPRING,
33501	HOSE, RAW WATER PUMP	33654	ADAPTOR, WATER OUTLE	33779	BONDING WIRE, RAW WA
33502	BRACKET, SUPPORT	33655	HOSE, 1/4" ID X 0.11	33781	FILTER ELEMENT, CHAN
33503	PIPE, 1.1/4", R/W PU	33658	TURBOCHARGER (6TG)	33790	SPACER, 9MM ID X 15M
33504	HOSE, 1.1/4" X 90 DE	33660	PIPE, DRAIN, WITH FL	33794	HOSE, 1/4" ID X 0.14
33505	SPACER, OIL FILTER H	33661	PIPE, OIL DRAIN, TUR	33797	HOUSING, AIR CLEANER
33508	BRACKET, MOUNTING, H	33662	PIPE, DRAIN, WITH FL	33803	PIPE, 1.3/4", MANIFO
33510	HOSE, 1.1/4" X 180 D	33663	ELBOW, INLET HOSE TO	33808	STUD, 1/4" UNF X 5"
33513	PIPE, FUEL, LEAK OFF	33664	ELBOW, AIR CLEANER T	33809	TURBOCHARGER(265/300
33514	PIPE, FUEL, SEDIMENT	33669	PIPE, FUEL, LIFT PUM	33810	HEAT EXCHANGER
33517	PIPE, 3 WAY CASTING,	33670	BRACKET, SUPPORT, FU	33811	BRACKET, LOWER, HEAT
33520	ADAPTOR, 1/4" BSP MA	33671	BRACKET, FRONT MOUNT	33812	BRACKET, UPPER, HEAT
33521	HOSE, 28MM X 22MM, 9	33674	PIPE, OIL FEED, TURB	33813	BRACKET, HEAT EXCHAN
33522	HOSE, 28MM X 16MM, 9	33675	HOSE, 2" X 1.3/4", 1	33816	PIPE, THERMOSTART, E
33523	PIPE, 5/8", THERMOST	33677	PIPE, FUEL, FILTERS	33818	PIPE, FUEL RETURN, I
33525	ADAPTOR, 3/4" NPTF X	33678	PIPE, FUEL, INJ PUMP	33819	ADAPTOR, FUEL RETURN
33526	GASKET, MANIFOLD	33679	PIPE, THERMOSTART	33825	ELBOW, 3/16" OD PIPE
33527	HOSE, 1.1/4" X 90 DE	33681	ADAPTOR, OIL SEPARAT	33826	HOSE, BY-PASS, FRESH
33528	PIPE, FUEL, SEDIMENT	33682	`O` RING (CYL BLOCK	33827	ADAPTOR, 3/8" BSP FE
33531	PIPE, OIL FEED, TURB	33683	`O` RING (OIL SEPARA	33833	HOSE, BREATHER TO AI
33533	END CAP, FRONT, HEAD	33684	SEPARATOR, OIL	33835	PIPE, 1.1/4", HEAT E
33538	HEAT EXCHANGER 4G	33685	HOSE, OIL SEPARATOR	33837	HOSE ASSEMBLY (3/8,
33539	TUBESTACK, HEAT EXCH	33689	TUBE, SUMP CONNECTIO	33838	TUBESTACK, HEAT EXCH
33541	JACKET, THERMAL, TUR	33690	HOSE ASSEMBLY (3/8,	33839	END CAP (WITH WATER




33840	END CAP (BLANKING WI	34002	GASKET, EXHAUST	34150	CAP, PRESSURE, 0.4 B
33843	BRACKET, STOP CABLE	34003	ELBOW, EXHAUST, WATE	34156	PIPE, 1.1/2", MANIFO
33845	HOSE END, 1/4" BSPT	34005	HOUSING, AIR CLEANER	34161	SPACER, 9MM ID X 16M
33848	PLUG, 1/8" NPTF, CYL	34006	HEADER TANK NATURAL	34164	GASKET SET, TOP OVER
33849	WASHER, M16, SHAKEPR	34037	HOSE ASSEMBLY (3/8,	34165	GASKET SET, TOP OVER
33852	NUT, COMPRESSION, 1/	34043	BRACKET, SUMP PUMP S	34167	PIPE, 1.1/4", INTERC
33853	FERRULE, 5/16" OD PI	34046	FILTER, AIR CLEANER	34195	Bracket, Rear, ZF301
33858	FUSE, BLADE, 10A	34047	SUPPORT, AIR CLEANER	34196	Bracket, Rear, ZF301
33859	FUSE, BLADE, 25A	34048	MOUNT, FLEXIBLE, ENG	34197	COVER, FUSE
33860	FUSE, BLADE, 40A	34054	HOSE ASSEMBLY, 1/4",	34200	EYELET, SAIL, NO. 20
33864	SPLASH GUARD	34055	HOSE ASSEMBLY, 5/16"	34201	RING, TURN-OVER, SAI
33866	SPACER, 5.5MM ID X 1	34056	NUT, COMPRESSION, 1/	34206	BRACKET, SUPPORT
33867	SCREW, M5 X 45, PAN	34057	OLIVE, 1/4" OD PIPE	34227	HOSE, 7MM ID X 0.3M,
33868	CLIP, SUPPORT, SIZE	34058	NUT, COMPRESSION, 1/	34232	HEADER TANK BLACK -
33869	CLIP, SUPPORT, SIZE	34059	OLIVE, 5/16" OD PIPE	34248	SOLENOID, STOP, 12V
33870	WIRE, VE LINK TO STA	34065	ADAPTOR, ENGINE BREA	34270	ADAPTOR, EXHAUST, TU
33872	LOOM, ALTERNATOR TO	34066	HOSE, AIR CLEANER TO	34281	HOSE ASSEMBLY (3/8,
33873	BRACKET, SUPPORT, FU	34067	HOSE, AIR CLEANER TO	34282	HOSE ASSEMBLY (3/8,
33878	NUT, M6, HALF	34068	HOSE, ENGINE BREATHE	34283	HEAT EXCHANGER/HEADE
33879	BRACKET, BELT GUARD	34073	HOSE, 1.1/4" X 90 DE	34297	ELBOW, EXHAUST, WATE
33882	PIPE, FUEL, LIFT PUM	34074	OIL COOLER, GEARBOX	34300	HEAT EXCHANGER 6T
33894	BRACKET, SUPPORT, AL	34080	LOOM, ENGINE WIRING,	34301	END CAPS, HEAT EXCHA
33903	END CAP (WITH WATER	34082	CONNECTOR, EXHAUST,	34303	STUD, M10 X 70 NOMIN
33916	HOSE, ENGINE BREATHE	34083	JACKET, THERMAL, 135	34304	PIPE, 3 WAY CASTING,
33923	PIPE, 1.3/8", HEAT E	34084	`O` RING (RAW WATER	34305	TURBOCHARGER (6TWGM,
33924	BELT COVER	34087	END CAP, STRAIGHT, G	34307	PIPE, 1.1/4", INTERC
33925	BRACKET, UPPER, BELT	34089	HOSE ASSEMBLY (3/8,	34308	EXHAUST OUTLET, WATE
33926	PILLAR, M16 MALE X M	34092	CAP, SCREW	34310	PIPE, BOOST CONTROL
33927	HOSE, 2.1/8" X 1.3/8	34093	CAP WASHER, SCREW	34311	PIPE, THERMOSTART
33928	HOSE, 1.3/4" X 1.3/8	34095	END CAP, 90 DEG, HEA	34312	PIPE, FUEL, LIFT PUM
33929	HEAT EXCHANGER	34096	HOSE, 1/4" ID X 0.21	34316	BRACKET, MOUNTING, H
33931	HOSE, 2" X 1.3/8" RE	34104	TUBESTACK, HEAT EXCH	34317	HOSE, 1" ID X 90 DEG
33939	CONNECTOR, EXHAUST,	34107	SERVICE KIT, RAW WAT	34318	BRACKET, BELT GUARD
33941	EXHAUST OUTLET, WATE	34108	SCREW, END COVER, SE	34319	BRACKET, BELT GUARD
33942	HOSE SET, M130C/M135	34109	SCREW, CAM, RAW WATE	34321	SPACER, 11MM ID X 19
33944	HOSE SET,	34110	CAM, RAW WATER PUMP	34322	GASKET SET, BOTTOM O
33946	EXHAUST OUTLET, WATE	34113	SEAL, MECHANICAL, AS	34332	ELBOW, EXHAUST, WATE
33950	CERTIFICATE, DECLARA	34114	BEARING, RAW WATER P	34340	INTERCOOLER/INLET MA
33955	HEADER TANK NATURAL	34115	SHAFT, RAW WATER PUM	34343	PIPE, THERMOSTART, E
33976	TURBOCHARGER, 4TGM	34117	IMPELLER (JABSCO 3/4	34347	HOSE, RAW WATER PUMP
33981	EXTENSION, BREATHER,	34118	HOSE, 1.3/4" X 1.1/2	34348	HOSE, STRAINER TO HE
33982	AIR CLEANER ASSEMBLY	34127	BULB, WARNING LIGHT,	34351	PIPE, BOOST CONTROL
33984	WATER PUMP, RAW WATE	34135	DAMPER DRIVE PLATE,	34352	HOSE, 1.1/4" X 90 DE
33991	HOSE, 1.1/2" X 90 DE	34136	HEADER TANK BLACK -	34353	FLANGE, EXHAUST ELBO
33992	HOSE, RAW WATER PUMP	34142	SOLENOID, NEGATIVE E	34358	ELBOW, EXHAUST, WATE
33993	CONNECTOR, 28MM HOSE	34148	BRACKET, PIPE SUPPOR	34368	HOSE, 1" X 50 DEG




34378	BRACKET, SUPPORT, AI	34588	SWITCH, PANEL LIGHT	34796	GASKET, EXHAUST, MAN
34379	BRACKET, SUPPORT, TH	34594	HOSE, 1/4" ID X 0.10	34797	HOSE, TURBO INLET DU
34381	END CAP, THERMOSTAT	34597	END CAP, STRAIGHT, G	34807	HOSE, MODINE COOLER
34382	PIPE, 3 WAY, KEEL CO	34600	EXHAUST OUTLET, WATE	34809	HOSE, 42MM TO 38MM R
34383	HOSE, 2" X 1.1/2", R	34602	SCREW, END COVER, SE	34810	GASKET, EXHAUST, TUR
34390	PIPE, THERMOSTART, R	34606	LOOM, ENGINE WIRING,	34819	EXHAUST OUTLET, WATE
34392	BRACKET, SUPPORT, 90	34607	BUZZER, WARNING.	34825	BODY, HEAT EXCHANGER
34393	BRACKET, SUPPORT	34609	VOLTMETER, 24V (OCEA	34826	SENDER/SWITCH, ENGIN
34397	HOUSING, THERMOSTAT	34610	BULB, WARNING LIGHT,	34832	SWITCH, HIGH TEMPERA
34412	HEAT EXCHANGER	34613	WARNING LIGHT, HIGH	34834	ELEMENT, AIR CLEANER
34419	PIPE KIT, FUEL INJ,	34615	OIL COOLER, GEARBOX	34843	SOCKET, RELAY, GLOWP
34439	CAP, BLANKING, 35.5	34619	END CAP, 90 DEGREE,	34846	RELAY, 12V, GLOWPLUG
34440	HOSE, THERMOSTAT HOU	34621	`Y' HARNESS, OCEANLI	34849	INJECTION PIPE ASSEM
34441	HOSE, REDUCER, H/EXC	34623	GASKET, EXHAUST BLAN	34850	PIPE, INJECTOR, CYL.
34442	HOSE, H/EXC TO F/W P	34630	DAMPER DRIVE PLATE,	34851	PIPE, INJECTOR, CYL.
34443	HOSE, ELBOW, REDUCER	34640	HEATSHIELD, TURBOCHA	34852	PIPE, INJECTOR, CYL.
34444	HOSE, ENG OIL COOLER	34641	PIPE, OIL FEED, TURB	34853	PIPE, INJECTOR, CYL.
34446	HOSE, THERMOSTAT BY-	34644	ASSEMBLY, TURBO DRAI	34854	PIPE, INJECTOR, CYL.
34447	PLATE, CLAMPING, RAW	34646	HOSE, TURBO TO INLET	34855	PIPE, INJECTOR, CYL.
34450	BRACKET, FRONT MOUNT	34648	EXHAUST OUTLET, WATE	34856	ADAPTOR, 3/4" NPTF M
34453	ELEMENT, AIR CLEANER	34649	`O' RING, TURBO OIL	34866	PLUG, 1/8" BSPT, STE
34455	HOSE, RAW WATER PUMP	34651	HOSE, 25.4MM X 110 D	34871	HOSE, 44.5MM I.D X 6
34457	CONNECTOR, 31.8MM O.	34654	SPACER, 9MM ID X 16M	34884	SETSCREW, M10 X 80
34459	CLIP, RETAINING, COO	34657	CONNECTOR, 31.8MM O.	34888	BULB, RED, INSTRUMEN
34460	PLATE, CYLINDER BLOC	34663	PRINTED CIRCUIT BOAR	34889	BULB AND HOLDER, RED
34461	BRACKET, MOUNTING, H	34669	HOSE, 31.75MM X 90 D	34892	SHROUD, WARNING LIGH
34464	GASKET, CYLINDER HEA	34672	HOSE, AIR CLEANER TO	34907	GAUGE, WATER TEMPERA
34465	MANIFOLD, 4 CYLINDER	34684	HOSE, WIRE REINFORCE	34909	TURBOCHARGER (6TWGM,
34467	HEAT EXCHANGER BODY	34704	CAP, INSULATED BLANK	34910	HOSE ASSEMBLY (3/8,
34468	ADJUSTER ARM, A127,	34710	TOOLBOX, PLASTIC CLE	34912	ADAPTOR HOUSING, PRM
34471	PIPE, 1.3/4", HEAT E	34711	PIPE, 1.1/2", KEEL C	34924	BRACKET, ADJUSTER, 9
34472	BRACKET, SUPPORT, G/	34712	WATER MANIFOLD, KEEL	34928	LOOM, ENGINE WIRING,
34474	CAM, RAW WATER PUMP	34722	WATER PUMP KIT, RAW	34930	MANIFOLD, INLET/EXHA
34477	HOSE, REDUCER, ENGIN	34724	BRACKET, ALTERNATOR	34932	BRACKET, SPEED CONTR
34484	ADAPTOR, POWER TAKE-	34725	PISTON POSITION PROB	34941	SHIM, 0.5 MM, ENGINE
34486	BRACKET, SUPPORT, G/	34728	TUBE, DIPSTICK (INJ	34942	SHIM, 1.0 MM, ENGINE
34487	GASKET, EXHAUST, MAN	34734	ADAPTOR, 1/8" NPTF,	34952	HOSE, ENG CYL BLOCK
34488	GASKET, EXHAUST, MAN	34748	STARTER, 12V, M127,	34962	LABEL, WARNING, COOL
34496	SWITCH, TWIN POLE, O	34751	FITTING INSTRUCTIONS	34966	PISTON POSITION PROB
34509	BRACKET, GEAR CONTRO	34764	FLANGE, BLEED, WATER	34968	LIFT PUMP, FUEL (MOT
34536	HOSE, 1/4" ID X 0.15	34767	SPACER, NYLON, 12.7M	34985	PIPE, BOOST CONTROL
34539	OIL COOLER, HURTH HB	34769	BELT COVER	34986	PIPE, FUEL, LEAK OFF
34542	SPACER, DAMPER DRIVE	34785	PLUG, 3/8" NPT X 1/2	34996	LOOM, ENGINE WIRING,
34577	PULLEY, TWIN GROOVE,	34793	HEATSHIELD, TURBOCHA	35005	SPACER, BORG WARNER
34586	DAMPER DRIVE PLATE,	34794	PIPE, OIL FEED, TURB	35017	PIPE, 1.1/4", R. W.
34587	WARNING LIGHT, WATER	34795	PIPE, DRAIN, TURBO	35020	GEARBOX, TACHOMETER




35027	PIPE, 1.1/4", R. W.	35161	PIPE, FUEL, LIFT PUM	35480	HEADER TANK, REMOTE
35035	BRACKET, FRONT FOOT/	35162	PIPE, FUEL, FILTER T	35481	SIGHT GAUGE, FLUID L
35050	LOOM, INTERCONNECTIN	35167	LOOM,INTERCONNECTING	35487	LOOM, INTERCONNECTIN
35051	LOOM, INTERCONNECTIN	35168	HOSE, BY-PASS, FRESH	35497	PUMP, FUEL INJECTION
35052	LOOM, INTERCONNECTIN	35169	PIPE, 3 WAY CASTING,	35519	PIPE, INJECTOR, CYL
35055	BRACKET, SUPPORT, RE	35171	BRACKET, REAR, HEAT	35520	PIPE, INJECTOR, CYL
35065	BRACKET, REAR MOUNTI	35172	WASHER, CLAMPING, RA	35521	PIPE, INJECTOR, CYL
35066	BRACKET, REAR MOUNTI	35188	BRACKET, REAR MOUNTI	35522	PIPE, INJECTOR, CYL
35067	SPACER, REAR FOOT, 2	35191	(197-5633) DECAL, CA	35527	ADAPTOR, 1/2" NPT TO
35080	MOUNT, FLEXIBLE, ENG	35197	HEIGHT ADJUSTER KIT,	35532	PLUG, M10 X 1.5, HEX
35081	PAD-JACKING, HEIGHT	35205	FLYWHEEL HOUSING, SA	35540	HOOK, CONTROL CABLE,
35082	BRACKET, FRONT MOUNT	35209	PANEL, INSTRUMENT, M	35550	PIVOT, CONTROL CABLE
35083	BRACKET, IN LINE REA	35211	ASSEMBLY, BASE MAIN	35551	COTTER PIN, 3/32" X
35085	BRACKET, REAR MOUNTI	35212	ASSEMBLY, MAIN STATI	35553	CONNECTOR, BALL AND
35086	BRACKET, FRONT MOUNT	35213	ASSEMBLY, MAIN STATI	35567	BRACKET, SUPPORT, TH
35087	HEIGHT ADJUSTER KIT,	35218	WASHER, STARLOCK	35570	HEADER TANK KIT, REM
35090	BRACKET, OPTION PLAT	35219	DECAL, SABRE PERKINS	35573	LOOM, INTERCONNECTIN
35095	SPACER BLOCK, MAN SI	35227	(197-0616)DECAL, WAR	35575	VALVE, NON RETURN
35096	SPACER, 10.5MM ID X	35282	PAINT, MATTERHORN WH	35576	`O` RING (M/PAL EXCE
35098	PIPE ASSEMBLY, CYLIN	35294	(198-6479) STICKER,	35580	PIPE, FUEL FILTER TO
35099	INSULATOR COLLAR, NY	35335	LOOM, ENGINE WIRING,	35581	PIPE, FUEL, LIFT PUM
35100	NUT, EXTENDED, M8 X	35350	DRAIN PLUG, FUEL FIL	35583	SOLENOID, EXCESS FUE
35105	LOOM, ALTERNATOR TO	35351	ELEMENT, PRE-FILTER	35600	LOOM, ENGINE WIRING,
35106	WIRE, LINK, VE (PCB)	35355	FUEL SEDIMENTER/WATE	35601	`O` RING, FUEL INJEC
35107	SPACER, 6.5MM ID X 1	35361	ALTERNATOR, 12V, AS1	35615	UNIVERSAL BILGE PUMP
35112	SCREW, FLANGED, M12	35362	ALTERNATOR, 24V, AS1	35619	SWITCH, ENGINE OIL P
35120	PIPE, 1.3/4", MANIFO	35363	PIPE KIT, FUEL INJ.	35633	LOOM, ENGINE WIRING,
35121	PIPE, 1.1/4", JABSCO	35373	BRACKET, FRONT MOUNT	35636	ACTUATOR ASSY (TO SU
35122	HEADER TANK ASSEMBLY	35374	HOSE, 1" X 90 DEGREE	35651	12V SOLENOID
35125	SWITCH, ENGINE OIL P	35384	SPACER, 13MM ID X 25	35652	24V SOLENOID
35126	#NAME?	35390	LOOM, ENGINE WIRING,	35658	BRACKET, FRONT FOOT/
35128	HEAT EXCHANGER, 3 PA	35401	PIPE KIT, FUEL INJ.	35676	AUDIBLE WARNING DEVI
35131	HOSE, BY-PASS, FRESH	35411	FILTER ASSEMBLY, FUE	35702	CAP, FILLER, BLACK,
35133	BRACKET, PIPE SUPPOR	35412	ELEMENT, FUEL FILTER	35703	FILLER NECK
35136	BRACKET, SUPPORT, HE	35413	ELEMENT, FUEL FILTER	35704	`O` RING
35137	HOSE, JABSCO RAW WAT	35416	(206-6909) ELEMENT,	35708	TUBE, NYLON, BLACK,
35139	HOSE, 2" X 1.3/4", 1	35417	SEDIMENTER ASSEMBLY,	35711	CONDUIT, NYLON, SCHL
35141	KSB UNIT WITH LOOM P	35419	ELEMENT, FUEL, PRE-F	35763	PULLEY, MOTOROLA 8SC
35146	INSULATOR, STARTER T	35425	RESISTOR, DROPPING,	35776	COUPLING, FLEXIBLE,
35153	PIPE, HEAT EXCHANGER	35427	BRACKET, SUPPORT, AU	35780	TACHOURMETER, 12V (0
35154	PIPE, 1.1/4", RAW WA	35439	HOSE ASSEMBLY (3/8,	35800	PIPE KIT, F.INJ, D/S
35155	HOSE, RAW WATER PUMP	35445	TOOL, IMPELLER REMOV	35818	BRACKET, SUPPORT, AI
35156	PIPE, RETURN, OIL CO	35448	BRACKET, FRONT FOOT/	35823	PUMP, FUEL INJECTION
35158	PIPE, FEED, OIL COOL	35453	(142-7548) STICKER,	35834	AUDIBLE WARNING DEVI
35159	PIPE 1.3/4" THERMOST	35455	(205-6463)STICKER, -	35904	BRACKET, SUPPORT, HE
35160	HOSE, HEAT EXCHANGER	35464	DRAIN PLUG, FUEL FIL	35920	WASHER, SPACER, M8,




35938	PIPE, FUEL, FILTER T	36151	ADAPTOR, 1/8" NPTF,	36313	SWITCH, PRESSURE, OI
35939	PIPE, FUEL, INJ PUMP	36156	BUSH, TAPER LOCK, 14	36315	SWITCH, HIGH WATER T
35940	PIPE, FUEL, L/OFF RA	36158	PUMP, 1", RAW WATER,	36322	AMMETER (V.D.O., 60-
35945	TUBE, DIPSTICK (4CYL	36160	SENDER, TACHOMETER	36325	RESISTOR, DROPPING,
35946	PIPE, FUEL, FILTER T	36161	TRANSDUCER, TACHO (P	36352	BACKET, SPEED CONTR
35947	PIPE, FUEL, RETURN,	36164	HOURLMETER, 12V (2.2C	36357	WASHER, M8, SHAKEPRO
35948	FUEL PRE-FILTER ASSE	36180	SENDER, ENGINE OIL P	36361	ASSEMBLY, EXTENSION
35957	PIPE, SUMP PUMP TO S	36183	SENDER, ENGINE OIL P	36362	SUPPORT STUD, BELT G
35970	EXHAUST OUTLET, WATE	36186	BOLT, BANJO, M18 X 1	36373	HOURLMETER (C2.2 LOOM
35971	BRACKET, FRONT MOUNT	36187	CONNECTOR ELBOW, 90	36374	RELAY, START/-VE EAR
35972	BRACKET, HEAT EXCHAN	36188	ADAPTOR, 1/4" NPT MA	36376	RELAY, RUN, 12V,
35983	ADAPTOR, POWER TAKE-	36190	SENDER, TEMPERATURE,	36377	RELAY, ON/STOP LATCH
35987	ACTUATOR, ELECTRONIC	36191	SENDER, WATER TEMPER	36378	CIRCUIT BREAKER, 20A
35988	GASKET, EXHAUST (C2.	36192	SENDER, TEMPERATURE,	36379	PIPE BRACKET, KEEL C
36014	HOSE, RAW WATER, JAB	36194	ADAPTOR BLOCK, FUEL	36380	KEEL COOLED KIT
36039	PLATE, SUPPORT, GEAR	36196	ADAPTOR, WATER OUTLE	36403	PIPE, FUEL, L/OFF RA
36042	BRACKET, SUPPORT, GE	36206	STUD, MANIFOLD SECUR	36431	KIT, EXPANSION TANK
36043	BRACKET, SUPPORT, GE	36207	STUD, MANIFOLD SECUR	36433	WASHER, COPPER, M18.
36052	GASKET, EX MANIFOLD	36210	SENDER, GEARBOX OIL	36437	FILTER ELEMENT, FUEL
36055	TUBE, PROTECTION, TR	36213	THERMOSTAT, 78 DEG C	36439	SPACER, 13MM ID X 25
36059	ELBOW, 3/4" BSPT MAL	36216	OIL PRESSURE SWITCH,	36443	PRINTED CIRCUIT BOAR
36064	HOSE, THERMOSTAT TO	36217	OIL PRESSURE SWITCH,	36446	RECEPTACLE , 12 WAY
36065	HOSE, FWP TO MANIFOL	36219	FLANGE, EXHAUST OUTL	36447	PLUG, 12 WAY
36088	BEARING, RAW WATER P	36222	BRACKET, LIFTING EYE	36448	WEDGELOCK
36090	END COVER, RAW WATER	36224	HOUSING, EC100, H/EX	36449	SEAT RETENTION, WITH
36091	CAM, RAW WATER PUMP.	36225	END CAP, HEAT EXCHAN	36451	SOCKET, CONTACT, FEM
36092	GEAR, RAW WATER PUMP	36240	SENDER, BOOST PRESSU	36452	FILLER PLUG.
36094	KEY, WOODRUFF	36244	PIPE, FUEL RETURN (C	36456	BRACKET, NEGATIVE EA
36095	`O' RING, RAW WATER	36245	HOSE ASSEMBLY, OIL D	36459	CABLE, -VE LINK (ALT
36096	RING, RETAINING	36246	TRANSDUCER, TACHO. (	36464	AIR FILTER (422GM)
36098	SHAFT	36247	BOLT, BANJO M16 X 1.	36502	RELAY, 33RA, 24V (RE
36099	WASHER	36252	GAUGE, BOOST PRESSUR	36513	CLIP, PIPE SUPPORT,
36114	ADAPTOR, 3/8" BSPT M	36254	SWITCH, HIGH EXH TEM	36514	BOLT, M12 X 120
36115	HOSE ASSEMBLY (3/8,	36257	SETSCREW, M14 X 1.5	36537	DAMPER DRIVE PLATE,
36116	PIPE, FUEL, INJ PUMP	36273	BULB, 14V, (C2.2 PAN	36538	SERVICE KIT, RAW WAT
36120	ADAPTOR, PUMP BLEED.	36277	CABLE, INTERCONNECTI	36541	TRAFAG OIL PRESS/WAT
36125	SIPHON BREAK, 1" HOS	36283	HOSE, AIR INLET (C2.	36560	STARTER MOTOR, ISKRA
36127	PLATE, MOUNTING, WIR	36287	PIPE, INJ, CYL 2, DU	36563	HOSE, THERMOSTAT TO
36128	PLATE, COVER, WIRING	36290	"O" RING, DRAIN MANI	36564	HOSE, R/W PUMP TO HE
36135	CLIP, PIPE SUPPORT,	36292	BLANKING CAP (DELPHI	36568	ADAPTOR, 1.25" HOSE
36136	HOSE, 2" X 2", 150DE	36295	CONTROLLER, ELECTONI	36579	LABEL, RAW WATER PRI
36138	ADAPTOR, 1/4" NPTF M	36297	END CAP, HEAT EXCHAN	36609	MANIFOLD, EXHAUST, 4
36139	PIPE, 2", MANIFOLD T	36298	SCREW	36610	GASKET, CYLINDER HEA
36140	SOCKET, 1/2" NPS, S.	36300	SWITCH, PRESSURE, OI	36612	PIPE, WATER, PUMP TO
36149	PIPE,OIL, LONG, FEED	36307	SWITCH, TEMPERATURE,	36633	RELAY, START/-VE EAR
36150	PIPE,OIL, RETURN (SH	36312	BOOT, INSULATING (RE	36636	RELAY, ON/STOP LATCH




36643	GAUGE, VOLTMETER, 24	36973	O RING, INTERCOOLE	37171	COVER, EMERGENCY STOP
36751	ALTERNATOR ASSEMBLY,	36975	ADJUSTER ARM, ALTERN	37195	HOSE, AIR FILTER TO
36752	SOLENOID, NEGATIVE E	36976	PIPE KIT, F/INJ, D/S	37196	HOSE, BREATHER TO AI
36756	ACTUATOR, ELECTRONIC	36977	TURBOCHARGER (VISTA	37197	HOSE, BREATHER
36759	RELAY, 24V, 40A, HEAVY	36982	GOVERNOR, L SERIES (	37201	ELBOW, EXHAUST OUTLE
36797	PLUG, BUTTON, 9.5MM	37002	ADAPTOR, LEVEL SWITC	37205	JACKET, THERMAL, EXH
36798	PLUG, BLANKING, 1" O	37003	HOSE, 1.25" DIA TO 3	37207	HEATSHIELD, TURBOCHA
36799	CONVERTER, VOLTAGE,	37004	HOSE, 1.25" DIA TO 3	37208	GUARD, FLAME, FUEL P
36809	ADAPTOR, 3/4" NPTF X	37005	SWITCH, LEVEL, FRESH	37211	HOSE, BREATHER TO AI
36812	STICKER, 24V	37012	BELTGUARD, C4.4 OPEN	37212	ADAPTOR, M16 X 1/2"
36814	SPACER, 9MM ID X 19M	37016	PIPE, MANIFOLD TO BL	37213	HOSE, 1/2" BORE (BRE
36840	BADGE, PERKINS/SABRE	37018	WASHER, COPPER, M5	37216	STUD, M6 X 24
36864	MANIFOLD, EXHAUST, 4	37019	HOSE ASSEMBLY, 1/4",	37217	COVER, FUEL PIPES
36865	DUCT, INTERCOOLER TO	37020	HOSE ASSEMBLY, 5/16"	37218	BRACKET, COVER SUPPO
36868	HEADER TANK, ALUMINI	37021	HOSE ASSEMBLY, FUEL	37221	PIPE, 1.1/4", R.W.P
36873	HOSE, F/W PUMP PIPE	37022	HOSE ASSEMBLY, INJ P	37223	HOSE ASSEMBLY, TURBO
36874	HOSE, THERMOSTAT PIP	37023	HOSE ASSEMBLY, INJ P	37224	PIPE, 1.1/4", INT TO
36875	HOSE, REDUCER, F/W P	37024	ADAPTOR, HOSE TAIL	37226	PIPE, OIL FEED, TURB
36877	PIPE, 2", THERMOSTAT	37025	VALVE, NON RETURN	37228	CONVERTER, VOLTAGE,
36878	SPACER, 11.0MM ID X	37026	ADAPTOR, MALE BRANCH	37236	ADAPTOR, OIL FILTER
36880	PIPE, MANIFOLD TO F/	37027	CLIP, SWIVEL, HOSE S	37244	KIT, HEADER TANK, RE
36881	BRACKET, MOUNTING, F	37028	CLIP, SWIVEL, HOSE S	37249	ALARM, AUDIBLE, PANE
36882	HOSE, REDUCER, 15.9M	37029	CLIP, HOSE SUPPORT	37256	SWITCH
36883	HOSE, REDUCER, 15.9M	37032	NUT, COMPRESSION, 3/	37260	BREAKER, CIRCUIT, 15
36884	HOSE, BYPASS, FRESH	37035	HOSE, 25.4MM X 50MM	37262	CONTACT ASSEMBLY
36886	BRACKET, LIFTING EYE	37038	CONNECTOR	40061	PULLEY, SINGLE GROOV
36892	HEADER TANK/EXHAUST	37040	PIN, CONNECTOR	40071	REGULATOR, 24V (A24-
36909	HOSE, CYL BLOCK TO M	37042	NUT, PLASTIC PANEL	40082	ALTERNATOR, 12V, A12
36910	HOSE, HEADER TANK TO	37043	WASHER, LOCK	40140	BELT (17 ACR ALTERNA
36913	SCREW, CAM, RAW WATE	37044	WORKSHOP MANUAL, M13	40186	SWITCH, TEMPERATURE,
36915	CAM, RAW WATER PUMP	37045	BRACKET, PIPE SUPPOR	40197	SOLENOID, STOP, 12V
36916	IMPELLER, RAW WATER	37055	PIPE, HEAT EXCHANGER	40198	SOLENOID, STOP, 24V
36917	O RING, END COVER	37060	HOSE, R.W.P TO INTER	40199	INSULATING BOOT
36918	END COVER	37061	BRACKET, BREATHER MO	40500	THERMOSTART, 12V
36919	SCREW, END COVER	37065	PIPE, MANIFOLD TO F/	40501	THERMOSTART, 24V DE
36920	GEAR, RAW WATER PUMP	37066	PIPE, THERMOSTAT TO	40510	ADAPTOR, 1.1/4" UNF
36921	O RING, CAM SCREW	37068	PIPE, F/W PUMP TO KE	40520	EARTHING PLATE, THER
36934	SPACER, 11.0MM ID X	37072	HOSE, AIR CLEANER TO	40561	FUSE, FAST (LINK)
36936	CONNECTOR, EXHAUST,	37075	PLUG, 1/4" BSP, SOCK	40601	BULB, WARNING LIGHT,
36942	ELEMENT, FUEL FILTER	37158	BOOT	40607	BULB, INSTRUMENT HEA
36944	ELEMENT, FUEL FILTER	37161	BREAKER, 20 AMP (6T-	45119	BELLOWS, EXHAUST, 5"
36956	GASKET, EXHAUST, MAN	37162	BREAKER, 10 AMP (6T-	45564	PIPE, FUEL INJECTOR,
36960	SPACER, 11MM ID X 19	37163	SWITCH, ISOLATOR	45565	PIPE, FUEL INJECTOR,
36961	ALTERNATOR, 12V, 90A	37168	KEY	45566	PIPE, FUEL INJECTOR,
36962	ALTERNATOR, 24V, 55A	37169	BLOCK, TERMINAL	45567	PIPE, FUEL INJECTOR,
36967	BRACKET, SUPPORT, IN	37170	SWITCH	45568	PIPE, FUEL INJECTOR,




45569	PIPE, FUEL INJECTOR,	49520	PIPE, INJECTOR, CYL	56354	SETSCREW, 3/8" UNF X
46499	PUMP, FUEL LIFT	49530	PIPE, INJECTOR, CYL	56356	SETSCREW, 3/8" UNF X
46520	HOSE, 2.3/4" X 2.1/2	49540	PIPE, INJECTOR, CYL	56357	BOLT, 3/8" UNF X 1.1
46522	HOSE, 1" X 2.1/2" (1	49550	PIPE, INJECTOR, CYL	56358	BOLT, 3/8" UNF X 1.3
46523	HOSE, 2" X 2.1/8" (T	50020	GASKET, ROCKER COVER	56410	SETSCREW, 7/16" UNF
46524	HOSE, 2.1/2" X 2.5/1	50025	GASKET, ROCKER COVER	56416	BOLT, 7/16" UNF X 2"
46621	FILTER ASSEMBLY, FUE	50026	GASKET, ROCKER COVER	56445	BOLT, 1/2" UNF X 2"
47013	LINER, CAST IRON	50027	GASKET, ROCKER COVER	57258	SETSCREW, 5/16" UNC
47150	PUSH ROD	50030	GASKET (HEADER TANK/	57271	BOLT, 5/16" UNC X 2.
47168	ADJUSTER, ROCKER ARM	50031	GASKET, FRESH WATER	57357	SETSCREW, 3/8" UNC X
47169	BANJO, INJECTOR LEAK	50040	GASKET, TIMING HOUSI	57358	SETSCREW, 3/8" UNC X
47190	SPRING, VALVE	50050	GASKET, OIL FEED/RET	57359	SETSCREW, 3/8" UNC X
47191	CAP, VALVE STEM (B`	50060	GASKET, MANIFOLD (6	57409	SETSCREW, 7/16" UNC
47193	SEAL, VALVE STEM	50061	GASKET, MANIFOLD, 4	57460	SETSCREW, 1/2" UNC X
47197	GUIDE, VALVE, STANDA	50069	GASKET, EXHAUST, TUR	57803	STUD, 3/8" UNC X 1.5
47199	INSERT, INLET VALVE,	50070	GASKET, EXHAUST, TUR	57820	STUD, 5/16" UNF - 5/
47230	LIFT PUMP, FUEL (BOS	50093	GASKET, CYLINDER HEA	57850	SCREW & WASHER
47245	RING GEAR, FLYWHEEL	50100	GASKET, SUMP SET	57851	STUD, MANIFOLD SECUR
47247	SCREW, RING GEAR SEC	50101	SEAL, CRANKSHAFT REA	57852	NUT, 3/8" UNF, S.S.
48013	GROMMET, 1/2" ID X 1	50102	SEAL, CRANKSHAFT FRO	57910	TRANSPILLAR (FAST FU
48127	PIPE, FUEL FILTER TO	50103	GASKET, SUMP, SET (4	58011	NUT, M8 (STAINLESS S
48161	INJECTOR ASSEMBLY (T	50130	HEADER TANK SEAL	58040	SCREW, M5 X 10, PAN
48167	SHIM, SET (KIT)	50141	GASKET, FLANGE, INTE	58041	SETSCREW, M5 X 12 (H
48169	CAP, DRAIN (FH93 FIL	50150	GASKET, TACHOMETER D	58042	SCREW, M5 X 16, PAN
48291	`O` RING (BARREL 126	50160	GASKET, LIFT PUMP	58045	SCREW, M5 X 50, PAN
48316	WASHER ,VENT PLUG	50161	GASKET, LIFT PUMP TO	58046	SETSCREW, M6 X 12, P
48336	SCREW (BLEED, 27572)	50170	`O` RING (INJECTION	58071	SETSCREW, M8 X 20
48340	`O` RING (126064/5)	50172	`O` RING, 7/16" ID X	58079	CAPSCREW, M6 X 20, S
49005	CAP, OIL FILLER	55001	NUT, M3, SELF LOCKIN	58080	SETSCREW, M12 X 30
49010	SEAL, INJECTOR PIPE,	55002	NUT, M4, SELF LOCKIN	58085	SETSCREW, M12 X 20
49012	CLAMP ASSEMBLY (INJE	55010	NUT, M5 (HEX. ZINC P	58104	SETSCREW, M10 X 30 (
49014	SEAL, INJECTOR INLET	55020	NUT, M6 (HEX)	58105	SETSCREW, M10 X 25 (
49016	NUT, INJECTOR LEAK O	55025	NUT, M6, BRASS (HEX)	58118	BOLT, M12 X 160
49017	ADAPTOR, INJECTOR LE	55028	NUT, M12 (FULL)	58119	NUT, M8 (HEX. FULL)
49027	TUBE, DIPSTICK, 0 DE	55210	NUT, 1/4" UNF (HEXAG	58201	SETSCREW, M14 X 1.5
49071	VALVE, CRANKCASE BLO	55211	NUT, 1/4" UNF, SELF	58220	NUT, M10 (HEXAGON, F
49098	PULLEY, SINGLE GROOV	55221	NUT, 5/16" UNF, SELF	58290	BUSH, HANK, M5
49105	THERMOSTAT, 82 DEG C	55230	NUT, 3/8" UNF (HEXAG	58295	SCREW, NO. 8 X 12.7
49112	HOUSING, INTERCOOLER	55231	NUT, 3/8" UNF, SELF	58400	SCREW, M4 X 10, CHEE
49114	`O` RING, 4.73" ID X	55245	NUT, 1/2" UNF, SELF	58500	SEAL, 1/2" BSP, BOND
49115	PLUG, 1/4" NPTF (INT	55246	NUT, 1/2" UNF	58511	SEAL, 1" BSP, BONDED
49200	LIP SEAL	55360	NUT, 1/4" UNC (HEXAG	58600	WASHER, COPPER, INJE
49307	PIPE, TURBO OIL FEED	55380	NUT, 3/8" UNC (HEXAG	59000	WASHER, 1/4", SPRING
49446	PUMP, INJECTION (P.5	56245	SETSCREW, 5/16" UNF	59001	WASHER, M12, SPRING
49500	PIPE, INJECTOR, CYL	56248	SETSCREW, 5/16" UNF	59002	WASHER, M8, SPRING
49510	PIPE, INJECTOR, CYL	56353	SETSCREW, 3/8" UNF X	59004	WASHER, M6, SPRING



59005	WASHER, M16, SPRING	66059	FOLLOWER, CAMSHAFT (	81256	BOX & LID, POLYCARBO
59006	WASHER, M14, SPRING	66061	RAIL, INJECTOR LEAK	81310	DOLLY COVER, RED (BU
59010	WASHER, 5/16", SPRIN	66130	BIG END SHELL, 1 PAI	81314	HOLDER, LAMP, RED LE
59030	WASHER, 3/8", SPRING	66145	PLUG, 3/4" NPTF, SOC	81315	HOLDER, LAMP, ORANGE
59040	WASHER, 7/16", SPRIN	66160	PUMP, WATER (80/120	81325	DOLLY COVER, GREY (U
59050	WASHER, 1/2", SPRING	66401	THERMOSTAT, MODIFICA	81326	RESISTOR, 22 OHMS, 2
59061	WASHER, 3/8", FLAT,	66615	TUBE, DIPSTICK (250/	100010	NECK, FILLER (AND OV
59062	WASHER, 7/16", FLAT,	66616	DIPSTICK (300 `B` EN	100061	PLUG, 1/4" BSPT (BRO
59065	WASHER, 5/8", T & C	66700	GASKET, CYLINDER HEA	100317	ADAPTOR, 3/8" BSP MA
59068	WASHER, M5, FLAT (EN	66702	GASKET, CYLINDER HEA	100327	NUT, FLARE, 3/8" X 5
59073	WASHER, 5/16", FLAT	66710	GASKET, TIMING CASE	100550	BELT (WATER PUMP M.A
59074	WASHER, 3/8", FLAT (	66711	GASKET, TIMING COVER	200020	PLASTIC BAG, 20" X 2
59076	WASHER, 1/2", FLAT (	66715	GASKET SET, SUMP	200100	(1/4" BSP, FEMALE, P
59078	WASHER, M10, FLAT (B	66719	`O` RING (INJECTION	200101	CAP, 3/8" BSP FEMALE
59079	WASHER, M4, FLAT (BR	66720	SEAL, CYLINDER BLOCK	200103	CAP, 3/8" BSP MALE,
59082	WASHER, 1/4" ID X 1"	66750	GASKET, TURBO MANIFO	200109	PLUG, 1/4" BSP, PLAS
59099	SPACER, 5/16" ID X 3	66753	GASKET, MANIFOLD (12	676312	BANJO BOLT
59100	WASHER, 3/8" ID X 3/	66759	GASKET, WATER PUMP/C	676980	BOLT
59102	WASHER, 3/8" ID X 1"	66762	GASKET, WATER PUMP/A	919035	SPACER
59104	WASHER, 5/16" ID X 3	66763	GASKET, TIMING CASE	35232	PLATE-SERIAL
59110	WASHER, M3, FLAT, S.	66767	GASKET, OIL FEED, TU	58051	BOLT-SOCKET HEAD (M8
59153	WASHER, M5, SHAKEPRO	66768	GASKET, OIL DRAIN, T	59003	LOCKWASHER (M10)
59154	WASHER, M6, SHAKEPRO	66769	GASKET, TURBOCHARGER	N37281	HOSE, 50MM I.D. x 90
59800	HOSE CLIP, SIZE 45,	66811	HOSE, 3" X 2.1/2" (S	N37287	FILM, INFO (BATTERY
59810	HOSE CLIP, SIZE 55,	66818	FLANGE, TURBO OIL I	N37288	BACKET, SUPPORT, HE
59812	HOSE CLIP, SIZE 60,	66823	PIPE, TURBOCHARGER O	N37289	HOSE, R.W.P TO HEAT
59813	HOSE CLIP, SIZE 20,	66824	FLANGE ASSEMBLY, TUR	N37290	HOSE, F.W.P TO MANIF
59814	HOSE CLIP, SIZE 30,	66827	PIPE, DRAIN, WITH FL	N37291	HOSE, THERMOSTAT TO
59815	HOSE CLIP, SIZE 70,	66828	PIPE, TURBO OIL FEED	N37293	OUTLET, EXHAUST 2.1/
59818	HOSE CLIP, SIZE 40,	66837	PIPE ASSEMBLY, THERM	N37297	STUD, M8 X 149
59819	HOSE CLIP, SIZE 50,	66862	PIPE, 1.3/4" FLANGED	N37303	RECEPTACLE, CONNECTO
59820	HOSE CLIP, SIZE 80,	66863	`O` RING, 1.88" ID X	N37304	PLUG, CONNECTOR
59821	HOSE CLIP, SIZE 100,	66895	PIPE, 3/16" BUNDY, B	N37324	BASE, CONTROL BOX
60210	PUMP, SUMP DRAIN	70034	SOCKET, 3/8" NPTF, S	N37325	COVER, CONTROL BOX
65066	NUT, M18 X 1.5, THIN	80215	PANEL, ASSEMBLY, ENG	N37326	SUPPORT, CONTROL BOX
65070	`O` RING, 0.5" ID X	81030	TERMINAL, 10MM RING,	N37350	BRACKET, MOUNTING, H
65074	CAPSCREW, M8 X 35, S	81056	HOLDER, PIN, 16 WAY	N37356	PUMP, RAW WATER
65077	PIPE ASSEMBLY, OIL P	81081	HOUSING, TAB (180924	N37390	BADGE, PERKINS/SABRE
65078	`O` RING (COOLING JE	81082	HOUSING, RECEPTACLE	N37395	PLUG, WEDGE
65092	PULLEY, CRANKSHAFT (	81083	RECEPTACLE, ELECTRIC	N37410	HOSE ASSEMBLY, INJEC
65093	RINGS, EXPANSION PAI	81084	TERMINAL, TAB (AMP 6	N37411	HOSE ASSEMBLY, INJEC
66019	BOLT, CYLINDER HEAD	81085	TIE, 2MM X 97MM	N37414	ADAPTOR, 3/8" BSP FE
66038	CAMSHAFT	81201	HOLDER, SOCKET, 16 W	N37427	HOSE, R.W.P TO GEARB
66049	BUSH, CONNECTING ROD	81202	CLAMP, CABLE, INSTRU	N37428	HOSE, GEARBOX OIL CO
66056	ROCKER POST, INTERME	81252	HOLDER, FUSE, IN LIN	N37436	RING, SEALING, 8MM
66058	SPRING, VALVE, EXHAU	81254	POLYCARBONATE BOX, E	N37437	NUT



N37438	HOSE ASSEMBLY (3/8",	N37564	SPEED CONTROL, REM MT	N38005	HEAT EXCHANGER AND G
N37440	PRE-FILTER WITH WATE	N37567	OVERLAY	N38010	GASKET, MANIFOLD TO
N37441	PRE-FILTER WITH WATE	N37573	GASKET, CYL BLOCK TO	N38040	PLUG (M18 STOR)
N37450	HOSE ASSEMBLY (3/8",	N37580	HOSE ASSEMBLY (3/8",	N38043	CONNECTOR, DEUTSCH (G
N37452	PIPE, HEAT EXCHANGER	N37581	HOSE ASSEMBLY (3/8",	N38047	HOSE, AIR FILTER TO
N37453	BRACKET, REAR LIFTIN	N37583	ELBOW, EXHAUST, 3" WA	N38071	HARNESS, STARTER REL
N37462	ELBOW, EXHAUST, 3" W	N37587	HOSE, BREATHER TO HEA	N38073	BKT, FUSE SUPPORT PCB
N37463	RELAY, 12V-70A	N37588	BOLT, M8 X 40, S.S	N38074	HOSE, H/EX TO EXHAUS
N37464	LOOM, ENGINE WIRING,	N37606	PANEL, STANDARD ASSE	N38075	KIT, KEEL COOLED (C2
N37465	CIRCUIT BREAKER, 10A	N37617	HARNESS, EXTENSION 15	N38076	HOSE, THERMOSTAT TO
N37466	CIRCUIT BREAKER, 80A	N37634	LAMP, SIGNAL, 24V	N38078	BRACKET, REGULATOR M
N37467	PLUG	N37635	BRACKET, RESERVOIR MO	N38082	PIPE, W/PUMP TO HEAT
N37469	COOLER, GEARBOX OIL	N37636	MOTOR, STARTER 12V	N38092	BRACKET, MOUNTING, DUP
N37470	BLANKET, HEAT, EXHAUS	N37646	ELBOW, EXHAUST, 3", WA	N38093	TRAY, DRIP, DUPLEX O
N37471	HOSE, H/E PIPE TO EX	N37657	PICK UP, MAGNETIC	N38101	ASSEMBLY, OIL FILTER
N37474	BANJO OIL FEED TURBO	N37658	PICK UP, MAGNETIC, A	N38102	MANIFOLD, EXHAUST, W
N37477	DUCT, TURBO TO INLET	N37662	BLANKET, TURBO CHARGE	N38104	ASSEMBLY, FUEL FILTE
N37478	HOSE, TURBO TO INLET	N37663	BLANKET, EXHAUST ELB	N38141	STARTER, AIR
N37493	PIPE, TURBO INLET (WIT	N37678	CONNECTOR, RS232	N38143	MANUAL, INSTALLATION
N37494	BRACKET, H/E SUPPORT	N37679	TOOL, SERVICE, L SER	N38147	REGULATOR, BOOST CON
N37495	BKT, FRONT FOOT/OPT P	N37681	ENCLOSURE, STANDARD	N38148	ADAPTOR, 3/16" PIPE
N37499	PIPE, INJECTOR, CYL	N37689	HEAT EXCHANGER	N38150	PIPE, INLET MANIFOLD
N37500	PIPE, INJECTOR, CYL	N37691	SWITCH, LOW OIL PRES	N38151	PIPE, REGULATOR TO I
N37501	PIPE, INJECTOR, CYL	N37693	TRANSMITTER, OIL PRE	N38159	O RING
N37502	PIPE, INJECTOR, CYL	N37793	DECAL, 12V	N38161	BRACKET, OIL COOLER
N37512	BLOCK, CONTACT NORMAL	N37794	PIPE, TURBO OIL DRAIN	N38213	PICKUP, DUAL MAGNETI
N37520	WIRING HARNESS, STAR	N37795	PIPE, TURBO OIL DRAIN	N38214	PLUG, 3 WAY (37165)
N37521	SOLENOID, STOP, INSU	N37796	JACKET, THERMAL, 135 D	N38216	SPACER, 6.5MM ID X 16
N37523	STOP SOLENOID, ASSEMB	N37797	JACKET, THERMAL, EXHAU	N38224	HOSE, FUEL FEED (FIL
N37524	SOLENOID, COLD START	N37798	JACKET, THERMAL, WAT	N38226	HOSE, FUEL RETURN (ENG
N37526	INVERTER, VOLTAGE, 1	N37804	STAY, SUPPORT, THERMOST	N38228	CLIP, 30MM, S.S
N37529	ENG CORE, C4.4TA TAG	N37805	BRACKET, SUPPORT, THER	N38230	ADAPTOR, TEE 5/16
N37532	HOSE, FUEL LEAK OFF,	N37806	KIT, PIPE, FUEL INJ, D/	N38239	PUMP, FUEL, ELECTRIC
N37537	COOLER, GEARBOX OIL	N37810	PIPE, FUEL, INJ L/OFF	N38240	PUMP, FUEL, ELECTRIC
N37543	LEAD ASSEMBLY, VOLTA	N37811	BLANKET, HEAT, TURBO	N38241	PULLEY, C/SHAFT, TWI
N37544	LEAD ASSEMBLY, VOLTA	N37828	GOVERNOR, CALIBRATED,	N38249	ADAPTOR, M30 X 1.5P
N37552	COOLER, GEARBOX OIL (K	N37846	HOSE ASSEMBLY, INJ P	N38252	TEE, 5/16-1/4 BSP
N37553	PIPE, 1.1/4", R.W.P	N37860	PIPE, TEE, 1" X 1" X 1	N38257	BRACKET, FUEL OUTLET
N37554	PIPE, 1.1/4", INTERC	N37861	ADPT, 3/16" ENOTS FEM	N38261	BONDING WIRE, RAW WA
N37555	PIPE, 1.1/4", HEAT E	N37912	ASSEMBLY, PIPE, OIL,	N38265	ADAPTOR, STRAIGHT, 5
N37556	PIPE, 5/8", MANIFOLD	N37913	ASSEMBLY, PIPE, OIL,	N38267	ELEMENT, FUEL
N37557	PIPE, 5/8", MANIFOLD	N37921	HOSE, LEAK OFF	N38268	ELEMENT, OIL (UNBRAN
N37558	PIPE, 5/8", MANIFOLD	N37956	HOSE, RAW WATER 1" BOR	N38270	ELEMENT, OIL (CAT BR
N37559	BRACKET, SUPPORT, WA	N37982	LABEL, INLAY INSTRUM	N38306	HOSE, ENGINE OIL, DU
N37560	HOSE, WATER PIPE TO G	N37985	MANIFOLD ISOLATION V	N38309	ASSEMBLY, RADIATOR,
N37561	HOSE, INTERCOOLER TO	N37988	KIT, SERVICE, RAW WA	N38310	ASSEMBLY, RADIATOR,



N38325	RECEPTACLE	N39615	SHAFT, RAW WATER PUM	N40557	HOSE, WIRE REINFORCE
N38337	PLATE,DAMPER DRIVE	N39634	HOSE, F.W.P. TO MAN	N40571	BLANKET, TURBOCHARGE
N38340	MANUAL, SERVICE 1100	N39661	CAP, 50.8 MM X 25 MM	N40573	SETSCREW, M8 X 60
N38401	RESISTOR ASSEMBLY, 5	N39666	24V SPARES KIT, MAJO	N40574	RETAINER, M8
N38460	SWITCH, HIGH WATER T	N39680	HOSE, REDUCER, 54 DI	N40576	SUPPORT STUD, BELT G
N38551	HOSE, RADIATOR TO TH	N39688	'O' RING, HEAT EXCHA	N40577	SUPPORT STUD, BELT G
N38581	MANIFOLD, EXHAUST (R	N39690	TUBESTACK, HEAT EXCH	N40585	BRACKET, ENGINE FOO
N38784	PUMP, FUEL, ELECTRIC	N39695	'O' RING, INTERCOOLE	N40611	ELBOW, 90 DEG, 8MM T
N38785	PUMP, FUEL, ELECTRIC	N39706	CLAMP-HOSE, 16-27	N40612	PIPE, RELIEF VALVE R
N38813	HOSE, SILICONE NOMEX	N39707	CLAMP-HOSE, 25-40	N40614	PIPE, INJECTION PUMP
N38814	HOSE, SILICONE NOMEX	N39745	GROMMET, 14.3MM ID X	N40618	BADGE, PERKINS
N38918	HOSE, ENGINE OIL, DU	N39764	GASKET, CYLINDER HEA	N40624	KIT, FUEL SYSTEM
N38924	EXH OUTLET, F.W.J. 1	N39792	STARTER MOTOR, 12V	N40626	BRACKET, MTG, THROTT
N38950	THERMOSTAT, 82 DEG (	N39793	STARTER MOTOR, 24V	N40627	LEVER, THROTTLE
N39040	SHROUD, EMERGENCY ST	N39875	CAP, 44.5MM, BLACK	N40640	DECAL, PERKINS, INST
N39069	SEAL-BONDED	N39885	ADAPTOR, M12 X 1.5 X	N40650	SPACER, 17.5 OD x 13
N39073	KIT, ELECTRICAL MATI	N39886	TEE, 8MM PIPE	N40658	DECAL, CONTROL BOX,
N39074	END CAP, BLANKING	N40162	ELBOW, 1/4" BSPT X 8	N40682	PLUG, 3/8" BSPT, SOL
N39081	ADAPTOR PLATE, SAE 3	N40163	GASKET,CYL BLOCK TO	N40684	HOSE, BREATHER TO CY
N39375	ELBOW, EXHAUST, 4" (	N40178	ASSEMBLY, MCS 2, CON	N40686	BREATHER, CRANKCASE
N39377	DECAL, COMPONENT LAY	N40206	CONTROLLER, DEIF, MC	N40687	ELEMENT, BREATHER
N39419	MOUNTS, CONTROL BOX	N40222	SPACER BLOCK, OIL FI	N40688	PANEL ASSEMBLY, MAIN
N39441	CAPSCREW, M5 X 35MM	N40290	HOSE, 5/16" ID, PVC	N40690	GAUGE, COOLANT TEMP
N39453	HANDBOOK, USERS, 400	N40294	INTERCOOLER (SINGLE	N40691	GAUGE, OIL PRESSURE
N39468	HOURLMETER, 24V	N40296	DECAL, COMPONENT LAY	N40692	GAUGE, VOLTAGE
N39473	HOSE,FUEL RETURN, IN	N40357	CONNECTION, M12 X 8M	N40693	GAUGE, TACHOMETER
N39474	HOSE, OIL FEED, FUEL	N40367	HOSE, 50.8 MM X 70 M	N40695	CONTROLLER
N39478	PLUG, BRASS, 1/4" BS	N40368	HOSE, 76.2 MM X 75 M	N40696	LED, AMBER
N39483	HOSE, 1" ID X 2M LON	N40386	HOSE, 1/4" TEXTILE B	N40697	LED, RED
N39507	BELT COVER, OPEN GEN	N40391	CLIP, CONVOLUTED TUB	N40698	SWITCH, TOGGLE (KEYS
N39512	KIT, MOTORPAL FUEL H	N40398	EXHAUST, 90 DEG, 3.5	N40699	SWITCH, TOGGLE (STAR
N39522	HARNESS, ENGINE OIL	N40401	BELLOWS, EXHAUST, AS	N40700	SWITCH, PUSHBUTTON (
N39523	USERS HANDBOOK, SPAN	N40435	INVERTER, VOLTAGE, 1	N40701	SWITCH, PUSHBUTTON (
N39524	ELBOW, 3/8" X 3/8" S	N40436	CONVERTER, VOLTAGE,	N40704	ALARM
N39527	ALTERNATOR, 12V, 55A	N40473	DUCT, TURBO TO CHARG	N40706	PANEL ASSEMBLY, AUX
N39528	ALTERNATOR, 24V, 35A	N40475	INSTALLATION MANUAL,	N40707	PANEL, AUX
N39530	GASKET, CYLINDER HEA	N40483	HOSE, 2" ID x 30° x	N40709	PANEL, KEYSWITCH
N39531	HEADER TANK AND EXHA	N40508	SPACER, 24 AF HEX X	N40710	RELAY, 12V 300A
N39543	BRACKET, MOUNTING, I	N40509	SPACER, 25 OD X 10.5	N40712	SENSOR, COOLANT LEVE
N39544	HOSE, F.W.P. TO MANI	N40517	COVER, FUEL PIPES	N40713	SENSOR, EXHAUST TEMP
N39545	HOSE, F.W.P. TO MANI	N40518	ASSEMBLY, PIPE, OIL,	N40716	PLUG, RESISTOR
N39546	HOSE, F.W.P. TO MANI	N40520	PIPE, FILLER, R.W.P.	N40717	BREAKER, CIRCUIT, 10
N39547	HOSE, BYPASS (TIER 3	N40526	BOLT, CARRIAGE HEAD,	N40720	RELAY, 24V 300A
N39560	PIPE, TURBO OIL FEED	N40538	ADAPTOR, 1/4" BSPT (	N40722	HARNESS, ENGINE WIRI
N39574	HOSE, R. W. P. TO CH	N40544	HOSE, CAC TO HEAT EX	N40723	HARNESS, CUSTOMER WI
N39612	IMPELLER, RAW WATER	N40556	PIPE, R/W PUMP INLET	N40724	TEE, J1939 CONNECTIO