

1. 打开文件 \fw-AC79_AIoT_SDK-release-AC79NN_SDK_V1.2.0\fw-AC79_AIoT_SDK-release-AC79NN_SDK_V1.2.0\cpu\wl82\tools\isd_config_rule.c

红色框的地方改为 1M

```
58 #if CONFIG_DOUBLE_BANK_ENABLE
59     BR22_TWS_DB=YES;
60     BR22_TWS_VERSION=0;
61     DB_UPDATE_DATA=YES;
62 #else
63     NEW_FLASH_FS=YES; [单备份模式]//单备份
64 #endif
65 #if __FLASH_SIZE__ == (1 * 1024 * 1024)
66     FLASH_SIZE=1M; [FLASH 总大小]
67 #elif __FLASH_SIZE__ == (2 * 1024 * 1024)
68     FLASH_SIZE=2M; [FLASH 总大小]
69 #elif __FLASH_SIZE__ == (4 * 1024 * 1024)
70     FLASH_SIZE=1M; [FLASH 总大小]
71 #elif __FLASH_SIZE__ == (8 * 1024 * 1024)
72     FLASH_SIZE=8M; [FLASH 总大小]
73 #elif __FLASH_SIZE__ == (16 * 1024 * 1024)
74     FLASH_SIZE=16M; [FLASH 总大小]
75 #elif __FLASH_SIZE__ == (32 * 1024 * 1024)
76     FLASH_SIZE=32M; [FLASH 总大小]
77 #elif __FLASH_SIZE__ == (64 * 1024 * 1024)
78     FLASH_SIZE=64M; [FLASH 总大小]
79 #endif
80
```

2. 删除下面目录下的 mp3 音频资源文件

\fw-AC79_AIoT_SDK-release-AC79NN_SDK_V1.2.0\fw-AC79_AIoT_SDK-release-AC79NN_SDK_V1.2.0\cpu\wl82\tools\audlogo