SEGA TOYS Homestar Flux

SEGA TOYS Homestar Flux Home Planetarium Star Projector Instruction Manual

Model: Homestar Flux

1. Introduction

The SEGA TOYS Homestar Flux is an advanced home planetarium designed to project a high-definition starfield onto your ceiling or wall. This manual provides essential information for the safe and effective use of your Homestar Flux projector, including setup, operation, and maintenance guidelines.



Image 1.1: The Homestar Flux projector creating a starfield in a room. This image illustrates the projector's primary function of displaying a realistic night sky indoors.

2. Safety Information

Please read all safety instructions before operating the device to prevent injury or damage.

- Do not look directly into the projection lens when the device is operating, as the bright light may cause eye discomfort.
- Keep the device away from water or moisture.
- Do not attempt to disassemble or modify the projector. Refer all servicing to qualified personnel.
- Use only the provided USB cable and wall plug, or a compatible power bank.
- Ensure proper ventilation around the device during operation.
- Keep out of reach of small children to prevent accidental damage or misuse.

3. Package Contents

Verify that all items are present in your package:

- Homestar Flux Planetarium Star Projector (Satin Black)
- Two Star Discs:
  - Northern Hemisphere (without constellations)
  - Northern Hemisphere (with constellations)
- USB Cable
- Wall Plug (AC Adapter)
- Instruction Manual (English, German, Chinese)
- Sky Map (Northern and Southern Hemisphere)
- Stylish Storage Box



Image 3.1: The Homestar Flux product packaging. The box contains the projector and its accessories.

4. Product Overview

Familiarize yourself with the components and controls of your Homestar Flux projector.



Image 4.1: Front view of the Homestar Flux projector. This image highlights the control panel and projection lens.

1. **Projection Lens:** Projects the starfield.
2. **Focus Dial:** Adjusts the clarity of the projected image.
3. **Disc Tray:** Where star discs are inserted.
4. **Timer Buttons (15, 30, 60):** Sets automatic shut-off time in minutes.
5. **Move Switch (N/S):** Controls the rotation direction of the star disc (Northern/Southern hemisphere).
6. **Shooting Star Button (SS):** Activates the shooting star effect.
7. **Power Switch (ON/OFF):** Turns the projector on or off.
8. **DC Input Port:** Connects the USB power cable.

5. Setup

1. **Placement:** Place the projector on a stable, flat surface. For optimal viewing, position it between 4 feet 7 inches (1.4 meters) and 8 feet 10 inches (2.7 meters) from the projection surface (ceiling or wall).
2. **Power Connection:**
    - Connect the provided USB cable to the DC Input Port on the projector.

- Plug the other end of the USB cable into the wall plug (AC adapter) and then into a power outlet.
- Alternatively, you can connect the USB cable to a compatible power bank for portable use.



Image 5.1: The Homestar Flux projector powered by a portable power bank. This demonstrates the flexibility of powering the device.

3. **Insert a Star Disc:**
    - Gently pull out the disc tray located on the side of the projector.
    - Carefully place one of the included star discs into the tray with the image side facing down (text side up) for best clarity. Avoid touching the image surface.
    - Slide the disc tray back into the projector until it clicks into place.

6. Operating Instructions

1. **Power On:** Flip the Power Switch to the "ON" position. The projector will illuminate, and the starfield will appear.
2. **Adjust Focus:** Rotate the Focus Dial until the projected stars appear sharp and clear on your chosen surface.
3. **Set Rotation:** Use the Move Switch to select the desired rotation direction:
    - "N" for Northern Hemisphere rotation.
    - "S" for Southern Hemisphere rotation.

    The disc will begin to rotate slowly, simulating the movement of stars.
4. **Activate Shooting Star:** Press the "SS" button to activate the shooting star effect. Note that the shooting star appears in a fixed location.
5. **Set Timer:** Press one of the Timer Buttons (15, 30, or 60) to set an automatic shut-off time in minutes. The projector will turn off after the selected duration.
6. **Power Off:** Flip the Power Switch to the "OFF" position when you are finished using the projector.



Image 6.1: The Homestar Flux projector in operation, casting a detailed starfield. This demonstrates the visual output of the device.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your projector.

- **Cleaning the Projector Body:** Wipe the exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Cleaning Star Discs:**
    - Dust on the disc surface can appear as dark spots in the projection.

- Gently blow off any loose dust from the disc.
- If necessary, use a clean, soft eyeglass cleaning cloth to carefully wipe the disc surface. Avoid scratching the image.
- Always handle discs by their edges.

- **Storage:** When not in use, store the projector and discs in their original packaging or a dust-free environment.

8. Troubleshooting

Problem	Possible Cause	Solution
No projection or dim light.	• Power cable not connected properly. • Power switch is off. • Room is too bright.	• Ensure the USB cable is securely connected and the wall plug is in a live outlet. • Flip the Power Switch to "ON". • Operate in a dark room for best results.
Projected image is blurry.	• Focus dial not adjusted correctly. • Projector is too close or too far from the surface.	• Rotate the Focus Dial slowly until the image is clear. • Adjust the projector's distance from the projection surface (recommended 4'7" to 8'10").
Dark spots or specks appear in the projection.	• Dust or debris on the star disc.	• Remove the disc and gently clean it as described in the Maintenance section.
Shooting star appears in the same spot.	• This is a design characteristic of the device.	• The shooting star function is not randomized. This is normal operation.

9. Specifications

Feature	Detail
Model Name	Homestar Flux
Brand	SEGA TOYS
Color	Satin Black
Light Source	5-watt warm white LED
Lens Type	Advanced multilevel glass lenses
Power Source	Corded Electric (USB cable & wall plug)
Voltage	110 Volts
Projection Distance	4'7" to 8'10" (1.4m to 2.7m)
Product Dimensions	7.5"L x 7.5"W x 9"H
Item Weight	11 Ounces (approx. 312g)
Features	Silent disc rotation, adjustable projection angle, shooting star function, timer (15/30/60 min)

10. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product or contact SEGA TOYS customer service directly. Specific warranty terms may vary by region and retailer.

© 2023 SEGA TOYS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question