

ANTIHUNTER
DIGI NODE

Operator's Guide: from the box to the field

Covers all four tiers: **Fully Assembled Unit** · **Complete Parts Kit** · **Populated PCB** · **Bare PCB**

Guide revision 1.4 · 23 October 2026 · Firmware v1.0.5 · Written for the current Stable and Beta firmware channels
github.com/lukeswitz/AntiHunter · Web flasher: lukeswitz.github.io/AntiHunter

Hello, operator

The DIGI node is a sensor board built around an ESP32 and a Meshtastic LoRa radio. AntiHunter, its firmware, listens to the Wi-Fi and Bluetooth around it and reports what it finds. You control the node from its web UI (Full build), by sending it text commands over LoRa from any Meshtastic radio on your channel, or by typing the same commands on its USB serial port. It needs no internet connection, cloud account or server.

This guide takes you from the box to a tuned node in the field. A label marks each section that applies to one tier only.

> **READ BEFORE APPLYING POWER: THREE RULES**
>
> **1. Regulated 5 V only.** Power the PCB from USB, a bench supply set to 5 V, a DC-DC regulator, or the UPS board. Never connect 18650 cells, a battery pack, or a vehicle supply directly to the board. Unregulated input permanently damages the modules. Voltages under 4.5 V cause instability.
>
> **2. Never power the LoRa radio without its antenna.** Transmitting into an open port can destroy the radio's power amplifier. Fit the LoRa antenna, or the U.FL pigtail plus antenna, before you power the node.
>
> **3. One USB cable at a time.** The ESP32 and the Meshtastic radio share the PCB's power rails, and with both USB ports plugged in one board back-feeds the other. Unplug one before you plug in the other.

What you are holding

Tier	What is in the box	What you still do
1 · Fully Assembled Unit	Built, tested, radio flashed.	Fit two 18650 cells, screw on the antennas (§2), flash AntiHunter (§5), set the radio region and channel (§7).
2 · Complete Parts Kit	All parts, unassembled and unflashed.	Assemble it (§3), flash Meshtastic on the radio (§7.1), flash AntiHunter (§5) and configure.
3 · Populated PCB	Assembled and tested, radio flashed.	Attach the antennas (§2), supply power, flash AntiHunter (§5), set the radio region and channel (§7).
4 · Bare PCB	One unpopulated board.	Source the BOM, assemble (§3), flash Meshtastic on the radio, fit an SD card, flash AntiHunter (§5).

The ESP32 ships empty on every tier, so you flash AntiHunter yourself.

Contents

1 Unboxing and inventory
2 Antennas
3 Assembly
4 First power-on
5 Flashing the firmware
6 Staying up to date
7 Mesh radio setup
8 First configuration
9 Using the node
10 Vibration sensor and tamper response
11 Mesh command reference
12 Command Center (C2)
13 Deployment
14 Maintenance and troubleshooting

1 Unboxing and inventory

Open the box on a static-safe surface and check it against your tier before you power anything.


1.1 Tier checklists

CHECK THE BOX AGAINST YOUR TIER

- ☐ **Tier 1:** a tested node with an 8 GB SD card fitted, SMA antennas for 2.4 GHz Wi-Fi/BLE and for LoRa in your region, and an active GPS helix antenna. Meshtastic is on the radio, and its serial link is set up.
- ☐ **Tier 2:** every part in the bill of materials (Appendix B), unassembled and unflashed, plus the 3D-printed enclosure and TPU seals. The GPS module comes with its factory ceramic antenna.
- ☐ **Tier 3:** a PCB with all modules soldered and an 8 GB SD card fitted, plus the factory U.FL antennas: a flat 2.4 GHz film, a coiled LoRa whip, and a ceramic GPS patch. Meshtastic is on the radio. It has no enclosure and no power source.
- ☐ **Tier 4:** one unpopulated 82 mm PCB. Everything else comes from Appendix B, and you flash the radio yourself.

1.2 What you supply


- **18650 cells** for tiers 1 and 2. Tier 3 can run from USB or a regulated 5 V supply. We never supply cells. Use brand-new cells of the same brand and capacity. Sourcing, charging, storage and disposal are your responsibility.
- **A micro SD card**, only on the Bare PCB tier. It must be FAT32, and 32 GB or larger is not recommended.
- **A USB-C data cable.** Charge-only cables will not flash the board.
- **A computer running Chrome or Edge** for the web flasher, or a terminal for the CLI installer.
- **Soldering tools** on tiers 2 and 4: temperature-controlled iron, solder, flux, tweezers, small Phillips and hex drivers.




The bare 82 mm board.




XIAO ESP32-S3.




Heltec V3.2 LoRa radio.




ATGM336H GPS module.



DS3231 real-time clock.



SW-420 vibration sensor. Note the trimpot.



Micro SD reader module.



U.FL-to-SMA pigtail.



5 V UPS charger board.

1.3 Power

The node draws roughly 160 mA idle and 600 mA while scanning. Inside the enclosure the UPS board provides the regulated 5 V. Outside it, use a USB-C adapter, a bench supply set to 5.0 V, or a DC-DC regulator.

> **POWER RULES**
>
> Do not connect batteries directly. Do not exceed 5 V. Do not use unregulated sources. A 2 A fast-blow fuse in the battery line, in series with the switch wiring, is optional and not supplied with any tier.

1.4 Thermal

The ESP32 runs warm under load and the GPS module gets hot while it searches for satellites. Both are normal. The node works without the fan and the thermal switch.


- The 30 mm fan plugs into the FAN JST output. Run it for a second and feel which way it blows before you screw it down. The sticker side is not always the exhaust side. The Fully Assembled Unit ships with the fan set to exhaust.
- The KSD9700 thermal switch (normally open, 40 °C) wires to the THERMO JST and switches the fan on when the enclosure heats up.
- To run the fan continuously, jump the THERMO input or supply 5 V straight to the fan port.

2 Antennas

U.FL connectors are small and break if pressed on at an angle.


2.1 Which antenna goes where

Antenna	U.FL set (tiers 2 and 3)	SMA set (tiers 1 and 2)	Connects to
2.4 GHz Wi-Fi / BLE	Flat black film, printed 2.4G	Shorter rubber duck, 6 dBi	XIAO ESP32-S3 U.FL socket, or its SMA bulkhead
LoRa (region specific)	Coiled black whip	Longer duck, marked 868 MHz (EU), 915 MHz (US) or 923 MHz (Asia)	Heltec / T114 U.FL socket, or its SMA bulkhead
GPS	Passive ceramic patch, supplied with the GPS module	Active helix, Fully Assembled Unit only	GPS module U.FL socket, or the SMA bulkhead in the battery housing



Factory U.FL antennas beside their sockets: GPS patch, LoRa whip (915 MHz shown), 2.4 GHz film.

> **PICK AN ORIENTATION AND KEEP IT**
>
> On an enclosed build, decide which bulkhead carries LoRa and which carries Wi-Fi, then wire every node the same way. A spare antenna then always fits the port you expect.



The two SMA bulkheads with the power switch centered between them.


MATCH YOUR ANTENNAS ACROSS NODES

Use the same antenna type and cable length on every node. Triangulation assumes the nodes hear the world the same way, and mismatched antennas skew the result.


2.2 Fitting a U.FL / IPX pigtail (tiers 2 and 3)

The pigtail's snap connector seats on each module's socket with a click.


1. Identify each pigtail and its socket. Route the cable before you connect it.
2. Hold the connector **parallel to the board** and align its rim over the socket. From the side, the two rims must line up one above the other.
3. Press **straight down** with a fingertip or the flat of a plastic tool until it clicks.
4. Tug the cable gently. If it lifts off, it never seated.



GPS module, connector facing up.



LoRa radio, socket circled.




XIAO ESP32-S3, Wi-Fi/BLE socket.

U.FL: DO NOT


- Do not press at an angle, and do not force a connector that will not click.
- Do not pull the cable to remove one. Lift the connector body straight up, or use a U.FL removal tool.
- Do not reseat one repeatedly. The contacts wear out.
- **Misalignment damage is permanent.** A crushed socket means a new module.

2.3 Fitting SMA antennas (tiers 1 and 2)

1. Check the bulkhead is tight in the shell. The nut and washer go on the outside, and the bulkhead must not rotate when you turn an antenna onto it.
2. Start the thread by hand, straight on, so it does not cross-thread.
3. Turn until finger-tight, then no more than an eighth of a turn. Do not use pliers.
4. Stand the antenna upright.



GPS SMA female in the battery housing, held by washer and nut.



Wi-Fi SMA (female, left) and LoRa SMA (male, right) in the main housing.

> **WET CONDITIONS**
>
> Put silicone grease on the SMA threads and the TPU seals to keep water out.

3 Assembly (tiers 2 and 4)

Tiers 1 and 3 arrive soldered. Skip to §4.

> **BUILD FROM THE ASSEMBLY MANUAL, NOT FROM HERE**
>
> The illustrated assembly manual covers soldering, connectors, the enclosure, the SD card and the power wiring.
>
> `hw/Prototype_STL_Files/Antihunter-DIGINODE-AssemblyManual.pdf`
> `github.com/lukeswitz/AntiHunter`, in the `hw` folder
>
> Finish it, then continue at §4.

4 First power-on

4.1 What a healthy boot looks like

Connect a USB-C cable to the **ESP32** only and open a serial monitor at 115200 baud. The firmware prints its banner and version, then the result of each hardware check: SD card, GPS, RTC, vibration sensor. It names any module that failed to start. On Full firmware a Wi-Fi access point named `Antihunter` also appears within a few seconds.

4.2 Confirming the hardware

On Full firmware, System tab → **Diagnostics** reports each subsystem:

- **SD card.** Mounted and writable. Without it the node still scans but logs nothing.
- **GPS.** Reports a fix once it has one. It needs a clear view of the sky and may never lock indoors. Detections carry coordinates only when the fix is valid.
- **Vibration sensor.** Shows `Standby`, or `Active` with the time of the last movement.

4.3 The clock

Every flasher sets the DS3231 clock: `pio upload`, the command-line script, and the web flasher's Connect & Configure step. With a GPS fix it re-syncs at most once an hour, and only when it is more than 1 s off. A coin cell keeps it running without power. You can also set it from USB serial with `SETTIME:<unix seconds>`. The clock keeps UTC. Logs, capture file names, results and heartbeats show local time, with daylight saving, once GPS places the node in one of these zones: Hawaii, Alaska, Arizona, Saskatchewan, US/Canada Pacific, Mountain, Central and Eastern, UK/Ireland, Central Europe, Eastern Europe. Elsewhere, and before the first fix after boot, they show UTC.

> **ORDER OF OPERATIONS**
>
> Flash the firmware first (§5), then set the clock and configure the radio. Flashing with **Erase Device** checked clears saved settings.

5 Flashing the firmware

Choose a build and flash it to the ESP32.

5.1 Full or Headless?

Both builds have the same detectors, mesh commands and scan engine. The difference is whether the node hosts a Wi-Fi access point.

	Full	Headless
Control	Web UI and HTTP API over its own AP, plus serial and mesh	Serial and mesh only
RF footprint	The AP beacons continuously, so the node is discoverable as a Wi-Fi network	Never beacons
Results	Cards in the Results tab	Text in `/last_results.txt`
SD logging	Identical on both builds (§9.14)	
Device database	`/devicedb.jsonl`, browsed in the Data tab under **All Discovered Devices**	The same file. Clear it with `DEVICE_DB_CLEAR` (§11)

Use Full for bench work and first setup, then reflash to Headless for covert and long-term field deployments. A reflash keeps settings unless you check **Erase Device**.

5.2 Release channels

Channel	Source	Use it when
Stable	`main` branch	Default. Field deployments.

Channel	Source	Use it when
Beta	`beta` branch	New features first, less tested.
Experimental	ESP32-C5 builds (2.4 + 5 GHz) and RadarNode	Only on C5 hardware. The flasher asks you to acknowledge these are test builds.

5.3 Method A: web flasher (recommended)

1. Open **lukeswitz.github.io/AntiHunter** in Chrome or Edge on a desktop. Other browsers cannot talk to serial ports.
2. Choose **Full** or **Headless**, and a release channel.
3. Plug the ESP32 in with a data cable, nothing else connected to the board.
4. Click **Connect & Flash** and pick the port.
5. Optionally set device parameters before flashing. The **Sentinel & Detectors** panel configures start-on-boot, radio mode, every detector toggle, mesh flags and thresholds. Anything left on *Default* keeps the firmware's own setting. The panel also has the **Erase key** field, the only place to set the key on Headless.

> **ERASE DEVICE**
>
> Check it when upgrading from firmware older than v0.9.2, or when you want to clear saved settings. Otherwise leave it off.

5.4 Method B: command line

```
curl -fsSL -o flashAntihunter.sh \
  https://raw.githubusercontent.com/lukeswitz/AntiHunter/main/Dist/flashAntihunter.sh
chmod +x flashAntihunter.sh
./flashAntihunter.sh
```

The script asks for a release channel, then Full or Headless. Flags: `-c` sets device parameters during the flash, `-e` erases flash first, `-l` lists available firmware, `-f FILE` flashes your own `.bin`.

5.5 Method C: build from source

```
git clone https://github.com/lukeswitz/AntiHunter.git
cd AntiHunter
pio device list                                # find the port
pio run -e AntiHunter-full -t upload           # Full build
pio run -e AntiHunter-headless -t upload       # Headless build
pio device monitor -e AntiHunter-full          # watch it boot
pio run -e AntiHunter-full -t erase -t upload  # clean flash
```

Environments: `AntiHunter-full` and `AntiHunter-headless` for the ESP32-S3, and `AntiHunter-c5-full` and `AntiHunter-c5-headless` for the ESP32-C5 on the `feat/c5` branch.

5.6 Verifying the flash

- The serial monitor prints the banner and firmware version at boot.
- Full build: join the `Antihunter` access point with password `antihunt3r123` and open **http://192.168.4.1** (`http`, not https). Log in as `admin`; the password is the AP password until you set a separate web password.

> **DO THIS BEFORE ANYTHING ELSE**
>
> The default AP name and password are public. Until you change them (§8.1), anyone nearby can join the node.

5.7 Board variants

The XIAO ESP32-C5 replaces the S3 on the same board and adds 5 GHz scanning. Those builds are on the flasher's Experimental channel. The RadarNode variant pairs a 24 GHz radar with the same mesh: it detects a moving target, then sweeps Wi-Fi and BLE to record which devices were present (see `docs/RADARNODE.md`).

6 Staying up to date

6.1 Where updates come from

The web flasher serves the current build of the channel you pick, so re-running it updates the node. The node never contacts the internet or updates itself.

6.2 Getting notified

1. Open **github.com/lukeswitz/AntiHunter** and sign in.
2. Click **Watch** → **Custom** → check **Releases** → Apply.
3. Read the release notes before you flash. They are in `docs/release-notes/notes.md` in the repository.

6.3 Updating a deployed node

1. Bring it in, or reach it over USB in place.
2. Re-run the web flasher or the CLI script on the same channel. Leave **Erase Device** unchecked to keep your settings.
3. Reconnect, check the version, and confirm your targets, node ID and detector settings survived.

The node keeps settings in its built-in memory and copies them to the SD card, so they normally survive an update, a reboot and a corrupted copy. Erase Device clears the built-in memory.


6.4 Rolling back

Flash the other channel, or build an earlier tag with PlatformIO. If a downgrade misbehaves, erase and flash clean, then reconfigure.

> **FLEET DISCIPLINE**
>
> Run one firmware version across a mesh. Message formats can differ between versions.

7 Mesh radio setup

The LoRa mesh carries commands and alerts between your radios and your nodes. It is optional. A single node works on its own.



A device scan sending results over the mesh. The header badge shows the transmit queue draining at the LoRa airtime cap (12 of 30 rows sent). Addresses and names are placeholders.

7.1 Flashing and linking the radio

Tiers 1 and 3 arrive with the radio on the latest stable Meshtastic and the serial link set as in the table below. The screen blanks after 1 s and the status LED is off. Do not redo it.

Tiers 2 and 4: connect the Heltec V3.2 (preferred) or T114 on its own USB and flash the latest stable Meshtastic from **flasher.meshtastic.org**. Then set the serial module in the Meshtastic app or web client, or with the script in §7.2:

Setting	Value
Serial module	Enabled
Mode	`TEXTMSG`
Baud	`115200`
Pins, Heltec V3	19 RX / 20 TX
Pins, T114	10 RX / 9 TX

Without this the node and the radio cannot talk.

> **THREE THINGS EVERY RADIO NEEDS, ON EVERY TIER**
>
> - **LoRa region.** It defaults to `UNSET`, so the radio receives but does not transmit (§7.2).
> - **Bluetooth pairing PIN.** Every unit has the same default PIN. Change it or turn BLE off.
> - **Channel.** It defaults to the public channel. Make your own encrypted channel primary and turn the public one off (§7.3).

7.2 Set the region

An `UNSET` region makes the radio receive-only. Set the region for the country you are in. It determines the frequency band and the legal power and duty-cycle limits.

Plug the **radio** in on its own USB, not the ESP32, and run:

```
pip3 install 'meshtastic[cli]' pyserial
python3 scripts/meshtastic_config.py
```

With no arguments it prints the current settings and opens an interactive menu. Non-interactive equivalent:

```
python3 scripts/meshtastic_config.py --serial on --board heltec-v3 \
    --screen off --led off --ble off --region US
```

Option	What it does
`--port`	Serial port, auto-detected if omitted
`--board heltec-v3 | t114`	Sets the serial-module pins for your board
`--region`	LoRa region, e.g. US
`--serial on | off`	The node link: TEXTMSG at 115200 on the board's pins
`--screen on | off | SECS`	`off` blanks after 1 s, or give a timeout in seconds
`--led on | off`	Status LED heartbeat
`--ble on | off`	Bluetooth radio
`--pin NNNNNN | none | random`	BLE pairing: fixed 6-digit PIN, none, or random

The Meshtastic phone app or web client can apply the same settings.

7.3 Your own encrypted channel

Meshtastic defaults to a public channel with a well-known key. Anyone in radio range running stock firmware can read your commands, detections and coordinates on it. Before you deploy:

1. In the Meshtastic app, create a **new channel** with a generated key and a name of your own.
2. Make it the **primary** channel.
3. **Turn the public default channel off.**
4. Share the channel to your other nodes and phone by QR code or channel URL. Every node must carry the same channel.

7.4 Quiet-ops settings

- **Screen off and LED off** remove the visual signature and save power: `python3 scripts/meshtastic_config.py --screen off --led off`.

- **Screenless node.** This step is optional and advanced, and you do it at your own risk. Heltec publishes no removal procedure for the soldered display. Without a screen, set a fixed pairing PIN with `--pin NNNNNN` (6 digits, or `none`), because `random` shows the PIN on the screen.
- **BLE off** on the radio removes its Bluetooth signature. Set a pairing PIN first if you may turn it on later.
- **Headless firmware** has no Wi-Fi access point.

7.5 Addressing and node IDs

- Node IDs are 2 to 5 characters, A-Z and 0-9. Give every node a distinct one.
- `@ALL COMMAND` sends to every node. `@AH01 COMMAND` sends to one. The node ignores a message without the `@` prefix.
- You can type the same lines on the ESP32's USB serial port at 115200 baud. A line can be at most 230 characters.
- The node ignores any message whose sender name equals its own node ID. Do not give the Meshtastic radio a short name that matches a node ID.
- The node sends at most about 400 bytes per second, with a 1000-byte burst. One message holds at most 230 bytes.

7.6 Reaching the mesh

Commands and detections are ordinary Meshtastic text messages. Pair the radio to the Meshtastic app over Bluetooth or Wi-Fi and send `@node COMMAND` messages, or use the Meshtastic ATAK plugin or an MQTT gateway node.

8 First configuration

Do this on the bench before you deploy the node.

8.1 Change the credentials

- **AP name and password.** The defaults `Antihunter` and `antihunt3r123` are public. Change both under System tab → **Settings** → **Access point** → **Wi-Fi network** and press **Save Wi-Fi settings**. **Network name (SSID)** takes 1 to 32 characters, and **Password** takes 8 to 63. Every save restarts the node after 3 seconds. **Security** is WPA2/WPA3 by default. Choose WPA2 only for older clients.
- **Hidden network.** Off by default. When on, the node stops broadcasting its network name and you type the name by hand to connect. Your phone or laptop then sends the name in its probe requests wherever it goes.
- **Web login.** Same section, **Web login**. **Require login** is on by default and the user name is `admin`. Until you set a **New web password**, the password is the Wi-Fi password. A web password is 8 to 63 characters with no `:`. Any change needs the **Current web password**, and five wrong passwords lock changes for 10 minutes.
- **Erase key.** Every wipe, cancel, auto-erase change and factory reset needs it. The node makes one on first start, and every way of flashing shows it: **Show my erase key** in Web Flasher step 2, the flash script, and `pio run -t upload`. **Write it down.** A flash with **Erase device** off keeps the key and shows a key the node made again. A flash with **Erase device** on replaces the key, and the node shows the new one. If you lose the key, flash with **Erase device** on. Settings come back from the SD card, and the AP password and web password go back to their defaults. Change the key in System tab → **Settings** → **Danger zone**, or with `CONFIG_ERASE_PSK:<new>:<current>`. §10.4 has the details.

8.2 Identity

Node ID. Set it in the web UI or with `@AH01 CONFIG_NODEID:AH02`. It prefixes every mesh message the node sends. For the clock, see §4.3.

8.3 Scan presets

System tab → **Settings** → **Scanning** → **Scan timing** → **Profile** sets the whole timing profile at once. Start on Balanced. Picking a profile also resets the Wi-Fi channel list to 1 to 11.

Preset	Wi-Fi chan time	Wi-Fi scan int	BLE scan int	BLE scan dur	RSSI	Use case
Relaxed	300 ms	5000 ms	6000 ms	3000 ms	–80 dBm	Low power
Balanced	160 ms	3000 ms	4000 ms	2000 ms	–95 dBm	General use (default)
Aggressive	110 ms	1500 ms	2000 ms	1000 ms	–100 dBm	Fast detection, high coverage
Custom	User-defined					Fine-tuned

What each parameter does


- **Wi-Fi channel time**, 110 to 300 ms. How long the radio stays on each channel. Access points beacon about every 100 ms, so a shorter time can miss them.
- **Wi-Fi scan interval**, 1000 to 10000 ms. Time between full-band access point scans. In between, the node captures frames while it hops channels.
- **BLE scan interval**, 1000 to 10000 ms. Time between BLE scans.
- **BLE scan duration**, 1000 to 5000 ms. How long each BLE scan listens. Wi-Fi capture pauses for that time, because Wi-Fi and BLE share one radio. The presets set it to half the BLE scan interval.
- **RSSI filter** (Signal filter), –100 to –10 dBm. The node drops weaker signals. Triangulation still uses every signal. Over mesh, `CONFIG_RSSI` accepts –128 to –10.
- **Wi-Fi channels.** A comma list, `1,6,11`, or a range, `1..13`. The default is 1 to 11.
- **RF environment** (Signal filter). The path-loss model for distance estimates (§9.9).
- **Distance calibration.** Measures this node's signal strength at 1 m against a device at a known distance, for this node or any mesh node (§9.9).

8.4 Field controls worth knowing now

- **Privacy.** The **Privacy** button masks MACs, GPS coordinates and device names, and replaces SSIDs with hashes, in the web UI. **Exports and SD data are not redacted.** Scrub those separately.
- **Allow list.** Scan tab → Device Discovery card → **Allow list**. Target Scan and Baseline skip the devices on it, so put your own devices there. Other scans ignore it.
- **Battery Saver.** System tab → **Settings** → **Sensors & power** → **Battery saver**, or `BATTERY_SAVER_START` from §11. Scanning stops, BLE turns off, the CPU drops to 80 MHz, and the node sends a heartbeat at the interval you pick: 1, 2, 5, 10, 15 or 30 minutes. The mesh and access point stay on, and the node reads GPS once a minute.
- **Theme and accent colors.** System tab → **Settings** → **Appearance**. **Theme**: Paper dark (default), Blue dark or Light. The sun and moon button in the header switches between Light and your dark theme. **Stop and clear buttons** and **Sentinel banners** set accent colors. Each browser stores its own choices.
- **Fleet.** System tab → **Fleet** lists the nodes and mesh radios heard on your channel. **Ping Nodes** sends `@ALL STATUS` so every node answers. **Clear** empties the list.
- **Node & mesh settings.** System tab → **Settings** → **Node & mesh**: **Mesh** turns the radio link on or off. **Status heartbeat** sends a status message every 1 to 60 minutes. It is off by default and uses 10 minutes when you turn it on. **Alert send interval** is the shortest gap between alert messages, 1500 to 30000 ms. **Repeat filter** skips a MAC the node already sent within 0 to 3600 seconds. The default is 300, and 0 sends every device on every scan. **Send only new devices** sends only devices not yet sent this session. **Clear cache** forgets what the node sent. The filters apply to device lists only. The node always sends alerts, drone events and triangulation.

9 Using the node

Every capability runs on the node itself. One scan mode runs at a time.



The Scan tab: scans on top, options left, schedule right.

9.1 Target Scan

Target Scan watches for the devices on your Targets list and sends an alert when one appears. A target is a full MAC address, an OUI (the first three bytes of a MAC, which matches every device from one maker) or an SSID (a Wi-Fi network name).

In the web UI: Scan tab → Device Discovery card → **Targets**, enter one target per line and save. Set **Mode**, **Duration (s)** or **Forever**, and press **Start Scan**. Over mesh:

```
@ALL CONFIG_TARGETS:AA:BB:CC:DD:EE:FF|11:22:33|MyNetwork
@ALL SCAN_START:2:300:1..11
```

Value	What it means
`CONFIG_TARGETS:` list	Replaces the whole Targets list. Separate entries with `|`.
`2`	Mode: 0 Wi-Fi, 1 BLE, 2 both.
`300`	Run time in seconds, 0 to 86400. 0 runs until `STOP`.
`1..11`	Wi-Fi channels to sweep: a list (`1,6,11`) or a range. This field is required. The node rejects `SCAN_START:2:300`. Use `FOREVER` here instead to run until stopped on channels 1 to 11.

Alert: `AH01: Target: MAC RSSI:dBm Type:WiFi|BLE [Name:name] [GPS=lat,lon] [V=vendor] [C=class]`. `RSSI` is signal strength in dBm. `V=` is the first word of the maker's name, sent when the MAC is not randomized. `C=` is the BLE class (§9.2).

With **Movement** checked, a target card shows **Getting closer** or **Moving away** when the signal has clearly risen or fallen over the last minute: at least 6 sightings over 15 s, a change of at least 6 dB, and a t-statistic of at least 3 (a measure that the trend is not noise). Otherwise it shows **Measuring** or **Steady**.

9.2 Device Discovery

Lists every Wi-Fi and BLE device nearby with signal strength, channel and name. Run it first at a new site. In the web UI, pick **Device Discovery** (second card on the Scan tab), set **Scan Mode** and duration, and press **Start**. Check **Capture Probes** to fill the probe database at the same time.

```
@ALL DEVICE_SCAN_START:2:300:+PROBE
```

Mode and run time work as in §9.1. `+PROBE` also records probe requests, and `CH1,6,11` limits the Wi-Fi channels. The extra fields can come in any order.

Split across nodes. Scan tab → Device Discovery → **Split across nodes** runs one scan across the nodes you check. **Split by** *Radio* makes nodes alternate Wi-Fi and BLE, and *Channel* gives each node its share of the channel list. Set **Duration (min)** and press **Start split scan**.

BLE classes. The **Classify BLE devices** checkbox is on by default. It labels each BLE device by what it advertises: an Apple service (AirDrop, Handoff, AirPods, Find My), or a class and maker such as `Wearable-Garmin`, `Tag-Tile`, `Vehicle-Tesla` or `Drone-RemoteID`. Results and mesh messages carry the label as `C=`. Turning it off saves processor time and memory. `BLE_CLASSIFY:0` turns it off, and `BLE_CLASSIFY:1` turns it on.

9.3 Probe Request Scanner

Listens for the probe requests devices send while looking for networks they know, and records the network names each device asks for. Pick **Probe Request Scanner** in the scan list. Check **Broadcast All Probes (mesh)** to send every probe over the mesh instead of only target hits.

```
@ALL PROBE_START:2:300:+ALL
@ALL PROBE_STOP
```

Mode and run time work as in §9.1, except that a run time of 0 counts as 1 second here. Add `:FOREVER` to run until stopped. `+ALL` sends every probe over the mesh.

Hit: `AH01: PROBE_HIT MAC [Randomized|maker] RSSI=dBm CH=N [SSID="net" [GHOST]]`. `CH` is the Wi-Fi channel. **Ghost SSID detection** adds `GHOST` when no access point nearby answers for the probed name.

9.4 Baseline Anomaly Detection

The node learns which devices belong at a site, then reports what is new, what returns, what changes signal strength and what disappears. In the **learning phase** the node records devices and sends no alerts. Its length is the **Baseline** setting: 5, 10 or 15 minutes, with 5 as the default. In the **monitoring phase** the node alerts on changes. Its length is **Monitor (s)** in the web UI, or the run time in the mesh command.

```
@ALL BASELINE_START:900
@ALL BASELINE_STATUS
```

`900` is the monitoring time in seconds, from 60 to 86400. The node raises a shorter value to 60. `:FOREVER` or 0 monitors until stopped. The mesh command uses the **Baseline** learning time stored on the node. `BASELINE_STATUS` reports


whether it is scanning, whether learning has finished, the device and anomaly counts, and the phase. `Phase1` is INACTIVE, ACTIVE or COMPLETE.

Options on the Scan tab when you pick **Baseline Anomaly Sniffer**:


Setting	What it does	Range, default
RSSI	Devices weaker than this raise no anomalies.	–40 to –80 dBm, –60
Baseline	Length of the learning phase.	5, 10 or 15 min, 5
Monitor (s)	Length of the monitoring phase.	0 to 86400 s, 300
RAM Cache	Devices kept in memory (1500 without an SD card).	200 to 500, 400
SD Device Storage	Devices kept on the SD card.	1000 to 100000, 50000
Marked Absent (s)	Time a device must be unseen before it counts as gone.	30 to 600 s, 120
Seen Reappear (s)	Window after a disappearance in which a return raises an alert.	60 to 1800 s, 300
RSSI Variation dB	Signal change that counts as significant.	5 to 50 dB, 20

Alerts: `ANOMALY–NEW` (a device not in the baseline), `ANOMALY–RETURN` (a gone device came back), `ANOMALY–RSSI` (signal moved by the RSSI Variation) and `DEVICE_DISAPPEARED`.


Compare from now. Press this button once monitoring starts, or send `@ALL BASELINE_WATCH` over mesh. The reply `BASELINE_ACK:NOT_RUNNING` means no baseline is running. From then on the node tracks what is new, what is gone, and what moved closer or away. Full shows the result in a *Since* section in Results. Headless prints the device list to serial and sends `BASELINE_WATCH: New=<n> Gone=<n> Moved=<n> Both=<n>` over mesh.



Target scan results (§9.1).



Probe detection results (§9.3).



Baseline monitoring: counts and each anomaly (§9.4).

9.5 Randomized MAC Tracer

Modern phones rotate their MAC address to defeat tracking. This experimental mode links rotating MACs to one identity using behavioral signatures, and reports the identity instead of the address. Pick **Randomized MAC Tracer** in the scan list.

```
@ALL RANDOMIZATION_START:2:300
```

Mode and run time work as in §9.1. The run time defaults to 60 if you leave it out. The node sends `IDENTITY:` messages. Treat them as a lead, not proof.

9.6 Deauth Detection

Detects deauthentication and disassociation frames, which disconnect a client from an access point, and tracks their source. Pick **Deauth Detection** in the scan list.

```
@ALL DEAUTH_START:300
```

Alert: `AH01: ATTACK: DEAUTH|DISASSOC [BROADCAST|TARGETED] SRC:MAC DST:MAC RSSI:dBm CH:N R:reason`. `SRC` is the sender, `DST` the target, `CH` the channel and `R` the IEEE reason code. The code is context only: codes 1, 2, 6 and 7 occur in normal traffic.

9.7 Sentinel threat detection

Sentinel is the node's threat detection. It detects Wi-Fi attacks and the tools that run them: deauth, beacon, auth and association floods, SAE denial of service, karma and evil-twin access points, probe floods, and handshake or PMKID capture attempts. It also detects interference, disruption of the node's Meshtastic channel, attack devices such as a Pwnagotchi, and Meshtastic and MeshCore radios. It names the tool where a frame carries a recognizable template. Control it on the Sentinel tab. **Start Sentinel** in the top bar starts and stops it. Under **Listening** → **Radio**, pick **Defend this AP** or **Scan all channels**. **Start on boot** starts it after a reboot.

```
@ALL SENTINEL_ON
@ALL SENTINEL_MODE:scan
@ALL SENTINEL_BOOT:1
@ALL GROUP:dos:on
@AH01 SENTINEL_STATUS
@AH01 INCIDENTS:50
```

Command	What it does
`SENTINEL_ON`	Starts Sentinel. `SENTINEL_OFF` stops it.
`SENTINEL_MODE:scan`	`scan` hops the configured channels. `defend` stays on the node's own access point channel. Headless has no access point, so use `scan`.
`SENTINEL_BOOT:1`	1 starts Sentinel at power-on, 0 does not.
`GROUP:dos:on`	Turns a detector group on or off: `dos`, `rogue`, `recon`, `physical`, `mesh`, `devices` or `all`.
`SENTINEL_STATUS`	Reports `en=` (you enabled it) and `run=` (it is running now).
`INCIDENTS:50`	Prints the newest 50 incidents (1 to 200, default 20) as JSON on USB serial. The mesh reply is only the length. `INCIDENTS_CLEAR` deletes the log.

Deauth flood, beacon flood and auth flood detection are always on. Their `mesh_deauth`, `mesh_beacon` and `mesh_auth` switches only decide whether the alert goes out over the mesh. Sentinel listens to Wi-Fi, plus Bluetooth while LoRa mesh radio detection is on. `DETECT_CFG` changes individual detectors and thresholds with a JSON object of up to 230 characters, for example `DETECT_CFG:{"karma":true,"pmkid_window":5000}`. The Sentinel tab sets the same keys. Each key's meaning, range and default are in `docs/mesh-commands.md` in the repository.

> **KARMA BAIT**
>
> Karma bait is the only Sentinel detector that transmits Wi-Fi: a probe request every 8 seconds to bait a karma access point into answering. It is off by default. Turn it on with `GROUP:rogue:on` or the **Karma** switch on the Sentinel tab, and only where transmitting is lawful.

LoRa mesh radios

This detector finds Meshtastic and MeshCore radios by Bluetooth. It is off by default because it adds a Bluetooth scan. Turn it on with the **Meshtastic / MeshCore** switch on the **Devices Nearby** card or with `DETECT_CFG:{"meshradio":true}`. It also finds your own nodes' radios. Add their MACs to the allowlist.


Wi-Fi interference

Wi-Fi interference detection is on by default. It learns each channel's noise floor for 60 seconds, then alerts when the noise floor rises 8 dB. The interference baseline is off by default. It also alerts when a busy channel goes quiet in `defend` mode. Turn it on with the **Interference Baseline** switch or `DETECT_CFG:{"jam_baseline":true}`. Turn **Wi-Fi Interference** off and on after you move the node.

Acting on a confirmed attack

Sentinel tab → **Attack response** → **On confirmed attack** picks what runs when a detector confirms an attack that has a source MAC. The choices are **Triangulate attacker**, **Packet capture to SD**, **Device discovery**, **Probe requests** and **Drone RID**. Each has its own duration, from 10 to 3600 s. The default is 120 s for the capture and 60 s for the others. Checked actions run top to bottom, one at a time, as the radio frees up. If the radio never frees, the node drops the queue after 15 minutes. Over mesh, `ATTACKER_TRILAT:1` turns the triangulation response on and `ATTACKER_TRILAT:0` turns it off. It is off by default, and `ATTACKER_TRILAT_STATUS` reports it.

The same panel sets the auto-capture limits for the `auto_` files these actions write. The node deletes the oldest to stay inside the limits and never touches manual captures. §9.11 sets the maximum size of one capture.



The Sentinel tab: detector counters, associated clients, mesh command log and incident log.

Setting	What it does	Range, default
Auto-capture budget	Most space all `auto_` files may use together.	16 to 262144 MB, 512
Keep free	Free space the card must keep.	0 to 262144 MB, 256

Over mesh, `PCAP_AUTO:512,256` sets budget and keep-free in MB. `PCAP_AUTO` alone reads them.

> **A RESPONSE IS A SCAN**
>
> Detection pauses while each action runs, so keep the durations short on a site that trips often.

9.8 Drone RID Detection

Identifies drones that broadcast Remote ID over Wi-Fi beacons, Wi-Fi NAN and BLE. It reads the ODID / ASTM F3411 and French ID formats. It reports the serial or registration number, position, altitude, speed and, when sent, the operator's location. Pick **Drone RID Detection** in the scan list.

```
@ALL DRONE_START:300
```

The node sends `DRONE:` once per appearance. `DRONE_LOST:` follows 120 s after its last beacon.

9.9 Triangulation

Several nodes each report the signal strength of one target MAC, and the coordinating node fits a position. It needs at least three nodes with valid GPS fixes and matched antennas. In the web UI, check **Triangulate** in the Device Discovery card, enter the **Target MAC**, pick the **RF Environment**, set **Distance Tuning** and press **Start Scan**.

```
@AH01 TRIANGULATE_START:AA:BB:CC:DD:EE:FF:60:2:1.0:1.0
@AH01 TRIANGULATE_RESULTS
@ALL TRIANGULATE_STOP
```

Value	What it means
`AA:BB:CC:DD:EE:FF`	The target MAC, or an identity such as T−1A2B from the Randomized MAC Tracer.
`60`	Run time in seconds. The node raises values under 10 to 10 and caps them at 3600.
2	RF environment (path-loss model): 0 open sky, 1 suburban, 2 indoor (default), 3 indoor dense, 4 industrial. A wrong choice skews every distance.
`1.0`, `1.0`	Wi-Fi and BLE distance multipliers, 0.1 to 5.0 (default 1.0). Below 1.0 puts the estimate closer and above 1.0 farther. Use them to correct a known bias.

Send `TRIANGULATE_START` to one node. That node coordinates and tells the others. `TRIANGULATE_RESULTS` asks it for the result, and `TRIANGULATE_STOP` ends the run. Results arrive in three messages. `T_D:` is one node's data, `T_F:` is the final fix with confidence and uncertainty, and `T_C:` marks the run complete with a map link. `TRIANGULATE_RESULTS:NO_DATA` means no node has reported yet.

Calibrate each node for better distances. Place a Wi-Fi access point or BLE device a measured distance from the node, then send the command below to that node, or use System → **Settings** → **Scanning** → **Distance calibration**. The node listens for 30 seconds, replies `CALIBRATE_DONE`, and keeps the result after a reboot and an RF environment change. Send `CALIBRATE_RESET` when you move the node.

```
@AH01 CALIBRATE:AA:BB:CC:DD:EE:FF:5
@AH01 CALIBRATE_RESET
```

9.10 CSI Motion Detection (experimental, Beta and C5 firmware)

Alerts when someone moves nearby, even through walls. Use it indoors. It detects movement, not someone sitting still. Stable firmware does not include it. Wi-Fi signals bounce around a room and the bounces change when a person moves, so the node listens to nearby routers and phones and alerts when several of their signals change at once.

Start it from Scan tab → **CSI Motion Detection** → **Start Scan**. Over mesh:

```
@ALL CSI_MOTION_START:0:FOREVER
```

`0` is the run time in seconds and `FOREVER` runs until stopped. Optional fields go in any order. `CH6` pins channel 6, and `CH0` or no channel field picks the busiest. `GAP30` allows one mesh motion alert per 30 s. `LISTEN_ONLY` or `ALLOW_TRANSMIT` sets whether the node may transmit. `MGMTONLY` uses management frames only, and `MGMTDATA` uses management and data frames. The rest are in `docs/mesh-commands.md`.

Sensitivity: **Low** (default) gives the fewest false alarms and needs two devices to see the movement. **Medium** also accepts one device seeing a very strong change (4× the trigger). **High** is Medium with a lower trigger and a shorter wait, and gives more false alarms. The other settings are on the Scan tab under CSI Motion Detection, most under Advanced:

Setting	What it means	Default
Movement needed before alerting	How long someone must move before you get an alert	8 s
Stillness before all-clear	How long it must be quiet before the alert clears	5 s
Devices that must agree	How many devices must see the movement at the same time	2
Trigger level	Lower catches smaller movement	set by sensitivity
Listen only, never transmit	The node never sends probes. Turn off only if it sees too little Wi-Fi	On

Setting	What it means	Default
Include randomized-MAC devices	Also listen to phones and watches, not only routers	On
Min. seconds between mesh motion alerts	Minimum gap between motion alerts sent over mesh	0 (no limit)

False alarms in an empty room: turn on "Per-packet score to serial", note the highest `sig` score printed while the room is empty, and set Trigger level slightly above it. Over mesh, `CSI_CFG` tunes the same settings. `docs/mesh-commands.md` in the repository lists them.

> **CAN TRANSMIT**
>
> If you turn off "Listen only, never transmit", the node sends Wi-Fi probe requests when there is too little traffic to measure, and anyone nearby can see them. Check local rules first.

9.11 Packet Capture

Records raw traffic to SD as a standard pcap. Wi-Fi frames carry a radiotap header with channel, rate and RSSI. The node writes BLE captures as Bluetooth HCI, link type 187, so Wireshark shows LE Advertising Reports with address, address type, advertising data and RSSI, but no RF channel.

Scan tab: pick **Packet Capture**, set **Radio**, **Band** and **Duration (s)**, and press **Start Capture**. **Advanced** sets a channel list, **Dwell (ms)** per channel, **Max file size (MB)** and **Management frames only**. A blank channel list uses the Scanning settings. Dwell runs from 50 to 5000 ms, with 250 as the default. Files land in `/pcap` and list under **Captures**.

```
@ALL PCAP_START:0:300:0
@ALL PCAP_STOP
```

Value	What it means
`0` (radio)	0 Wi-Fi, 1 BLE. One radio per capture. The node treats any other value, including 2, as Wi-Fi. Here 2 does not mean both.
`300`	Run time in seconds. It is required and must be above 0. The node refuses `FOREVER` and 0 with `PCAP_ACK:FAILED`.
`0` (band)	0 is 2.4 GHz, 1 is 5 GHz, 2 is both. 5 GHz needs a C5 board.
`CH1,6,11`	Optional. Wi-Fi channels to visit.

The node answers `PCAP_ACK:STARTED`, `BUSY` when another scan holds the radio, `NOSD` when there is no SD card, or `FAILED`. It then sends `PCAP_START: WIFI D=300` or `PCAP_START: BLE D=300` to name the radio that started. A capture started by a vibration trigger or a Sentinel response is always Wi-Fi on 2.4 GHz.

A capture ends on its own when the file reaches the size cap or the card stops accepting writes. The summary `PCAP_DONE: F=frames B=bytes D=dropped` adds `R=SIZECAP` or `R=WRITEFAIL` for those two causes. The size cap is 8 to 300 MB, 100 by default. `@ALL PCAP_LIMITS:150` sets it to 150 MB, and `PCAP_LIMITS` alone reads it.

> **CAPTURES ARE LARGE AND CARRY EVERYTHING**
>
> A busy channel fills megabytes per minute. Check free space first, and treat the file as a raw intercept.

STOP THE CAPTURE BEFORE YOU CUT POWER

FAT has no power-fail protection. Resetting or unplugging a node while a capture is writing can leave the card unreadable until you reformat it. The node then runs with no storage, so it has no logging, no baseline and no captures. Stop the capture first.

A node can rebuild its own card. This is off by default because rebuilding erases everything on it. In the web UI, System tab → **Settings** → **Storage** has **Rebuild an unmountable card** and **Repair now**. Over mesh:

```
@ALL SD_REPAIR:ON
@ALL SD_REPAIR:NOW
@ALL SD_REPAIR:OFF
```

`ON` allows the rebuild, `OFF` forbids it. `NOW` tries to mount the card once, rebuilding it if every attempt fails, without changing the setting. With repair off, a failed mount says so once a minute and the SD line in System tab → **Diagnostics** counts the failures.

9.12 Scheduling scans

The Schedule panel on the Scan tab runs a scan at set times. The node runs it, so you can close the web page. Schedules need the clock from §4.3. On a node without a working RTC, blocks wait until you open the web UI once after boot, which gives the node the time.

1. Pick the scan and set its options.
2. Press **Schedule this scan**.
3. Choose **Run on** (*This node* or another node from the Fleet list), set **Start**, **Duration (min)** and **Repeat**, then press **Add**.

The block keeps the options you set when you added it. To change them, delete the block and add it again.

Setting	Values
Start	Date and time in the node's local time, shown with its zone, for example MST
Duration	1 to 1440 minutes
Repeat	Once, hourly, every 6 hours, every 12 hours, daily, weekly

- **Time zone.** The node picks its zone from the GPS fix, daylight saving included, so daily and weekly blocks keep the same clock time. With no GPS fix, or outside the zone table, times are UTC.
- **Busy radio.** A block that comes due while another scan holds the radio runs as soon as the radio frees, and a repeating block then moves to its next slot. If a mesh command takes the radio at the same moment, the block tries again 5 seconds later.
- **Vibration and attack scans.** By default they wait for a scheduled scan. The node skips a vibration auto-scan, and it runs an attack response when the scan ends. Turn on **Interrupt scheduled scans** under System tab → **Settings** → **Sensors & power**, or under Sentinel tab → **Attack response**. That trigger then stops the scheduled scan, runs, and resumes the scheduled scan for its remaining time. A resumed Baseline starts its learning phase again.
- **Battery Saver.** Schedules pause while Battery Saver is on. A block that came due runs once when it ends.
- **Limits.** 8 blocks and 3800 bytes in total. They survive reboots.
- **Baseline blocks.** Adding one saves the Scan tab's baseline settings to the node, and each run uses the settings saved at that time.

Over mesh. `SCHED_ADD:2026-09-30T02:00|86400|/sniffer|detection=device-scan&deviceScanMode=2&secs=600` adds a daily block. `SCHED_LIST` prints the blocks to serial. `SCHED_DEL:2` deletes the second block. A `|` separates the fields of `SCHED_ADD`:

Field	What it means
`2026-09-30T02:00`	First start, in the node's local time (UTC without a GPS zone).
`86400`	Seconds between runs. 0 runs once. Otherwise 600 to 2678400.
`/sniffer`	Which scan: `/scan` Target Scan, `/sniffer` the Scan tab's second card, `/drone` Drone RID Detection.
`detection=…`	The scan's options as `name=value` pairs joined by &: `detection` (`device-scan`, `probe-scan`, `randomization-detection`, `drone-detection`, `baseline`, `deauth`, `pcap`), `secs` (run time), a mode field (`mode` for `/scan`, otherwise `deviceScanMode`, `probeScanMode`, `droneScanMode` or `randomizationMode`) and `ch` (channels, `/scan` only).

9.13 Campaigns

A campaign is a name the node attaches to its SD logs between a start and a stop, so you can export one operation as a set. In the web UI, Data tab: type a **Campaign name**, press **Start**, and press **Stop** when done. Pick a campaign or a time range in the dataset filter and press **Export campaign**. The node records starts and stops in `/campaigns.csv`.

```
@AH01 CAMPAIGN_START:site-a
@AH01 CAMPAIGN_STATUS
@AH01 CAMPAIGN_STOP
```

`site-a` is the name: 1 to 23 letters, digits, - or _. Starting a new campaign stops the current one. `STATUS` and `SUMMARY` show the active name as `Camp:`.

9.14 Reading the results

Both builds log to the SD card. Appendix C lists the main files. Full also shows results as cards in the Results tab and the device database in the Data tab. Over mesh you receive every alert above plus end-of-scan summaries. `SCAN_DONE: W= B= U= H= TX= DUP=` reports Wi-Fi devices, BLE devices, unique MACs, hits, devices sent and devices skipped as repeats. `LIST_SCAN_DONE: Hits= Unique= Targets= TX= PEND=` is the Target Scan version. `PEND` counts targets not yet sent.

> **EXPORTS CARRY LOCATION**
>
> SD logs, exports and mesh alerts can all contain GPS coordinates. Review any file before you post it publicly or attach it to a report. Privacy Mode only redacts the live web UI.

10 Vibration sensor and tamper response

10.1 How it works

The SW-420 is a mechanical vibration switch with a comparator and a trimpot on board. Its output goes high when movement exceeds the threshold the trimpot sets. It connects to GPIO 2 on the ESP32-S3 (GPIO 0 on the C5).

When it fires, the firmware:

- Sends a mesh alert if vibration alerts are on: `NODE: VIBRATION: Movement detected at TIME [GPS:lat,lon]`
- Writes an event to `/vibrations.jsonl` on the SD card
- Optionally starts a scan (§10.3)
- Counts toward the tamper auto-erase trigger when you arm it (§10.4)

Alerts are on by default. The node sends at most one vibration alert every 3 seconds, and logs and scans at the same rate. The tamper count sees every movement. System tab → **Diagnostics** shows `Standby`, or `Active` with the time of the last movement.

Turn mesh alerts on and off with `@AH01 VIBRATION_ON` and `VIBRATION_OFF`, or with **Mesh alert** under System tab → **Settings** → **Sensors & power** → **Vibration sensor**. `VIBRATION_STATUS` reports whether alerts are on and the seconds since the last movement.

10.2 Tuning the trimpot

The trimpot is the small brass screw on the sensor module. It sets the sensitivity threshold. Tune it **after** the node is in its final position, not on the bench.

1. Power the node and watch the sensor's LED, or watch a serial monitor for `[VIBRATION]` lines.
2. Leave the node still. If it triggers by itself, turn the screw an eighth of a turn at a time in the direction that stops it. Wait several seconds between adjustments, because the module reacts slowly.
3. When it is silent at rest, back off slightly further.
4. Tap the enclosure the way a person handling it would. It should fire.
5. If it does not, turn back the other way a fraction at a time until a tap triggers it but the node at rest does not.
6. Confirm the events reached the firmware: the diagnostics timestamp updates and `/vibrations.jsonl` gains a line. It adds at most one line per 3 seconds.

> **TUNING BY SYMPTOM**
>
> - **Constant false alerts.** Too sensitive, or mounted on something resonant. Reduce sensitivity, and consider a foam pad or a stiffer mount.
> - **Nothing fires even when you shake it.** Too insensitive, or the sensor is not seeing its GPIO (2 on S3, 0 on C5). Check the diagnostics line and the solder joints on the sensor header.
> - **Fires only sometimes.** You are on the edge of the threshold. Turn it a fraction toward sensitive.

10.3 Vibration auto-scan

Movement can start a scan. In the web UI, use System tab → **Settings** → **Sensors & power** → **Vibration sensor**: check **Scan on vibration**, pick **Scan to run**, set **Duration** and **Cooldown**, and press **Save**. Over mesh:

```
@AH01 VIBSCAN_SET:1:2:60:60:1
@AH01 VIBSCAN_STATUS
```

Value	What it means
1 (enable)	1 turns the trigger on, 0 turns it off.
2 (scan)	The scan to start. See the table below.
60 (secs)	Scan length in seconds, 0 to 65535. 0 runs until stopped, except scan 8, which needs a length above 0.
60 (cooldown)	Optional. Seconds before the sensor can start another scan, 5 to 86400. Without it the stored value stays.
1 (interrupt)	Optional. 1 lets the trigger stop a running scheduled scan, which resumes afterwards. 0 waits for it (§9.12).

Scan	Started	Scan	Started
0	None	5	Drone / Remote ID

Scan	Started	Scan	Started
1	All-device scan	6	Deauth (blue team)
2	Probe-request detect	7	Baseline anomaly
3	Randomized-MAC detect	8	Packet capture
4	List scan (targets), channels 1 to 11		

`VIBSCAN_STATUS` reports the current values. The node skips the trigger when a scan is already running or Battery Saver is on. Scan 8 writes an `auto_` capture, which falls under the auto-capture budget (§9.7).

10.4 Tamper auto-erase

The node erases its settings and SD files when someone moves it. It is **off by default.** A wipe cannot be undone and needs an SD card in the node. In the web UI, use System tab → **Settings** → **Danger zone** → **Auto-erase on tampering**: check **Auto-erase**, set the five values and press **Save**.

Setting	What it does	Default	Web UI	Mesh
Setup delay (**Setup period**)	Time after you enable auto-erase before it arms. Place the node and leave	2 min	30 s to 10 min	30 to 600 s
Vibrations required	Movement events that start the countdown	3	2 to 5	2 to 5
Detection window	Time in which those events must happen	20 s	5 s to 1 min	10 to 60 s
Erase delay (**Erase countdown**)	Countdown from tamper to wipe. You can cancel in this time	30 s	10 s to 5 min	10 to 300 s
Cooldown (**Trigger cooldown**)	Shortest time between two countdowns	5 min	1 min to 1 h	300 to 3600 s

Over mesh, send all five values or none to keep the current ones. The node clamps values outside the range. The last field is the answer code that proves you know the erase key (see Remote erase).

```
@AH01 AUTOERASE_ENABLE:60:30:3:30:300:<answer>
@AH01 AUTOERASE_ENABLE:<answer>
@AH01 AUTOERASE_STATUS
@AH01 AUTOERASE_DISABLE:<answer>
```

The first line sets setup delay 60 s, erase delay 30 s, 3 vibrations, a 30 s window and a 300 s cooldown. The second enables auto-erase with the stored values. Enabling restarts the setup delay. `DENIED` means the answer was wrong. `AUTOERASE_STATUS` reports whether auto-erase is on, whether the setup delay is running, whether a countdown is active and the five values.

When a tamper starts the countdown the node sends `TAMPER_DETECTED: Auto-erase in Xs`. To cancel in the web UI, press **Abort tamper countdown**. Over mesh, send `ERASE_REQUEST` after that alert, then `ERASE_CANCEL:<answer>` before the countdown ends.

Remote erase

A wipe cannot be undone, so the node wipes only if you prove you know its erase key (§8.1). The key does not travel over the radio. The node gives you a one-time **token** (a random challenge). You turn the token and your key into a short **answer** code and send the answer back. The token lasts 5 minutes and works once.

1. Ask for a token: `@AH01 ERASE_REQUEST`. The node replies `AH01: ERASE_TOKEN:AH_3F2A91C0_77B0E412_000004D2 Expires:300s`.
2. Work out the answer: open **Erase Answer** on the web flasher page (lukeswitz.github.io/AntiHunter), paste the token and your key, and press **Get answer**. The page works it out in your browser and sends nothing. From a

terminal: `printf %s 'AH_3F2A91C0_77B0E412_000004D2' | openssl dgst -sha256 -hmac 'yourKey' | awk '{print $NF}' | cut -c1-8`.

3. Within 5 minutes, send the command with the answer: `@AH01 ERASE_FORCE:<answer>`.

- The answer is 8 hex characters (the full 64 also work), upper or lower case.
- One attempt uses up the token, right or wrong. A new `ERASE_REQUEST` or a tamper trigger replaces it. You can request one token per 20 s.
- `ERASE_FORCE` wipes and keeps the node running. `ERASE_ACK:DENIED` means a wrong key or an expired or used token. `FAILED` means no SD card. `SET_KEY_FIRST` means the node has no key.
- 5 wrong answers, or 5 wrong keys on the web, lock erase commands for 10 min. Logs show keys and answers as ***.

In the web UI, enter the key in System tab → **Settings** → **Danger zone** → **Erase key** and press **Wipe now**. After a wipe the node writes one decoy file, `/weather-air-feed.txt`, holding a weather-monitor error message.

> **CHANGING THE KEY OVER MESH SENDS IT IN THE CLEAR**
>
> `@AH01 CONFIG_ERASE_PSK:<new>:<current>` puts both keys in a radio message anyone on the channel can read. Send it only on your own encrypted channel, or use USB serial or the web UI. A key you set is 8 to 64 characters without `:`.

Factory reset

```
@AH01 FACTORY_RESET:FULL:<answer>
```

The first value is the scope: `FULL` erases settings and SD files, `CONFIG` erases settings only, `DATA` erases SD files only. The last value is the answer code. The node restarts. `DENIED` means a wrong answer, and `DENIED_NO_PSK` means the node has no erase key. Send it to one node at a time, because each node issues its own token. In the web UI, use **Factory reset** in the Danger zone and pick **What to reset**.

> **DATA DESTRUCTION IS IRREVERSIBLE**
>
> Test your settings with a node that holds nothing you care about.

11 Mesh command reference

Send commands as text messages from the Meshtastic app, a Command Center or any client on your channel, or type them on the USB serial port. Start each with `@ALL` (every node) or `@` and a node ID (one node). Every reply starts with the node ID, for example `AH01: SCAN_ACK:STARTED`.

Mode, run time and channels work as in §9.1, and `answer` works as in §10.4. The run time `secs` runs from 0 to 86400, and 0 or `:FOREVER` runs until `STOP`. A `BUSY` reply means another scan holds the radio. Send `STOP` first. Each command has a short form, shown in brackets below, that saves airtime: `@ALL SS:2:300:1..11` is the same as `@ALL SCAN_START:2:300:1..11`.

Commands without their own section


Command	What it does
`STATUS` [ST]	Reports mode, scan state, target hits, temperature and uptime. Adds GPS position and HDOP when there is a fix. HDOP is GPS accuracy, and lower is better.
`STOP` [X]	Stops every scan and pending attack response, and clears queued mesh output.

Command	What it does
`MESH_TX_CANCEL` [MTC]	Drops queued mesh messages and keeps the scan running.
`DEVICE_DB_CLEAR` [DBX]	Clears the device database. Headless only.
`BATTERY_SAVER_START:10` [BSS]	Starts Battery Saver (§8.4) with a heartbeat every 10 minutes (1 to 30, default 5). `BATTERY_SAVER_STOP` [BSX] ends it.
`HB_ON` [HB1], `HB_OFF` [HB0], `HB_INTERVAL:10` [HBI]	Turns the status heartbeat on or off (off by default) or sets its interval in minutes, 1 to 60.

The full list, with every argument, reply and alias, is in `docs/mesh-commands.md` in the repository. The ten commands to learn first are on the card in Appendix E.

12 Command Center

One node needs no server. For a fleet, AntiHunter Command & Control PRO collects every node's detections on a live map, with TAK, MQTT and ADS-B integration and a Sentinel console.



Nodes work independently and coordinate over the mesh. The Command Center aggregates.

12.1 What you need

- A computer running Linux, macOS or Windows 10/11.
- A Meshtastic radio on USB, joined to **your** channel.
- Node.js 20 or newer and PostgreSQL. The installer provides both.

12.2 Quick install: Linux and macOS

```
curl -o setup-local.sh \
  https://raw.githubusercontent.com/TheRealSirHaXalot/AntiHunter-Command-Control-
PRO/main/scripts/setup-local.sh
chmod +x setup-local.sh
./setup-local.sh
```

Run it as a normal user, **not** with sudo. It asks for sudo when needed. It installs the prerequisites, clones the project, sets up the database and creates an admin login. Open **http://localhost:5173** and log in with the credentials it printed.

12.3 Quick install: Windows 10/11

1. Install Git in any PowerShell window, then close it so Git lands on your PATH:

   ```
   winget install -e --id Git.Git --accept-package-agreements --accept-source-agreements
   ```

2. Open PowerShell **as Administrator**.
3. Clone and run the installer:

   ```
   cd $HOME
   git clone https://github.com/TheRealSirHaXalot/AntiHunter-Command-Control-PRO.git
   cd AntiHunter-Command-Control-PRO
   powershell -ExecutionPolicy Bypass -File scripts\setup-windows.ps1
   ```

4. Press Enter to accept the defaults. **Write down the admin email and password it shows you.**
5. Start it with **Start-AntiHunter.cmd** in the project folder, or `pnpm AHCC`, and open **http://localhost:5173**.

> **WINDOWS NOTES**
>
> - At the firewall prompt on first start, click **Cancel** if you only use it on this PC. To reach it from other devices, click Allow and check **Private** only.
> - For serial hardware, put `SERIAL_DEVICE=COM3` (your port from Device Manager → Ports) in `apps\backend\.env` and restart.
> - Do not use WSL. COM ports do not pass through cleanly.

12.4 Docker

Needs Docker 25 or newer. If you have no serial adapter at `/dev/ttyUSB0` (every macOS and Windows host), first comment out the `devices:` and `group_add:` lines under the `backend` service, or the container will not start.

```
git clone https://github.com/TheRealSirHaXalot/AntiHunter-Command-Control-PRO.git
cd AntiHunter-Command-Control-PRO
docker compose up -d --build
```

This starts Postgres, the backend on port 3000, and the frontend on **http://localhost:8080**. The seeded admin is `admin@example.com` with password `admin`. `docker compose down` stops it. Add `--volumes` to delete the database too.

> **CHANGE THE ADMIN PASSWORD IMMEDIATELY**
>
> The seeded credentials are public. Change them at first login. Enable two-factor authentication and HTTPS if anyone will reach the instance across a network, and follow the hardening checklist in the project README.

12.5 Updating

Use the in-app update page, or run `git pull` in the project folder. With Docker, run `git pull && docker compose up -d --build`.

12.6 Reaching it from anywhere, and alerts to your phone

The Command Center's Remote Connections guide covers each option:

- Phone access away from site: Tailscale (a private VPN between your own devices).
- Access for others without an app: Cloudflare Tunnel with an email login.
- Alerts: push, Signal, ntfy, Matrix, Discord, IFTTT, Home Assistant or email.
- Nodes and targets in ATAK, iTAK or WinTAK: the TAK bridge.
- Detections to scripts, or linking two sites: an MQTTS broker and federation.

Never forward the Command Center's ports on your router.

13 Deployment

13.1 Siting

- **Mount it high**, above metal, vehicles and crowds.
- **Keep antennas vertical**, clear of the enclosure's metalwork, and keep the LoRa and Wi-Fi antennas as far apart as the enclosure allows.
- **GPS needs sky.** Indoors it may never lock. Without a fix your detections carry no coordinates and triangulation cannot run.
- For triangulation, spread nodes around the area rather than in a line, each with a clear GPS fix and matched antennas.




Mast, tripod, can and puck builds.

13.2 Sealing and mounting

- Fit the TPU seals for the housing, GPS and USB-C port.
- The printed enclosure has no IP rating. Treat it as weather-resistant, not waterproof.
- The base takes a ¼"-20 insert for tripods and the universal bracket. STL files for brackets and solar mounts are in the `hw/` folder.
- Point the vented lid and fan opening downward or shielded so water does not sit in them.



An enclosed build, antennas vertical.



Vented lid, SMA bulkheads on top, battery housing below.

13.3 Power planning

- Aggressive presets and continuous capture sit at the top of the 160 to 600 mA range (§1.3).
- Feed solar through the UPS board, never directly to the PCB. Solar mount frames are in the STL folder.
- Never use the chassis USB input and the UPS fast-charge input at the same time.

13.4 Playbooks

Set-and-forget setups. Set schedule blocks as in §9.12. The repeat of `86400` seconds below means daily.

Overnight perimeter watch (home, shop, site)

Learn what belongs, then flag anything new after dark. Sentinel covers Wi-Fi attacks, interference, and attack devices.

```
@AH01 SCHED_ADD:2026-10-05T21:00|86400|/sniffer|detection=baseline&secs=32400   # 21:00 daily,
monitor 9 h after learning
@AH01 SENTINEL_BOOT:1                    # 1 = start Sentinel at power-on
@AH01 VIBRATION_ON                       # send vibration alerts over mesh
```

Someone casing the place

To catch the same phone or car on different days, run a device scan while they are around, put the MACs you care about on the watchlist, then hunt them on a schedule.

```
@AH01 DEVICE_SCAN_START:2:600                                        # Wi-Fi and BLE, 600 s
@ALL CONFIG_TARGETS:AA:BB:CC:DD:EE:FF|11:22:33                        # replace the watchlist
@ALL SCAN_START:2:0:1..11:FOREVER                                    # channels 1-11 until STOP, or
schedule it:
@AH01 SCHED_ADD:2026-10-05T08:00|86400|/scan|mode=2&secs=36000&ch=1..11   # 08:00 daily, 10 h
```

A hit sends `Target: MAC RSSI Type Name GPS V=vendor` at once. The web UI shows Getting closer or Moving away as it moves.

While you are away

Start a baseline when you arrive. When you leave, press **Compare from now** or send `@AH01 BASELINE_WATCH`. When you return, the results list what is new, what is gone, and what moved closer.

Drones over the property

```
@AH01 SCHED_ADD:2026-10-05T06:00|86400|/drone|droneScanMode=2&secs=57600   # 06:00 daily, 16 h
```

The node reports each aircraft broadcasting Remote ID once, with its ID, position, and operator location when sent.

Your Wi-Fi is being attacked

Most Wi-Fi attacks start by knocking clients off with deauthentication frames. The Deauth scan catches that on every build. Run it around the clock.

```
@AH01 DEAUTH_START:0:FOREVER                # run until STOP
@AH01 SCHED_ADD:2026-10-05T00:00|86400|/sniffer|detection=deauth&secs=86400   # or a daily 24 h
block
@AH01 SENTINEL_ON                          # also evil twins, karma, PMKID, floods
```

Unattended in a vehicle or camp

```
@AH01 VIBSCAN_SET:1:1:300:600              # on, device scan, 300 s, 600 s cooldown
@AH01 BATTERY_SAVER_START:10                # heartbeat every 10 min
```

Several sites, one screen

Run the Command Center (§12) on a machine at one site with a Meshtastic radio on USB. Reach it from your phone over Tailscale and route alerts to Signal or push (§12.6).

13.5 Before you walk away

Work through the setup order in Appendix E. Then record the erase key somewhere safe, check the auto-erase values if you armed it, confirm the node answers `@NODEID STATUS` over the mesh from where you will stand, and check that the antennas are tight, the seals seated and the lid closed.

14 Maintenance and troubleshooting

14.1 Symptom table

Symptom	Likely cause	What to do
No `Antihunter` Wi-Fi network	Headless firmware, or the AP name was changed	Check over serial which build is running. Reflash Full if you need the UI.
Web UI will not load	Not connected to the node's AP, or using https	Join the node's AP and open **http://192.168.4.1**.
Flashing fails or the port never appears	Charge-only cable, a serial monitor holding the port, both USB ports connected, or the wrong browser	Use a data cable, close other serial tools, unplug the radio, use Chrome or Edge.
SD card not detected	Not FAT32, 32 GB or larger, or not seated	Reformat FAT32 on a card under 32 GB. Reseating means opening the enclosure.
No GPS fix	Antenna not connected, or no view of the sky	Check the connection, move outdoors, give it time. The module runs hot while searching.
Nothing arrives over the mesh	Region `UNSET`, serial module off, wrong pins, or nodes on different channels or keys	Re-run `meshtastic_config.py` and print the settings. Confirm every node carries the same channel.
Node hears commands but never answers	Region unset on *that* node	Set its region.

Symptom	Likely cause	What to do
Constant vibration alerts	Trimpot too sensitive, or a resonant mount	Retune in place (§10.2). Add a foam pad or a stiffer mount.
Vibration never fires	Trimpot too insensitive, or a bad joint on the sensor header	Retune, check the diagnostics line and the solder joints on the sensor header.

14.2 Routine maintenance

- Archive the SD card logs periodically, then clear them, so a lost node carries less.
- Retire a swollen or damaged 18650 immediately and never recharge it.
- Re-check antenna tightness and seals after any period in the field.

14.3 Getting help

Open an issue or discussion at **github.com/lukeswitz/AntiHunter**. Include the firmware build and channel, Full or Headless, board type, what you did, what you expected, what happened, and the serial output around the failure. Scrub coordinates and MAC addresses from anything you paste.

15 Legal and safety

15.1 Authorization

AntiHunter is distributed for lawful, authorized defensive use only: security research, blue-team training, compliant monitoring, event security and network auditing. Operate it only on networks, devices, spectrum and datasets you own or have explicit written permission to assess. Its detection, correlation and triangulation features exist to characterize an environment you are authorized to assess, not to identify, follow or profile people. Targeted surveillance, stalking, harassment and tracking individuals without informed consent are prohibited.

15.2 Radio compliance

You are responsible for every rule governing radio use where you operate: FCC Part 15 and Part 97, CE/RED, Ofcom and their national equivalents, ISM band allocations, power limits, duty cycles and licensing conditions. LoRa is region-locked (868 MHz EU, 915 MHz US, 923 MHz Asia), and running a region outside the one you are in may be unlawful. Never use the node to cause harmful interference.

15.3 Interception and privacy

Most jurisdictions regulate passive reception of radio emissions separately from network access. Capturing, storing, decoding or disclosing frame contents and identifiers may engage the US Wiretap Act and ECPA, state two-party-consent statutes, the UK Investigatory Powers Act or equivalents. Check each capture mode is lawful where you are before you enable it.

MAC addresses, probe request contents, BLE advertisements and Remote ID broadcasts may be personal data under GDPR, UK GDPR, CCPA/CPRA and similar laws. Collect only with a lawful basis, keep as little as you can, set a retention and destruction schedule, and honor data-subject rights. The maintainers never receive, process or host your data.

15.4 Drone Remote ID

Receiving broadcast Remote ID is permitted in most places. Using that data to locate, approach, confront or interfere with an aircraft or its operator may violate aviation, harassment or anti-stalking law, including 18 U.S.C. § 32.

15.5 Hardware and battery safety

Kits, bare boards and assembled units are supplied for people competent in electronics assembly. Correct assembly, ESD control, antenna selection and attachment, and a regulated 5 V supply are your responsibility. Operating the transceiver without a matched antenna can damage the hardware. Lithium cells are never supplied. Sourcing, protection, charging, storage, transport and disposal are yours and carry fire and injury risk. The hardware is not certified for life-safety, medical, aviation, automotive or industrial-control applications. It does not replace a certified security or alarm system, and its output is advisory, with false positives and false negatives.

15.6 Experimental features

Modes marked beta or experimental, and Sentinel, Triangulation and MAC Randomization Correlation, are unvalidated and may produce inaccurate output. Do not rely on them for operational, evidentiary, investigative or safety decisions.

DISCLAIMER

THE PROJECT, INCLUDING SOFTWARE, FIRMWARE, HARDWARE DESIGNS AND DOCUMENTATION, IS PROVIDED "AS IS" AND "AS AVAILABLE", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, NON-INFRINGEMENT, ACCURACY, DETECTION EFFICACY OR UNINTERRUPTED OPERATION. This supplements and does not limit the warranty disclaimer and liability limitation in sections 15 to 17 of the GNU Affero General Public License v3.0.

TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE AUTHORS, DEVELOPERS, MAINTAINERS AND CONTRIBUTORS SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, PUNITIVE OR CONSEQUENTIAL DAMAGES, including loss of data, profits, goodwill, equipment or business interruption, or damages arising from failure to detect, false detection, or regulatory enforcement action, ARISING FROM OR RELATED TO YOUR USE OF THE PROJECT, EVEN IF ADVISED OF THE POSSIBILITY. Where liability cannot be fully disclaimed, total aggregate liability shall not exceed the greater of the amount paid for the unit giving rise to the claim, or USD $0.

Assembly, sale or instruction by the maintainers creates no warranty, no certification, no fitness-for-purpose representation and no responsibility for how a unit is later configured, deployed or used. Once the unit is in your hands, operation and compliance are yours alone. Flashing the firmware, by web flasher, shell script or any other means, is acceptance of these terms.

Nothing here excludes liability that cannot lawfully be excluded, including for death or personal injury caused by negligence, for fraud, or non-excludable statutory consumer rights. Some jurisdictions do not allow the exclusion of implied warranties or the limitation of incidental or consequential damages, so parts of the above may not apply to you.

You alone are responsible for ensuring your build, deployment and operation comply with all applicable laws, regulations, licenses, permits, equipment authorizations, organizational policies and third-party rights. **If you do not agree to these terms, do not build, flash, assemble, deploy or operate AntiHunter.**

Full text: `Legal Disclaimer` in the project README. Firmware is licensed under the GNU AGPL v3.0. Hardware and documentation are licensed as stated in their own files.

Appendix A · Pinout

XIAO ESP32-S3 on the DIGI NODE board. Pin assignments may change with board revisions. Verify against your revision.

Function	GPIO	Notes
Vibration sensor	2	SW-420 tamper detection, rising-edge interrupt, input pull-down
RTC SDA	3	DS3231 I²C data
RTC SCL	6	DS3231 I²C clock

Function	GPIO	Notes
GPS RX	44	NMEA in
GPS TX	43	Unused
SD CS	1	Chip select
SD SCK	7	SPI clock
SD MISO	8	SPI MISO
SD MOSI	9	SPI MOSI
Mesh RX	4	From the Meshtastic radio
Mesh TX	5	To the Meshtastic radio

Appendix B · Bill of materials

Core and power

- 1× AntiHunter DIGI PCB, 82 mm, 2-layer
- 1× Seeed XIAO ESP32-S3, 8 MB flash minimum, or XIAO ESP32-C5 for 2.4 and 5 GHz
- 1× Heltec Wi-Fi LoRa 32 V3.2 (T114 also works)
- 1× ATGM336H GPS module, 1× DS3231 RTC module, 1× SW-420 vibration sensor, 1× micro SD reader module
- 1× FAT32 SD card, 8 GB supplied on every tier but the Bare PCB
- 1× 30 mm 5 V fan with JST lead, and 1× KSD9700 normally-open thermal switch, 40 °C
- 1× 3-pin mini on/off switch
- 1× waterproof Type-C female chassis jack, 2-pin 22 AWG leads, 14 mm panel nut, dust cap
- 1× Type-C 15 W 3 A 5 V UPS board, dual 18650
- 2× 18650 cells, protected flat-top, never supplied with any tier; 1× 2 A fast-blow fuse, optional, not supplied

Antennas, connectors and enclosure

- 3× U.FL to SMA pigtail, 10 to 20 cm, and SMA bulkheads
- 1× 6 dBi 2.4 GHz antenna, and 1× 6 dBi LoRa antenna for your region
- 1× GPS antenna: passive ceramic patch on the kit and populated PCB, active helix on the assembled unit
- 5× JST 2.54 2-pin terminals, 2× JST power male cables, M3 and M2 heat-set inserts, 2× 15 mm brass standoffs, M3 and M2 screws, 1× ¼"-20 tripod insert
- 3D-printed weatherproof enclosure. STLs, seals, brackets and solar mounts are in `hw/Prototype_STL_Files/`

Part links: `hw/Prototype_STL_Files/BOM-Links.md`

Appendix C · Defaults, addresses and files

Item	Default	
Wi-Fi AP name and password	`Antihunter`, `antihunt3r123`	**change both** (§8.1)
Wi-Fi AP hidden	off, the network name is broadcast	optional, see §8.1 before turning it on
Web UI	`http://192.168.4.1`	Full firmware only
Web login	required, user `admin`	password is the Wi-Fi password until you set one

Item	Default	
Erase key	made by the node on first start, shown at flash	**write it down**
Meshtastic serial	TEXTMSG, 115200	pre-configured on tiers 1 and 3, you set it on 2 and 4
LoRa region	UNSET, receive only	**set it**
Meshtastic channel	public default	**replace with your own encrypted channel**
Scan preset	Balanced	
Wi-Fi channels	1 to 11	
Repeat filter (mesh dedup)	300 s	0 turns it off
Vibration alerts	on	at most one per 3 s
Vibrations required for tamper	3	range 2 to 5
Heartbeat	off	
Auto-erase, karma bait, attacker auto-triangulation	off	§10.4, §9.7
Command Center frontend	`http://localhost:5173`, Docker 8080	
Command Center admin	`admin@example.com`, `admin` (Docker seed)	**change at first login**

Files on the SD card

Path	Contents
`/last_results.txt`	Most recent scan results as text
`/devicedb.jsonl`	Device database
`/campaigns.csv`	Start and stop times of each campaign (§9.13)
`/vibrations.jsonl`	Vibration events
`/pcap/wifi_*.pcap`, `/pcap/ble_*.pcap`	Captures you started by hand. Never pruned automatically
`/pcap/wifi_auto_*.pcap`, `/pcap/ble_auto_*.pcap`	Captures started by a vibration trigger or a Sentinel response. Deleted as needed to stay inside the budget and free-space floor

Appendix D · Glossary

BSSID	The MAC address of an access point.
Evil twin	A rogue AP impersonating a legitimate network to capture clients.
Karma	An AP that answers every probe request, claiming to be whatever a client asks for.
PMKID	A value in the first EAPOL message that can be captured and cracked offline without a full handshake.
Remote ID	The broadcast identification a drone emits under ASTM F3411 and equivalent rules.
RSSI	Received signal strength, in dBm. Less negative is stronger.

Appendix E · Quick reference

Print this page and keep it with the node.

Never

- Power from anything but a regulated 5 V source
- Power the radio with no LoRa antenna fitted
- Connect both USB ports at once
- Press a U.FL connector at an angle
- Leave the default AP password or the public mesh channel in place

Addresses

Web UI	`http://192.168.4.1`, AP `Antihunter`
Web flasher	`lukeswitz.github.io/AntiHunter`
Firmware, docs, issues	`github.com/lukeswitz/AntiHunter`
Command Center	`github.com/TheRealSirHaXalot/AntiHunter-Command-Control-PRO`
Meshtastic flasher	`flasher.meshtastic.org`

Ten commands

```
@ALL STATUS                          who is alive
@ALL STOP                            stop everything
@AH01 CONFIG_NODEID:GATE1            name a node
@ALL CONFIG_TARGETS:AA:BB:CC|MyWiFi  set the watchlist
@ALL SCAN_START:2:600:1..11          watchlist scan, 10 min
@ALL DEVICE_SCAN_START:2:300         survey everything
@ALL BASELINE_START:900              learn, then monitor 900 s
@ALL SENTINEL_ON                     attacker-tool detection
@ALL DRONE_START:0                   drone watch until stopped
@AH01 BATTERY_SAVER_START:10         idle, mesh stays up
```

Setup order for a new node

1. Fit the antennas
2. Flash AntiHunter, Full to start with
3. Change the AP credentials
4. Set the radio region
5. Create your encrypted channel and disable the public one
6. Set the node ID and the clock
7. Confirm the SD card and GPS
8. Tune the vibration trimpot in place
9. Verify `@NODEID STATUS` answers over the mesh
10. Seal and deploy