

Theme Selector UX

Theme Selector UX

Theme Selector UX

Note: Knob button behavior uses `on_multi_click` exclusively (no `on_press`). Short press (<600ms + release) = page-specific action. Long press (>1.5s) = theme selector. Long press does NOT trigger short-press action.

1. Accessing the Selector

The Theme Selector is a hidden, device-level menu. It should not interfere with daily lighting control.

- **Action:** Long-press the rotary knob (hold for > 1.5 seconds). - **Feedback:** The screen transitions to the Theme Selector page, and the LED ring pulses briefly to confirm entry.

2. Navigating Themes

Once inside the Theme Selector: - **Action:** Rotate the knob clockwise (CW) or counter-clockwise (CCW). - **Feedback:** The screen scrolls through the 20 available themes. The display updates immediately to show a preview of the highlighted theme.

3. The Selector Interface

The Theme Selector page will display: - **Header:** "THEME SELECTOR" (small, top center) - **Index:** "1 / 20" (medium, indicating position) - **Theme Name:** e.g., "Minimal Thermostat" (large, center) - **Instruction:** "Press to apply" (small, bottom center)

4. Applying a Theme

- **Action:** Short-press the rotary knob while a theme is highlighted.
- **Feedback:**
 - The `active_theme` global is updated.
 - The `render_active_theme` script executes, applying the new visual style.

- The screen transitions back to the Power page (Page 0).
- The selection is saved to flash memory.

5. Exiting Without Changes

- **Action:** Swipe down, or wait for the 60-second idle timeout.
- **Feedback:** The screen returns to the Power page without changing the `active_theme`.

6. Home Assistant Integration

The active theme will be exposed to Home Assistant as a diagnostic text sensor (if supported by the ESPHome configuration) or simply managed locally. The primary control target remains

`light.bedroom_group` regardless of the active theme.