

DD-WRT

Buffalo WHR-AMPG
(4MB flash, 16mb memory)

Buffalo WHR-AMPG

(2007年: 8000~10000JPY)



BUFFALO WHR-AMPG Wireless Access Point AirStation

TOP WAN/LAN 無線設定 セキュリティ ゲーム&アプリ 管理設定 ステータス

かんたん設定&基本情報 ログアウト

かんたん設定

基本設定

- インターネット接続を行う
- 無線の基本設定をする
- 無線の暗号化を設定する

インターネット

- インターネット対応ゲームを使う
- Windows Live (MSN) メッセンジャーを使う
- ブロードバンド放送を使う

その他

- ファームウェアを更新する
- 設定を初期化する

動作モード情報

ルータモード

動作モード切り替え

WAN情報 (DHCP自動取得)

接続状態 通信中

解放 書き換え

接続確認 現在の状態を表示する

無線情報

IEEE 802.11a (40ch)

SSID	tomato50
認証方式	認証を行わない
暗号化	暗号化を行わない

IEEE 802.11g (13ch)

SSID	tomato24
認証方式	認証を行わない
暗号化	暗号化を行わない

無線設定画面へ WPS設定画面へ

かんたん設定&基本情報

左側がかんたん設定。
右側がエアステーションの基本情報となります。

基本設定

インターネット接続を行う

WAN側の回線種別を探索し、インターネット接続が完了するまでの設定をします。
[プロバイダ](#)から入手したパスワード等の資料がある場合は用意してください。

無線の基本設定をする

無線LANのSSIDとチャンネルの設定を行います。

無線の暗号化を設定をする

無線LANの暗号化(WEP/[TKIP](#)/[AES](#))の設定を行います。

インターネット

固件下载

<https://dd-wrt.com/support/router-database/>

dd-wrt.com

HOME | DOWNLOADS | SHOP | ACTIVATION CENTER

Professional

Router Database

Documentation

Support

FAQ

Other Downloads

Community

Contact

Router Database

Search terms (You can search by manufacturer, model, etc.)

☐ Show only devices available preflashed

14 routers found

Manufacturer	Model	Revision	Supported	Activation required
Buffalo	WHR-1166D (AC1200)	v1	yes	no
Buffalo	WHR-300HP2(D)	v1	yes	no
Buffalo	WHR-600D	v1	yes	no
Buffalo	WHR-AMG54	-	yes	no
Buffalo	WHR-G125	-	yes	no
Buffalo	WHR-G300N	v1	yes	no
Buffalo	WHR-G300N	v2	yes	no
Buffalo	WHR-G54S	-	yes	no
Buffalo	WHR-HP-AG108	-	yes	no
Buffalo	WHR-HP-G300N	-	yes	no
Buffalo	WHR-HP-G54	-	yes	no
Buffalo	WHR-HP-G54-DD	-	yes	no
Buffalo	WHR-HP-GN	-	yes	no
Buffalo	WHR3-AG54	-	yes	no

Latest DD-WRT Releases

To obtain the matching version for your router please use the Router Database:

[» Router Database](#)

Imprint | Privacy Policy

Copyright © 2026 embeDD GmbH

固件: dd-wrt.v24_micro_generic.bin

The screenshot shows the dd-wrt.com website interface. At the top, there's a navigation bar with links: HOME | DOWNLOADS | SHOP | ACTIVATION CENTER. Below this is a search bar and a menu with tabs: Professional, Support, Community, and Contact. Under the Professional tab, there are sub-tabs: Router Database (highlighted), Documentation, FAQ, and Other Downloads.

The main content area is titled "Router Database". It features a search bar with the text "whr" and a checkbox for "Show only devices available preflashed". Below the search bar, it says "(Click into the search field to return to the list)". The search results show "Buffalo WHR-AMG54 _".

Under "Router details", the following specifications are listed:

- Chipset: Broadcom5352
- RAM: 16 MB
- FLASH: 4 MB

Below the specifications, there's a "Supported by" section with a dropdown menu showing "v3.0 [Beta] Build 44715".

The "Additional information" section contains a table of firmware releases:

Description	Filename	Date	Size
DD-WRT Broadcom Generic - K2.4 - Micro + OLSRD	dd-wrt.v24_micro_olsrd_generic.bin		
DD-WRT Broadcom Generic - K2.4 - Micro	dd-wrt.v24_micro_generic.bin		
DD-WRT Broadcom Generic - K2.4 - Mini	dd-wrt.v24_mini_generic.bin		
DD-WRT Broadcom Generic - K2.4 - Mini	dd-wrt.v24_nokaid_generic.bin		
DD-WRT Broadcom Generic - K2.4 - Mini	dd-wrt.v24_std_generic.bin		
DD-WRT Broadcom Generic - K2.4 - Mini	dd-wrt.v24_voip_generic.bin		
DD-WRT Broadcom Generic - K2.4 - Mini	dd-wrt.v24_vpn_generic.bin		

On the right side of the page, there's a section titled "Latest DD-WRT Releases" with the text: "To obtain the matching version for your router please use the Router Database:". Below this text is a button labeled "» Router Database".

At the bottom of the page, there's a footer with links: Imprint | Privacy Policy and a copyright notice: Copyright © 2026 embeDD GmbH.

tftp上传固件

(路由器恢复出厂设置) IP固定：192.168.11.2

命令提示符

```
C:\Users\Admin>ping 192.168.11.1
```

```
正在 Ping 192.168.11.1 具有 32 字节的数据:
```

```
来自 192.168.11.1 的回复: 字节=32 时间=2ms TTL=64  
来自 192.168.11.1 的回复: 字节=32 时间<1ms TTL=64  
来自 192.168.11.1 的回复: 字节=32 时间=1ms TTL=64  
来自 192.168.11.1 的回复: 字节=32 时间=1ms TTL=64
```

```
192.168.11.1 的 Ping 统计信息:
```

```
数据包: 已发送 = 4, 已接收 = 4, 丢失 = 0 (0% 丢失),  
往返行程的估计时间(以毫秒为单位):  
最短 = 0ms, 最长 = 2ms, 平均 = 1ms
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>ping 192.168.11.1
```

```
正在 Ping 192.168.11.1 具有 32 字节的数据:
```

```
请求超时。
```

```
来自 192.168.11.1 的回复: 字节=32 时间<1ms TTL=100  
来自 192.168.11.1 的回复: 字节=32 时间=1ms TTL=100
```

```
请求超时。
```

```
192.168.11.1 的 Ping 统计信息:
```

```
数据包: 已发送 = 4, 已接收 = 2, 丢失 = 2 (50% 丢失),  
往返行程的估计时间(以毫秒为单位):  
最短 = 0ms, 最长 = 1ms, 平均 = 0ms
```

```
C:\Users\Admin>_
```

选择 C:\Windows\System32\cmd.exe

```
C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin  
连接请求失败
```

```
C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin  
传输成功: 3 秒 1728512 字节, 576170 字节/秒
```

```
C:\>_
```

失败→成功

(失败原因：DHCP指派)

命令提示符

```
C:\Users\Admin>
C:\Users\Admin>ping 192.168.11.1

正在 Ping 192.168.11.1 具有 32 字节的数据:
来自 192.168.11.1 的回复: 字节=32 时间=2ms TTL=64
来自 192.168.11.1 的回复: 字节=32 时间<1ms TTL=64
来自 192.168.11.1 的回复: 字节=32 时间=1ms TTL=64
来自 192.168.11.1 的回复: 字节=32 时间=1ms TTL=64

192.168.11.1 的 Ping 统计信息:
    数据包: 已发送 = 4, 已接收 = 4, 丢失 = 0 (0% 丢失),
往返行程的估计时间(以毫秒为单位):
    最短 = 0ms, 最长 = 2ms, 平均 = 1ms

C:\Users\Admin>
C:\Users\Admin>
C:\Users\Admin>ping 192.168.11.1

正在 Ping 192.168.11.1 具有 32 字节的数据:
请求超时。
来自 192.168.11.1 的回复: 字节=32 时间<1ms TTL=100
来自 192.168.11.1 的回复: 字节=32 时间=1ms TTL=100
请求超时。

192.168.11.1 的 Ping 统计信息:
    数据包: 已发送 = 4, 已接收 = 2, 丢失 = 2 (50% 丢失),
往返行程的估计时间(以毫秒为单位):
    最短 = 0ms, 最长 = 1ms, 平均 = 0ms

C:\Users\Admin>
```

选择 C:\Windows\System32\cmd.exe

```
(c) Microsoft Corporation. 保留所有权利。

C:\>tftp -i 192.168.1.1 put dd-wrt.v24_micro_generic.bin
连接请求失败

C:\>tftp -i 192.168.1.1 put dd-wrt.v24_micro_generic.bin
C:\>

C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin
^C
C:\>

C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin
连接请求失败

C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin
连接请求失败

C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin
连接请求失败

C:\>
C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin
连接请求失败

C:\>tftp -i 192.168.11.1 put dd-wrt.v24_micro_generic.bin
传输成功: 3 秒 1728512 字节, 576170 字节/秒

C:\>
```

成功后更换IP网段 (192.168.11.2→192.168.1.2)

C:\> 选择 命令提示符

```
C:\Users\Admin>ping 192.168.11.1
```

正在 Ping 192.168.11.1 具有 32 字节的数据:
请求超时。

192.168.11.1 的 Ping 统计信息:
数据包: 已发送 = 1, 已接收 = 0, 丢失 = 1 (100% 丢失),

```
Control-C
```

```
^C
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>
```

```
C:\Users\Admin>ping 192.168.1.1
```

正在 Ping 192.168.1.1 具有 32 字节的数据:

来自 192.168.1.1 的回复: 字节=32 时间=8ms TTL=64

来自 192.168.1.1 的回复: 字节=32 时间=1ms TTL=64

来自 192.168.1.1 的回复: 字节=32 时间<1ms TTL=64

来自 192.168.1.1 的回复: 字节=32 时间<1ms TTL=64

192.168.1.1 的 Ping 统计信息:

数据包: 已发送 = 4, 已接收 = 4, 丢失 = 0 (0% 丢失),

往返行程的估计时间(以毫秒为单位):

最短 = 0ms, 最长 = 8ms, 平均 = 2ms

```
C:\Users\Admin>
```

Internet 协议版本 4 (TCP/IPv4) 属性

常规

如果网络支持此功能, 则可以获取自动指派的 IP 设置。否则, 你需要从网络系统管理员处获得适当的 IP 设置。

☐ 自动获得 IP 地址(O)

☒ 使用下面的 IP 地址(S):

IP 地址(I):

192 . 168 . 1 . 2

子网掩码(U):

255 . 255 . 255 . 0

默认网关(D):

192 . 168 . 1 . 1

☐ 自动获得 DNS 服务器地址(B)

☒ 使用下面的 DNS 服务器地址(E):

首选 DNS 服务器(P):

192 . 168 . 1 . 1

备用 DNS 服务器(A):

. . .

☐ 退出时验证设置(L)

高级(V)...

确定

取消

网络连接详细信息

网络连接详细信息(D):

属性	值
连接特定的 DNS 后缀	
描述	Realtek PCIe GbE Family Controller
物理地址	80-FA-5B-00-AC-97
已启用 DHCP	否
IPv4 地址	192.168.1.2
IPv4 子网掩码	255.255.255.0
IPv4 默认网关	192.168.1.1
IPv4 DNS 服务器	192.168.1.1
IPv4 WINS 服务器	
已启用 NetBIOS over Tc...	是
连接-本地 IPv6 地址	fe80::21d:7219:e79:488c%3
IPv6 默认网关	
IPv6 DNS 服务器	

关闭(C)

初次WEB登录

192.168.1.1

dd-wrt.com

... control panel

Firmware: DD-WRT v3.0-r44715 micro (11/03/20)
Time: 01:07:24 up 7 min, load average: 0.00, 0.00, 0.00
WAN IP: 0.0.0.0

Setup

Wireless

Services

Security

Access Restrictions

NAT / QoS

Administration

Status

Router Management

Your router is currently not protected and uses an unsafe default username and password combination; please change it using the following dialog!

Router Password

Router Username

.....

Router Password

.....

Re-enter to confirm

.....

Score:

0%

Complexity:

Too Short

Change Password

System Information

Router

Router Name	DD-WRT
Router Model	Buffalo WHR-AM54G54
LAN MAC	00:16:01:E5:68:B1
WAN MAC	00:16:01:E5:68:B2
Wireless MAC	00:16:01:E5:68:B3
WAN IPv6	
WAN IPv4	0.0.0.0
LAN IP	192.168.1.1

Services

DHCP Server	Enabled - Running
WRT-radauth	Disabled

Memory

Total Available	
Free	
Used	
Buffers	
Cached	
Active	
Inactive	

Space Usage

NVRAM	16 KiB / 32 KiB
-------	-----------------

Wireless

Radio	Radio is On
Mode	AP
Network	Mixed
SSID	dd-wrt
Channel	6
TX Power	71 mW
Rate	54 Mbit/s

Wireless Packet Info

Received (RX)	
Transmitted (TX)	

Wireless

Clients										
MAC Address	Radioname	Interface	Uptime	TX Rate	RX Rate	Info	Signal	Noise	SNR	Signal Quality

Setup

Wireless

Services

Security

Access Restrictions

NAT / QoS

Administration

Status

Router

WAN

LAN

Wireless

Bandwidth

Sys-Info

Router Information

Help

[more...](#)

System

Router Name	DD-WRT
Router Model	Buffalo WHR-AM54G54
Firmware Version	DD-WRT v3.0-r44715 micro (11/03/20)
Kernel Version	Linux 2.4.37 #62657 Tue Nov 3 07:24:46 +03 2020 mips
MAC Address	<u>00:16:01:E5:68:B2</u>
Hostname	
WAN Domain Name	
LAN Domain Name	
Current Time	Not available
Uptime	17 min

Router Name:

This is the specific name for the router, which you set on the *Setup* tab.

MAC Address:

This is the router's MAC Address, as seen by your ISP.

Firmware Version:

This is the router's current firmware.

Current Time:

This is time received from the NTP server set on the *Setup / Basic Setup* tab.

Uptime:

This is a measure of the time the router has been "up" and running.

Load Average:

This is given as three numbers that represent the system load during the last one, five, and fifteen minute periods.

CPU

CPU Model	Broadcom BCM5350 chip rev 0
CPU Cores	1
CPU Clock	200 MHz
Load Average	0.00, 0.00, 0.00

0%

Memory

Total Available	14016 KiB / 16384 KiB
Free	6728 KiB / 14016 KiB
Used	7288 KiB / 14016 KiB
Buffers	896 KiB / 7288 KiB
Cached	2716 KiB / 7288 KiB
Active	2296 KiB / 7288 KiB
Inactive	1332 KiB / 7288 KiB

86%

48%

52%

12%

37%

32%

18%

Space Usage

NVRAM	16 KiB / 32 KiB
-------	-----------------

Network

参考文章

- <https://netnotora.hatenadiary.org/entry/20110324/1300983760>

参考にしたのはここ:(Google Cache)AirStation 改造計画 « やっぱりマックでしょ！

1. DD-WRTのサイトからインストールするファームウェアを用意します。今回はWHR-HP-G54用V24prePS2[Beta] Build 13064のStandard genericを一応使いました。新バージョンも出てるようですが、試すのはあとでということ。
2. WHR-AMPG-AをINITスイッチで初期化します。起動し、DIAGランプが消え、通常状態になったらINITスイッチを針金などで長押しして、初期化します。
3. ルーターのIPアドレスが192.168.11.1になるので、パソコンとLANケーブルで直結し、パソコンのIPアドレスを192.168.11.2ぐらいに適当に設定します。
4. コマンドプロンプトを開き、ダウンロードしたファイルのあるディレクトリに移動し、以下のように入力しておきます。

```
“ tftp -i 192.168.11.1 PUT (ファイル名)
```

1. 一度WHR-AMPG-Aの電源を切り、再度投入します。DIAGランプが点灯したときに、先述のコマンドを実行します。
2. 転送はすぐ終わり、うまく行けば書き換えが始まります。書き換え中はDIAGランプが光ってはずです。
3. 再起動し、書き換えが成功するとDIAGランプが消え、電源とgランプだけが付いた状態になります。ag両方付いてると失敗のようですが、一発でうまくいきました。
4. インストール後、WHR-AMPG-AのIPアドレスは192.168.1.1になっているので、パソコン側も直し、ウェブブラウザで192.168.1.1を開きます。
5. 管理ユーザー名、パスワードを設定して、ひとまずはインストール終了です。