

SUNMI V2 Integration

QuickServe supports the SUNMI V2/V2 Pro/V2s built-in 58mm printer through a browser/WebView bridge.

What Is Implemented

- Printer model presets: SUNMI V2 Built-in, SUNMI V2 Pro Built-in, and SUNMI V2s Built-in.
- New printer interface: SUNMI.
- Receipt, order-list, kitchen-ticket, shift-close, drawer, and beep commands all use the same ESC/POS output pipeline.
- The POS detects common bridge objects: QuickServeSunmi, SunmiPrinter, sunmiPrinter, SunmiPrint, sunmiPrint, WoyouPrinter, woyouPrinter, Android, and android.
- The preferred bridge method is printEscPosBase64(base64).
- Compatible raw methods are also supported: printRawBase64, printBase64, sendRawBase64, runRAWData, sendRAWData, sendRawData, and printRawData.

Required SUNMI Wrapper

A normal web browser cannot reliably access the SUNMI built-in printer directly. SUNMI documents the printer paths as Android AIDL/service, virtual Bluetooth, or an H5 page through a JS bridge. For this React POS, the recommended deployment is an Android WebView wrapper on the SUNMI device.

The wrapper should expose this JavaScript object:

```
window.QuickServeSunmi.printEscPosBase64(base64EscPosBytes)
```

Optional methods:

```
window.QuickServeSunmi.printerInit()
```

```
window.QuickServeSunmi.initPrinter()
```

```
window.QuickServeSunmi.isReady()
```

```
window.QuickServeSunmi.getServiceVersion()
```

Accepted success responses:

```
true
```

```
"true"
```

```
"ok"
```

```
"success"
```

```
{ "success": true }
```

```
{ "ok": true }
```

```
{ "code": 0 }
```

Native Wrapper Notes

On Android, bind to SUNMI's printer service or use SUNMI's printer library, then decode the base64 payload and pass the raw ESC/POS bytes to the printer. The GitHub examples and SUNMI docs call this kind of method sendRAWData or runRAWData.

Minimum native behavior:

1. Load the QuickServe URL in a WebView.
2. Enable JavaScript.
3. Add a JavaScript interface named QuickServeSunmi.
4. Implement printEscPosBase64(String base64) to decode and send raw bytes to the built-in printer.
5. Implement printerInit() if available from the SUNMI library.

Device Setup

1. Open QuickServe on the SUNMI wrapper app.
2. Go to POS settings, then Printer.

3. Add printer.
4. Set Interface to SUNMI.
5. Select SUNMI V2 Built-in or the matching V2 model.
6. Press Connect Built-in Printer.
7. Save the printer profile.
8. Run Test Print.

Fallback

External Bluetooth receipt printers still use the existing Web Bluetooth flow. The SUNMI built-in printer should use the SUNMI interface, not the Bluetooth interface, unless your wrapper intentionally exposes the internal printer as a BLE-compatible device.