

ARM MPU AM3358 General Purpose EVM Base Board ZCZ Package


- -See the Hardware User Guide for board details
- -See the PCB Build Specification for PCB Details
- -See the EVM Errata Document for Known Issues

































User Reset/Interrupt Switches





Expansion Connector - EXPO V1_8D V1_8D C132 C132 C133 C134 C133 C134 C135 C136 C136 C137 C138 C138

