

EDAN Agile PLM Electronic Signature Information

--Signatures related to this document and performed in EDAN Agile PLM.

文件名称(Document Name) : Acclarix AX3 系列使用说明书基础册_英文

文件编号(Number) : 01.54.458117

版本(Version) : 2.4

产品型号(Product Model) : Acclarix AX3;Acclarix LX3

项目编码(Project Code) : 00001G000

签批信息(Signature):

作者(Originator) : 钟 晓婷 (zhongxiaoting) 2022-09-27 10:20:08

审核人(Reviewers) : 李 娴 (lijiao) 2022-09-27 11:41:46

审核人(Reviewers) : 陈 亦君 (chenyijun) 2022-09-27 16:04:28

审核人(Reviewers) : 龚 穗 (gongying) 2022-09-27 14:14:07

审核人(Reviewers) : 危 林意 (weilinyi) 2022-09-27 16:15:17

批准人(Approvers) : 黄 君君 (huangjunjun) 2022-09-28 16:47:42

批准人(Approvers) : 刘 嘉惠 (liujiahui) 2022-09-28 14:41:49

版权©深圳市理邦精密仪器股份有限公司 (Copyright©Edan Instrument,Inc.)

Acclarix AX3 Series
Diagnostic Ultrasound System
Version 2.4

User Manual
Basic Volume

CE₀₁₂₃



About This Manual

P/N:01.54.458117

MPN: 01.54.458117024

Release Date: September, 2022

© Copyright EDAN INSTRUMENTS, INC. 2018-2022

This User Manual applies to 2.2X releases for Acclarix AX3 series Diagnostic Ultrasound Systems including Acclarix AX3, Acclarix AX3 Exp, Acclarix AX3 Super, Acclarix AX25, Acclarix AX28, Acclarix AX2, Acclarix AX2 Exp, Acclarix AX2 Super, Acclarix AX15 and Acclarix AX18. See Appendix A.10 for the difference between these models.

This User Manual Basic Volume together with the User Manual Advanced Volume (P/N:01.54.458907) contains necessary and sufficient information to use the Acclarix AX3 series Diagnostic Ultrasound Systems safely for the intended purposes and approved clinical applications.

Please read and make sure you understand all of the instructions in this manual prior to using the system. Disregarding instructions, particularly warnings and cautions, is considered abnormal use.

Not all measurements and features are available for all system models and configurations. This manual is based on the complete set of transducers and features available. Therefore, some of the contents may not apply to your product. If you have any questions, please contact your local EDAN representative. The pictures and interfaces in this manual are for reference only.

Conventions

In this manual, the following conventions are used to describe the system for better understanding:

- **Bold:** bold texts indicate keys or items on main screen or touch screen.
- **<Bold>:** bold texts in angular brackets indicate buttons, knobs and other controls on the console or on the keyboard.
- ->: Arrow indicates operations following the path.

Contact Information

For sales or service information, please contact your local distributor or the EDAN Service Department at: support@edan.com

Regulatory Approval Remarks

The following feature is not available at the time of release of this user manual in CE, FDA and Canada territories. Consult your local representatives for the availability of the feature.

- Fetus Score
- Auto Vessel Diam
- L12-5WQ Transducer
- ECL12-3Q Transducer

Contents

1	Introduction	1
1.1	Intended Use/ Indications for Use	1
1.2	Contra-indications	1
1.3	Device Description	1
2	Safety	2
2.1	Warnings	2
2.2	Cautions	4
2.3	Labeling Symbols	8
3	Getting Started.....	12
3.1	System Configuration	12
3.2	System Overview	15
3.2.1.	Main Unit	15
3.2.2.	Control Panel	18
3.2.3.	Screen Layout.....	21
3.2.4.	Touch Screen	24
3.2.5.	Trackball.....	25
3.3	System Preparation.....	27
3.3.1.	Battery Use	27
3.3.2.	AC Power Use.....	28
3.3.3.	Transducer Connection.....	29
3.3.4.	Powering on/ off	30
4	Exam Operation	32
4.1	How to Start an Exam	32
4.2	How to End an Exam	33
4.3	How to Restart an Exam	33
4.4	The Patient Information Page	34
4.5	Modality Worklist	36
5	Imaging	37
5.1	B-mode.....	37
5.1.1.	Using B-mode	37
5.1.2.	B-mode Image Optimization	37
5.2	Color Mode.....	41
5.2.1.	Color Mode Variants	41
5.2.2.	Using Color Mode	41
5.2.3.	Color Image Optimization	42
5.3	PW Mode.....	45
5.3.1.	Using PW Mode	45
5.3.2.	PW Image Optimization	45
5.3.3.	HPRF	48

5.4 CW Mode	49
5.4.1. Using CW Mode	49
5.4.2. CW Image Optimization.....	49
5.5 M-mode	51
5.5.1. Using M-mode.....	51
5.5.2. M-mode Image Optimization.....	51
5.6 Anatomic M Mode.....	53
5.6.1. Linear Anatomic M Mode	53
5.6.2. Curved Anatomic M Mode	54
5.7 Color M Mode.....	55
5.7.1. Using Color M Mode	55
5.7.2. Color M Image Optimization	55
5.8 TDI Mode.....	56
5.8.1. Using TDI mode	56
5.8.2. TDI Image Optimization	56
5.9 3D/4D Mode	57
5.9.1. Pre-3D/Pre-4D	57
5.9.2. 3D Volume Sweeping.....	58
5.9.3. 3D Image Review.....	59
5.9.4. 4D Volume Acquisition	64
5.9.5. 4D Live Volume.....	64
5.9.6. 4D Cine	65
5.10 Panorama.....	66
5.11 Elastography.....	67
5.11.1. Using Elastography Mode	67
5.11.2. Elastography Image Optimization	68
5.12 ECG.....	69
5.12.1. ECG Touch Screen Controls.....	70
5.12.2. ECG Basic Operations.....	71
5.12.3. ECG Review	71
6 Transducers and Biopsy.....	72
6.1 Transducers.....	72
6.2 Using Transducers	74
6.3 Transducer Cleaning and Disinfecting	77
6.3.1. Cleaning	77
6.3.2. Disinfecting.....	77
6.3.3. Sterilization.....	80
6.3.4. Storage.....	80
6.4 Needle Biopsy Guide	81
6.4.1. Installing Needle Guide Bracket	81
6.4.2. Activating Needle Guide Function	86

6.4.3. Calibrating the Needle Guide Line.....	87
6.5 Needle Visualization.....	88
6.6 Center Line.....	89
6.7 Needle Guide Bracket Cleaning and Sterilization	89
6.7.1. Cleaning	90
6.7.2. Sterilization.....	90
6.7.3. Storage.....	90
7 Features	91
7.1 Comment.....	91
7.2 Body Mark	93
7.3 Split Display.....	94
7.3.1. Dual Imaging.....	94
7.3.2. Quad Imaging	94
7.4 Zoom	95
7.5 Cine Review	95
8 Measurements and Reports	97
8.1 Generic Measurements	100
8.1.1. B-mode Generic Measurements.....	100
8.1.2. M-mode Generic Measurements	104
8.1.3. Strip Doppler Generic Measurements	106
8.2 Application Measurements	110
8.2.1. Abdomen Measurements.....	111
8.2.2. Gynecology Measurements	112
8.2.3. Obstetrics Measurements.....	113
8.2.4. Cardiac Measurements.....	118
8.2.5. Small Parts Measurements.....	126
8.2.6. Urology Measurements.....	127
8.2.7. Vascular Measurements	128
8.2.8. Pediatric Measurements	132
8.2.9. Emergency Measurements.....	134
8.3 Worksheet and Report	135
8.3.1. Worksheet.....	135
8.3.2. OB Worksheet.....	137
8.3.3. Growth Curve	138
8.3.4. Fetus Score.....	140
8.3.5. Findings.....	141
8.3.6. Report	142
8.4 Measurement Accuracy	143
9 Exam Data Management	144
9.1 Storing Images	144
9.2 Reviewing Images	145

9.3 Exam Database.....	147
9.4 Archiving Studies.....	149
9.5 Structured Report.....	150
9.6 Image Compare.....	150
10 Presets	151
10.1 Preset Organization	151
10.2 Selecting a Preset	152
10.3 Storing and Editing a Preset	152
10.3.1. Exam Preset	153
10.3.2. Image Preset.....	155
10.3.3. Comment Preset.....	156
10.3.4. Body Mark Preset	157
10.3.5. Measure Preset.....	158
11 Utilities	160
11.1 System Set-up	160
11.1.1. General Set-up.....	160
11.1.2. Patient Set-up.....	162
11.1.3. Storage Set-up	163
11.1.4. Print Set-up	164
11.1.5. Report Set-up.....	166
11.1.6. Image Set-up.....	168
11.1.7. Power Set-up.....	169
11.1.8. User Set-up	170
11.2 Connectivity	171
11.2.1. TCP/IP	172
11.2.2. DICOM	174
11.2.3. FTP Server	178
11.2.4. Time Synchronization.....	180
11.3 Maintenance	180
11.3.1. License	180
11.3.2. Version	181
11.3.3. Export/Import.....	182
11.3.4. Demo	183
11.3.5. Self-Check.....	183
11.3.6. Tool	183
11.3.7. Transducer Element Check.....	184
11.4 Screen Adjust	184
12 In Between Exams	185
12.1 Unpacking	185
12.2 Transport	185
12.3 Storage.....	185

13 Troubleshooting and Maintenance	186
13.1 Daily Checklist.....	186
13.2 Troubleshooting.....	186
13.3 System Cleaning and Disinfection	187
13.3.1. Cleaning and Disinfecting the System Surface	188
13.3.2. Cleaning and Disinfecting the ECG Module and Cable	190
13.4 Maintenance.....	191
Appendix A Specifications	192
A.1 Electrical Safety Classifications	192
A.2 Power Supply.....	192
A.3 Machine Specifications	193
A.4 Display Specifications.....	193
A.5 General Specifications	193
A.6 Wi-Fi Specifications	194
A.7 ECG Specifications	195
A.8 Operating, Storage and Transportation Environment.....	195
A.8.1 Operating Environment	195
A.8.2 Storage and Transportation Environment	195
A.9 Transducer Specifications	196
A.10 Configuration Difference	196
Appendix B Ultrasound Intensity and Safety	197
B.1 Ultrasound in Medicine	197
B.2 Ultrasound Safety and the ALARA Principle.....	197
B.3 Explanation of MI/TI.....	198
B.3.1 MI (Mechanical Index).....	198
B.3.2 TI (Thermal Index).....	198
B.3.3 Display of MI/TI	199
B.4 Acoustic Output	199
B.4.1 Factors that Contribute to Uncertainty in the Output Display	199
B.4.2 Differences between Actual and Displayed MI/TI	199
B.4.3 Measurement Uncertainty	199
B.4.4 Acoustic Power Default Settings.....	200
B.4.5 Acoustic Output Limits	200
B.5 Operator Control Features.....	200
B.6 Prudent Use Statement	200
B.7 References for Acoustic Output and Safety	201
B.8 Transducer Acoustic Output Data.....	201
Appendix C Order List	202
Appendix D EMC Information.....	205

1 Introduction

1.1 Intended Use/ Indications for Use

The Acclarix AX3 series Diagnostic Ultrasound System is intended for use by a qualified physician or allied health professional for ultrasound evaluations in hospitals and clinics. General clinical applications include: Abdominal, Gynecology, Obstetric, Cardiac, Small Parts, Urology, Musculoskeletal, Peripheral Vascular, Intra-operative, Pediatric, Neonatal, and Adult Cephalic.

The modes of operation for Acclarix AX3 series include B mode, M mode, Doppler mode, Harmonic Imaging, Elastography Imaging and their combination modes.

1.2 Contra-indications

The Acclarix AX3 series Diagnostic Ultrasound System is not intended for ophthalmic use or any use causing the acoustic beam to pass through the eye.

1.3 Device Description

The Acclarix AX3 series Diagnostic Ultrasound System consists of a main system and associated ultrasound transducers.

The system circuitry generates an electronic voltage pulse, which is transmitted to the transducer. In the transducer, a piezoelectric array converts the electronic pulse into an ultrasonic pressure wave. When coupled to the body, the pressure wave transmits through body tissues. The waves are then reflected within the body and detected by the transducer, which then converts the waves back to an electrical signal. The system then analyzes the returned signals and generates an ultrasound image or spectral Doppler display.

The Diagnostic Ultrasound System provides the operator the ability to measure anatomical structures, and offers analysis packages that provide information used by competent health care professionals to make a diagnosis.

The system's user interface provides both hard keys for functions frequently used throughout an exam and touch screen controls for mode-specific functions.

2 Safety

Throughout this document the following terms are used:

- **Warning:** Advises against certain actions or situations that could result in personal injury or death.
- **Caution:** Advises against actions or situations that could damage equipment, produce inaccurate data, or invalidate a procedure.
- **Note:** Provides useful information regarding a function or a procedure.

Please read all warnings and cautions prior to using the system. For your convenience, all warnings and cautions are provided in this section, but may be duplicated elsewhere in this document in the context of the instructions for use.

2.1 Warnings

- Only use Edan supplied power adapter and power cord.
- Only use Edan supplied battery. Read and understand the battery installation instructions prior to changing the battery.
- Only use Edan supplied transducer. Use of other transducers may result in electric shock or system malfunction.
- Only use a hospital grade, grounded, power outlet and plug. Do not use with an ungrounded outlet.
- The system is ordinary equipment (sealed equipment without liquid proof). The transducers (not including transducer connector) is IPX7 certified. The footswitch is IP68 certified. Do not immerse or expose any of the parts to extended moisture. Splash resistance does not extend to transducer connectors. Please keep connectors dry.
- Do not use in a wet environment or when the relative humidity exceeds 95%.
- Do not reverse the positive and negative poles when installing the battery.
- Do not use the battery near heat sources or when the ambient temperature is over 40°C. Do not heat or dispose of in fire.
- Do not destroy the battery; do not pierce or cause a strong impact to the battery.
- Do not touch the connector pins on the transducer port.
- Parts and accessories used must meet the requirements of the applicable IEC/EN60601 series safety standards, and/or the system configuration must meet the requirements of the IEC/EN60601-1.
- Use protective barriers (legally marketed gloves and transducer sheaths) whenever possible. Follow sterile procedures when appropriate. Thoroughly clean transducers and reusable accessories after each patient examination and disinfect or sterilize as needed. Refer to transducer use and care instructions. Follow all infection control policies established by your office, department or institution as they apply to personnel and equipment.
- Not intended for Ophthalmic use or any use causing the acoustic beam to pass through the eye.

- If a sterile transducer cover becomes compromised during an intra-operative application involving a patient with transmissible spongiform encephalopathy, such as Creutzfeldt-Jakob disease, follow the guidelines of the U.S. Disease Control Center and this document from the World Health Organization: WHO/CDS/APH/2000/3, WHO Infection Control Guidelines for Transmissible Spongiform Encephalopathies. The transducers for your system cannot be decontaminated using a heat process.
- Contact with natural rubber latex may lead to a severe anaphylactic reaction in persons sensitive to the natural latex protein. Sensitive users and patients must avoid contact with these items. EDAN strongly recommends that health-care professionals identify their latex-sensitive patients, and refer to the March 29, 1991 Medical Alert on Latex products. Be prepared to treat allergic reactions immediately.
- Improper operation may cause the internal lithium battery (hereinafter called battery) to become hot, ignited or possibly explode, and it may lead to decreased battery capacity. It is necessary to read the user manual instructions and warning messages carefully.
- Do not touch accessible contacts of electrical equipment and the patient simultaneously.
- This device is not suitable for intra-cardiac use or direct cardiac contact.
- The system shall not be serviced or maintained while in use with a patient.
- Install the system according the EMC guidance provided in Appendix D.
- Do not stack the system on other electronic equipment.
- The use of transducer and connecting cable not supplied by the manufacturer may result in increased emissions or decreased immunity of the equipment.
- Refer to Appendix D for recommended separation distances from other equipment, including portable and RF communication devices.
- The power adapter is used to isolate the system from main power. Position the system so that it is easy to disconnect it from the power supply.
- No modification of this equipment is allowed.
- The system should be maintained regularly, at least annually, by a qualified technician who has adequate training, knowledge and experience. That person should be familiar with the Service Manual, available from your Edan representative.
- Keep non-medical equipment out of the vicinity of the patient (1.5m/6ft.).
- Use of an extension cord or multi-socket outlet setup to provide power to the ultrasound system or to the system's peripheral devices, may cause the system to exceed current leakage limits.
- It is not suggested to use a multiple socket-outlet with the device. If one is required, make sure that the multi-socket complies with the requirement specified in Chapter 16 of IEC 60601-1, or the multi-socket is with an isolation transformer. And the multi-socket shall not be placed on the floor.
- **SHOCK HAZARD** - Don't connect electrical equipment, which has not been supplied as a part of the system, to the multiple portable socket-outlet supplying the system.
- **SHOCK HAZARD** - Don't connect non-electrical equipment, which has been supplied as a part of the system, directly to the wall outlet when the non-medical equipment is intended to be supplied by a multiple portable socket-outlet with an isolation transformer.

- SHOCK HAZARD – Do not connect non-isolated electrical equipment to the same circuit being used to power the system.
- Edan recommends the use of isolated connectors on any electrical equipment attached to the system, and/or using isolation transformers that comply with IEC60601-1 to power that electrical equipment.
- Always use sterile technique during a biopsy procedure. Sterilize the needle guide assembly between uses.
- Use a sterile needle with each use.
- The system may be interfered with by other equipment, even if that other equipment complies with CISPR EMISSION requirements.
- The system cannot be used together with high-frequency surgical equipment.
- Remove the battery from the device when the device is not used for a long time.
- Verify measurement results prior to entering them into a report.

Transducer Warnings

- To avoid infection, always use protective gloves when cleaning or disinfecting.
- Read and follow all manufacturer instructions for disinfection agents.
- To avoid infection, ensure that expiration date of the disinfecting solution has not passed.
- Disinfect the transducer after each intra-cavity or intra-operative procedure. Use a new sterile sheath for each such procedure.
- Use a pyrogen-free transducer sheath for intra-operative procedures.
- The system is not intended to come into contact with the central nervous system and central cardiovascular system.
- Unplug the transducer from the system prior to cleaning or disinfecting.
- Do not immerse the transducer beyond the point indicated in Figure 6-3.
- Do not allow the transducer connector to get wet.
- "Intra-operation" exam preset must be used when doing intra-operative examination using transducer L17-7SQ.

2.2 Cautions

- Excessive dust and dirt could clog internal airflow and cause overheating. Do not use in a dusty environment.
- Do not use a battery that leaks, emits an odor, appears deformed, or discolored. Immediately replace it with a new Edan-supplied battery and dispose of the old battery according to local regulations. Replace a battery that has reached the end of its service life.
- Use care when storing or disposing of batteries. Do not allow the leakage from one battery to come in contact with other batteries. Batteries (including button cell on the main board) are hazardous waste. Do not dispose of them together with household garbage. At the end of their life hand the batteries over to the applicable collection points for the recycling of waste batteries. Inappropriate disposal of waste may contaminate the environment.
- Inspect the system regularly, at least weekly. Before use, ensure there is no visible evidence of damage to the equipment, cables, and transducers. If a component is damaged, replace it before use.

- Do not use in locations subject to vibration.
- Read and understand the section *Appendix B.2 Ultrasound Safety and the ALARA Principle* before using the system. Do not expose a patient to ultrasound energy longer than clinically reasonable.
- Practice ALARA principle when operating ultrasound system. Minimize the acoustic power without compromising the image quality.
- Do not use in the presence of a flammable anesthetic.
- The system generates radio frequency energy, which may cause interference with other devices in the vicinity. If interference is suspected, try re-orienting or relocating the equipment.
- The use of electrosurgical units or other devices that generate radio frequency interference may cause image distortion or other malfunctions.
- During long term storage, the battery should be charged at least once every 6 months to ensure battery capacity.
- The system should only be used by a qualified physician or allied health professional for ultrasound evaluations.
- Use only Edan supplied or recommended parts and accessories.
- Verify measurement results prior to entering them into a report.
- Contact your local distributor or Edan Service if there is excessive noise from the system speaker or fans.
- Please read and understand cleaning instructions prior to use.
- Please read and understand maintenance instructions prior to use.
- Please read and understand instructions for system operation prior to use.
- Studies stored on the system hard drive should be archived regularly. The system is not intended for long term storage of patient information. Confirm successful archiving before deleting a study from the hard drive.
- Ensure that the system vents are clear and unobstructed.
- Confirm patient identification information prior to storing or printing any exam information.
- If you have any questions about maintenance, technical specifications, or system functionality, please contact your local distributor or Edan Service at: support@edan.com
- Ultrasound images occasionally have artifacts, and should only be used as one part of an overall clinical assessment.
- To avoid electrical shock, turn off and disconnect the device from the AC power source before cleaning and disinfecting.
- No user serviceable parts are inside the system. All repairs on the system must be performed by EDAN certified service personnel.
- The device and accessories are to be disposed of according to local regulations after their useful lives. Alternatively, they can be returned to the dealer or the manufacturer for recycling or proper disposal.
- The packaging is to be disposed of according to local or hospital's regulations; otherwise, it may cause environmental contamination. Place the packaging at a location that is inaccessible to children.
- Properly dispose of used cleaning agents or disinfectants according to your hospital's

regulations.

- The system does not need calibration as part of routine maintenance.
- The format of USB disk should be FAT32.
- Any serious incident that has occurred in relation to the device should be reported to the manufacturer and the competent authority of the Member State in which the user and/or patient is established.
- Automated cleaning/disinfection is prohibited for ultrasound system and its accessories.

Transducer Cautions

- Do not use a transducer that has a damaged, scratched surface or exposed wiring of any kind.
Do not subject the transducer to knocks or drops.
- Do not use disinfection agents beyond their expiration date.
- Do not use sterile sheaths beyond their expiration date.
- Inspect the transducer connector, cable, and head periodically. Do not use if there is evidence of excessive wear or damage.
- Do not operate the transducer to temperatures in excess of 40°C or store the transducer in temperatures in excess of 55°C.
- Do not use a transducer giving off excessive heat or anything not functioning properly, otherwise it may do harm to the patient such as tissue damage or coagulation.
- Do not kink or pull on the transducer cable.
- Broken or bent connector pins can cause image artifacts. Do not use a transducer with broken or bent pins.

Network Security Cautions

- Keep your ultrasound system safe to protect the patient information and data from being modified, damaged or disclosed caused by unauthorized disassembly.
- Always ensure the privacy of patient information and data displayed/stored in the ultrasound system or exported to external storage devices.
- The software upgrade can only be performed by EDAN-qualified service professionals with upgrade files of known provenance. Confirm that the system boots to imaging after an upgrade.
- Make sure the ultrasound system is used under secure network environment, and all the approved devices connecting with the ultrasound system are physically secure.
- Anti-virus measures such as USB device virus scanning should be carried out prior to using the USB flash drive.
- Do not connect a USB device with unknown provenance to the ultrasound system.
- When the ultrasound system is returned for maintenance, disposed of, or removed from the medical institution for other reasons, ensure all patient data are removed from the ultrasound system.
- Always hide your password when entering it on the system, protecting it from being disclosed.

Federal Communications Commission (FCC) Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2.3 Labeling Symbols


The following labels are used on the system:

No.	Symbol	Definition
1		Serial Number
2	P/N	Part Number
3		Date of Manufacture
4		Manufacturer
5		Operating instructions
6		Warning (Background: Yellow; Symbol & outline: Black)
7		Refer to instruction manual/ booklet (Background: Blue; Symbol: White)
8		Caution
9		CE Marking
10		Authorized Representative in the European Community
11		Disposal method. Indicates that the equipment should be sent to special agencies according to local regulations for separate collection after its useful life.
12	Rx only	Caution: Federal (U.S.) law restricts this device to sale by or on the order of a physician.
13	IPX7	Protected against the effects of temporary immersion in water.
14		Type BF Applied Part
15		Probe for sector-shaped sound field

16		Pencil Probe(reserved)
17		Locking, general
18		Unlocking
19		Computer network
20		Trademark
21		Current: Direct
22		Video Output
23		USB 2.0 port
24		USB 3.0 port
25	HDMI	HDMI port
26		Alternating Current
27		Electric Energy
28		Battery Check
29		Non-ionizing electromagnetic radiation
30	FCC ID:SMQAX3EDAN	Federal Communications Commission: FCC ID:SMQAX3EDAN
31		Non-sterile. Indicates a medical that has not been subjected to a sterilization process.
32	IP68	Dust-tight (No ingress of dust); Protected against the effects of continuous immersion in water.

33	ETL CLASSIFIED  Intertek 4005997	Conforms to AAMI Std. ES60601-1, IEC Std. 60601-2-37, IEC Std. 60601-1-6. Certified to CSA Std. C22.2 No. 60601-1, No 60601-2-37, IEC Std. 60601-1-6.
34		DEFIBRILLATION-PROOF TYPE CF APPLIED PART
35		Probe Version.
36		Unique device identifier
37		Medical Device
38		Biological risks

The following labels are used on the packaging:

No.	Symbol	Definition
1		THIS WAY UP
2		Fragile, handle with care
3		Keep dry
4		General Symbol for recovery / recyclable
5		STACKING LIMIT BY NUMBER

6		DO NOT STEP ON
7		HANDLE WITH CARE

NOTE: The user manual is printed in black and white.

3 Getting Started

3.1 System Configuration

Standard Configuration:

The system is shipped with the following components:

- ◆ 1 main unit
- ◆ 1 AC adapter
- ◆ 1 power cord
- ◆ 1 rechargeable lithium battery
- ◆ 1 USB disk
- ◆ 1 bottle of coupling gel
- ◆ 1 basic user manual and 1 advanced user manual
- ◆ 1 packing list

Options:

The following options are also available:

- ◆ Transducers:
C5-2Q, L12-5Q, E8-4Q, P5-1Q, L17-7Q, L17-7HQ, L17-7SQ, P7-3Q, MC8-4Q, C6-2MQ, C5-1Q, MC9-3TQ, E10-3BQ, E10-3HQ, L12-5HQ, L12-5WQ, ECL12-3Q.
- ◆ Needle Guide Bracket Kit

Model	Type	Angle/Depth	Description
BGK-L40UB	In-plane	34°, 43°, 53°, 66°	For use with the L17-7Q Supports: 14G-23G
BGK-CR10UA	In-plane	2°	For use with the E8-4Q, Supports: 16G-18G
BGK-001	Out-of-plane	1.0cm, 1.5cm, 2.0cm	For use with the L17-7Q, Supports: 21G
BGK-002	In-plane	38°, 46°, 58°	For use with the L12-5Q/L17-7HQ/ L12-5HQ, Supports: 14G-23G
BGK-003	Out-of-plane	1.0cm, 1.5cm, 2.0cm	For use with the L12-5Q/L17-7HQ/ L12-5HQ, Supports: 21G
BGK-004	In-plane	12°, 20°	For use with the MC9-3TQ, Supports: 14G-23G

BGK-005	In-plane	0°	For use with the E10-3BQ, Supports: 16G-18G
BGK-006	In-plane	1°	For use with the E10-3HQ, Supports: 16G-18G
BGK-007	In-plane	18°, 25°, 35°	For use with the C5-2Q, Supports: 14G-23G
BGK-008	In-plane	12° , 22°	For use with the P5-1Q Supports: 14G-23G
BGK-009	In-plane	14°, 20°, 32°	For use with the C5-1Q Supports: 14G-23G
BGK-010	In-plane	44° ,53° ,64°	For use with the L12-5WQ Supports: 14G-23G
BGK-012	In-plane	11°, 20°, 37°	For use with the MC8-4Q Supports: 14G-23G
BGK-013	In-plane	0.5cm, 1.0cm, 1.5cm, 2.0cm, 2.5cm, 3.0cm, 3.5cm, 4.0cm, 4.5cm, 5.0cm	For use with the ECL12-3Q Supports: 18G

Table 3-1 Needle Guide Bracket Kits

- ◆ 2nd rechargeable lithium battery
- ◆ Footswitch
- ◆ Suitcase
- ◆ MT-808 Trolley
- ◆ Multi-Transducer Connector (MTC)
- ◆ ECG Module
- ◆ 512GB SSD
- ◆ 1TB SSD
- ◆ WIFI Module

Supported Peripheral Accessories:

- ◆ The recommended local printers are listed as follows:

Printer Type	Printer Model	Interface
Color Video Printer	SONY UP-25MD	S-Video
	SONY UP-D25MD	USB
B/W Video Printer	SONY UP-X898MD	USB
Photo Printer	Cannon CP1300	USB
Report Printer	HP OfficeJet Pro 251dw	USB
	HP LaserJet Pro 200 color M251n	USB
	HP LaserJet CP1525n Color	USB
	HP DeskJet Ink Advantage 2010	USB
	HP DeskJet 1010	USB
	HP DeskJet 1510	USB
	HP LaserJet 400 M401d	USB
	HP DeskJet Ink Advantage Ultra 2029	USB
	HP DeskJet 1112	USB
	Canon E518	USB
	Canon iP2780	USB
	HP LaserJet Pro MFP M126nw	USB
	EPSON L310	USB
	HP DeskJet 1050	USB
	HP DeskJet 2050	USB
	HP LaserJet M252n	USB
	EPSON L130	USB
	HP Color LaserJet Pro M254nw	USB
	HP Color Laser 150a	USB
	HP Color Laser 150nw	USB
	HP Laser 103a	USB
	EPSON L3118	USB

Table 3-2 Printer List

WARNING

Only the recommended printers listed above are verified by EDAN. Therefore, it is suggested to only use these printers. Use of other printers should comply with IEC 60950 or IEC 60601-1. Edan is not responsible for the accuracy of other printers.

- ◆ Recommended DVD drive: LITEON eBAU108.

3.2 System Overview

3.2.1. Main Unit

This manual takes the illustrations of a dual-transducer-port ultrasound system as an example to introduce the appearances of the ultrasound system. All illustrations in this manual are for reference only. The ultrasound system you bought may only have one transducer port.




Figure 3-1 Main Unit

No.	Name	Description
1	15.6 inch Monitor	Display the images and parameters during scanning.
2	Power Switch	Power on/off the system.
3	10.1 inch Touch Screen	Use to control operation and activate functions.
4	Control Panel	Use to control the operation.
5	AC Power Indicator 	<p>It illuminates in green when the system is connected to AC power. It is off when the system is no connected to AC power</p>
	System Working Indicator 	<p>It illuminates in green when the system is running. It is off when the system is shutdown. It flashes in green when the system is in sleep mode.</p>
	Battery Indicator 	<p>It is off when no battery is connected or battery is fully charged. It illuminates in orange when battery is low. It illuminates in green when the system operates on battery power or the battery is charging.</p>
6	Transducer Locking Lever	Use to lock or unlock the transducer.
7	Transducer Port	Used for connecting a transducer to the system.
8	Handle	Used for carrying the system.
9	Safety Lock Connector	Used for connecting a safety lock to the system.
10	Vents	Used for heat dissipation and ventilation.
11	I/O Ports	Use to connect the I/O extend modules.

Table 3-3 Main Unit Description

CAUTION

1. Bad ventilation will result in high system temperature. To ensure good ventilation for the system, please use the system as follows:
 - a. Operate the system in the environment temperature between 0° and 40°.
 - b. Place the system on a flat desk where there should be no object, for example cloth, affecting the heat dissipation.
 - c. Leave at least 20 cm around the system to ensure system vents are clear and unobstructed.
2. When the system temperature is too high, the system will display prompt message "System Temperature is High. Please check the system for good ventilation". Refer to section 13.2 Troubleshooting for the specific troubleshooting steps.
3. Excessive dust and dirt could clog internal airflow and cause overheating. Do not use in a dusty environment.


I/O Ports on the left panel:

Figure 3-2 I/O ports

1.	Power supply	2.	Network port
3.	S-Video output port	4	HDMI port
5	USB 3.0 port	6	USB 2.0 port
7.	USB 2.0 port		

Table 3-4 I/O Ports

Caution

1. The HDMI port does not support "hot plug" feature. Please connect the external display to the HDMI port before starting the ultrasound system. Otherwise the external display may be unrecognized or displays abnormally.
2. For the normal operation of the DVD drive, it should be connected to the USB 3.0 port.

3.2.2. Control Panel








Figure 3-3 Control Panel

No.	Key	Name	Description
1.		Power switch	Press to power on/off the system
2.		Patient	Invokes the Patient Information Screen typically used to start/end exams or to modify patient information during an exam. See section 4.
3.		Transducer	Press to switch transducers or exam presets.
4.		Review	Press to enter exam database or image review mode. See section 9 for details.
5.		Print	Press to print images via the connected video printer.

6.		Report	Press to display the report page.
7.		F1	User-defined button
8.		F2	User-defined button
9.		Clear	Press to clear all the measurements, calculations, comments, and body marks displayed on the current image.
10.		Body Mark	Enters or exits the Body Mark function. See section 7.2 for details.
11.		Cursor	Press to hide or display the mouse cursor.
12.		B	Press to return to B-mode imaging from any other imaging modes. See section 5.1 for details. In Zoom status, press to restore the image to the size of the default zoom factor.
13.		Color	Press to enter or exit Color Mode. See section 5.2 for details.
14.		M	Press to enter or exit M Mode. See section 5.5 for details. Use the trackball to adjust the M sample line.
15.		PW	Press to get the sample line. Use the trackball to adjust the position of the sample line. Press <Update> to display the Doppler strip. See section 5.3 for details.
16.		CW	Press to get the sample line. Use the trackball to adjust the position of the sample line. Press <Update> to display the Doppler strip. See section 5.4 for details.
17.		Comment	Enters or exits the Comment function. See section 7.1 for details.
18.		Measure	Invokes the Measure function for Generic and Application Measurements. See section 8 for details.

19.		Single	Press to display the currently active side of Dual image as a single image. See section 7.3 for details.
20.		Dual	Enters dual split screen. Each single press on it toggles between two images. See section 7.3 for details.
21.		Store Image	Press to store static images.
22.		Store Clip	Press to store clips.
23.		Freeze	Press to switch between the frozen and real-time states. The button is highlighted when the image is frozen.
24.		Update	In measurement, pressing <Update> switches the active side of calipers. See section 8 for details. In Pre-Doppler mode, pressing <Update> invokes Spectral Doppler mode. When Spectral Doppler strip is displayed, pressing <Update> allows switching between live acquisition of the Doppler strip or the reference image.
25.		Trackball	Move the trackball to change the cursor position, adjust M mark position in M mode, adjust sample line position in PW mode, etc.
26.		Trackball keys	Two trackball keys provide a wide variety of functions depending on the system state (e.g., selects a start or end point of a measurement, selects menu items on the screen, etc). For the convenience of introduction, we call them <Set> throughout this user manual.
27.		Zoom/Angle	The functions of this knob vary with system functions. When one function is activated, its indicator illuminates. Then rotate to zoom in an image or adjust the angle. For example: In B and Color mode, the Zoom function is auto activated and its indicator illuminates. Rotating the knob will zoom in images. In PW or CW mode, the Angle function is auto activated and its indicator illuminates. Rotating the knob will adjust the Doppler scale to account for the angle between the Doppler cursor and the blood flow. When Comment or Body Mark function is enabled, the

			Angle function is auto activated and its indicator illuminates. Rotating the knob will adjust the angle of comment arrow or the transducer icon.
28.		Depth	Rotate to adjust the depth of the image displayed.
29.		Auto/Gain	<p>In B mode, press the Auto button to automatically update the Overall Gain and TGC.</p> <p>In PW mode, press the Auto button to automatically update the PW gain, DR, baseline and scale.</p> <p>In Color mode, press the Auto button to automatically update the gain.</p> <p>Each single press of the button renews the automatic optimization. Whether Gain, DR or Scale/Baseline is optimized when pressing Auto button in PW mode can be configured in Set-up. See section 11.1.5for detail.</p> <p>Rotate the Gain button to adjust the gain of the image.</p>

Table 3-5 Buttons on Control Panel

3.2.3. Screen Layout



Figure 3-4 Main Screen Display

① Information Field

The top line of this field contains your hospital/institution name. Please see Section 11.1.1 General Set-up for information on customization.

The next two lines show the patient's basic information, including the patient name, gender, age, ID,

LMP, etc., as entered through the Patient Information screen.

This field also contains data fields for:

- The currently active transducer
- The currently active preset
- System date and time.

② Image Field

The ultrasound image appears in the Image field, under the Information field. The Image field also contains information typically associated with the image, such as depth, TGC, maps, image parameters, MI and TI.

③ Measurements Display Field

The left side of the screen displays available generic and application measurement items for current exam preset.

④ Thumbnail Field

The right side of the screen displays thumbnail images of all statics and clips captured for currently active exam or when in Review. In frozen or review status, moving the cursor onto a thumbnail image can quickly preview it in the image area.

This field also contains several shortcut keys for selecting, viewing, deleting, exporting images. See the below for details:

No.	Shortcut Keys	Description
1		CloudShare Transfer selected image/clip to mobile devices.
2		Select All Selects all the displayed static images and clips.
3		Delete Deletes the selected static images and clips.
4		Export Exports the selected static images and clips to removable storage devices.
5	 	Next/Previous Pages Shows next/previous pages when more than one page of images are displayed.

⑤ User Feedback Field

The user feedback field is displayed below image field and above status bar. This field displays:


- Virtual trackball and trackball keys.
- Cine bar when the system is frozen.
- An "Exit" icon . Only displayed in review mode. Clicking on this icon will exit the review

mode.

- The active function of user-defined key F1 and F2.

⑥ Status Bar

The bottom of the screen is used to display icons that provide system status. These include:

No.	Icons	Description	
1	Utility icon		Provides access to system setup, screen adjust, connectivity, maintenance, etc.
2	Image Store icon		Displays the number of static images and clips stored in the current exam.
3	USB icon		USB disk available.
4	Printer icon		Printer available. Symbol is in green when printing in progress.
5	Wi-Fi icon		Wi-Fi function is enabled, but no Wi-Fi network is connected. No Wi-Fi icon will be displayed when Wi-Fi function is disabled in Connectivity setup.
			Wi-Fi network is connected. Clicking on this icon shows a list of available Wi-Fi networks. Selecting an available network displays a dialog box for entering password. Clicking on the "WiFi: Turn off" button above the list will disconnect the currently connected Wi-Fi network.
			Wi-Fi network is disconnected. Clicking on this icon shows a "WiFi: Turn on" button. Clicking on this button shows a list of available Wi-Fi networks. Selecting an available network displays a dialog box for entering password.
6	Network Transfer Status icon		The network transfer status icon shows the transfer statuses of the network server. <ul style="list-style-type: none"> Outline in grey color: Successful connection with a Server. Outline in green color: Data exchange with a Server. Outline in red color: Failure to connect with a configured Server. Clicking on this icon displays a queue of exam or image transfers and as well as the transfer status of each exam or image including refused, pending, active, succeeded, failed, etc. All the transfer tasks are allowed to re-transfer manually.
7	Hard Drive icon		Hard drive available.

			Hard drive data exchange, symbol in green.
			Hard drive 95% full, symbol in red.
			Hard drive 95% full with data exchange, symbol in red.
8	Battery icon		Battery fully charged, symbol in green.
			Battery more than 80% charged.
			Battery 60%-80% charged.
			Battery 40%-60% charged.
			Battery low, symbol in red.
			Battery removed.
			Battery charging.
9	DVD icon		Symbol in grey: DVD device is connected. Symbol in green: DVD device is connected, disc is inserted and data transmission is available.

3.2.4. Touch Screen

The Touch Screen contains controls that vary depending on the active imaging mode or function.

There are several types of controls used by the touch screen, as illustrated below:




Figure 3-5 Touch screen of the System

- A. **Tabs:** Each imaging mode that is active has a tab at the top of the touch screen. Usually, the imaging mode that was most recently activated is the top tab and has priority. Pressing on any other tab will bring it to the top and provide access to the controls available for that imaging mode.
- B. **Paddle:** Pressing on the top or bottom of a paddle changes the control setting by one value. Pressing anywhere on the control and swiping across it will continuously change the value.
- C. **Push button:** This can either be an on/off control (like “Colorize”) or a one-shot control that immediately performs an action.
- D. **Radio Buttons:** A collection of buttons where only one is active at any time. Activating one will de-activate all others.
- E. **TGC:** The B-mode tab has a specialized control for TGC. Each slider can be dragged horizontally and individually. Dragging vertically down across the sliders will set all sliders.
- F. **Pages:** When a tab has multiple pages of controls, each page is represented by a dot at the top of the page. The current page is indicated by a filled-in dot. You can move between pages by dragging your finger horizontally across the dots. These dots do not appear when there is only one page in the current tab.

3.2.5. Trackball

The trackball operation is easy and convenient. It can achieve the following functions:

- ◆ Move the measurement cursor during measurement.
- ◆ Move the comment cursor in the comment status.
- ◆ Move the body mark cursor in the body mark status.
- ◆ Move the M Mark in the M mode.
- ◆ Move the scan area of Color mode, increase or decrease the size of scan area of Color mode.
- ◆ Move the sample line and adjust the size of sample gate in the PW/CW mode.

- ◆ Playback the cine in frozen status.
- ◆ Move the zoomed window in the zoom status.

NOTE:

1. Please be gentle when running the trackball.
2. Please keep the surface of trackball clean.

3.3 System Preparation

3.3.1. Battery Use

The system may come with two lithium-ion batteries depending on your order. The batteries are automatically charged when the system is plugged in.

The system has two battery compartments which are identified by letter A and B respectively. The battery icon of the battery which is installed in battery compartment A is displayed with letter A on it and the battery icon of the battery which is installed in battery compartment B is displayed with letter B on it.

CAUTION

1. If the system will remain unused for more than one week, charge the battery to at least 80% capacity, take the battery out and store the system and battery separately.
2. During long term storage, the battery should be charged at least once every 6 months to ensure battery capacity is more than 80%.
3. Only use Edan supplied battery.

To install the battery:

1. Turn off and unplug the system.
2. Close the monitor, turn the system upside down and rest it on a flat stable surface.
3. Unscrew the three screws securing the battery door, and remove the battery door.




Figure 3-6 Removing battery door.

4. Put the battery gently to battery compartment.




Figure 3-7 Installation of the Battery

5. Close the battery door and screw the three screws.

To remove a battery:

1. Turn off and unplug the system.
2. Close the monitor, turn the system upside down and rest it on a flat stable surface.
3. Unscrew the three screws securing the battery door, and remove the battery door.
4. Remove the battery.
5. Close the battery door and screw the three screws.

WARNING

1. When the battery capacity is $\leq 20\%$, the battery status icon turns red.
 2. When the battery capacity is $\leq 10\%$, the system displays a prompt "Low Battery. The system will shutdown in 3 mins. Please plug in the power supply immediately."
-

3.3.2. AC Power Use

When using AC power, position the system so that it is easy to disconnect it from AC power supply.

To connect AC power:

1. Connect the AC power cord with the power adapter.
2. Connect the DC power cord from the power adapter to the power connector on the system. Make sure the side labeled with "This side up" should face upside when connecting the DC power connector.
3. Push the power cord in firmly to ensure a secure connection.
4. Connect the AC power cord to a hospital-grade power outlet.

WARNING

1. Make sure the AC power supply complies with the following specifications: 100V-240V~, 50Hz/60Hz.
 2. Only use a hospital grade, grounded, power outlet and plug. Do not use with an ungrounded outlet.
 3. Only use Edan supplied power adapter and power cord.
-

3.3.3. Transducer Connection

To connect a transducer:




Figure 3-8 Tansducer Locking Handle

1. Align the connector with the transducer port and carefully push into place.
2. Toggle the locking handle to the top position.
3. Do not allow the transducer head to hang free. Impact to the transducer head could result in irreparable damage.




Figure 3-9 Lock the tansducer locking handle

To disconnect a transducer:

1. Toggle the locking handle to the bottom position to unlock the transducer connector.
2. Firmly grasp the transducer connector and carefully remove it from the system port.
3. Store transducer in its protective carrying case prior to transport.

CAUTION

1. Do not touch the pins of the transducer connector.
2. Broken or bent connector pins can cause image artifacts. Do not use a transducer with broken or bent pins.
3. Only disconnect a transducer when the system is shutdown or is frozen.

Multi-Transducer Connector (MTC)

The Multi-Transducer Connector (MTC) is an optional addition to the system that allows up to four transducers to be connected to the system simultaneously. The MTC can be mounted to the optional cart, or lie flat on an adjacent table.




Figure 3-10 Connect to the MTC

Note:

1. Plugging and unplugging the MTC should be done while the system is frozen or turned off.
2. Only one MTC is allowed to connect with the ultrasound system.

3.3.4. Powering on/ off

Please review and follow the steps described in the Section 13.1.*Daily Checklist* prior to powering on the system.

To power on

1. Connect the system to a hospital grade power supply, or use the battery as the power supply.
2. Press the Power on/off key on the top left of the control panel.

To Login

If Password Protection is enabled (see section 11.1.7), the system displays a Login dialog when booting up the system. Type in or select user name from the User Name drop-down list, then enter password and click **Login**. At the first system powering on after you received the system, a dialog will display for you to set the login password of the pre-defined administrator user.

For emergency use, click **Emergency** to log on directly without entering user name and password.

NOTE:

1. It is not suggested to use Emergency login under non-Emergency situation. Please login the system with your account or switch to your account through the Switch User function (See "To Switch Users" below) prior to imaging scanning.
2. Ensure the privacy of patient information and data created through Emergency login. It is suggested to remove the patient exam data from the ultrasound system after Emergency scanning for protecting patient data from being accessed by unauthorized users.

To Switch Users

If Password Protection is enabled, switching users is allowed without restarting the system.

1. Press Power on/off key, and the system will display a confirmation dialog box.
2. Select **User** from the confirmation dialog box. A login information dialog box will be displayed providing access to change user.
3. Select another user from the User Name drop-down list and then enter password to login.

To power off:

1. Press the Power on/off key on the top left of control panel and the system displays a confirmation dialog box.
2. Select “Shut Down” from the confirmation dialog box.

If the system is unresponsive, a long press of the Power on/off key will shut down the system directly.

NOTE:

1. Turn off and unplug the device after use.
2. Please unplug the AC adapter from the power socket and disconnect the battery prior to storage.

Sleep mode

The system will enter a sleep mode that maintains exam information while using minimal power. There are three events that can invoke sleep mode:

- Close the cover of the system without powering-off the system.
- No user input for a configurable amount of time. Please see System Set-up to configure this time.
- Pressing the **Sleep** button on the confirmation dialog box when powering off.




Figure 3-11 Confirmation Dialog Box When Power off

The following events can exit sleep mode:

- Open the cover of the system.
- Press any hard key on the control panel or move the trackball if the system is not in deep sleep mode.
- Press the Power on/off key if the system is in deep sleep mode.

4 Exam Operation

4.1 How to Start an Exam

1. Press the **<Patient>** key and enter patient information, or select a scheduled patient from the modality worklist.

If there is no previous exam, pressing the **<Patient>** key will bring you directly to the Patient Information Page (see figure 4-3 below).

If a previous exam is still active you will see the following dialog:




Figure 4-1 Exam Confirmation Dialog

The following options are available:

- **End Exam:** Select this to end the current exam and return to live imaging to start a new exam.
- **Edit Current:** This lets you edit the Patient Information for the current exam. It does not start a new exam.
- **New Exam:** Select this to start a new exam.
If **Same Patient** is checked, selecting **New Exam** will end the previous exam and create a new exam for the same patient. The main screen will display the Patient Information Page with the previously entered patient information except for the exam accession number.
If **Same Patient** is unchecked, selecting **New Exam**, a blank Patient Information Page will be displayed for entering patient information for a new patient.
Tick the check box of **Same Patient** when operating multiple exams for same patient.
- **Cancel:** Exits the dialog without starting or ending an exam.
- **Abort Exam:** Aborts the current exam. Select **Abort Exam** button, and an abort reason selection page will be displayed on the screen. Click the drop-down box to select the abort exam reason.

Note: The **Abort Exam** button is displayed only when the MPPS function is enabled. See section 11.2.2.4. for details.

2. Press **OK** on the touch screen or press the **<Patient>** key again to start scanning.
3. To change transducer or exam preset, press the **<Transducer>** key, and then the **Transducer** touch screen provides you choices of available transducers and exam presets, as the figure below.




Figure 4-2 Example of Transducer Touch Screen

4.2 How to End an Exam

There are two ways to end an exam:

- Pressing the <Patient> key, as described above, and then selecting **New Exam**. This both ends the exam and displays the Patient Information Page for the next exam.
- Pressing the <Patient> key, as described above, and then selecting **End Exam**. This brings up a dialog to confirm you want to end the exam, but does not invoke the Patient Information Page for the next exam.

4.3 How to Restart an Exam

1. Select an exam from the Exam Database within the time limit selected in **Patient Set-up** menu. For the setting of time limit, refer to section 11.1.2 *Patient Set-up*.
2. Press **Restart** on the touch screen to continue/edit the exam that was performed on the selected patient. You can also modify the patient information by pressing <Patient>-->**Edit Current**.

4.4 The Patient Information Page

The Patient Information Page is used to enter or modify patient demographic data. The following figure is an example:

The screenshot shows a dark-themed user interface for entering patient information. At the top, there are four input fields: 'ID' (empty), 'Last Name' (empty), 'First Name' (empty), and 'Accession' (empty). Below these is a 'DOB' field containing 'MM/DD/YYYY' with a plus sign and a dropdown for 'Age' with units 'Years'. A row of tabs is present: ABD, OB (which is selected and highlighted in blue), GYN, Pediatric, SMP, Vascular, Cardiac, Urology, and Other. Underneath the tabs are various data entry fields: 'Gender' dropdown, 'LMP' dropdown with a plus sign, 'GA' dropdown, 'EDD' dropdown with a plus sign, 'G/P/A' dropdown with a plus sign, 'Fetus' dropdown, 'Height' dropdown with 'cm' suffix, 'Weight' dropdown with 'Kg' suffix, 'BSA(m²)' dropdown, 'BMI' dropdown, 'Study Description' text input, 'CPT Code' dropdown, 'Ref. Physician' dropdown, 'Dx. Physician' dropdown, 'Operator' dropdown, 'Additional Materials' dropdown, and a large 'Comment' text area. A 'More' button is located at the bottom left.

Figure 4-3 Patient Information Page(OB Exam)

The top three lines are for entering the patient last name, first name, ID, exam accession number, and DOB (Date-of-Birth) or age. If date of birth is entered, the age is automatically calculated.

Note:

By default, the patient name has two fields: family name and given name. It can be configured to be one field in the Patient Setup screen (See section 11.1.2 for details).

The next line displays tabs of multiple exam presets, and the associated patient information fields are displayed below this line. The patient information needed to fill in changes with different exam presets.

All the possible patient information fields you may need to fill in are listed below:

- Gender: Select the patient's gender: "M" (Male), "F" (Female), "O" (Other), or "<blank>".
- LMP: Last Menstrual Period (yyyy/mm/dd or mm/dd/yyyy). If LMP is entered then GA and EDD are calculated. An LMP more than 300 days ago is considered invalid.
- BBT: Enter the ovulation day when the BBT (Basal Body Temperature) reaches the peak. If BBT is entered then GA and EDD are calculated. A BBT more than 300 days ago is considered invalid.

Note: LMP and BBT can be switched to enter the value according to your needs.

- GA: Gestational Age (xxWyD), it is auto calculated when LMP/BBT is entered (only in OB Exam). A GA of more than 42W6D is considered invalid and not displayed.
- EDD: Estimated Date of Delivery (YYYY/MM/DD,MM/ DD/YYYY,DD/ MM/YYYY). EDD can be auto calculated when LMP/BBT is entered, or you can manually enter the EDD. The system will calculate GA and LMP/BBT automatically based on the EDD you manually entered.
- Fetus: Enter 1 up to 4 for multiple gestations.

- G/P/A: G stands for Gravida, P stands for Para and A stands for Aborta. Enter values for each in the fields separated by slashes.
- Study Description: enter the study description.
- Height: Enter the patient's height. The units can be set in the Patient section of Setup.
- Weight: Enter the patient's weight. The units can be set in the Patient section of Setup.
- BSA: Body Surface Area, it is auto-calculated and displayed when Height/Weight is entered.
- BMI: Body Mass Index, it is auto-calculated and displayed when Height/Weight is entered.
- HR: Enter the Heart Rate.
- BP: Enter the Blood Pressure.
- PSA: Prostate Specific Antigen.
- PPSA Coefficient: Predicted Prostate Specific Antigen.
- Ref. Physician: Enter the name of the Ref.Physician.
- Dx. Physician: Enter the name of the Dx.Physician.
- Operator: Enter the name of the person performing the exam.
- Additional Materials: Record other materials used during the ultrasound exam. You can set whether to display Additional Materials on the Patient Information Page. See section 11.2.2.4. for details.
- CPT code: Current Procedural Terminology code.
- Comment: Enter any additional comments.

While the Patient Information Page is displayed the following buttons are displayed on the touch screen and Patient Information Page:




Figure 4-4 Patient Information Touch Screen

Press **OK** to exit the Patient information Page and save the patient information.

Press **Cancel** to exit the Patient Information Page without storing any of the entered data.

Press **Clear All** to clear all of the demographic fields except for name and ID.

4.5 Modality Worklist

Modality worklist provides a list of scheduled patients derived from a DICOM server. It is available only when a DICOM server is configured and worklist is enabled.

The worklist is shown to the left of the Patient Information Page, as shown below.

The screenshot displays the 'Modality Worklist' interface. On the left, there is a list of patients with columns for 'Patient Name' and 'Patient ID'. To the right of the list is a large form for entering patient details. The form includes fields for ID, Last Name, First Name, DOB (MM/DD/YYYY), Age (Years), Gender, LMP, GA, EDD, G/P/A, Fetus, Height (cm), Weight (Kg), BSA(m²), Study Description, Ref.Physician, Dx.Physician, Operator, Additional Materials, Comment, RP Description, RP ID, RP Code Meaning, Scheduled Date, and Scheduled Time. At the bottom of the form are buttons for 'OK', 'Clear All', and 'Cancel'. A 'Filter' button is located at the bottom left of the list area. The top right corner of the interface shows the date and time: 11/10/2021 20:12:02.

Figure 4-5 Modality Worklist Display

The worklist is displayed on the left side of the Patient Information Page in two columns labeled patient name and patient ID. Clicking on the header of each column will sort the list for the corresponding column.

Select one patient from the list and the detailed patient information is entered into the associated fields on the patient information page, with the option to edit or complete. Then press **OK** on the touch screen to start an exam.

Filter: The worklist can be filtered from either of the following search bases.

- From the downloaded worklist: Enter Patient ID or Patient name in the **Filter** box below the worklist to filter the worklist to the scheduled exams that contain the entered text.
- From the Worklist Server: Enter the relevant information in the information boxes above the worklist to display the scheduled exams that contain the entered text in the worklist. You can set whether to display these information boxes on **Worklist** setting page under the **Filter** item. Configurable information includes **Modality (US)**, **AE Title**, **Patient Info**, and **Date Range**. See section 11.2.2.3 for details.

Update: Press to query the patient data and update the list manually.

Hide List: Press "<<" symbol to hide the list. Press the ">>" symbol to display the list and other buttons.

More: Press to display more scheduled exam information, including **Scheduled Date Time**, **Scheduled AE Title**, **Request Code Meaning**, **Request Procedure ID**, **Request Description**.

5 Imaging





5.1 B-mode

5.1.1. Using B-mode

1. Press on the console to enter B mode.
2. Perform the image scanning.
3. Adjust Image parameters to optimize the image.

5.1.2. B-mode Image Optimization

The following touch controls can be used to optimize the B-mode image.

Name	Control	Description
TGC		The Time Gain Compensation control (TGC) adjusts the gain of the image at different depths. Each slider can be adjusted separately, or you can drag your finger vertically to adjust all sliders to a new setting.
Dynamic Range		The Dynamic Range, or log compression, adjusts how echo intensities are converted to brightness. A high dynamic range will display more shades of gray, while a low dynamic range will display fewer shades of gray and a more contrasty image.
eSRI		eSRI is Speckle Reduction Imaging. There are 4 levels: Off, Low, Med. and High. High level provides more aggressive speckle reduction.
Persistence		Persistence averages frames together to reduce random noise. There are 4 options: Off, Low, Med., and High. The persistence level corresponds to the number of frames averaged. The frame rate is unchanged.
Frequency		Frequency allows selection of the fundamental or harmonic frequencies used for imaging. The Harmonic option must be invoked to access the harmonic frequencies. Frequency selection is available during live imaging.
Harmonic		The Harmonic control invokes and exits harmonic imaging. While in harmonic imaging the control is highlighted and an

		'H' is displayed in the B-mode frequency field. Depending on the transducer, there may be multiple harmonic frequencies.
Spatial Compounding		Spatial Compounding combines images derived from multiple angles to reduce speckle, reduce shadow artifacts, and enhance contrast resolution. Spatial compounding is an on/off control.
Focus Number		Focus Number adjusts the number of foci displayed. As the number of foci increases, image uniformity across depth will increase, but the frame rate will decrease.
Focus Position		Focus Position adjusts the depth of the focus or foci. Upward presses move the focus shallower, regardless of the U/D invert status of the image.
Gray Map		Gray Map adjusts the post-processing map used on the B-mode image. In general, higher map numbers correspond to more contrast in the image.
Colorize		The Colorize control adds a color tint to the B-mode image.
Tint		The Tint control changes the color tint being used. If Colorize had been off, changing the Color map control will automatically activate it.
Left/Right		The Left/Right invert control is indicated by a backward R and is used to toggle the left/right orientation of the image. The Edan E orientation marker at the top of the image switches with the left/right invert to match the orientation marker on the transducer.
Up/Down		The Up/Down invert control is indicated by an upside-down R and is used to toggle the up/down orientation of the image. The TGC curve is also re-oriented with Invert On, so that the top of the TGC curve corresponds to the top of the image on the screen.

FOV		The Field of View control adjusts the image width. Full, Large, Med. and Small settings are available. As the image becomes narrower, the frame rate increases.
Steer		The Steer control is only available for linear transducers and steers the B-mode image left or right, without moving the transducer. This function can be particularly useful when visualizing needles or other objects that are enhanced by a perpendicular beam. If Spatial Compounding or Trapezoid is turned on, using Steer will exit Spatial Compounding or Trapezoid.
Trapezoid		Press to invoke the touch screen for Trapezoid function, supported only by linear transducer. After Trapezoid function is enabled, the trapezoid imaging will be displayed, and the size of the image area of trapezoid image can also be adjusted.
Image Type		B-mode supports presets for Detail, General, and Penetration. See section 10.3.2 for more information.
Line Density		Adjusts the line density to optimize the lateral resolution for the best possible image. The higher the line density, the higher the lateral resolution, but the lower the frame rate.
Needle		Press to invoke the touch screen for Needle Biopsy Guide function. See section 6.4 for more information.
Acoustic power		Adjusts the acoustic output power of the activate transducer and is only available in live imaging. Higher acoustic power numbers correspond to increased sensitivity in the image with improved penetration, but the ALARA principle should be followed in actual clinical situations.







Center Line		Press to activate the Center Line function. Refer to section 6.6 for details.
eLearn		Press to access the instruction guide for basic scanning and for nerve block.
LGC		Lateral Gain Control (LGC) adjusts the gain along the scan line to improve the lateral resolution of the image. Press LGC touch screen key to display 8 gain control sliders. Move the slider downwards to decrease the gain, while move the slider upwards to increase the gain. Each slider can be adjusted separately, or you can drag your finger horizontally to adjust all sliders to a new setting.
3D 4D		Press to activate 3D/4D imaging mode. Refer to section 5.8 <i>3D/4D mode</i> for details.
Quad		Press to activate quad imaging mode. Refer to section 7.3.2 <i>Quad Imaging</i> for details.
Elastography		Press to invoke Elastography mode. Refer to section 5.11 for details.
Quick Rotation		Four radio buttons used to quickly rotate the image. Available angles are: 0°/90°/180°/270°.

Table 5-1 B-mode Touch Screen Controls

5.2 Color Mode

5.2.1. Color Mode Variants

The system supports 3 types of Color Doppler imaging:

- Color (Color Doppler): This is velocity Color Doppler that shows direction and velocity of flow. Different colors represent different velocities and positive flow has different colors than negative flow.
- PDI (Power Doppler Imaging): PDI shows the power, or intensity, of the Doppler signal. PDI is typically more sensitive to low levels of flow, but cannot distinguish the velocity or direction of the flow.
- DPDI (Directional Power Doppler Imaging): This is similar to DPI in that it shows the power of the Doppler signal instead of the velocity. However, it does map positive flow to different colors than negative flow.

5.2.2. Using Color Mode

1. Perform the image scanning to get a good image in B mode;
2. Press **<Color>** to enter B+Color mode and display ROI box;
3. Adjust the size and position of ROI box.
Presses on **<Set>** switch between the status of adjusting the size and position of ROI box. Use trackball to adjust.
4. Press **PDI**, **DPDI** or **Color** mode key on the touch screen to switch Color Doppler modes when necessary;
5. Adjust image parameters to optimize the Color image.

5.2.3. Color Image Optimization

The following touch controls can be used to optimize the Color image.

Name	Control	Description
Color Mode Variation		A set of radio-buttons display the color modes that are available on the current transducer, and let you switch between them. See section 5.2.1 for details.
Scale		Scale adjusts the range of velocities that are displayed. Upward presses increase scale and downward presses decrease it. It is available in Velocity, PDI, and DPDI. It is not available in Freeze/Cine.
Baseline		The Baseline control adjusts the Color baseline. Upward presses move the baseline up on the scale and downward presses move the baseline down. Baseline is not available in PDI mode.
Invert		Normally, signals above the baseline are positive velocities (moving toward the transducer). However, when Invert is pressed then negative velocities are above the baseline. Invert does not affect the baseline position. Invert is not available in PDI mode.
Wall Filter		The Filter control removes excessive noise from movement of vessel walls. Options of Low, Med. and High are available. Higher wall filter level will suppress more strong single of the vessel walls, but low flow signal will be missing.
Map		Adjusts the current map for the active color variation.

Persist		Persistence determines the number of frames that are averaged together for display. Levels of Off, Low, Med. and High are available.
Smooth Filter		The smoothness filter determines the spatial filtering that is applied to the Color image. Higher filter levels create a smoother image. Upward presses increase the filter. Downward presses decrease the filter.
Threshold		When the system receives both B-mode and color signals from a region within the Color ROI box, the Threshold determines whether to display overlapping signals as grayscale or color. In Color mode, higher Threshold values display more color, and lower Threshold values display more grayscale. Upward presses increase threshold. Downward presses decrease threshold.
Frequency		Frequency determines the transmit frequency used by color Doppler. Upward presses increase the frequency. Downward presses decrease the frequency.
Steer		This control is only available for linear transducers. It steers the Color ROI box angle left or right.
Image Type		Color Doppler supports image presets for Low Flow, Medium Flow, and High Flow.
Dual Live		To activate split screen with simultaneous live B/Color and live B. The live B image without color and the same live B image with color are simultaneously displayed on each side of the image field. Freezing the image will freeze both sides simultaneously. Cine review will review both sides simultaneously.

Dynamic Range		The Dynamic Range, or log compression, adjusts how echo intensities are converted to brightness. A high dynamic range presents a flatter, less contrasty color display, while a low dynamic range presents a more contrasty color display. Only available in PDI/DPDI mode.
Line Density		Adjusts the line density to optimize the lateral resolution for the best possible image. The higher the line density, the higher the lateral resolution, but the lower the frame rate.
Acoustic Power		Adjusts the acoustic output power of the activated transducer. It is only available in live imaging. Higher acoustic power numbers correspond to increased color sensitivity and penetration, but the ALARA principle should be followed in actual clinical situations.
Color Hide		Hides/Shows the Color ROI box.
Velocity Distribution		Displays the distribution of blood flow velocity in a histogram on the left of image area. (Available on frozen status.)

Table 5-2 Color Mode Touch Screen Controls




5.3 PW Mode

5.3.1. Using PW Mode

1. Perform the image scanning to get a good image in B mode or B+Color(DPI/DPDI) mode;
 2. Press <PW> on the console to display sample line;
 3. Use the trackball, <Angle> knob and other controls to adjust the position of the sample line and the size and angle of the sample gate;
- Note:
1. Pressing <Set> key can switch between the status of adjusting the position of the sample line and adjusting the size of the sample gate.
 2. Rotate the <Angle> knob to adjust the angle correct; Pressing <Angle> knob can quickly switch the angle of the sample line.
4. Press <Update> on the console to enter B+PW or B+Color(PDI/DPDI)+PW mode and display Doppler strip.
 5. Adjust image parameters to optimize the Doppler strip.
 6. When spectrum is displayed, pressing <Update> toggles between acquiring the Doppler strip and acquiring the reference image.

5.3.2. PW Image Optimization

The following touch controls can be used to optimize the PW image.

Name	Control	Description
Scale		Scale adjusts the range of velocities that are displayed. Upward presses increase scale and downward presses decrease scale. Increasing scale when the PW cursor is relatively deep may result in invoking HPRF, if it is configured. See section 5.3.3 for details.
Baseline		The Baseline control adjusts the Doppler baseline. Upward presses move the baseline up on the screen and downward presses move the baseline down.
Invert		Normally, signals above the baseline are positive velocities (moving toward the transducers). However, when Invert is pressed, the negative velocities are displayed above the baseline. Invert does not affect the baseline position.
Quick-Angle		Adjusts the angle correct quickly to one of 60°/-45°/-30°/-15°/0°/15°/30°/45°/60 °.

Filter		The Filter control removes excessive noise from movement of vessel walls. Options of Low, Med. and High are available. Higher wall filter level will suppress more strong signal of the vessel walls, but low flow signal will be missing.
Colorize		Switches between grayscale and colorized (pseudo-color) post-processing maps.
Gray Map Tint		Adjusts the current post-processing, either grayscale or tinted.
Dynamic Range		The Dynamic Range, or log compression, adjusts how signal intensities are converted to brightness. A high dynamic range will display more shades of gray, while a low dynamic range will display fewer shades of gray and a more contrasty Doppler display.
Gate Size		Gate adjusts the size of the sample volume gate. Upward presses increase the gate size. Downward presses decrease the gate size.
Sweep Speed		Sweep adjusts the sweep speed of the Doppler strip. Options of Slow, Low, Med., High and Fast are available. Upward presses increase sweep speed. Downward presses decrease sweep speed.
Strip Size		Changes the relative size of the Doppler strip compared to the reference image. Full, Large, Med. and Small are available.

Volume		Volume adjusts the audio volume of the Doppler strip. This can be adjusted in pre-Doppler to set the initial volume upon invoking Doppler acquisition.
Duplex Triplex		This determines if the strip mode and reference image are imaging simultaneously or not. In Duplex mode, either the Doppler strip or the reference image is updated continuously. In Triplex mode, both the Doppler strip and reference image are updated simultaneously.
Image Type		Spectral Doppler supports image presets for Low Flow, Medium Flow and High Flow.
Steer		This control is only available for linear transducers and steers the Doppler cursor angle left or right.
Frequency		This determines the Doppler transmit frequency used for imaging.
Auto Trace		Press to activate the Auto Trace function on a real-time or frozen PW Doppler strip. The Auto Trace function automatically traces the spectral Doppler waveform and records several measurements on selected waveforms.
Trace Side		Press one of the three options to specify which side of the Doppler baseline to take measurements from: Up: traces positive portion of waveform (above baseline). Down: traces negative portion of waveform (below baseline). Both: traces waveform on both sides of baseline.

Acoustic Power		Adjusts the acoustic output power of the activated transducer. It is only available in live imaging. Higher acoustic power numbers correspond to increased sensitivity in the Doppler display and improved penetration, but the ALARA principle should be followed in actual clinical situations.
Side-by-side		This is an on/off control. When On, the PW-Mode strip is displayed side-by-side with the B-mode image. When Off, the PW-Mode strip is displayed below the B-mode image

Table 5-3 PW Mode Touch Screen Controls

5.3.3. HPRF

Conventional PW Doppler scales are limited by the Nyquist limit. High Pulse Repetition Frequency (HPRF) allows the system to exceed the Nyquist limit by having multiple Doppler pulses in the body at the same time. In HPRF imaging, multiple Doppler gates are displayed since the multiple Doppler pulses could be giving information from different depths. HPRF is automatically invoked when needed to maintain the requested depth and scale. For example, if the system is at a high scale and you move the cursor deeper, the system may automatically invoke HPRF. This can also happen if the cursor is deep and you increase scale.

If HPRF is active, you will see multiple Doppler gates on the reference image. If you do not want to be in HPRF, decrease the scale or move the primary PW gate to a shallower location until only one gate is displayed.

5.4 CW Mode

5.4.1. Using CW Mode




CW mode is only available on phased array transducer.








1. Perform the image scanning to get a good image in B mode or B+Color(DPI/DPDI) mode;
2. Press <**CW**> on the console to display sample line;
3. Use the trackball to adjust the position of the sample line;
4. Rotate the <**Angle**> knob to adjust the angle correct; Pressing <**Angle**> knob can quickly switch the angle of the sample line.
5. Press <**Update**> on the console to enter B+CW or B+Color(PDI/DPDI)+CW mode and display Doppler strip.
6. Adjust image parameters to optimize the Doppler strip.
7. When spectrum is displayed, pressing <**Update**> toggles between acquiring the Doppler strip and acquiring the reference image.

In CW mode, pressing on <**PW**> on the console will switch PW mode directly.

5.4.2. CW Image Optimization

The following touch controls can be used to optimize the CW image.

Name	Control	Description
Scale		Scale adjusts the range of velocities that are displayed. Upward presses increase scale and downward presses decrease it.
Baseline		The Baseline control adjusts the Doppler baseline. Upward presses move the baseline up on the screen and downward presses move the baseline down.
Image Type		Strip Doppler supports image presets for Low Flow, Medium Flow, and High Flow.
Invert		Normally, signals above the baseline are positive velocities (moving toward the transducer). However, when Invert is pressed then negative velocities are above the baseline. Invert does not affect the baseline position.

Quick-Angle		Adjusts the angle correct quickly to one of -60°/-45°/-30°/-15°/0°/15°/30°/45°/60°.
Filter		The Filter control removes excessive noise from movement of vessel walls. Options of Low, Med. and High are available. Higher wall filter level will suppress more strong single of the vessel walls, but low flow signal will be missing.
Colorize		Switches between grayscale and tinted (pseudo-color) post-processing maps.
Gray Map Tint		Adjusts the current post processing, either grayscale or tinted.
Dynamic Range		The Dynamic Range, or log compression, adjusts how signal intensities are converted to brightness. A high dynamic range will display more shades of gray, while a low dynamic range will display fewer shades of gray and a more contrasty Doppler display.
Sweep Speed		Sweep adjusts the sweep speed of the Doppler strip. Options of Slow, Low, Med., High and Fast are available. Upward presses increase sweep speed. Downward presses decrease sweep speed.
Strip Size		Changes the relative size of the Doppler strip compared to the reference image. Full, Large, Med. and Small are available.
Volume		Volume adjusts the audio volume of the Doppler strip. This can be adjusted in pre-Doppler to set the initial volume upon invoking Doppler acquisition.
Auto Trace		Press to activate the Auto Trace function on a real-time or frozen CW Doppler strip. The Auto Trace function automatically traces the spectral Doppler waveform and records several measurements on selected waveforms.

Auto Trace Direction		Press one of the three options to specify which side of the Doppler baseline to take measurements from: Up: traces positive portion of waveform (above baseline). Down: traces negative portion of waveform (below baseline). Both: traces waveform on both sides of baseline.
Acoustic Power		Adjusts the acoustic output power of the activated transducer. It is only available in live imaging. Higher acoustic power numbers correspond to increased sensitivity in the Doppler display and improved penetration, but the ALARA principle should be followed in actual clinical situations.
Side-by-side		This is an on/off control. When On, the CW-Mode strip is displayed side-by-side with the B-mode image. When Off, the CW-Mode strip is displayed below the B-mode image

Table 5-4 CW Mode Touch Screen Controls

5.5 M-mode

5.5.1. Using M-mode

1. Perform image scanning to get a good image in B mode;
2. Press **<M>** to display M strip and sample line;
3. Move the trackball to adjust the sample line;
4. Adjust image parameters to optimize M strip.

5.5.2. M-mode Image Optimization

The following touch controls can be used to optimize the M-mode image.

Name	Control	Description
Colorize		Switches between grayscale and colorized (pseudo-color) post-processing maps.
Gray Map Tint		Adjusts the current post-processing, either grayscale or tinted.

Dynamic Range		The Dynamic Range, or log compression, adjusts how echo intensities are converted to brightness. A high dynamic range will display more shades of gray, while a low dynamic range will display fewer shades of gray and a more contrasty M-mode display.
Focus Pos		The focus position set in B-mode applies to M-mode as well. Upward presses move the focus shallower, regardless of the U/D invert status of the M-mode. Downward presses move the focus deeper.
Sweep Speed		Sweep adjusts the sweep speed of the M-mode strip. Options of Slow, Low, Med High and Fast are available. Upward presses increase sweep speed. Downward presses decrease sweep speed.
Strip Size		Changes the relative size of the M-mode strip compared to the reference image. Full, large, Med. and small are available.
Side-by-side	Side by Side	This is an on/off control. When On, the M-Mode strip is displayed side-by-side with the B-mode image. When Off, the M-Mode strip is displayed below the B-mode image
Line Persistence		The line Persistence determines how many M-mode lines are averaged together for the display (similar to persistence in B-Mode). Off, Low, Med. and High settings are available.
Frequency		Frequency determines the transmit frequency used by M-Mode. Upward presses increase the frequency. Downward presses decrease the frequency.


Acoustic Power		Adjusts the acoustic output power of the activated transducer. It is only available in live imaging. Higher acoustic power numbers correspond to increased sensitivity and penetration in the image, but the ALARA principle should be followed in actual clinical situations.
Anatomic M		Invokes Linear Anatomic M mode. See section 5.6 for details.

Table 5-5 M-Mode Touch Screen Controls

5.6 Anatomic M Mode

Anatomic M mode allows you to manipulate the position and angle of M sample line and displays real-time M strip image. Only phased array transducer supports Anatomic M mode.

The Anatomic M mode supported on this system includes Linear Anatomic M mode and Curved Anatomic M mode.

5.6.1. Linear Anatomic M Mode

Using Linear Anatomic M mode:

- Press **Anatomic** button on the M-mode touch screen to invoke Anatomic M mode.
- Press **Show one**, **Show two** or **Show three** button on the touch screen to display single or multiple M sample lines.
- Use trackball to adjust the position of M sample line.
- Rotate **<Angle>** knob on the console to adjust the angle of M sample line.
If multiple M sample lines are displayed pressing **<Set>** key can switch between the M sample lines.
- Adjust image parameters to optimize M strip.

Optimizing Anatomic M Image:

For touch screen controls consistent with those in M mode, please refer to section 5.5.2 M-mode Image Optimization. This section only introduces special touch screen controls in Anatomic M mode.




Name	Control	Description
M sample lines		Displays only one M sample line.
		Displays two M sample lines.
		Displays three M sample lines.

Table 5-6 Anatomic M Mode Touch Screen Controls

5.6.2. Curved Anatomic M Mode

In curved Anatomic M mode, the distance/time curve is derived from the curved sample line manually drawn on the image.

Using Curved Anatomic M mode:

1. Press **Curved AMM** button on the M-mode touch screen to invoke the Curved Anatomic M mode.
2. Move the cursor to the start point on the B image, and press <**Set**> key to fix it. The digital number "1" is marked beside the point.
3. Move the cursor to next point, and press <**Set**> key to fix it. The sample line segment between these two points is displayed in green.
Pressing **Undo** on the touch screen will cancel the current point and activate the previous point.
4. Repeat step 3 to place other points. Each point is marked with a number in sequence.
5. Press <**Set**> key to complete this curved sample line.

Editing the Curved Sample Line:

■ Editing the sample line:

Press **Edit** on the touch screen to enter the editing status, and the cursor becomes a small green box. Move the cursor over one point, press <**Set**> key to activate this point, and then move the cursor to change the shape of the curved sample line. Press <**Set**> key to finish the editing.

■ Removing the sample line:

Press **Delete** on the touch screen to remove the curved sample line.

Optimizing Curved Anatomic M Image:

The controls for optimizing Curved Anatomic M image are consistent with those in M mode, please refer to section 5.5.2 M-mode Image Optimization.

5.7 Color M Mode

Color M mode superimposes color encoded information on M mode strip to indicate the direction, velocity and timing of cardiac flow and tissue movements. The direction of cardiac tissue movements can be identified by color changes. Only phased array transducer supports Color M mode.

The Color M mode includes Color Flow M mode and Color Tissue M mode.

5.7.1. Using Color M Mode

1. Enter Color M mode
 - Enter Color Flow M mode
 - In B+M mode, press <Color> key;
 - In B+Color mode, press <M> key to display M sample line.
 - Enter Color Tissue M mode: configure user defined key <F1>/<F2> as TDI (see section 11.1.1 for details);
 - In M mode, press the pre-defined TDI key.
 - Press the pre-defined key to enter TDI mode, press <M> key to display M sample line.
2. Adjust the position of ROI box or M sample line.
3. Press <Update> key to display the M-mode strip
4. Adjust image parameters to optimize the image.

5.7.2. Color M Image Optimization

Touch screen controls that can be adjusted in Color M mode are the same as those in B mode, Color mode and M mode (certain parameters may not be adjusted), please see section 5.1.2, section 5.2.3 and section 5.5.2 for details.

5.8 TDI Mode

Tissue Doppler Imaging (TDI) mode shows information about low-velocity and high-amplitude tissue motion, usually used to evaluate cardiac tissue motion. Only Phased array transducer supports TDI mode.

There are four types of TDI modes available on this system:

- TVI (Tissue Velocity Imaging) mode: shows the speed and direction of tissue motion on real-time Color image.
- TEI (Tissue Energy Imaging) mode: shows the energy of tissue motion on real-time Color image.
- TVD (Tissue Velocity Doppler) mode: shows the speed of tissue motion on Strip Doppler image.
- TVM (Tissue Velocity Motion Imaging) mode: shows the cardiac motion through a direct angle.

5.8.1. Using TDI mode

Configure the function of user defined key F1 or F2 as TDI.

- In Color mode, press the pre-defined key on the console to enter TVI mode.
- In TVI mode, press **TEI** on the touch screen to enter TEI mode.
- In Pre-PW mode, press the pre-defined key on the console, and then press <**Update**> to enter TVD mode.
- In M mode, press the pre-defined key on the console, and then press <**Update**> to enter TVM mode.

5.8.2. TDI Image Optimization

Touch screen controls for optimizing TVI image are the same as those in Color mode, see section 5.2.3 Color Image Optimization for details. Touch screen controls for optimizing TVD image are the same as those in PW mode, see section 5.3.2 PW Image Optimization for details.

5.9 3D/4D Mode

3D/4D mode is only available on a Wobble transducer. To activate pre-3D or Pre-4D mode: press the **3D** or **4D** button on the touch screen in B-mode.

5.9.1. Pre-3D/Pre-4D

The Pre-3D and Pre-4D mode supports defining the 3D and 4D acquisition location and settings. Figure 5-1 shows an example of the pre-3D image.




Figure 5-1 Pre-3D Image

The VOI (Volume of Interest) indicates the portion of the image that will be used for 3D. The top horizontal line is the clip plane. The initial volume rendering will show everything below this line. It can be adjusted to a curved line upwards and downwards and its top point can be adjusted to left or right by using the trackball. Also the position/size of the VOI can be adjusted using the trackball. Press **<Set>** key to toggle among VOI position, VOI size and horizontal line adjusting.

The touch screen controls in Pre-3D and Pre-4D:

Name	Control	Description
Image Quality	<div style="text-align: center;"> ^ Quality ▼ </div>	Adjusts the trade-off between speed and image quality of the acquisition. Settings include High (quality), Middle, and Fast.
Angle	<div style="text-align: center;"> ^ Angle 60 ▼ </div>	Adjusts the angle of the volume acquisition. Upward presses increment the angle. Downward presses decrement the angle.

Surface/ Skeleton	<input checked="" type="radio"/> Skeleton <input type="radio"/> Surface	These two radio buttons determine if the acquisition is optimized for looking at Skeleton or Surface.
3D	<input checked="" type="radio"/> 3D	Press to switch to Pre-3D.
4D	<input checked="" type="radio"/> 4D	Press to switch to Pre-4D.
Start	<input checked="" type="radio"/> Start	Start an acquisition.

Table 5-7 Pre-3D Touch Screen

5.9.2. 3D Volume Sweeping

Select **Skeleton** or **Surface** on the Pre-3D touch screen and press **Start** button or <Update> key to start image acquisition.

During the process of 3D volume sweeping, the images swept in VOI box are displayed in the image area.




Figure 5-2 3D Image Scanning



While scanning, the sector  in the right bottom is filled gradually, and no buttons on the control panel and touch screen can be activated.

5.9.3. 3D Image Review

The system will enter to the 3D review status after finishing one sweep.










Figure 5-3 3D Image Review

There are two image modes: Volume imaging mode and multi-slice imaging mode. Figure 5-3 shows Volume Imaging Mode in quad screen with a Baby Face volume rendering.

- Quadrant A shows a slice through the data that mimics the original ultrasound image.
- Quadrant B is orthogonal to A, as if the transducer had been rotated 90 degrees.
- Quadrant C is orthogonal to A and B, showing a slice that is parallel to the transducer face.

The following table shows the touch screen controls that are available in Volume Imaging Mode

Name	Control	Description
Volume/ Multi-slice	Volume Multi-Slice	These two radio buttons toggle between the Volume display and the Multi-Slice display.
A/B/C/3D	A B C 3D	These four radio buttons select which quadrant is the focus of the navigation/panning controls. A/B/C are three orthogonal slices through the volume, while '3D' is the rendered image.
Reset	Reset	Reset the operation of pan, rotate and zoom to the initial condition.

Single, Dual, Quad		These three radio buttons switch the display to show 1, 2, or 4 images at once. Single shows the 3D image, dual shows the A slice and 3D image, Quad shows three MPR slices and 3D image.
VOI		Press to activate the function of adjusting VOI or clip plane. Use the trackball to adjust and press <Set> to switch between VOI and clip plane.
Cut		This is a folder of cut functions with various cut tools inside. See below for details.
Cut tools		These are two radio buttons. The region inside or outside the trace will be cut. To draw the trace, move the trackball and press <Set> to locate the start point, use trackball to draw trace and second press <Set> to locate the end point.
		These are two radio buttons. The region inside or outside the box will be cut. To draw the box, move the trackball and press <Set> to locate the top left point, move the trackball and a box is displayed. Press <Set> to locate the lower right point of the box.
		These two radio buttons switch the size of the eraser. To use eraser to cut, move the trackball and press <Set> to locate the first point, move the trackball and the path that the eraser moves is cut, and then press <Set> to complete the cut.
Undo		Undo the previous cut operation.
Redo		Redo the previous undo operation.
Undo All		Return to the condition before cutting.
Render		This is a folder containing various render modes inside. Render modes of Surface and Max. are available. Surface: helpful for surface imaging, for example, fetus face, hand or foot. Max: displays the maximum intensity of gray values in the VOI. This is helpful for viewing bony structures.
Threshold		Adjust the threshold of 3D image.

Brightness		Adjust the brightness of 3D image.
Contrast		Adjust the contrast of 3D image.
3D Smooth MPR Smooth		Adjust smoothness of ABC slices and 3D images. Higher filter levels create a smoother image. Upward presses increase the filter. Downward presses decrease the filter.
Quick Rotation		Four radio buttons used to quickly rotate the image. Available angles are: 0°/90°/180°/270°.
Rotation X		Rotate the image by the X-axis of the activated window.
Rotation Y		Rotate the image by the Y-axis of the activated window.
Rotation Z		Rotate the image by the Z-axis of the activated window.





New Volume		End the 3D volume sweeping and return to the pre-3D interface
MPR Review		MPR (multi-planar reconstruction) review function. After this button is activated, the 3D volume is hidden and two perpendicular lines appear on the selected quadrant. These two lines are color matched with the other 2 MPR quadrants and show where the three planes intersect. Move trackball left/right or up/down to change location of lines and intersection on the MPR's. Moving one line will move the other perpendicular line.
3D Tint		Select 3D tint.
MPR Tint		Select MPR tint.
eFace		Press to show the baby face automatically. Only available in Surface render mode.

Table 5-8 Volume imaging Mode Touch Screen

Image area and touch screen controls in multi-slice imaging mode:











Figure 5-4 Multi-slice Imaging Mode

In figure 5-4, the first image shows the basis slice, other images are orthogonal to the basis slice and parallel to each other. Lines on the basis slice indicate the locations of the parallel slices. If there are more slices than images then the un-displayed slices are shown with a dotted line. A number below each parallel slice shows the slice location in the basis slice, with 0 being the middle slice.

Control	Name	Description
A/B/C		These three radio buttons determine which slice is the required parallel slice. These three choices are the same as on the Volume display in quad mode.
3*3, 2*2, 3*2		These three radio buttons determine the layout of the display.
Reset		Reset the operation of pan, rotate and zoom to the initial condition.
Number		Select how many slices to use
Distance		Adjust the distance between slices.
Next		When there are more slices than can be displayed at once this control cycles through the subset of slices displayed.
Tint		Select multi-slice tint.
Smooth		Adjust smoothness of A\B\C slices. Higher filter levels create a smoother image. Upward presses increase the filter. Downward presses decrease the filter.

Rotation X		Rotate the basis slice by the X-axis of the activated window. Parallel slices change with the rotation operation.
Rotation Y		Rotate the basis slice by the Y-axis of the activated window. Parallel slices change with the rotation operation.
Rotation Z		Rotate the basis slice by the Z-axis of the activated window. Parallel slices change with the rotation operation.

Table 5-9 Multi-slice Mode Touch Screen

5.9.4. 4D Volume Acquisition

In Pre-4D mode, select **Skeleton** or **Surface** first, adjust the VOI box and then press **Start** button on the touch screen or the <Update> key to begin sweep.

5.9.5. 4D Live Volume

4D Live volume continuously sweeps and displays successive 3D volumes. As shown in figure below, image in the left is A slice and image in the right is the live 3D volume rendering.




Figure 5-5 4D Volume Sweeping Image

5.9.6. 4D Cine

During the process of 4D live volume imaging, press the <Freeze> button on the control panel to enter the 4D cine mode. A cine replay scroll bar appears below the images. Use the trackball to replay the images. For the selected frame, user can execute all operations that are available in 3D review status. Press <Freeze> again to return to the live image.




Figure 5-6 4D Cine

5.10 Panorama

Panorama constructs an extended field of view image as the user slides the transducer along its long axis. Panorama is available only with Linear transducers.

This system also provides Color Panoramic imaging so that you can get color flow information on the panoramic image.

Caution

1. The panoramic image is for reference only. Diagnosis must not be based on results achieved from panoramic image alone. The quality of panoramic image depends on sonographer's scanning techniques and experience, therefore affecting the measurement accuracy on a panoramic image.
2. Make sure enough coupling gel is applied along the scan path.
3. Always move the probe slowly and steadily during the scanning process.
4. Auto measurement is not available on a panoramic image.

Acquiring panoramic image:

1. Enter B or Color mode.
2. Press **Panorama** key on the touch screen to enter panoramic imaging mode.
3. Adjust image parameters to optimize the image.

In Color Panoramic Imaging mode, roll the trackball to adjust position of ROI box. After pressing the <Set> key, the size of ROI box can be adjusted by the trackball.

4. Press the <**Update**> key to start acquisition.
5. Slide the transducer along its longitudinal axis. The image will extend to incorporate the newly imaged anatomy.
6. When the full anatomy has been acquired, press the <**Freeze**> hard key. System also will enter the panorama review state when exceeding the default time.

Speed Indicator

During an acquisition, a speed indicator bar on the screen will show the current scan speed. Keep the indicator in the green center of the graphic in order to achieve best results.



Figure 5-7 Panorama Speed Indicator

Panoramic Image Review

After acquisition, the system enters review status and the completed panoramic image is redisplayed to fit on the screen. In the review status, Zoom, Angle, Comments, Body Marks and Measurements are supported on the panoramic image.

5.11 Elastography

Elastography imaging maps the elastic properties of soft tissue with different colors in a region of interest by estimating the strain before and after tissue distortion caused by external or internal forces. Only L12-5Q and L17-7HQ transducers support Elastography under Carotid, Thyroid, Breast, Testis and MSK exam modes.





Figure 5-8 Example of Strain Elastography Display

5.11.1. Using Elastography Mode

To Use Elastography Mode:

1. Perform the scan in B mode and locate the lesion.
2. Press **Elasto** on the touch screen to invoke Elastography mode.
3. Adjust the size and position of ROI box if necessary.
Use **<Set>** key to toggle between adjusting the position and the size. Use trackball to adjust.
4. Create a distortion in the tissue (e.g. push the body surface with a transducer) according to clinic experiences while you are scanning the lesion. The strain pressure generated is indicated by the pressure curve in real-time at the bottom of display screen.



5. Press **Freeze**.

To Measure Strain Ratio:

Refer to Section 8.1.1 B-mode Generic Measurements for detailed steps of measuring Strain Ratio.

Caution

1. Proper pressure should be applied to the lesion when scanning according to the clinic situation and experience, otherwise misdiagnosis may result.
2. The ROI box should be adjusted to proper size and position, in which lesion and adequate normal tissue should be included for better diagnosis.

3. The Elastography image is for reference only. The image quality and measured results in Elastography mode always depend on the accuracy of the procedure performed. Any clinic diagnosis should be verified with other effective diagnosis methods.

5.11.2. Elastography Image Optimization

The following touch controls can be used to optimize the Elastography image.






Name	Control	Description
Opacity		Adjusts the opacity feature of Elastography image. Higher level provides more opacity.
Smooth		Adjusts smoothness of Elastography image. Higher filter levels provide a smoother image.
Map		Adjusts the postprocessing map used on Elastography image.
Persistence		Persistence averages frames together to reduce random noise of Elastography image. The persistence level corresponds to the number of frames averaged. The frame rate is unchanged; as each new frame is acquired, it is averaged with the preceding frames.
Dynamic Range		The Dynamic Range, or log compression, adjusts how echo intensities are converted to brightness. A high dynamic range will display more shades of gray, while a low dynamic range will display fewer shades of gray and a more contrasty image.
Invert		Inverts the Elastography color bar, and therefore inverts the colors of stiffer tissue and softer tissue.
Exit		Exits Elastography mode.

Table 5-12 Elastography Touch Screen Controls

5.12 ECG

The ultrasound system can be configured with an optional ECG module. The ECG module obtains ECG signals via ECG patient cable to display ECG waveform synchronously with the ultrasound image. The ECG signals can be used as time reference in cardiac exam for marking the systolic and end diastolic moments.

WARNING

1. The ECG waveforms displayed on the main screen are not intended for ECG diagnosis and monitoring.
2. The ECG module and electrodes are not intended for intra-cardiac use or direct cardiac contact.
3. Do not use the ECG function on the patient with pacemaker.
4. Only the ECG module, patient cable and electrodes supplied by EDAN can be used.
5. Only authorized service personnel can service the ECG module.
6. The conductive parts of electrodes and associated connectors, including the neutral electrode, should not contact any other conductive parts including earth.
7. The electrodes must be removed from the patient before a high-frequency surgical equipment is used on the patient.
8. The quality of the ECG waveform depends on the stability and conductivity of the electrodes because patient's movements can cause artifacts.
9. Only the ECG applied part is defibrillation-proof. Please remove transducer and other accessories from patient before defibrillation. Always refer to the defibrillator's user manual when performing defibrillation.
10. After defibrillation, the ECG waveform recovers within 10 seconds if the correct electrodes are used and applied according to the manufacturer's instructions.
11. Always do the follows prior to operation:

Check the patient cable for visible evidence of any damage. If any damage is found, a new patient cable should be used.

Connect the electrodes to patient correctly following the manufacturer's instruction. If a ECG lead is off, the ultrasound system will display " ECG Lead Off " message..

12. The disposable electrodes can only be used for one time. Do not use the electrodes passing its expiry date.
13. The disposable electrodes should be disposed of according to the local regulations.
14. Regularly check, clean and maintain the patient cable and electrodes following the manufacturer's instruction.
15. The chest lead of the 5-lead patient cable is not intended to output signal and waveform display. But in order to ensure patient safety, please attach the chest lead correctly on the patient.

5.12.1. ECG Touch Screen Controls

The following touchscreen controls impact the ECG function:

Name	Control	Description
ECG		Displays or hides ECG waveforms and heart rate value on the main screen.
Gain		Adjusts the gain of ECG waveform.
ECG Lead		Selects the ECG lead from I, II and III lead as the ECG waveform source.
Position		Moves the position of ECG waveform vertically in the image area.
Invert		Inverts the display of ECG waveform upside down for better viewing of the cardiac image.
R Trigger		Triggers the image scanning when the R waveform of ECG signal is detected.

The system also supports **AC Filter** settings to select the AC filter frequency according to the AC power you use. Enter System Settings ->POC page to select 50 Hz or 60 Hz.

5.12.2. ECG Basic Operations

1. Invoke ECG function.

Invoke a phased array transducer as the currently active transducer, and select Cardiac exam preset. Connect the ECG module to the system and the system will display a Physio tab, press the tab to enter ECG page and adjust ECG controls on the touch screen.

2. Connect patient cable and electrodes.

Connect the patient cable to the ECG connector on the ultrasound system first.

Place electrodes on the patient's body as the figure below (Take 3-lead placement of AHA standard as an example).




Figure 5-9 3-lead Placement of AHA Standard

3. The image area displays real-time ECG waveform and heart rate value. There is a red mark on the ECG waveform indicating the temporal position of ultrasound image in relation to the ECG waveform.
4. Switch imaging modes and adjust relevant parameters to optimize the image.
5. Adjust ECG Gain and select ECG lead if necessary.
6. Freeze the image and review.
7. Exit ECG mode.

Remove electrodes from patient's body and disconnect ECG module from the ultrasound system.

5.12.3. ECG Review

Pressing <Freeze> key will freeze ultrasound image and ECG waveform at the same time. Moving trackball left or right will playback the ECG waveform and ultrasound image together. The red mark on the ECG waveform indicates the time of the currently displayed image. In this manner, you can move the red mark to locate the diastolic or systolic moments and check relevant ultrasound image at that moment.

6 Transducers and Biopsy

6.1 Transducers

No.	Model	Type	Application	Applied Region
1	L17-7HQ	Linear	Small Parts(Thyroid, Testes, Breast) Peripheral Vascular Musculoskeletal	Body Surface
2	P5-1Q	Phased array	Adult Cardiac Abdominal Pediatric Cardiac Adult Cephalic	Body Surface
3	E8-4Q	Micro Convex	Fetal / Obstetrics Trans-vaginal Trans-rectal Urology Gynecology	Intra-cavity
4	C5-2Q	Convex	Abdominal Fetal / Obstetrics Urology Gynecology Musculoskeletal	Body Surface
5	L12-5Q	Linear	Abdominal Small parts(Thyroid, Testes, Breast) Peripheral Vascular, Musculoskeletal	Body Surface
6	L17-7SQ	Linear	Intra-operative Musculoskeletal Peripheral Vascular	Body Surface/ Intra-operative
7	MC8-4Q	Micro Convex	Pediatric Abdominal Neonatal Cephalic Musculoskeletal Peripheral Vascular	Body Surface
8	MC9-3TQ	Micro Convex	Pediatric Abdominal Neonatal Cephalic Peripheral Vascular Musculoskeletal	Body Surface

9	P7-3Q	Phased Array	Adult Cardiac Pediatric Abdominal Pediatric Cardiac Neonatal Cephalic	Body Surface
10	L12-5WQ	Linear	Abdominal Small parts(Thyroid, Testes, Breast) Peripheral Vascular, Musculoskeletal	Body Surface
11	E10-3BQ	Micro Convex	Fetal / Obstetrics Trans-vaginal Trans-rectal Urology Gynecology	Intra-cavity
12	E10-3HQ	Micro Convex	Fetal / Obstetrics Trans-vaginal Trans-rectal Urology Gynecology	Intra-cavity
13	C6-2MQ	Convex	Fetal / Obstetrics Abdominal Gynecology	Body Surface
14	C5-1Q	Convex	Abdominal Fetal / Obstetrics Urology Gynecology Musculoskeletal	Body Surface
15	L12-5HQ	Linear	Small Parts(Breast, Testes, Thyroid) Peripheral Vascular Musculoskeletal Abdominal	Body Surface
16	ECL12-3Q	Biplane transducer	Abdominal Gynecology Urology	Intra-cavity

Table 6-1 Transducer Model & Application

Note: The abdominal application includes ABD and lung scanning on transducers C5-2Q, C5-1Q and P5-1Q and includes lung scanning on transducers L12-5Q and L12-5HQ.

6.2 Using Transducers

Understanding a Transducer:

Figure 6-1 takes L12-5Q transducer to show an example of a transducer.




Figure 6-1 Typical transducer

No.	Name	Function
1	Transducer head	Converts electrical signals to sound waves, and then converts received echoes back to electrical signals. The tip of the transducer is the acoustic lens.
2.	Center line mark	Indicates the center line position of the transducer, which is usually used for out-of-plane needle guide.
3.	Transducer model	Displays the transducer model.
4	Needle-guided bracket fixing tabs and grooves	Provides mounting support for the needle-guided bracket.
5.	Transducer orientation mark	The side of orientation mark on the transducer corresponds to the side of orientation mark on the display screen.
6	Transducer cable	Transmits electrical signals between the transducer head and the transducer connector.
7	Transducer connector	Connects the transducer to the ultrasound imaging system.

Image Orientation Mark

The image orientation mark on the display screen and on the transducer are shown as below. The side of orientation mark on the transducer corresponds to the side of orientation mark on the display screen. Ensure orientation marks on the display screen and transducer are on the same side prior to scanning.




Figure 6-2 Image Orientation Mark

Proper Use of Transducers

To extend the service life and maintain optimum transducer performance, please operate as follows:

- Inspect transducer cable, socket and acoustical window of the transducer periodically.
- Shut down the machine before connecting or disconnecting the transducer.
- Do not drop the transducer onto the floor or collide with hard objects. Otherwise it will be damaged easily.
- Do not heat the transducer.
- Do not pull or bend the transducer cable.
- Coupling gel can only be used on the head of the transducer, and it should be wiped off after use.
- Clean and disinfect the transducer after every use.
- The acoustical window and the shell of the transducer should be examined frequently.

CAUTION


1. Do not disinfect or clean transducers under high temperature. The temperature should be below 45°C.
2. To avoid damaging the device, the disinfection method is limited to regular maintenance of devices in hospitals. Disinfecting instruments should be cleaned first.
3. The coupling gel adapted to the transducer is a medical ultrasound coupling gel. Use only ultrasound coupling gel that complies with local regulations. When using ultrasound coupling gel, please follow the instructions given by the coupling gel manufacturer.
4. To minimize disease transmission, legally marketed, sterile coupling gel is required to use for intra-cavitory and intra-operative procedures.

Use of Transducer sheath

CAUTION

1. Always wear gloves to perform the following steps.
2. To minimize disease transmission, legally marketed, sterile transducer sheath is required to use for intra-cavitory and intra-operative procedures.
3. Use a pyrogen-free transducer sheath for intra-operative procedures.
4. DO NOT use an expired transducer sheath. Check whether the term of validity has expired prior to using transducer sheaths.
5. The single-use sheath should comply with the local regulations.
6. Before cleaning or disinfecting the transducer, remove the sheath gently and discard it. Put on a new single-use sheath before using the transducer.
7. Use of protective sheath with natural rubber latex may lead to a severe anaphylactic reaction in persons sensitive to the natural latex protein.
8. Transducer sheath should be used with all clinical situations where infection is a concern.

To install transducer sheath:



1. Place an adequate amount of sterile coupling gel in the protective sheath and/or on the acoustic window of the transducer;
2. Insert the transducer into the sheath;
3. Pull the sheath over the transducer and cable until the sheath is fully extended. Check and eliminate bubbles between the surface of the transducer and the sheath. Be careful not to pierce the sheath.
4. Secure the sheath using the bands or clips supplied with the sheath;
5. Inspect the sheath to ensure that there are no damages (i.e. holes or tears).

6.3 Transducer Cleaning and Disinfecting

Transducers should be cleaned and/or disinfected as necessary or between use with a recommended cleanser or disinfectant. Disconnect the transducer from the system prior to cleaning and disinfecting.

6.3.1. Cleaning

The validated cleaning agents for cleaning the transducers are:

- Ethanol (75%)
- Isopropanol (70%)

Cleaning agents should be applied and removed using a clean, soft, sterile, non-abrasive cloth or paper towel.

To clean the transducers:

1. Disconnect the transducer from the system.
2. Wear sterile protective gloves to prevent infection.
3. Remove all residual foreign matters from the transducer using sterile cloth or paper towel immediately after examination. For the situation where a protective sheath is used, the protective sheath should be removed first and discarded.
4. Wipe the surface of transducer and cable with a sterile cloth dampened with the cleaning solution until no visible contaminants remain.
5. After cleaning, wipe off the cleaning solution with a new sterile cloth or towel dampened with tap water until no visible cleaning agent remains.
6. Wipe off with a dry sterile cloth to remove residual moisture.
7. Leave the transducer to air dry.
8. If the transducer is not visually clean at the end of the cleaning steps, please repeat the cleaning steps through step 4 to step 7.
9. Inspect the transducer to ensure that there is no damage. The transducer should be disposed of properly when any damage is found.

WARNING

1. Unplug the transducer from the system prior to cleaning or disinfecting.
2. To avoid infection, always use protective gloves when performing cleaning and disinfecting procedures.
3. Prohibit infiltration of any type of liquid into the device or the transducer.

6.3.2. Disinfecting

Selecting a proper way to disinfect your transducers based on your transducer applied region:

Transducer Applied Region	Transducer Type	Disinfecting Intensity	Disinfecting Method
Contact intact body surface	Body surface	LLD	Spraying or wiping
Contact mucous membrane	Intra-cavity	HLD	Immersion
Contact normally sterile tissue	Intra-operative	Sterilization	Immersion

Note: LLD=Low-level Disinfection; HLD=High-level disinfection

The validated disinfectants for transducer are:

Disinfectants	Disinfecting Intensity	Disinfecting Method
Ethanol (75%)	LLD	Spraying or wiping
Isopropanol (70%)	LLD	Spraying or wiping
Cidex OPA (0.55%)	HLD	Immersion
Cidex Glutaraldehyde(2.4%)	HLD, Sterilization	Immersion

Note: The disinfectants used for high level disinfection and sterilization mentioned above are FDA-cleared.

WARNING

1. Unplug the transducer from the system prior to cleaning or disinfecting.
2. To avoid infection, always use protective gloves when performing cleaning and disinfecting procedures.
3. To avoid infection, ensure that expiration date of the disinfecting solution has not passed.
4. Please clean the transducer prior to disinfection.

Disinfecting by spraying or wiping:

1. Disconnect the transducer from the system.
2. Wear protective gloves to prevent infection.
3. Clean and dry the transducer according to the methods in section 6.3.1 *Cleaning*.
4. Prepare the disinfectant solution (75% ethanol or 70% isopropanol).
5. Spray the solution to the transducer interface or wipe it with a sterile cloth dampened with the disinfectant solution. Follow the disinfectant manufacturer's recommended contact time and mode.
6. Rinse the transducer according to the disinfectant instructions. Wipe the transducer with a dry sterile cloth or leave the transducer to air dry.
7. Inspect the transducer to ensure that there is no damage.

Note:

If Ethanol or Isopropanol is used for both cleaning and disinfecting, then a new sterile cloth is required for the disinfection step.

Disinfecting by Immersion:

1. Disconnect the transducer from the system.
2. Wear protective gloves to prevent infection.
3. Clean and dry the transducer according to the methods in section 6.3.1 *Cleaning*.
4. Prepare the disinfectant solution (Cidex OPA 0.55% or Cidex Glutaraldehyde 2.4%). Refer to the instructions provided by the disinfectant manufacturer for the concentration of the disinfection solution, method of dilution, method of disinfection, temperature and cautions during use.
5. Place the cleaned and dried transducer in contact with the disinfectant (refers to figure 6-3 for the contacting area) for the time specified by the disinfectant manufacturer. For example, the contact time recommended by the manufacturer for soaking in Cidex Glutaraldehyde(2.4%) is at least 45 min.

6. Rinse the transducer thoroughly with sterile water to remove all chemical residues. For example, it is required to flush the transducer after soaking in Cidex Glutaraldehyde(2.4%) with plenty of sterile water (about 2 gallons) at least one time. Or, follow the complete rinsing instructions provided by the disinfectant manufacturer to rinse the transducer.
7. Wipe off the water on the transducer with a dry sterile cloth. Leave the transducer to air dry.
8. Inspect the transducer to ensure that there is no damage.




Figure 6-3 Depth of the Transducer Immersed into Disinfectant

WARNING

1. Do not immerse the transducer connector. If the cable connector is immersed, do not plug the connector into the system. Rinse the connector under running water and dry it thoroughly. If necessary, contact EDAN for service.
2. Prohibit infiltration of any type of liquid into the device or the transducer.
3. Do not immerse the cable and connector of the transducer into solutions. Transducers can be submerged to, but not including, the strain relief of the transducer array. Do not immerse or soak any part of a transducer in any cleaning material not listed in the recommended list of disinfectant.
4. Use the immersion method to disinfect the intra-cavitory and intra-operative transducers.
5. Only non-immersion method can be used with solution of ethanol or isopropanol.
6. The immersion time should not exceed the time that is specified by the disinfectant manufacturer.
7. Patient contact area should be immersed into the solution while using the immersion method, but should not exceed the depth shown in figure 6-3.

6.3.3. Sterilization

Intra-operative transducers must be sterilized before the first use and after each exam.

Sterilizing the transducers:

1. Disconnect the transducer from the system.
2. Wear protective gloves to prevent infection.
3. Clean and dry the transducer according to the methods in section 6.3.1 *Cleaning*.
4. Prepare the disinfectant solution (Cidex Glutaraldehyde 2.4%). Refer to the instructions provided by the disinfectant manufacturer for the concentration of the disinfection solution, method of dilution, method of disinfection, temperature and cautions during use.
5. Place the cleaned and dried transducer in contact with the disinfectant (refers to figure 6-3 for the contacting area) for 10 hours. Or, follow the time specified by the disinfectant manufacturer to soak the transducer.
6. Flush the transducer with plenty of sterile water (about 2 gallons) at least one time. Or, follow the complete rinsing instructions provided by the disinfectant manufacturer to rinse the transducer.
7. Wipe off the water on the transducer with a dry sterile cloth. Leave the transducer to air dry.
8. Inspect the transducer to ensure that there is no damage.

WARNING

1. Do not sterilize the transducer using techniques such as autoclave, ultraviolet, gamma radiation, gas, steam, or heat. Severe damage may result.
2. If L17-7SQ transducer is applied to normally sterile tissue without using a sterile sheath, it must be sterilized. If L17-7SQ transducer is applied to normally sterile tissue using a sterile sheath, it should be sterilized, or disinfected (High-level disinfection).

6.3.4. Storage

WARNING

1. Dry the transducer after high-level disinfection or sterilization and store it in sterile environment.
2. Do not use the carrying case for storing the transducer, because the carrying case may become a source of infection.
1. Ensure the transducer is cleaned, disinfected, sterilized and completely dried before storage.
2. Store the transducer in a sterile environment or in a disposable sterile package.
3. Store the transducer under the following conditions:
 - a) Atmospheric Temp.: -20°C ~ +55°C
 - b) Relative Humidity: 15%~95% (Non-condensing)
 - c) Atmospheric Pressure: 70kPa ~ 106kPa.

6.4 Needle Biopsy Guide

NOTE:

Use proper sterile technique at all times when performing a biopsy.

Always follow these basic precautions:

WARNING


1. The needle guide bracket kits are not disinfected or sterilized before delivery. Sterilize the needle guide kit before the first use and after each use.
2. When performing biopsy procedures, use only sterile ultrasound gel that is certified to be safe. Manage the ultrasound gel properly to ensure that it does not become a source of infection.
3. Calibrate the needle guide kit (see section 6.4.3) under any of the following conditions:
 - a) The first time that each bracket/transducer combination is used.
 - b) If the bracket or transducer head is dropped or struck, or has evidence of wear.
 - c) If previous use has shown some drift of the needle from the center of the guidelines.
4. The displayed needle guide pathway on the EDAN video monitor is intended for reference during biopsy procedures. A variety of factors outside EDAN's control, such as changing tissue density, bending of the needle, off-axis pressure by the person holding the transducer, etc., may cause deflection of a needle outside of the displayed video pathway even when the transducer, needle guide, and the system software are all performing as intended and within manufacturing specification. The specialist performing a biopsy procedure must be aware of potential external factors when performing an invasive procedure.
5. Do not freeze the system when performing a biopsy.
6. EDAN needle guides are designed and manufactured to attach firmly to designated transducers and should not require excessive force to assemble or disassemble. Do not use a needle guide that requires excessive force or manipulation to assemble or disassemble.
7. A single-use sheath should be used on transducer when performing a biopsy.

6.4.1. Installing Needle Guide Bracket


WARNING

1. For illustration purpose only, transducer and bracket may be shown without a protective sheath. Always place a protective sheath on transducer and bracket to protect cross infection.
- a. BGK-L40UB/BGK-002/BGK-004/BGK-007/BGK-008/BGK-009/BGK-010/BGK-012**


The installation steps for these brackets are the same. Here we take one bracket for illustration.

Structures:**Installation and Use Steps:**


1. Place an appropriate amount of gel on transducer surface, and insert transducer into the sheath.
2. Loosen the locking knob to open the clamp of bracket. Attach the bracket to the transducer by aligning the locating markers on the bracket and the transducer. Properly secure the clamp of bracket with the locking knob. Ensure the bracket is firmly attached.




3. Loosen the angle knob to select a needle guide angle, and secure the angle knob.



4. Press the tab release and place the biopsy needle into the needle guide path. Use the adjusting knob to properly secure the needle.




5. After biopsy, press the tab release to remove the needle, and loosen the locking knob to remove the bracket from the transducer.



b. BGK-CR10UA/BGK-006


The installation steps for these brackets are the same. Here we take one bracket for illustration.

Structures:




Installation and Use Steps:

1. Place an appropriate amount of gel on transducer surface, and insert transducer into the sheath.
2. Loosen the locking knob to open the clamp of bracket. Attach the bracket to the transducer by aligning the locating markers on the bracket and the transducer.




3. Properly secure the clamp of bracket with the locking knob. Ensure the bracket is firmly attached, and then place the biopsy needle into the needle guide path.




c. BGK-005

Structures:




Installation and Use Steps:


1. Place an appropriate amount of gel on transducer surface, and insert transducer into the sheath.
2. Use the quick release to open the clamp of bracket. Align the locating markers on the bracket and the transducer and push the bracket to click into place.



3. Press the left and right side of the clamp as the figure below to attach the bracket to the transducer firmly.




4. Ensure the bracket is firmly attached, and then place the biopsy needle into the needle guide path.



d. BGK-001/BGK-003


The installation steps for these brackets are the same. Here we take one bracket for illustration.

Structures:



Installation and Use Steps:


1. Place an appropriate amount of gel on transducer surface, and insert transducer into the sheath.
2. Loosen the locking knob to open the clamp bracket. Attach the bracket to the transducer by aligning the locating markers on the bracket and the transducer. Properly secure the clamp of bracket with the locking knob.



3. Install the disposable Needle Guide.
- a. Select appropriate disposable needle guide to achieve target depth from skin line:

Specification	Depth
21G (1.0cm)	0.8 - 1.2 cm
21G (1.5cm)	1.3 - 1.7 cm
21G (2.0cm)	1.8 - 2.2 cm

- b. Install the needle guide to the needle guide holder, and then put in the biopsy needle:



6.4.2. Activating Needle Guide Function

To enable the needle guide function:

1. In the B mode imaging, press **Needle** button on touch screen. A needle touch screen UI is displayed. Press **Enable** button to active the Needle Guide function.
2. Press **Double Line** button to switch double line and single line as the Needle guide Line graphics.
3. Some needle guide brackets support multiple angles. If the current transducer supports such a guide then the **Line** paddle key appears. Pressing it selects guide lines of different angles. Each line represents a corresponding angle marked on the needle guide bracket.




Figure 6-4 Needle Guide Touch Screen

There is a depth and length mark on the guide line. The depth indicates the position of the mark in the image and the length indicates the distance along the guide line between the mark and the patient's skin surface. Move the trackball to adjust the position of the mark and the real-time depth and length values will be shown below the image.

WARNING

1. To avoid patient injury when using a multi-angle bracket, make sure that the same angle (A, B, C or D) is selected on both the bracket and the ultrasound system.

6.4.3. Calibrating the Needle Guide Line

WARNING

1. Calibrate the needle guide under any of the following conditions:
 - a) The first time a needle guide is used with a given transducer.
 - b) Any time the needle guide or transducer has been dropped or struck against a hard surface.
 - c) After repeated use.
2. Do not use the needle guide bracket if the needle does not track with the guide during calibration.




Figure 6-5 Needle Guide Calibration Touch Screen

To calibrate the guide line

1. Assemble the needle guide bracket on the transducer, and use the transducer to image a water bath or needle guide phantom.
2. From the Needle function on the B-mode touch screen, press the **Line** paddle key to select a guide line.
3. Press the **Calibration** button on the touch screen to display the **Angle** and **Position** paddle buttons.
 - Use the **Position** paddle to adjust the line horizontally until the origin aligns with the actual needle.
 - Use the **Angle** paddle to adjust the angle of the line until the entire line aligns with the actual needle.
4. Any changes will be saved as the default value automatically.

6.5 Needle Visualization

Needle Visualization is an image processing technology that enhances needle visibility. It is available in B-mode for all linear transducers.



Figure 6-6 Needle Enhancement Visualization

Needle Visualization is invoked by pressing the **Needle** button on B-mode touch screen, and then the **Enable** button in the Needle Visualization section of the Needle touch screen. The following parameters can be adjusted when it is active.

- **Enable:** Enables or disables Needle Visualization.
- **L/R:** press to display the angle line on left side or right side of the image field.
- **Shallow/Medium/Steep:** press to enhance the needle visibility for different needle inserted angles. For best results use the angle line that is closest to perpendicular to the needle path.




Figure 6-7 Touch Screen for Needle Enhancement Visualization

6.6 Center Line

The Center Line is a vertical dotted line displayed at the middle of the image field, representing the middle of ultrasound beam. The Center Line helps to locate the position and depth of a target disease focus for out-of-plane biopsy, lithotripsy and etc.

To use Center Line:

1. Press **Center-Line** on B-mode touch screen to activate Center Line.
2. A dotted center line with a depth mark is displayed vertically at the middle of the image field. The position and direction of the center line cannot be changed.
3. Move the transducer to locate the target.
4. Move the mark to the target and its depth will be displayed below the image.

Note:

Center Line is not available on Intra-cavity transducer.

6.7 Needle Guide Bracket Cleaning and Sterilization

NOTE:

1. Use proper sterilization technique at all times when performing a biopsy.
2. Ensure that protective gloves are worn.

WARNING

1. The needle guide bracket kits are not disinfected or sterilized before delivery. The operators must clean and sterilize the needle guide bracket kits before the first use and after each use.
2. Inspect the bracket for damage such as cracks or breakage. If damage is evident, discontinue use of bracket and contact your Edan representative for disposal guidance.
3. Sterilize the bracket before disposal or sending back to manufacturer for repair.

6.7.1. Cleaning

1. Wear sterile protective gloves to prevent infection.
2. Disconnect the needle guide bracket from the transducer after each use, and remove all visible residues from the needle guide bracket using a small and soft-bristled brush or other similar devices. Do the cleaning quickly before the needle guide bracket dries out.
3. Soak the needle guide bracket in the cleaning solution (Ethanol 75% or Isopropanol 70%) for at least five minutes. Use a soft-bristled brush to clean the needle guide bracket during the soaking.
4. Take out the needle guide bracket from the cleanser and wipe all residues with a sterile cloth.
5. Let the bracket air dry, or dry the bracket with a sterile cloth.
6. If the bracket is not visually clean at the end of the cleaning steps, please repeat the cleaning steps through step 3 to step 5.
7. Inspect the bracket to ensure that there is no damage. The bracket should be disposed of properly when any damage is found.

6.7.2. Sterilization

1. Wear sterile protective gloves to prevent infection.
2. Disconnect the bracket from the transducer, and remove all visible residues from the bracket using sterile cloth.
3. Clean and dry the bracket according to the methods in *section 6.7.1 Cleaning*.
4. Sterilize the bracket assembly by dynamic air removal steam sterilizer for at least four minutes at 132° C. Dry the bracket for at least 30 min after sterilization.
5. Inspect the bracket to ensure that there is no damage.

6.7.3. Storage

WARNING

1. Dry the bracket after sterilization and store it in sterile environment.
 2. Do not use the carrying case for storing the bracket, because the carrying case may become a source of infection.
-
1. Ensure the bracket is cleaned, sterilized and completely dried before storage.
 2. Store the bracket in a sterile environment or in a disposable sterile package.
 3. Store the bracket under the following conditions:
 - a) Atmospheric Temp.: -20°C ~ +55°C
 - b) Relative Humidity: 15%~95% (Non-condensing)
 - c) Atmospheric Pressure: 70kPa ~ 106kPa.

7 Features

7.1 Comment

The Comment function allows you add annotation to an image. The Comment function is invoked by pressing the <Comment> hard key on the console. Figure 7-1 shows an example touchscreen for the Comment function. The top portion of the screen shows comments that are pre-defined in presets. See section 10 for details on how to configure these. The bottom portion of the screen shows controls available while the Comment function is active. Table 7-1 gives an overview of these controls.




Figure 7-1 Comment Touch Screen

Button	Description
Home	Set the cursor in a pre-defined location.
Set Home	Set the current cursor location as the new Home location
Delete	Delete a whole text or text group or an arrow
Delete All	Clear all comments on the image area
Arrow	Create a new arrow for annotating
Keyboard	Show or hide a touch screen keyboard.
Exit	Press to exit the comments function.

Table 7-1 Comment Touch Screen Description

Adding comments

You can add either pre-defined comments or use a keyboard.

➤ Adding comments using the keyboard

1. Invoke the Comment function.
2. Press the “**Keyboard**” touch screen key to display a keyboard on the touch screen.
3. Move the cursor to the desired location and type the desired text.

➤ Adding comments using pre-defined comments

1. Invoke the Comment function
2. Move the cursor to the desired location and press the desired pre-defined comment.

Some of the pre-defined comments may be grouped together with a border surrounding them (such as ‘Rt’ and ‘Lt’ in figure 7-1). These are special keys that let you quickly replace one term with another, regardless of where the cursor is within a block of text. For example, if you had entered “Rt. Kidney” as a block of text, pressing the “Lt.” button would change that block to “Lt. Kidney” even if the cursor is not at the specific location.

➤ Adding arrows

1. Invoke the Comment function.
2. Press **Arrow** button on the touch screen to display an arrow at the current cursor location.
3. Move the arrow to the desired location. Note that while the arrow is being moved the orientation of the arrow is fixed.
4. Rotate the **<Angle>** knob on the console to adjust the orientation of the arrow.
5. Press **<Set>** key to confirm the arrow and you can now enter text at the end of the arrow.

If the “**Continuous Arrow**” is checked on General Comment Settings Screen, pressing **<Set>** key will confirm the arrow and display a second arrow. Repetition of this will add multiple arrows.

Modifying comments

1. Move the cursor to a desired comment, notice that an insert cursor appears in the text as the cursor moves over an existing block of text.
2. Enter text using either the keyboard or pre-defined comments. The new comments will be added to the old text.

Deleting comments

There are several ways to delete comments:

- ◆ Move the cursor to the desired block of comments and press the **Delete** button on the touch screen to delete that block of comments.
- ◆ Press the **Delete All** button on the touch screen to remove all comments.
- ◆ Press the **<Clear>** hard key on the console to remove all comments, body marks, and measurements.

7.2 Body Mark

Body Mark allows you add a body mark graphic to an image and indicate the location of the transducer using a transducer icon on that graphic. The Body Mark function is invoked by pressing the <Body Mark> hard key on the console. Figure 7-2 shows an example touch screen for Body Mark. The main portion of the screen shows a grid of body marks that are pre-defined in presets. See section 10 for details on how to configure these. The bottom portion of the screen shows controls available while the Body Mark function is active. Table 7-2 gives an overview of these controls.




Figure 7-2 Body Mark Touch Screen

Button	Description
Delete	Delete the graphics on the image area
Exit	Press to exit the body mark function.

Table 7-2 Body Mark Touch Screen Description

Adding a body mark:

1. Invoke the **Body Mark** function

The default body mark graphic appears on the main screen with the transducer icon shown in the default position.

2. Select a desired body mark graphic on the touch screen, that graphic replaces the default.
3. Move the position of transducer icon as needed. The orientation of the transducer icon can be changed with the <Angle> knob on the console.
4. Press <Update> key and roll the trackball to move the position of body mark graphic.
The <Update> key can be used to toggle between moving the transducer icon and moving the body mark graphic.
5. Press <Set> to complete the adding of a body mark.

NOTE: In dual image or quad imaging mode, body mark can be added separately on each image.

Deleting a body mark:

There are two ways of deleting a body mark graphic:

- Press **Delete** on the touch screen to delete the graphics on the image area.
- Press the <Clear> hard key to delete all body marks, comments, and measurements.

7.3 Split Display

7.3.1. Dual Imaging

Dual Imaging displays images side by side on the screen. During real-time imaging when Dual imaging is enabled, the active image is displayed in real-time and the other image is frozen.



Dual imaging is invoked by pressing the Dual hard key  on the console. Each single press of Dual key during real-time imaging activates the image on one side and the image on other side



becomes frozen. With both images frozen, each single press of Dual key  toggles between two images, but does not change the frozen status of the system.



In Dual mode, press the Single hard key  on the console to return to single image real-time scanning.

Dual Exit

Exit Dual using any of the following:

- Pressing the B, M, PW, CW hard key.
- Transducer change, preset recall, or new exam.
- Pressing the Single or Quad key.

Dual imaging is available in B and Color Doppler mode.

7.3.2. Quad Imaging

Quad Imaging displays images in four quadrants on the screen. During real-time imaging when Quad imaging is enabled, the active image is displayed in real-time and other images are frozen.

Quad imaging is invoked by pressing **Quad** touch screen button. Quad function button is a one-shot button. Each single press on it during real-time imaging activates one of the four images in the following order: from top left image to top right image, then to bottom left image and bottom right image. Each single press on it during frozen status switches among the four images in an order described above, but does not change the frozen status of the system.

Quad Exit


Quad is exited by any of the following:

- Pressing the B, M, PW, CW hard key.
- Pressing the Dual or Single hard key.
- Transducer change, preset recall, or new exam.

Color Doppler is available during Quad imaging.

7.4 Zoom

Zoom mode is available on the live or frozen image in B mode and Color mode. When the indicator of zoom function illuminates, rotate the physical Zoom knob on the console, as shown below, to zoom an image. The indicator of zoom function will illuminate whenever zoom function is available.



When in Zoom mode, use the trackball to pan the position of zoomed image and the bottom of the display screen displays a thumbnail of the full image with a green box on it indicating the currently zoomed area. The B image remains zoomed after entering other imaging modes.

Full Screen Zoom:

The Full Screen Zoom function can zoom in the image to full screen display. To use Full Screen Zoom:

1. Configure the function of user-defined key <F1> or <F2> as full screen zoom (See section 11.1.1 for details).
2. Press the user-defined key <F1> or <F2> to zoom in the image area and image parameter area.
3. Press the user-defined key <F1> or <F2> again to zoom in the image area only.
4. Press the user-defined key <F1> or <F2> again to exit the full screen zoom.

7.5 Cine Review

Press <Freeze> key on the console to freeze the image or select a stored cine clip, and the cine bar is displayed on the bottom of the screen, as shown below.




Figure 7-3 Typical Cine Bar in B/Color Mode




Figure 7-4 Typical Cine Bar in PW/CW/M/CM Mode

The cine can be reviewed manually or automatically.

Manual Review:

Move the trackball to review the cine frame by frame. As the trackball moves, the current cine number is displayed on the right of the cine bar.

Auto Review:

1. Set the start frame: in manual review status move the trackball to review frame by frame until the frame that you want to set as the start point, press **Set Start** button on the touch screen to select a frame as the start frame.
2. Set the end frame: in manual review status, move the trackball to review frame by frame until the frame that you want to set as the end point, press **Set End** button on the touch screen to select a frame as the end frame.
3. Adjust the review speed by the **Speed** paddle key.
4. Press **Play** button on the touch screen to review the cine within the set region automatically.

Or,

After freezing the system, rolling the trackball rightwards quickly could play the cine automatically. When the cine is playing, moving the trackball will stop the playing.

In dual/quad imaging, freeze the image, and press quad/quad to toggle between each window. The cine bar corresponds to the currently active image, and you can perform manual/auto review for the currently active image.

8 Measurements and Reports

The Measure function lets you perform measurements on a live or frozen image. The Measurement function is invoked by pressing the <Measure> hard key on the console. When measurement function is invoked, generic and application could be switched by the tabs on the main screen or touch screen.

Generic Measurements: These are simple tools like Distance or Area. There is no specific anatomy associated with these measurements and they do not appear in a report.

Application Measurements: These are measurements for specific anatomy or clinical conditions. The results can be entered into a report that can be printed later.

Understanding Measurement Main Screen Display

The following figure is an example of the measurements displayed on the left side of main screen. The measurements displayed on main screen vary with different imaging modes and exam presets. Here we take the measurement main screen display of B-mode Carotid preset for illustration:




Figure 8-1 Measurement Main Screen Display

Measurement main screen display is divided into three fields:

Field 1: Displays measurement labels and attributes:

- The first line displays labels of Application Measurements and Generic Measurements. Clicking on each of them displays its associated measurement items.
- The second and third line display the attributes of Application measurement: Left, Right, Proximal, Mid, Distal, Fetus A, Fetus B, Fetus C, Fetus D, etc. For example, in Carotid exams, IMT measurements can be done for right or left carotid; in Abdomen exams, measurements can be done for right or left kidney; in Vascular exams several measurements can be done in a Proximal, Mid, or Distal location; in a twin OB exam the OB measurements can be done on either fetus.

Field 2: Displays measurement groups.

All the measurement items supported by this ultrasound system are categorized into different groups based on clinic applications, which facilitates locating the desired measurement item on the main screen and touch screen. The measurement groups vary with the current active application measurement package or generic measurements. Selecting one measurement group will show its associated measurement items below in Field 3.

Field 3: Displays measurement items.

This field displays all currently available measurement items of the selected measurement group. Select one measurement item and then measuring operations are allowed on the ultrasound image.

Understanding Measurement Touch Screen Display

The following figure is an example of the measurement touch screen display. Here we take the application measurement touch screen display of B-mode Carotid preset for illustration. All the measurements displayed on the touch screen and main screen are consistent.




Figure 8-2 Application Measurement Touch Screen Display

No.	Name	Description	
A	Measurement label	Displays application and generic measurement labels. Pressing on any label will display its associated measurements on the touch screen.	
B	Measurement groups	Displays available measurement groups. Selecting one measurement group will show its associated measurement items below.	
C	Measurement items	Displays all available measurement items of the selected measurement group. Select one measurement item and then measuring operations are allowed on the ultrasound image.	
D	Controls	Application Measurement	When you want to perform one measurement which is not included in current application measurement package, pressing this button will bring you all the application measurements supported on this system, and then select the desired measurement.
		Exit	Exit measurement function.
		Undo	Undo the last operation.
		Delete Last	Delete the last measurement result.
E	Measurement attributes	Displays the attributes of some application measurements, such as Left, Right, Proximal, Mid, Distal, Fetus A, Fetus B, Fetus C, Fetus D, etc. Switch these attributes by the paddle keys. These attributes are only displayed when they are applicable.	
F	Tool	When one measurement supports different tools, one Tool paddle key will display for switching tools.	

8.1 Generic Measurements

Each imaging mode supports different types of generic measurements. This chapter describes all the generic measurements supported in each imaging mode.

8.1.1. B-mode Generic Measurements

The generic measurements supported in B-mode are listed in the table below.

No.	Measurement Group	Measurement Item	Remark
1.	Distance	Dist. 2 Point	2-point method
		Ratio D1/D2	2-point distance method
		Stenosis% Dist.	
2.	Circ/Area	Area Ellipse	
		Area Trace	
		Area Spline	
		Ratio A1/A2	Ellipse method
		Stenosis% Trace	
		Stenosis% Ellipse	
		Stenosis% Spline	
3.	Angle	Angle 3 Point	
4.	Volume	Volume 3 Dist.	
		Ellipse 1 Dist.	
5.	Vessel	Diam.2 point	2-point distance method
		Diam. Ellipse	Ellipse method
		Stenosis% Diam.	
		Stenosis% Area	
		IMT	2-point distance method
		VF Area	2-point distance method
6.	Eratio	Eratio-Ellipse	Only available for Elastography mode.
		Eratio-Trace	
7.	Color	Color Vel	Only available in Color mode.

8.1.1.1. Distance

The distance measurement measures the distance between two points.

2-Point Method:

1. Invoke the generic measurement function.
2. Select **Distance-> Dist. 2 Point**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point.
5. Move the caliper to the end point.

Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the position of start point and end point.

6. Press the **<Set>** key to fix the end point and complete the measurement.

8.1.1.2. Circumference/Area

Circumference/Area measurement can measure the circumference and area of a closed region. There are Ellipse, Trace and Spline methods.

Ellipse Method:

1. Invoke the generic measurement function.
2. Select **Circ/Area-> Area Ellipse**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point.
5. Move the caliper to show the ellipse and press the **<Set>** key to fix the end point. Move the trackball to adjust the size of the ellipse.
Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the ellipse diameter.
6. Press the **<Set>** key to complete the measurement.

Trace Method:

1. Invoke the generic measurement function.
2. Select **Circ/Area-> Area Trace**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point and start drawing the trace.
5. Moving the caliper to mark the trace outline.
6. Press the **<Set>** key to complete the trace.

Spline Method:

1. Invoke the generic measurement function.
2. Select **Circ/Area-> Area Spline**.
3. Move the caliper to the desired location.
4. Press the **<Set>** key to place the first point.
5. Repeat step 3~4 to place other points. A closed trace will be created after three points are placed.
6. If a point is not placed satisfactorily, press **Undo** button to remove it. Each press of **Undo** button removes one point.
7. Double press the **<Set>** key to complete the trace.

8.1.1.3. Angle

The Angle measurement can be done by 3-point method.

3-point Method:

1. Invoke the generic measurement function.
2. Select **Angle-> Angle 3 Point**.
3. Move the caliper to the vertex of the angle you are measuring, and press the **<Set>** key to fix the first point.
4. Move the caliper to one end of the angle, and press the **<Set>** key to fix the second point.
5. Move the caliper to the other end of the angle.
Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the

position of the three points that make up the angle.

6. Press the <Set> key to fix the third point and complete the angle measurement.

8.1.1.4. Volume

Volume can be measured with 3 Distances or 1 Ellipse+1 distance method.

3-Distance Method:

1. Invoke the generic measurement function.
2. Select **Volume-> Volume 3 Dist..**
3. Move the caliper to the start point.
4. Press the <Set> key to fix the start point.
5. Move the caliper to the end point.
Presses of the <Update> key will toggle between active calipers, allowing you to adjust the position of start point and end point.
6. Press the <Set> key to fix the end point and complete the measurement of the first distance.
7. Repeat step 3~6 to complete the measurements of the second and third distance. Then the Volume measurement result displays.

Ellipse+ 1 Distance Method:

1. Invoke the generic measurement function.
2. Select **Volume-> Ellipse 1 Dist.**
3. Perform one Ellipse measurement following the Ellipse method in section 8.1.1.2 Circumference/Area measurement.
4. Perform one Distance measurement following the 2-point method in section 8.1.1.1 Distance measurement.
5. Then the Volume measurement result displays.

8.1.1.5. Stenosis

Stenosis can be measured with Distance, Ellipse, Trace or Spline method.

1. **Distance Method:** Invoke the generic measurement function.
2. Select **Distance-> Stenosis% Dist..**
3. Perform two Distance measurements following the 2-point method in section 8.1.1.1 Distance measurement.
4. Then the Stenosis measurement result displays.

Ellipse Method:

1. Invoke the generic measurement function.
2. Select **Circ/Area-> Stenosis% Ellipse.**
3. Perform two Ellipse measurements following the Ellipse method in section 8.1.1.2 Circumference/Area measurement.
4. Then the Stenosis measurement result displays.

Trace Method:

1. Invoke the generic measurement function.
2. Select **Circ/Area-> Stenosis% Trace.**
3. Perform two trace measurements following the Trace method in section 8.1.1.2 Circumference/Area measurement.

4. Then the Stenosis measurement result displays.

Spline Method:

1. Invoke the generic measurement function.
2. Select **Circ/Area-> Stenosis% Spline**
3. Perform two spline measurements following the Spline method in section 8.1.1.2 *Circumference/Area* measurement.
4. Then the Stenosis measurement result displays.

8.1.1.6. Elastography Ratio

Elastography Ratio(Eratio) can measure the strain ratio between lesion and normal tissue. There are Ellipse and Trace methods.

Ellipse Method:

1. Invoke the generic measurement function.
2. Select **Eratio-> Eratio Ellipse**.
3. Measure the lesion (Displayed as A=XX%) following the Ellipse method in section 8.1.1.2 *Circumference/Area* measurement.
4. Measure the normal tissue (Displayed as B=XX%) following the Ellipse method in section 8.1.1.2 *Circumference/Area* measurement.
5. The system automatically calculates the strain ratio between lesion (A) and normal tissue (B). It is suggest to measure the lesion and normal tissue at the same depth.

Trace Method:

1. Invoke the generic measurement function.
2. Select **Eratio-> Eratio Trace**.
3. Measure the lesion (Displayed as A=XX%) following the Trace method in section 8.1.1.2 *Circumference/Area* measurement.
4. Measure the normal tissue (Displayed as B=XX%) following the Trace method in section 8.1.1.2 *Circumference/Area* measurement.
5. The system automatically calculates the strain ratio between lesion (A) and normal tissue (B). It is suggested to measure the lesion and normal tissue at the same depth.

8.1.2. M-mode Generic Measurements

The generic measurements supported in M-mode are listed in the table below.

No.	Measurement Group	Measurement Item	Remark
1.	Generic	Dist.2Point	2-point method
		Ratio D1/D2	2-point method
		Slope	
		Time	
		HR	
2.	Tei Index	COT	Only available for Cardiac exam
		ET	

8.1.2.1. Distance

The distance measurement measures the distance between two points at the vertical direction. To measure the distance:

1. Invoke the generic measurement function.
2. Select **Dist. 2 Point**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point.
5. Move the caliper to the end point.

Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the position of start point and end point.

6. Press the **<Set>** key to fix the end point and complete the measurement.

8.1.2.2. Slope

The Slope measurement measures the distance and time between two points, and calculates the slope. To measure Slope:

1. Invoke the generic measurement function.
2. Select **Slope**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point.
5. Move the caliper to the end point.

Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the position of start point and end point.

6. Press the **<Set>** key to fix the end point and complete the measurement.

8.1.2.3. Time

The Time measurement measures the time interval between two points. To measure Time:

1. Invoke the generic measurement function.
2. Select **Time**.
3. Move the caliper to the start point.

4. Press the **<Set>** key to fix the start point.
5. Move the caliper to the end point.

Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the position of start point and end point.

6. Press the **<Set>** key to fix the end point and complete the measurement.

8.1.2.4. HR

The HR measurement measures the time interval between two points, and calculates the heart rate. To measure HR:

1. Invoke the generic measurement function.
2. Select **HR** and choose the number of heartbeat from one to eight on the paddle key.
3. Move the caliper to the first heartbeat.
4. Press the **<Set>** key to fix the start point.
5. Move the caliper to the next beat.

Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the position of start point and end point.


6. Press the **<Set>** key to fix the end point and complete the measurement.

8.1.2.5. Tei Index

The Tei index measurement is useful for the assessment of ventricular systolic and diastolic function. Higher Tei index indicates decreased ventricular function.

To use the Tei measurement:

1. In Cardiac exams, invoke the generic measurement function on a Doppler strip.
2. Select **Tei Index**.
3. Measure **COT** (Mitral Valve Close-Open Duration) by caliper pairs.
4. Measure **ET** (Ventricular Ejection Time) by caliper pairs.
5. The system calculates the Tei index automatically. The illustration is shown below:



$$\text{Index} = \frac{a - b}{b} = \frac{(IVCT + IVRT)}{ET}$$

8.1.3. Strip Doppler Generic Measurements

The generic measurements supported in strip Doppler mode are listed in the table below.

No.	Measurement Group	Measurement Item	Remark
1.	Generic	PS	
		ED	
		RI	
		PI	
		PS,ED,RI,S/D	
		Time	
		HR	
		Manual Trace	
		Auto Trace	
2.	Generic	Spline Trace	
		Velocity	
		Manual Trace	
		Spline Trace	
		HR	Only available for Cardiac exam
		Time	
		PGMax	
3.	Vessel	Vol. Flow	Distance + Auto Trace
	Tei index	COT	Only available for Cardiac exam
4.		ET	
5.	dp/dt	dp/dt	

8.1.3.1. Velocity

Multiple types of velocity measurements are supported on Doppler Strip, for example velocity at any point, at PS or ED.

Velocity: measures the velocity at any point on the strip, and calculates PG.

1. Invoke the generic measurement function.
2. Select **Generic-> Velocity**.
3. Move the caliper to the desired point on the strip.
4. Press the **<Set>** key to fix the point, and then Velocity and PG results display.

PS/ED: measures the velocity at PS and ED points.

1. Invoke the generic measurement function.
2. Select **Generic-> PS or ED.**
3. Move the caliper to the PS or ED point on the strip.
4. Press the **<Set>** key to fix the point, and then PS or ED result displays.

RI: measures the velocity at PS and ED points, and calculates RI result.

1. Invoke the generic measurement function.
2. Select **Generic-> RI.**
3. Move the caliper to the PS point.
4. Press the **<Set>** key to fix the PS point.
5. Move the caliper to the ED point.

Presses of the **<Update>** key will toggle between active calipers, allowing you to re-position the PS point or ED point.

6. Press the **<Set>** key to fix the ED point and complete the measurement.

S/D: measures the velocity at PS and ED points, and calculates S/D result.

1. Invoke the generic measurement function.
2. Select **Generic-> PS, ED, RI, S/D.**
3. Move the caliper to the PS point.
4. Press the **<Set>** key to fix the PS point.
5. Move the caliper to the ED point.

Presses of the **<Update>** key will toggle between active calipers, allowing you to re-position the PS point or ED point.

6. Press the **<Set>** key to fix the ED point and complete the measurement.

8.1.3.2. Trace

The Trace measurement can provide a wide range of results, as shown below. The actual results displayed will depend on Measure Setup (See section 10.4 for details).

- PS
- ED
- MD
- TAMax
- PGMax
- PGMean
- PI
- RI
- S/D
- VTI
- Time
- AT
- DT
- HR

Trace measurement is only available on a frozen strip. There are Manual Trace, Spline Trace and Auto Trace methods.

Manual Trace Method:

1. Freeze the strip and invoke the generic measurement function.
2. Select **Generic-> Manual Trace**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point and start drawing the trace.
5. Moving the caliper to mark the trace outline.
Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the positions of the PS or ED points in the trace.
6. Press the **<Set>** key to complete the trace.

Spline Trace Method:

1. Freeze the strip and invoke the generic measurement function.
2. Select **Generic-> Spline Trace**.
3. Move the caliper to the desired location.
4. Press the **<Set>** key to place the first point.
5. Repeat step 3–4 to place other points. A trace will be created after three points are placed.
6. If a point is not placed satisfactorily, press **Undo** button to remove it. Each press of **Undo** button removes one point.
7. Double press the **<Set>** key to complete the trace.

Auto Trace Method:

1. Freeze the strip and invoke the generic measurement function.
2. Select **Generic-> Auto Trace**.

Note: press the touch screen paddle key **AT Side** can change the trace side to Up, Down or Both.

3. The trace waveform(s) automatically appear, and measurement result displays.

NOTE:

1. Auto trace measurement can only be activated on a frozen Doppler strip.
2. Live Auto Trace is available as a separate feature on the Doppler touch screen. To activate Auto Trace in real time mode, press **Auto Trace** button on PW touch screen.
3. The accuracy for Auto Trace measurement is $\pm 10\%$.

8.1.3.3. Time

The steps of time measurement are the same as those of time measurement in M mode. Please refer to section 8.1.2.3 for details.

8.1.3.4. HR

The steps of HR measurement are the same as those of HR measurement in M mode. Please refer to section 8.1.2.4 for details.

8.1.3.5. PI (Pulse Index)

PI measurement can be measured with manual trace method. To measure PI:

1. Freeze the strip and invoke the generic measurement function.
2. Select **Generic-> PI**.
3. Move the caliper to the start point.
4. Press the **<Set>** key to fix the start point and start drawing the trace.
5. Moving the caliper to mark the trace outline.
Presses of the **<Update>** key will toggle between active calipers, allowing you to adjust the positions of the PS or ED points in the trace.
6. Press the **<Set>** key to complete the trace.

8.1.3.6. Volume Flow

Volume Flow can be measured in Strip Doppler mode by the following method:

1. Freeze the strip and invoke the generic measurement function.
2. Select **Vessel-> Vol Flow**.
3. The system will first activate the measurement function on B image. Measure the vessel diameter by a 2-point distance method, and then the system traces the Doppler strip automatically. Press **<Set>** key to complete the measurement.
4. All the measured results are displayed in the measurement result window.

8.1.3.7. PG (Pressure Gradient)

PGMax and PGMean can be measured in Cardiac exams. The measurement method is manual trace. Please refer to the steps of manual trace method in *section 8.1.3.2 trace measurement* for details.

8.1.3.8. Tei Index

The steps of Tei index measurement are the same as those of Tei index measurement in M mode. Please refer to *section 8.1.2.5* for details.

8.1.3.9. dp/dt

The left ventricular dp/dt measurement is a useful index for evaluating myocardial contractility.

To use the dp/dt measurement:

1. In Cardiac exams, invoke the generic measurement function on a Doppler strip.
2. Select **dp/dt**.
3. Move the caliper to the position at the 100 cm/s scale on one of the cardiac cycles and press the **<Set>** key.
4. Move the caliper to the position at 300 cm/s scale on the same cardiac cycle and press the **<Set>** key. The time difference "dt" between the two positions come out.
5. The system calculates dp/dt based on the "dt" value. *Formula:*

$$\text{dp/dt} = 32/\text{dt} \text{ (mmHg/s)}$$

8.2 Application Measurements

Application Measurements have a pre-defined meaning and can be entered into a report. The system supports the following application packages, each with its own set of measurements, calculations and report:

- OB (including multiple fetuses)
- Abd
- Vascular
- Cardiac
- Gynecology
- Small Parts
- Urology
- Pediatric(including Neonatal)

When you select an application measurement from the touch screen it will automatically invoke the type of measurement it needs. For example, if you select “BPD” from the OB application it will automatically invoke a distance measurement. These measurements generally behave as described above for generic measurements. The results are entered into the report when the measurement is done.

Some application measurements can have multiple variations. For example, in a twin OB exam the OB measurements can be done on either fetus. As another example, in Vascular exams several measurements can be done in a Proximal, Mid, or Distal location. When a measurement has multiple variations, you will see buttons on the touch screen that let you pick which variation you are measuring.

Please refer to the Advanced User Manual for the calculation formulas and references.

8.2.1. Abdomen Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	Liver	Liver L	Liver Length	2-point distance in B-mode generic measurements
		Liver W	Liver Width	
		Liver H	Liver Height	
		Portal Vein	Portal Vein Diameter	
		CHD	Common Hepatic Duct	
1.2	Gall Bladder	GB L	Gallbladder Length	2-point distance in B-mode generic measurements
		GB H	Gallbladder Height	
		GB wall th	Gallbladder wall thickness	
		CBD	Common Bile Duct	
1.3	Pancreas	Panc duct	Pancreatic duct	2-point distance in B-mode generic measurements
		Panc head	Pancreatic head	
		Panc body	Pancreatic body	
		Panc tail	Pancreatic tail	
1.4	Spleen	Spleen L	Spleen Length	2-point distance in B-mode generic measurements
		Spleen H	Spleen Height	
1.5	Renal	Renal L	Renal Length	2-point distance in B-mode generic measurements
		Renal W	Renal Width	
		Renal H	Renal Height	
		Cortex	Renal Cortex thickness	
1.6	Aorta Diam		Aorta Diameter	
1.7	Bladder	Pre-BL L	Pre-void Bladder Length	Doppler generic measurements
		Pre-BL W	Pre-void Bladder Width	
		Pre-BL H	Pre-void Bladder Height	
		Post-BL L	Post-void Bladder Length	
		Post-BL W	Post-void Bladder Width	
		Post-BL H	Post-void Bladder Height	
Section 2: Doppler Measurements				
2.1	AA	PS ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Abdominal Aorta	Doppler generic measurements
2.2	SMA		Superior Mesenteric Artery	
2.3	IMA		Inferior Mesenteric Artery	
2.4	HA		Hepatic Artery	
2.5	Splenic A		Splenic Artery	
2.6	Renal A		Renal Artery	
2.7	Portal V		Portal Vein	Velocity in Doppler

No.	Measurement Group	Measurement Item	Description	Method
2.8	IVC		Inferior Vena Cava	generic measurements
2.9	M Portal V		Main Portal Vein	
2.10	Hepatic V		Hepatic Vein	
2.11	M Hepatic V		Middle Hepatic Vein	
2.12	Splenic V		Splenic Vein	
2.13	SMV		Superior Mesenteric Vein	
2.14	IMV		Inferior Mesenteric Vein	

8.2.2. Gynecology Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	Uterus	Uterus L	Uterus Length	2-point distance in B-mode generic measurements
		Uterus W	Uterus Width	
		Uterus H	Uterus Height	
		Endo	Endometrium Thickness	
		UT Cavity	Uterine Cavity Depth	
1.2	Cervix	Cervix L	Cervix Length	
		Cervix W	Cervix Width	
		Cervix H	Cervix Height	
1.3	Ovary	Ovary L	Ovary Length	
		Ovary W	Ovary Width	
		Ovary H	Ovary Height	
1.4	Cyst*			
1.5	Follicle*			
1.6	Fluid POD		Fluid Pouch of Douglas	
1.7	Pelvic Floor	BSD(R)	Bladderneck Symphseal Distance (at rest)	
		BSD(S)	Bladderneck Symphseal Distance(under stress)	

No.	Measurement Group	Measurement Item	Description	Method
Section 2: Doppler Measurements				
2.1	Ovary A	PS, ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Ovary Artery	Doppler generic measurements
2.2	Ut. A		Uterine Artery	

*The measurement method for Cyst and Follicle includes 1 Distance, 2 Distances and 3 Distances, which can be switched by the Tool paddle key.

8.2.3. Obstetrics Measurements

Obstetric measurements are used to calculate the GA (Gestation Age), EDD (Estimated Delivery Date) and EFW (Estimated Fetus Weight).

Multiple fetuses

The Obstetric package supports measurements and reports on up to four fetuses. If you know the number of fetuses at the start of the exam, then you can enter this in the Patient page (see section 4.4). When the number of fetuses is known the system adjusts the user interface to optimize for that number. If no information is entered about the number of fetuses the system will assume there is one.

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	Fetal Biometry	BPD	Biparietal Diameter	2-point distance in B-mode generic measurements
		HC	Head Circumference	Cir/Area in B-mode generic measurements
		AC	Abdominal Circumference	
		FL	Femur Length	2-point distance in B-mode generic measurements
		HUM	Humerus Length	
		OFD	Occipital Frontal Diameter	
		CER	Cerebellum Diameter	
		NF	Nuchal Fold	
		TAD	Transverse Abdominal Diameter	
		APAD	Anteroposterior Abdominal Diameter	

No.	Measurement Group	Measurement Item	Description	Method
		THD	Thoracic Diameter	
		APTD	Anteroposterior Trunk Diameter	
		TTD	Transverse Trunk Diameter	
		FTA	Fetal Trunk Area	Cir/Area in B-mode generic measurements
1.2	Early Gest	CRL	Crown Rump Length	
		BPD	Biparietal Diameter	
		FL	Femur Length	
		HUM	Humerus Length	
		NT	Nuchal Translucency	
		GS*	Gestational Sac	
		YS	Yolk Sac	
		AF	Deepest Pocket	
1.3	Lone Bones	HUM	Humerus Length	2-point distance in B-mode generic measurements
		ULNA	Ulna Length	
		RAD	Radius Length	
		TIB	Tibia Length	
		FIB	Fibula Length	
		Foot	Foot Length	
1.4	Fetal Cranium	NT	Nuchal Translucency	
		CER	Cerebellum Diameter	
		CM	Cistern Magna	
		LVW	Lateral Ventricle Width	
		NB	Nasal Bone	
		PNT	Prenasal Thickness	
		NF	Nuchal Fold	
		BOD	Binocular Distance	
1.5	AFI	Q1	Amniotic Fluid Index	
		Q2		
		Q3		
		Q4		
1.6	Ovary	Ovary L	Ovary Length	

No.	Measurement Group	Measurement Item	Description	Method
		Ovary W	Ovary Width	
		Ovary H	Ovary Height	
1.7	Chamber	LV Diam	Left Ventricular Diameter	
		LA Diam	Left Atrium Diameter	
		RV Diam	Right Ventricular Diameter	
		RA Diam	Right Atrium Diameter	
1.8	LVOT/AO	LVOT Diam	Left Ventricular Outflow Tract Diameter	
		Ao Asc	Ascending Aorta Diameter	
		Ao Arch	Aorta Arch Diameter	
		Ao Isthmus	Aorta Isthmus Diameter	
		Desc Ao	Descending Aorta Diameter	
1.9	RVOT/PA	RVOT Diam	Right Ventricular Outflow Tract Diameter	
		MPA Diam	Main Pulmonary Artery	
		Ductus A	Duct Arteriosus Diameter	
1.10	CTAR	Area 1	Cardio/Thorax area ratio	Trace in B-mode generic measurements
		Area 2		Ellipse in B-mode generic measurements

Section 2: Doppler Measurements

2.1	MCA	PS ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Middle Cerebral Artery	Doppler generic measurements
2.2	Umb. A		Umbilical Artery	
2.3	Planenta A		Placenta Artery	
2.4	Ovary A		Ovary Artery	
2.5	Ut. A		Uterine Artery	
2.6	Fetal Ao		Fetal Aorta	
2.7	Desc Aorta		Descending Aorta	
2.8	SMA		Superior Mesenteric Artery	
2.9	IVC	S	Inferior Vena Cava	
		D		
		a		
2.10	Ductus V		Ductus Venosus	Velocity in Doppler generic measurements
2.11	FHR		Fetal Heart Rate	

No.	Measurement Group	Measurement Item	Description	Method
2.12	MV		Mitral Valve	
2.13	TV		Tricuspid Valve	
2.14	MPV		Main Pulmonary Vein	
2.15	Ductus A		Fetal Aorta	
Section 3: M-mode Measurements				
3.1	FHR		Fetal Heart Rate	HR in M generic measurements

*The measurement method including 1 Distance, 2 Distances and 3 Distances can be switched by the Tool Options paddle key.

8.2.3.1. Auto OB Measurement

Auto OB is a semi-automatic method designed for automatic fetal biometry measurements to evaluate the growth of the fetus. These measurements include BPD, HC, HUM and FL.

To use Auto OB measurement:

1. Select **OB** or **Early OB** exam preset and perform image scanning in B mode.
2. Freeze the image when a standard fetal image is obtained.
3. Press **<Measure>** key on the console.
4. Select the desired measurement item **BPD**, **HC**, **HUM** or **FL** on the touch screen.
5. If **Auto** is not the default tool, press **Tool** to switch to **Auto**.
6. The auto measurement process starts. The result is displayed on the main screen.
7. If you are not satisfied with the measurement result, press **<Update>** key to switch the active caliper and use trackball to do manual correction.
8. Press **<Set>**key to complete measurement.

WARNING

1. The fetal image for Auto OB measurement should be standard enough, otherwise the measurement accuracy may be affected. When no valid fetal image is recognized, the system will prompt you with "No valid measurement result."
2. Auto OB measurement is only available on a frozen image.
3. The measurement result of Auto OB is for reference only. The measurement accuracy depends on the quality of fetal image.

8.2.3.2. Auto NT Measurement

Auto NT is a semi-automatic method designed to measure the Nuchal Translucency.

To use Auto NT measurement:

1. Select **Early OB** exam preset and perform image scanning in B mode.
2. Freeze the image when a standard fetal image is obtained.
3. Press <**Measure**> key on the console.
4. Select the measurement item **NT** on the touch screen.
5. If **Auto** is not the default tool, press **Tool** to switch to Auto
6. After pressing <**Update**> key you can use trackball to adjust the size of ROI box, and press <**Update**> key again to fix the size of ROI box.
7. Rotate the trackball to move ROI box to the desired measurement location. The auto measurement process starts. The result is displayed on the main screen.
8. Press <**Set**>key to complete measurement.
9. If you are not satisfied with the measurement result, press **Tool** to switch to **Distance** and use trackball to do manual correction.

WARNING

1. The fetal image for Auto NT measurement should be standard enough, otherwise the measurement accuracy may be affected. When no valid fetal image is recognized, the system will prompt you with "This measurement tool is unavailable."
2. Auto NT measurement is only available on a frozen image.
3. The measurement result of Auto NT is for reference only. The measurement accuracy depends on the quality of fetal image.

8.2.4. Cardiac Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	LV Simpson	A4C Dias.	Left Ventricular apical four-chamber views at End-diastole	Simpson (See section 8.2.4.1)
		A4C Sys.	Left Ventricular apical four-chamber views at End-systole	
		A2C Dias.	Left Ventricular apical two-chamber views at End-diastole	
		A2C Sys.	Left Ventricular apical two-chamber views at End-systole	
1.2	LV Study	IVSTd	Interventricular Septal Thickness at End-diastole	2-point distance in B-mode generic measurements
		LVIDd	Left Ventricular Internal Diameter at End-diastole	
		LVPWd	Left Ventricular Posterior Wall Thickness at End-diastole	
		IVSTS	Interventricular Septal Thickness at End-systole	
		LVIDs	Left Ventricular Internal Diameter at End-systole	
		LVPWs	Left Ventricular Posterior Wall Thickness at End-systole	
1.3	LV/RV	RVAWd	Right Ventricular Anterior Wall Thickness at End-diastole	2-point distance in B-mode generic measurements
		RVIDd	Right Ventricular Internal Diameter at end-diastole	
		LVIDd	Left Ventricular Internal Diameter at End-diastole	
		LVIDs	Left Ventricular Internal Diameter at End-systole	
1.4	LA/Ao	LA	Left atrial diameter	2-point distance in B-mode generic measurements
		AoD	Aortic root diameter	
1.5	AO	AoD	Aortic Root Diameter	
		Ao Asc	Ascending Aorta Diameter	
1.6	RVOT	RVOT Diam	Right Ventricular Outflow Tract	

No.	Measurement Group	Measurement Item	Description	Method
1.7	LVOT	LVOT Diam	Left Ventricular Outflow Tract	
1.8	PV	PV Diam	Pulmonary Valve Diameter	
1.9	RVDs		Right Ventricular Diameter at end-systole	
1.10	LA/RA	RA Length	Right Atrium Length Diameter	
		RA Width	Right Atrium Width Diameter	
		LA Length	Left Atrium Length Diameter	
		LA Width	Left Atrium Width Diameter	
1.11	LVM (A-L) (Left Ventricular Mass)	LVAd Sax Epi	Left Ventricular Epicardial Area at Papillary Muscle Level at End Diastole in Short-axis View	B-mode generic measurements
		LVAd Sax Endo	Left Ventricular Endocardial Area at Papillary Muscle Level at End Systole in Short-axis View	
		LVAd Apical	Left Ventricular Long Axis Length at End Diastole in Apical View	
1.12	LVM (T-E) (Left Ventricular Mass)	LVAd Sax Epi	Left Ventricular Epicardial Area at Papillary Muscle Level at End Diastole in Short-axis View	
		LVAd Sax Endo	Left Ventricular Endocardial Area at Papillary Muscle Level at End Systole in Short-axis View	
		a	Semi-major Axis from Widest Minor Axis Radius to Apex	
		d	Truncated Semi-major Axis from Widest Minor Axis Radius to Mitral Annulus Plane	
1.13	LVM (Cube) (Left Ventricular Mass)	IVSTd	Interventricular Septal Thickness at End-diastole	
		LVIDd	Left Ventricular Internal Diameter at End-diastole	
		LVPWd	Left Ventricular Posterior Wall Thickness at End-diastole	
1.14	MVA		Mitral Calve Area	
1.15	AVA		Aortic Valve Area	

No.	Measurement Group	Measurement Item	Description	Method
1.16	Auto EF	4CH	4 Chamber	Auto tool(See section 8.2.4.2)
Section 2: Doppler Measurements				
2.1	MV (Mitral Valve)	E/A	E-wave Velocity/ A-wave Velocity	Doppler generic measurements
		MV HR	Mitral Valve Heart Rate	
		MV PHT	Mitral Valve Pressure Half Time	
		MV VTI	Mitral Valve Velocity Time Integral	
		IVRT	Isovelocity Relaxation Time	
		MV A Dur	Mitral Valve A-wave Duration	
		MV E Dur	Mitral Valve E-wave Duration	
		MV DecT	Mitral Valve Deceleration Time	
		MR Vmax	Mitral Valve Regurgitation Maximum Velocity	
		MR VTI	Mitral Valve Regurgitation Velocity Time Integral	
2.2	TV (Tricuspid Valve)	TV VTI	Tricuspid Valve Velocity Time Integral	Doppler generic measurements
		TV E/A	E-wave Velocity/ A-wave Velocity	
		TV HR	Tricuspid Valve Heart Rate	
		TV Vmax	Tricuspid Valve Maximum Velocity	
2.3	AV(Aortic Valve)	LVOT VTI	Left ventricular outflow tract Velocity Time Integral	Doppler generic measurements
		LVOT Vmax	Left ventricular outflow tract maximum Velocity	
		AV VTI	Aortic Valve Velocity Time Integral	
		AV HR	Aortic Valve Heart Rate	
		AV Vmax	Aortic Valve maximum Velocity	
		AV Accel Time	Aortic Valve Acceleration Time	
		AV Decel Time	Aortic Valve Deceleration Time	
		AR VTI	Aortic Valve Reversed Flow Velocity Time Integral	
		AR Vmax	Aortic Valve Regurgitation Maximum Velocity	
		AR Accel Time	Aortic Valve Regurgitation Acceleration Time	

No.	Measurement Group	Measurement Item	Description	Method
		AR PHT	Aortic Valve Regurgitation Pressure Half Time	
		AR Decel Time	Aortic Valve Regurgitation Deceleration Time	
2.4	PV (Pulmonic Valve)	PV VTI	Pulmonic Valve Velocity Time Integral	
		PV HR	Pulmonic Valve Heart Rate	
		PV Vmax	Pulmonic Valve maximum Velocity	
		PV Accel Time	Pulmonic Valve Acceleration Time	
		PR Vmax	Pulmonic Valve Regurgitation max velocity	
2.5	P Vein (Pulmonic Vein)	PVein S Vel	Pulmonic Veins Systole Velocity	
		PVein D Vel	Pulmonic Veins Diastole Velocity	
		PV A Vel	A Point Reverse Velocity	
		PV A Dur	Pulm A Duration	
2.6	Hep Veins	Hep S Vel	Hepatic Vein S-wave Flow Velocity	
		Hep D Vel	Hepatic Vein D-wave Flow Velocity	
		Hep A Vel	Hepatic Vein A-wave Flow Velocity	
		Hep A Dur	Hepatic Vein A-wave Duration	
2.7	TDI	Sa Medial	Mitral Valve Medial Systolic Motion	Doppler generic measurements
		Ea Medial	Mitral Valve Medial Early Diastolic Motion	
		Aa Medial	Mitral Valve Medial Late Diastolic Motion	
		Sa Lateral	Mitral Valve Lateral Systolic Motion	
		Ea Lateral	Mitral Valve Lateral Early Diastolic Motion	
		Aa Lateral	Mitral Valve Lateral Late Diastolic Motion	
2.8	RVSP	TR Vmax	Tricuspid Regurgitation maximum Velocity	Doppler generic measurements
		RA Pressure	Right Atrium Pressure	Dialog input
2.9	AVA(VTI)	LVOT VTI	Left ventricular outflow tract Velocity Time Integral	Doppler trace measurement
		AV VTI	Aortic Valve Velocity Time Integral	

No.	Measurement Group	Measurement Item	Description	Method
2.10	QP/Qs	LVOT VTI	Left ventricular outflow tract Velocity Time Integral	Doppler Caliper
		RVOT VTI	Right ventricular outflow tract Velocity Time Integral	
2.11	PISA	MR Trace	Mitral Valve Trace	PISA (See section 8.2.4.3)
		AR Trace	Aortic Valve Trace	
		TR Trace	Tricuspid Valve Trace	
		PR Trace	Pulmonary Valve Trace	
Section 3: M-mode Measurements				
3.1	LV Study	IVSTd	Interventricular Septal Thickness at End-diastole	M-mode generic measurements
		LVIDd	Left Ventricular Internal Diameter at End-diastole	
		LVPWd	Left Ventricular Posterior Wall Thickness at End-diastole	
		IVSTS	Interventricular Septal Thickness at End-systole	
		LVIDs	Left Ventricular Internal Diameter at End-systole	
		LVPWs	Left Ventricular Posterior Wall Thickness at End-systole	
3.2	LV/RV	RVAWd	Right Ventricular Anterior Wall Thickness at End-diastole	M-mode generic measurements
		RVIDd	Right Ventricular Internal Diameter at end-diastole	
		LVIDd	Left Ventricular Internal Diameter at End-diastole	
		LVIDs	Left Ventricular Internal Diameter at End-systole	
3.3	Time	LVET	Left Ventricular Ejection Time	M-mode generic measurements
		LV PEP	Left Ventricular Pre-ejection Period	
		RV PEP	Right Ventricular Pre-ejection Period	
3.4	MV(Mitral Valve)	E-F Slope	Mitral Valve E-F slope	
		EPSS	E point septal separation	
		MV D-E Exc	Mitral Valve DE Wave Amplitude	


No.	Measurement Group	Measurement Item	Description	Method
		MV D-E Slope	Mitral Valve D-E Slope	
		MV E-E SEP	Mitral Valve E-E Separation	
		MV A-C Interval	Mitral Valve A-C Interval time	
		MAPSE	Mitral Annular Plane Systolic excursion	
3.5	TAPSE	TAPSE	Tricuspid Annular Plane Systolic excursion	
3.6	LA/Ao	LA	Left atrial diameter	
		AoD	Aortic root diameter	
		RVOT Diam	Right Ventricular outflow tract	
		ACS	Aortic Valve Cusp Separation	
3.7	HR		Heart rate	
3.8	LVM(Cube) (Left Ventricular Mass)	IVSTd	Interventricular Septal Thickness at End-diastole	
		LVIDd	Left Ventricular Internal Diameter at End-diastole	
		LVPWd	Left Ventricular Posterior Wall Thickness at End-diastole	
3.9	IVC-CI	IVCmax	Inferior Vena Cava max diam	
		IVCmin	Inferior Vena Cava min diam	
Section 4: Color-mode Measurements				
4.1	PISA	MR Rad	Mitral Valve Stenosis Radius	PISA(see section 8.2.4.3)
		MR Als. Vel	Mitral Regurgitation Aliasing Maximum Velocity	
		AR Rad	Aortic Valve Stenosis Radius	
		AR Als. Vel	Aortic Regurgitation Aliasing Maximum Velocity	
		TR Rad	Tricuspid Valve Stenosis Radius	
		TR Als. Vel	Tricuspid Regurgitation Aliasing Maximum Velocity	
		PR Rad	Pulmonary Valve Stenosis Radius	
		PR Als. Vel	Pulmonary Regurgitation Aliasing Maximum Velocity	

8.2.4.1. Simpson's Method of Disks (MOD)

Simpson's MOD is a method used to calculate LV diastolic and systolic volumes and ejection fraction. Simpson's MOD is available in the Cardiac presets.

To use the Simpson's MOD measurement:

1. Invoke the B-mode Measure function.
2. Select a measurement which could be done by Simpson's method of disks. A single caliper will be displayed on the image field.
3. Move the caliper and press **<Set>** key to position the start point A at one end of left ventricular long axis.
4. Draw the trace along the endocardium of the left ventricle.
5. Press **<Set>** key to fix the end point B and complete the trace. A new caliper positions automatically at the apex (Point D) of the trace, connecting the Point C (Midpoint of point A and B). This distance between point C and D is the longest detected by the system, as shown below:



6. Pivot the Point D caliper to a new desired position if necessary.
7. Press **<Set>** key to complete the measurement.

8.2.4.2. Auto EF

Auto EF is an application for Left Ventricular function evaluation. The EF (Ejection Fraction) is evaluated by using the four-chamber (4CH) view from the orthogonal apical plane to provide automatic analysis of the LV function.

Using Auto EF:

1. Scan the cardiac image in B mode, and acquire cine loops of 4CH views.

Note:

It is required to acquire cine loops of at least 3 heartbeat cycles.

2. Freeze the ultrasound system.
3. Press the **<Measure>** key on the console to invoke the application measurement function.
4. Select **Auto EF** on the touch screen, and then select **4CH**.
5. The ultrasound system starts to automatically analyze and calculate the EF results.

Note:

If the EF cannot be processed automatically because of improper image, the system will display prompt message.

WARNING

1. The Auto EF function is intended for use by the clinician who is qualified to use ultrasound for cardiac function evaluations.

-
2. The measurement result is for reference only. The accuracy of the measurement result can be affected by the image quality, the cardiac image section and procedures performed. The user is responsible for the final decision.
 3. Always confirm the detection of cardiac borders by visual inspection before storing the results in the worksheet and report. If the result is in doubt, manual or other effective methods should be applied to verify the correctness.
-

The measurement accuracy values of Auto EF feature is listed in the table below:

Measurement/ Calculation	Accuracy (Mean±1.96STD)	Range
EDV (4CH)	6 ±32ml	45-254ml
ESV (4CH)	1.84±27ml	17-238ml
EF (4CH)	1.36±14 % points	6-68%

8.2.4.3. PISA

PISA (Proximal Isovoltage Surface Area) is a tool in Cardiac presets used for quantitative analysis of regurgitation. It is only available in Color and Doppler mode.

To use PISA measurement in Color mode:

1. Adjust the color image until the aliasing appears. Invoke the application measurement function.
2. Select **PISA** measurement on the touch screen and then select a measurement label from **MR Rad, MR Als. Vel, AR Rad, AR Als. Vel, TR Rad, TR Als.Vel, PR Rad** and **PR Vls. Vel**. A single caliper will be displayed on the image field.
3. Move the caliper and press <Set> key to position the caliper as the center of the semicircular.
4. Move the trackball to adjust the radius length and orientation of the semicircular.
5. Press <Set>key to fix the semicircular and then a dialog box of “Color Aliasing Velocity” pops up.
6. Select “Top aliasing velocity”, “Bottom aliasing velocity”, or manually enter the aliasing velocity from 0 cm/s to 500 cm/s.
7. Click OK and then measurement results are shown.

To use PISA measurement in Doppler mode:

1. Freeze a strip image. Invoke the application measurement function.
2. Select **PISA** measurement on the touch screen and then select a measurement label from **MR Trace, AR Trace, TR Trace** and **PR Trace**.
3. Use the Doppler trace tool to get the measurement results.

8.2.5. Small Parts Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	Thyroid	THY L	Thyroid Length	2-point distance in B-mode generic measurements
		THY W	Thyroid Width	
		THY H	Thyroid Height	
		Isthmus	Thyroid Isthmus	
1.2	Breast	Lesion 1	Breast Lesion 1	2-point distance in B-mode generic measurements
		Lesion 2	Breast Lesion 2	
		Lesion 3	Breast Lesion 3	
		Lesion 4	Breast Lesion 4	
		Lesion 5	Breast Lesion 5	
1.3	Testis	Testis L	Testis Length	Doppler generic measurements
		Testis W	Testis Width	
		Testis H	Testis Height	
Section 2: Doppler Measurements				
2.1	STA	PS ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Superior Thyroid Artery	Doppler generic measurements
2.2	ITA		Inferior Thyroid Artery	

8.2.6. Urology Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	Renal	Renal L	Renal Length	2-point distance in B-mode generic measurements
		Renal W	Renal Width	
		Renal H	Renal Height	
		Cortex	Renal Cortex thickness	
1.2	Bladder	Pre-BL L	Pre-void Bladder Length	
		Pre-BL W	Pre-void Bladder Width	
		Pre-BL H	Pre-void Bladder Height	
		Post-BL L	Post-void Bladder Length	
		Post-BL W	Post-void Bladder Width	
		Post-BL H	Post-void Bladder Height	
1.3	Prostate	Prostate L	Prostate Length	
		Prostate W	Prostate Width	
		Prostate H	Prostate Height	
1.4	Seminal	Seminal L	Seminal Length	
		Seminal W	Seminal Width	
		Seminal H	Seminal Height	
1.5	Testis	Testis L	Testis Length	
		Testis W	Testis Width	
		Testis H	Testis Height	
Section 2: Doppler Measurements				
2.1	Renal A	PS ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Renal Artery	Doppler generic measurements
2.2	Arcuate A		Arcuate Artery	
2.3	Seg. A		Segmental Artery	
2.4	Int. A		Interlobar Artery	

8.2.7. Vascular Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	CCA	IMT Far	Common Carotid Artery Intima-Media Thickness (Far vessel wall)	2-point distance in B-mode generic measurements; Auto (See section 8.2.7.1).
		IMT Near	Common Carotid Artery Intima-Media Thickness (Near vessel wall)	
		IMT All	Common Carotid Artery Intima-Media Thickness (Far and Near vessel walls)	
1.2	ICA	IMT Far	Internal Carotid Artery Intima-Media Thickness (Far vessel wall)	
		IMT Near	Internal Carotid Artery Intima-Media Thickness (Near vessel wall)	
		IMT All	Common Carotid Artery Intima-Media Thickness (Far and Near vessel walls)	
1.3	BIF	IMT Far	Carotid Artery Bifurcation Intima-Media Thickness (Far vessel wall)	
		IMT Near	Carotid Artery Bifurcation Intima-Media Thickness (Near vessel wall)	
		IMT All	Common Carotid Artery Intima-Media Thickness (Far and Near vessel walls)	
1.4	VF Area		Volume Flow Area	2-point distance in B-mode generic measurements
1.5	Stenosis% Dist.		Stenosis% Distance	
1.6	Stenosis% Area		Stenosis% Ellipse	Ellipse
			Stenosis% Trace	Trace
			Stenosis% Spline	Spline

No.	Measurement Group	Measurement Item	Description	Method
1.7	Vessel Diam		Vessel Diameter	2-point distance in B-mode generic measurements; Auto (See section 8.2.7.2).
Section 2: Doppler Measurements				
2.1	CCA	PS ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Common Carotid Artery	Doppler generic measurements
2.2	ECA		External Carotid Artery	
2.3	ICA		Internal Carotid Artery	
2.4	Vert A		Vert Artery	
2.5	SUBC A		Subclavian Artery	
2.6	Axill A		Axillary Artery	
2.7	Brach A		Brachial Artery	
2.8	Ulnar A		Ulnar Artery	
2.9	Radial A		Radial Artery	
2.10	CFA		Common Femoral Artery	
2.11	DFA		Deep Femoral Artery	
2.12	SFA		Superficial Femoral Artery	
2.13	CIA		Common Iliac Artery	
2.14	EIA		External Iliac Artery	
2.15	IIA		Internal Iliac Artery	
2.16	Pop A		Popliteal Artery	
2.17	Peron A		Peroneal Artery	
2.18	PTA		Posterior Tibial Artery	
2.19	ATA		Anterior Tibial Artery	
2.20	DPA		Dorsalis Pedis Artery	
2.21	SUBC V		Subclavian Vein	Velocity in Doppler generic measurements
2.22	Axill V		Axillary Vein	
2.23	Brach V		Brachial Vein	
2.24	Cepha V		Cephalic Vein	
2.25	Basilic V		Basilic Vein	
2.26	Ulnar V		Ulnar Vein	
2.27	Radial V		Radial Vein	
2.28	M Cubital V		Median Cubital Vein	

No.	Measurement Group	Measurement Item	Description	Method
2.29	CFV		Common Femoral Vein	
2.30	DFV		Deep Femoral Vein	
2.31	SFV		Superficial Femoral Vein	
2.32	CIV		Common Iliac Vein	
2.33	EIV		External Iliac Vein	
2.34	IIV		Internal Iliac Vein	
2.35	Saph V		Great Saphenous Vein	
2.36	Pop V		Popliteal Vein	
2.37	Peron V		Peroneal Vein	
2.38	PTV		Posterior Tibial Vein	
2.39	ATV		Anterior Tibial Vein	
2.40	SSV		Small Saphenous Vein	
2.41	HR		Heart Rate	HR in Doppler generic measurements
2.42	Vol Flow		Volume Flow	2-point distance+ Auto Trace
2.43	ACA	PS ED RI PI PS,ED,RI,S/D Time HR Auto Trace Manual Trace Spline Trace	Anterior Cerebral Artery	Doppler generic measurements
2.44	MCA		Middle Cerebral Artery	
2.45	PCA		Posterior Cerebral Artery	
2.46	ACoA		Anterior Communicating Artery	
2.47	PCoA		Posterior Communicating Artery	
2.48	BA		Basilar Artery	
2.49	VA		Vertebral Artery	
2.50	ICA		Internal Carotid Artery	

8.2.7.1. Auto IMT

Intima-media thickness (IMT) is a measurement of the thickness of tunica intima and tunica media. The system provides a semiautomatic measurement of the Carotid IMT.

To measure IMT:

1. Invoke the B-mode application measurement in Carotid Preset.
2. Select an IMT measurement on the touch screen and change the Tool option to **Auto**. A ROI box will be displayed on the image field.
3. Press the **Position** and **Left/Right** paddle key to select a different position of carotid artery.
4. Press **<Update>** key and use the trackball to adjust the size of ROI box.
5. Press **<Update>** key again to confirm the size of ROI box.
6. Use the trackball to move the ROI box to desired measurement location, and then the system automatically displays the IMT measurement results.
7. Press **<Set>** key to complete measurement and save the results in the worksheet.
8. If you are not satisfied with the measurement result, press **Tool** to switch to **Distance** tool and do the IMT measurement manually.
9. The IMT measurement can display the following result:
 - Max (the maximum value of the IMT results)
 - Min (the minimum value of the IMT results)
 - Avg (the average value of the IMT results)
 - Width (the width of the ROI box)
 - SD (the Standard Deviation of the IMT results)
 - Points (the number of valid points in the IMT results)

WARNING

1. Auto IMT measurement can only be activated on a frozen image.
2. Select the Right or Left, Near or Far vessel wall, and vessel segment before generating IMT measurement, otherwise the measurement results may not be accurate.
3. Always confirm the IMT is correctly traced prior to entering the IMT result into the report.

Accuracy of Auto IMT measurement:

Auto Measurements	Error
Auto IMT	≤±5%

8.2.7.2. Auto Vessel Diam

Auto Vessel Diam is a semi-automatic function for measuring the diameter of the blood vessel automatically.

To use Auto Vessel Diam:

1. Select the PICC exam mode.
2. Scan the vessel image in B mode, freeze the image after acquiring the transverse view of the blood vessel
3. Press the <Measure> key on the console, and select **Vessel Diam** measurement item on the touch screen.
4. If **Auto** is not the default tool, press **Tool** to switch to **Auto**.
5. Move the cursor to the target vessel and press the <Set> key to start automatic measurement. The measurement result will be displayed automatically on the main screen and the ratio of vessel diameter to catheter size will be displayed at the same time.

Note: Before the measurement is completed, the catheter size button can be used to switch the catheter size. According to the measured vessel diameter, the system will display the ratio between the vessel diameter and the catheter size, and indicate whether the current catheter is available.

6. If you are not satisfied with the measurement result, press <Update> key to switch the active caliper and use trackball to do manual correction.
7. Press the <Set> key again to complete measurement.

WARNING

1. The transverse image of the blood vessel for Auto Vessel Diam measurement should be standard enough, otherwise the measurement accuracy may be affected. When no valid image is recognized, the system will prompt you with "No valid measurement result."
2. Auto Vessel Diam measurement can only be activated on a frozen image.
3. Always confirm the accuracy of measurement result prior to entering the Auto Vessel Diam result into the report.


8.2.8. Pediatric Measurements

No.	Measurement Group	Measurement Item	Description	Method
Section 1: B-mode Measurements				
1.1	LLV		Left lateral ventricle	2-point distance in B-mode generic measurements
1.2	RLV		Right lateral ventricle	
1.3	LT Tri		Left trigone	
1.4	RT Tri		Right trigone	
1.5	HIP	HIP Angle	Hip joint angle	Hip Joint(See section 8.2.8.1)
		HIP d/D	Hip joint d/D ratio	

8.2.8.1. Hip Joint Measurement

Hip Joint Angle Measurement:

Hip Joint Angle Measurement is intended to evaluate the development of acetabular roof and the subluxation of femoral head for pediatrics. This measurement is performed by adding three straight lines on the anatomic image, thereby calculating two angles. See the illustration below.



- Line BL (Baseline) connects the osseous acetabular convexity to the point where the joint capsule and the perichondrium unite with the iliac bone;
- Line IL (Inclination Line) connects the osseous acetabular convexity to the labrum acetabulare;
- Line RL (Roof Line) connects the lower edge of the iliac bone to the osseous acetabular convexity.
- α is the angle between baseline and roof line.
- β is the angle between baseline and inclination line.

To use Hip Joint Angle measurement:

1. Invoke the B-mode application measurement function.
2. Select **HIP-> HIP Angle** on the touch screen and then select **Left** or **Right** on the touch screen.
3. Press the **Tool** paddle key to select the **3 Distances** or **Semi-auto** Method.

3 Distances method:

Add the baseline, roof line, and inclination line by the method of measuring distance with two points, and the system displays the results of α and β angle.

Semi-auto method:

- a. Move this horizontal straight line to place the baseline. Rotate the Angle knob on the console to adjust the angle of baseline if necessary.
 - b. Press <**Set**> key and the default angle α and roof line comes out.
 - c. Use the trackball to place the roof line and rotate the Angle knob to adjust the angle α . Press the <**Angle**> knob can quickly switch the angle α to left or right.
 - d. Press <**Set**> key and the default angle β and inclination line comes out.
 - e. Use the trackball to place the inclination line and rotate the Angle knob to adjust the angle β . Press the <**Angle**> knob can quickly switch the angle β to left or right.
4. Press <**Set**> key to complete the measurement.
 5. If the age of the patient is entered, dislocation type will also be displayed in the result window. Evaluate the type of hip joint according to the Graf method, as shown in the table below.

Dislocation type		Criteria		
		α	β	Patient Age
I		$>=60^\circ$	$<77^\circ$	All
II	IIa	$50^\circ - 59^\circ$	$<77^\circ$	≤ 3 months
	IIb	$50^\circ - 59^\circ$	$<77^\circ$	>3 months
	IIc	$43^\circ - 49^\circ$	$\leq 77^\circ$	All
	IId	$43^\circ - 49^\circ$	$>77^\circ$	All
III		$<43^\circ$	$>77^\circ$	All
IV*		The angle cannot be performed.		All
????		Others		All

Hip Joint d/D Ratio Measurement:

Hip Joint d/D Ratio measurement is intended to measure the percentage of the femoral head coverage under the iliac bone roof.

To use Hip Joint d/D Ratio measurement:

1. Invoke the B-mode Measure function.
2. Select **HIP->HIP d/D** on the touch screen and then select **Left** or **Right** on the touch screen. A single caliper will be displayed on the image field.
3. Add the baseline along the iliac bone by the method of measuring distance with two points.
4. Press **<Set>** key, and a second line displays below the baseline. Move the second line to make it be tangent to the femoral head, and the "d" distance comes out.
5. Press **<Set>** key and a third line displays above the baseline. Move the third line to make it be tangent to the femoral head, and the "D" distance and "d/D" ratio come out.

8.2.9. Emergency Measurements

The following emergency exam modes are available in current system: EM Abd, EM OB, EM Card, EM Vas and EM MSK. Specifically, EM Abd, EM OB and EM Card have their corresponding measurement package. The commonly used measurement tools are contained and the measurement items are consistent with that of the exam mode. For more information about measurement package, please refer to the corresponding chapter.

- For EM Abd measurement, please refer to 8.2.1 Abdomen Measurements;
- For EM OB measurement, please refer to 8.2.3 Obstetrics Measurements;
- For EM Card measurement, please refer to 8.2.4 Cardiac Measurements.

8.3 Worksheet and Report

Worksheet is available at any time during an exam, and is displayed as default on the main screen. Report contains the information from a worksheet but it is formatted in a slightly different manner.

8.3.1. Worksheet

To view a worksheet:

Press <Report> key on the console to open worksheet screen. A worksheet includes: Patient Information, Measure/Calculation data, Comments Findings, etc.

The screenshot shows the 'EDAN' brand interface with 'WER 123,456'. It displays clinical data: LMP (blank), Clinical GA (blank), Exam Date: 09/03/2020, Fetus:A/2, C5-2Q, 09/03/2020, ABD, 09:36:52, page:1/1. Below this are fields for GA(AUA) (16w0d), Clinical EDD (blank), FetusPos (blank), EDD(AUA) (02/18/2021), and PlacentalPos (blank). A section titled '• 2D Measurements' lists BPD and CER measurements. BPD is 31.93mm (AUA checked, Value 31.93, V1 31.93, Method Last, Reference Hadlock, GA 16w0d). CER is 14.85mm (AUA checked, Value 14.85, Method Last, Reference Goldstein, GA 16w0d). At the bottom is an EFW table with Hadlock4(AC,BPD,FL,HC) reference. A 'Clear All' button is at the bottom left.

Figure 8-3 2D Worksheet Main Screen Display




Figure 8-4 Worksheet Touch Screen Display (OB as Example)

There is a group of radio button that includes: **Report**, **Worksheet** and **Growth Curve**.

Note: Radio Buttons are buttons where only one is active at any time. Activating one will de-activate all others.

- ◆ Press **Report** button on the touch screen to get the report page.
- ◆ Press **Worksheet** button on the touch screen to switch back to the worksheet page.
- ◆ Press **Growth Curve** button on the touch screen to access the fetal growth curves. It is only available in OB worksheet, and is not displayed for any other preset. See section 8.3.3 *Growth Curve* for details.
- **2D, M, Doppler, Expand:** These are a group of radio buttons where only one is active at any time. Pressing **2D**, **M** or **Doppler** will display separate measurement data by each image mode, while pressing **Expand** will display all the measurements done in all image modes. The **Expand** button is on status as default.
- **Comment:** Press to display or hide comment section. This is an editable field for user to type any diagnosis or treatment comments.
- **Findings:** Press to display or hide the findings section. This is an editable field for user to type any ultrasound findings. See section 8.3.5 *Findings* for details.
- **Fetus Compare:** Click it to get the pages to compare multiple fetus data in one page. It only shows summary data for each fetus. It is available only in multiple fetus situations.
- **Fetus A, Fetus B, Fetus C, Fetus D:** There is a group of radio button to switch fetus, and worksheet main screen page shows data of selected fetus. It is only available in multiple fetus situations, and the number of enabled button equals current fetus number which is determined in patient information page.
- **Page:** Press to switch worksheet page in multiple pages. This is disabled when there is only one page.
- **Application:** The doctor can select a measurement package to display as needed if the patient has received multiple measurements in different measurement packages.

To edit a worksheet:

Move the cursor over an editable field such as a measurement result, and press the <**Set**> key. A touch QWERTY is automatically invoked. Type in your changes and press the **Enter** key to save the changes. After editing a result, an "underline" will be displayed below the value to indicate this is a manually edited value.

The **Clear All** key on the worksheet page can be used to clear all the measurement results in the worksheet.

8.3.2. OB Worksheet

Please see previous section for an overview of reports and worksheets. This section describes worksheet capabilities that are unique to OB. Figure 8-5 shows an example of the OB worksheet.

The screenshot displays the OB Worksheet interface with several labeled components:

- A:** LMP(CUA) field, showing 04/09/2022.
- B:** GA(CUA) field, showing 20w1d.
- C:** EDD(CUA) field, showing 01/14/2023.
- D:** Reference dropdown menu, currently set to "Hadlock".
- E:** CUA measurement table for HC, AC, and FL. HC is 160.94mm, AC is 132.23mm, and FL is 44.14mm. The table includes columns for Value, V1, V2, V3, V4, Method (Last), GP, GA, and Reference.
- F:** EFW reference dropdown menu, currently set to "Hadlock1(AC,FL)".
- 2D Measurements:** Below the table, there are three calculated values: HC/AC (1.22), FL/HC (27.43%), and FL/AC (33.38%).
- APAD:** Below the 2D Measurements, there is a table for APAD with a single row showing a value of 33.60mm.

Figure 8-5 OB Worksheet With **Expand** on.

A: LMP/BBT: Two different versions of the LMP/BBT are displayed:

- LMP/BBT: If the LMP/BBT was entered on the Patient page that date is transferred to here.
- LMP/BBT(AUA/CUA): Displays LMP/BBT(AUA/CUA) calculated from GA (AUA/CUA).

B: GA: Two different versions of the GA are displayed:

- Clinical GA: Calculated from the LMP/BBT.
- GA (CUA) or GA (AUA): Displays Composite Ultrasound Age (CUA) or Average Ultrasound Age (AUA), depending the Default GA display configured in Measure Preset (see section 10.3.5 for details).

C: EDD: Two different versions of the EDD are displayed based on the two GA values.

- Clinical EDD: Calculated from the LMP/BBT and GA.
- EDD (CUA) or EDD (AUA): Displays EDD calculated from Composite Ultrasound Age (CUA) or Average Ultrasound Age (AUA), depending the Default EDD display configured in Measure Preset (see section 10.3.5 for details).

D: Reference: Change the equation used to calculate the GA.

E: CUA/AUA: These checkboxes let you decide which results are included in the CUA or AUA calculation. CUA is calculated from the selected BPD, HC, AC and/or FL measurement result; AUA is the averaged value of the selected GAs calculated from single parameter including BPD, HC, AC, FL etc. Whether CUA or AUA is displayed depends on the Default GA display configured in Measure Preset (see section 10.3.5 for details).

F: EFW reference: Change the equation used to calculate the estimated fetal weight.

8.3.3. Growth Curve

OB Growth Curve indicates predicted fetal growth patterns according to the selected reference for a measurement or calculation. A growth curve graph can display information acquired in the current exam. Multiple fetus data can be display in the same graphic to compare their growth trending details.

For each growth curve graph, there is a drop-down list for selecting specific measurement or calculation, and a drop-down list for selecting specific reference of selected measurement or calculation. Selecting one of them, the growth curve graph will change accordingly.



Figure 8-6 Growth Curve Graph

To view a growth curve graph:

Press the <Report> hard key to enter the Worksheet, and then press the **Growth Curve** button on the touch screen to display the Growth Curve Graph.




Figure 8-7 Growth Curve Touch Screen

Following controls are invoked by **Growth Curve** button.

- **Single/Quad:** press to select the number of the growth curve graph for display.




Figure 8-8 Quad Growth Curve Graph

- **Fetus Compare:** Press to display multiple fetus data in the same graphic for comparing their data directly .It appears only in multiple fetus situations, and the fetus number is determined by which is entered in patient information.



Figure 8-9 Comparing fetus in a growth curve graph

- **Fetus A, Fetus B, Fetus C, Fetus D:** There is a group of radio button to switch fetus, and the growth curve graph shows data of selected fetus. It is only available in multiple fetus situations, and the number of enabled button equals current fetus number which is determined in patient information page. It is disabled when **Fetus Compare** is on.

- **Print:** At the left side of each growth curve graphic a Print checkbox is displayed for you to determine whether to print the growth curve graphic in the report.

8.3.4. Fetus Score

Fetus score means to obtain a few indexes related to fetal growth through observation and measurement. The clinician will evaluate the hazardous situation that the fetus is facing by grading these indexes respectively according to generally acknowledged criteria. The scoring is undergone in the basis of fetal ultrasound image in a certain period of time. Fetus score is normally used in high-risk pregnancy, overdue pregnancy and pregnancy that lacks fetal movement. It helps to detect slow fetal growth during pregnancy.

Click **Fetus Score** in the OB worksheet page, the main screen displays the fetus score chart, shown as the figure below. You can manually input the scores into the system:

Fetus Score	
Reactive FHR	0 < 2 times, or Reactive FHR < 15bpm
FM	0 FM ≤ 2 times
FBM	0 No FBM or duration ≤ 30s
FT	0 Limbs stretch, no bend, fingers loose
AF	0 No AF, or AF volume < 2 x 2cm
Score	0 Chronic asphyxia risk high

OK **Cancel**

Figure 8-10 Fetus Score main screen display

The scoring criteria the system provides is shown in the table below:

Fetal growth index	0 score	2 score	Observation time
Reactive FHR	<2 times, or Reactive FHR <15 bpm	Reactive FHR ≥15 bpm, duration ≥15s, ≥2 times	30 minutes
FM	FM ≤ 2 times	FM ≥3 times (Continuous movement is deemed to 1 time)	30 minutes
FBM	No FBM or duration ≤30s	FBM ≥1 time, duration ≥30s	30 minutes
FT	Limbs stretch, no bend, fingers loose	Limbs and spine stretch-bend ≥ 1 time	/
AF	No AF, or AF volume < 2x2cm	One or more AF volume > 2x2cm	/

Table 8-1 Fetus Score Criterion

Different fetal scoring results indicate different growth condition:

Total scores	Growth condition
8-10 scores	Normal, chronic asphyxia risk low
4-6 scores	Chronic asphyxia risk suspicious
0-2 scores	Chronic asphyxia risk high

8.3.5. Findings

The findings user interface allows you to quickly create a paragraph of findings for the current exam. It consists of three interactions:

- Findings preset. It determines the pre-defined findings displayed. The default findings preset is auto linked to the measure preset of current exam mode. Click the Preset drop list and select one preset, for example ABD, then the pre-defined findings field shows all the pre-defined findings associated with ABD preset.
- Pre-defined findings. This interaction shows a list of pre-defined findings. Checking the checkbox before each findings will insert it into the editable field. This list is divided into sections, and each section can be expanded/contracted using the arrow button next to the section header.
- An editable field that displays the findings for this exam. Text can be entered directly into this field by setting the cursor in the field and using the touchscreen keyboard, or by using the library of pre-defined findings.




Figure 8-11 The Findings page

To customize the pre-defined findings:

1. Export the findings to a USB stick as described in section 11.3.3. The findings will be saved to the folder following the path UltraA3 Settings→Findings→Human.
2. Open the findings file on a PC using a text-editing program.
3. Edit the pre-defined findings. Be careful to follow the established format regarding the headers of each section and the section contents.
4. Save the file back to the USB stick. Make sure the file extension remains .xml.
5. Import the findings back into the system using the same interface described in section 11.3.3..

Note: The system only supports Findings Export/Import across ultrasound systems with the same system language.

8.3.6. Report

Press the <Report> hard key to enter the Worksheet, and then press the **Report** button on the touch screen to display the Report screen. A report includes: Header, Patient Information, Images, Measurement/Calculation data, Comments, Sonographer signature, etc.




Figure 8-12 Report Main Screen

The middle part of the main screen is the general layout of a report.

On the left side of the main screen, you can set the layout of the report:

- **Auto Adjust:** Automatically adjusts the layout of the report.
- **Image Column:** Selects the column number and the images will be displayed accordingly.
- **Select All Images:** Select all images to add into the report. When there are more than 30 images in the exam, the last 30 images are selected by default.




Figure 8-13 Report Touch Screen

Save As: Press it to store the report as PDF file to external storage.

Preview: Press it to invoke print preview before print. Then switching report pages and zooming in report are supported.

Print: Press it to print the report via the connected report printer.

8.4 Measurement Accuracy

Table 1 Measurement Accuracy

Parameter	Range	Accuracy
1.B Mode Measurement		
Distance	Full Screen	< ±5%
Circumference (Ellipse)	Full Screen	< ±5%
Circumference (Trace)	Full Screen	< ±5%
Area (Ellipse)	Full Screen	< ±10%
Area (Trace)	Full Screen	< ±10%
Angle	Full Screen	< ±3%
2. M Mode Measurement		
Distance	Full Screen	< ± 5%
Time	Timeline display	< ±5%
HR	Timeline display	< ±5%
3.Doppler Mode Measurement		
Velocity	10-200cm/s	When angle ≤60° , < ±10%
Time	Timeline display	< ±5%
HR	Timeline display	< ±5%

Table 2 Strain Elastography Imaging Performance and measurement accuracy

Transducer Model	L12-5Q	L17-7HQ
Max. Penetration Depth(cm)	≥30mm	≥30mm
Spatial Resolution	≤10.5mm	≤10.5mm
Error of Geometric	≤±20%	≤±20%
Contract ratio of B image and Elastography image	≤±10%	≤±10%
Range of Strain Ratio	0.32-3.2	0.32-3.2
Error of Strain Ratio	≤±50%	≤±50%
Repetition Rate of Strain Ratio	≤10%	≤10%

9 Exam Data Management

9.1 Storing Images

The system supports storing static images and cine clips. What is displayed in Information area, Image area and Image parameter area on the main screen will be stored.

Storing static images:



Pressing the  hard key on the console will always capture what is on the image area of the screen. This includes live, frozen, or Cine images. It also includes reports or other GUI screens and review.

Storing a clip:



Pressing the  hard key on the console will capture the moving images in scanning or cine review status.

➤ Live Store

Live store is to capture the moving images in image scanning status. The system continues scanning while storing.



The store starts with the press of the  hard key and continues for the configured length of the clip or until the clip store is interrupted. The length of the clip can be configured by setting the **Duration for prospective** on the **Store/Print** page (See section 11.1.3 for details).

The following events can cause the clip store to stop:



- A second press of  key
- Display of a GUI screen or dialog
- Mode change
- Image parameters change
- Unfreeze the image

➤ Frozen Store

Frozen store is to store the cine clip between the start frame and end frame when in cine review status.



Freeze the image and press the  hard key to start storing. The default length of the cine clip between start frame and end frame can be configured by setting the **Duration for retrospective** on the **Store/Print** page (See section 11.1.3 for details). Or, you can manually change the start frame or end frame to determine the clip length.

9.2 Reviewing Images

To enter image review:

If Static or Clip images have been stored for the current exam, then they can be reviewed by pressing the <Review> hard key on the console. The review touch screen is shown as the figure below.

NOTE: If nothing has been stored in the current exam, then the <Review> hard key will invoke the Exam Database function (see the next section).




Figure 9-1 Review Touch Screen

Button	Description
'1*2', '2*2', '2*3', '4*4'	Change the displayed layout: 1*2, 4*4, 2*2, 2*3
'Page' navigation button	Turn pages to move forward or backward through the available images, one page at a time.


Select All	Select all the images in the current exam.
Show Selected	Toggle between showing all images and only showing the selected images.
Delete	Delete the selected image.
Export	<p>Export selected images to a removable media currently available. Plug in a USB disk, select an image, press this button and the following confirmation dialog pop-up:</p>  <p>Select the export path from destination drop list menu, select the export format and click OK to export. If there is no USB plugged in, the Export button is unavailable.</p>
Raw Data	Load the raw data of the selected image or clip for post-processing. Use controls on the console or on the touch screen to do post-processing operations, such as imaging optimization, measurement, annotation, etc.
DICOM Print	Select the reviewing images to print via the DICOM printer. Refer to Section 11.2.4 for details on configuring DICOM print.
Compare	Compare images in the same exam of the same patient, in different exams of the same patient and in different exams of different patients. Refer to Section 9.6 for details.

Table 9-1 Review Touch Screen Controls

9.3 Exam Database

The Exam Database provides a list of recently performed studies. It can be accessed by pressing the <Review> hard key on the console when there is no active exam.




Figure 9-2 Exam Database Main Screen

The main part of the display shows a list of studies. Clicking on the header of a field will sort the list by that field. Fields can be displayed or hidden.

Filter:

The database filter field at the top-left of the screen provides a powerful tool to find the study of interest. It filters the list based on the text that is typed in this field. The filter applies to all fields. By default the filter is set to blank, so the default list shows all exams.

Storage Size:

There is a box displaying current disk usage. It contains text with the current usage and is filled with a solid color to the extent that the current capacity is used. The text shows "<current usage> of <total capacity>". The units are "Mb" for values less than 1 Gb, and "Gb" for anything larger. The solid color fill is green when usage is less than 75% of capacity, yellow for usage between 75% and 95%, and red when disk usage is above 95%.

Send:

Pressing this button will send the selected exam(s) to the destination. This button is available when one or more exams are selected.

A dialogue box will pop up for you to choose Destination and Export Format when **Send** is pressed.

Destination is the location where the highlighted exam(s) shall be exported, it includes all configured network locations and any writable USB disk currently available. This includes:

- Available DICOM server location(s). (See 11.2.2)
- Available FTP server location(s). (See 11.2.3)
- Any inserted USB disk.
- Any inserted DVD drive.

Export Format: This location displays export format for static images, clips and Report. BMP, JPEG, TIFF, Raw Data and DICOM formats are available for static images. AVI, MP4, WMV, Raw Data and DICOM formats are available for clips. PDF format is available for Report.

➤ **Working with one study:**

A study is selected by clicking on it. When a study is selected thumbnail images from that study are shown on the right side of the screen. Operations such as reviewing and restarting of the selected study can be accessed on the touch screen. If a selected study contains measurement, pressing on the **Report** touch screen button can go directly to the worksheet page of that selected study.

A study can also be send to a network server, saved to a USB device or DVD drive, or deleted. If the study has been copied to either a server or to a USB device or DVD drive a small save icon appears next to it, indicating that it has been saved.

CAUTION:

- Studies stored on the system hard drive should be archived regularly. The system is not intended for long term storage of patient information. Confirm successful archiving before deleting a study from the hard drive.

➤ **Working with multiple studies:**

Multiple studies can be selected by clicking the small box at the left of each listed study. Multiple studies can be stored to a network server, saved to a USB device or DVD drive, or deleted. Only one study can be reviewed at a time.

Query/Retrieve:

Pressing this will open the Query/Retrieve page, as shown below, where you can enter key words and query prior exams from the configured DICOM Server. To configure the DICOM server, please see section 11.2.2.




Figure 9-3 Query/Retrieve Page

- **Patient ID, Patient Name, Accession:** enter the key words for query.
- **Exam Date:** enter the date range.

- **Query:** press to start the query, and all the queried exams will be displayed in the box below.
- **Retrieve:** select one queried exam and press **Retrieve** to download it from the DICOM server to the **Retrieve result** box.
- **Clear:** clear all the queried and retrieved results.

NOTE: **Query/Retrieve** button only displayed when Query/Retrieve function is invoked. The function could be configured in the Query/Retrieve, see section 11.2.2.7 for details.

9.4 Archiving Studies

All Clips and Static images stored on the system are stored internally in Raw Data format. They can be archived to other storage device for long-term storage in .bmp, .avi, .dcm and Raw Data formats as described below.

- The study can be sent to a DICOM server.
- The study can be send to a FTP server.
- The study can be saved to a USB or DVD drive.
- Images/clips can be sent to mobile devices.

Note:

If a clip length exceeds 3s, when selecting to export in DICOM format to DICOM server, USB stick or DVD drive, only the last 3s will be exported for this release.

Sending a study to DICOM server:

1. Configure a DICOM server. See Section 11.2.2 for details.
2. From the exam database screen, select a study or multi-studies.
3. Press **Send** and select a configured DICOM server from the **Destination** drop-down list.
4. Select the export formats and press **OK**.

Sending a study to FTP server:

Please see section 11.2.3 for details on configuring a FTP server. Once an FTP server is configured, the exam can be sent to the server from the exam database screen. Select the exam(s) from the list shown, and press **Send** to select the FTP server from the list of currently configured destinations. Select the export format and press OK to start sending the exam. A PDF report will be also sent to the FTP server together with the exam.

Saving a study to USB or DVD:

1. Plug the USB device or DVD drive into a USB port.
2. From the exam database screen, select a study or multi-studies.
3. Press **Send** and select the USB device or DVD drive from the **Destination** drop-down list.
4. Select the Export Formats and press **OK**.

Sending images/clips to mobile device

The images/clips stored on the ultrasound system can be sent to a mobile device, such as mobile phone and iPad. Follow the steps below to send images/clips to a mobile device:

1. Connect the network for your ultrasound system (See 11.2).
2. Go to exam Thumbnail field and select the image/clip you want to export. Maximum 10 images/clips can be transferred at one time.



3. Click the  shortcut key and the system will start exporting.
Note: The image and clip will be exported in JPEG and MP4 format respectively.
4. An instruction dialogue will pop up to guide you to extract the exported image/clip. Use WeChat on your mobile device to scan the QR code step by step.
5. All the images/clips of this exam will be viewed on your mobile device. Press the images/clips to save them to your mobile device.

WARNING

1. Please turn off the QR code dialogue box on the main screen when scanning is finished.
2. Please keep the transferred images/clips safe on your mobile devices, otherwise it may lead to patient information and data being disclosed.

9.5 Structured Report

Structured Reports are supported for OB, Gynecology, Cardiac and Vascular measurements on this system. They can only be sent to a DICOM server together with images after the function of sending structured report being enabled in DICOM setup page (see Section 11.2.2 for detail).

Sending structured reports to a DICOM server:

There are two ways to send structured reports to a DICOM server.

- From the exam database screen, select the exam that has structured report and image, select a configured server from the list of available destinations and send it manually. For this way, you should first go to DICOM setup page and select "Transfer on demand" as the DICOM store way.
- Go to DICOM setup page and select "Auto-transfer when End Exam" as the DICOM store way. The system will automatically send the structured report at the end of the exam.

9.6 Image Compare

Image Compare function is comparing images in the same exam of the same patient, in different exams of the same patient and in different exams of different patients.

To compare images of the same patient:

- There are two ways to compare images from the same patient exam.
 1. When there is an exam in progress, enter **Review** page, and press **Compare** button on the touch screen to open the image selection page. Select images to be compared, and press **Compare** button again to start the comparison.
 2. When there is no exam in progress, enter **Exam Database** page, and select the exam of the patient. Press **Compare** button on the touch screen to open the image selection page, and all the historical exam images of the patient will be displayed on the main screen. Select images to be compared, and press **Compare** button again to start the comparison.

To compare images of different patients:

- When there is no exam in progress, enter **Exam Database** page and select different exams of different patients. Press **Compare** button on the touch screen to open the image selection page. Select images to be compared, and press **Compare** button again to start the comparison.

Note: **Image Compare** in this release only supports comparing static images.

10 Presets

10.1 Preset Organization

The Presets are divided into two levels: the Exam Presets and Application Presets.

Exam Preset: Each transducer has its own set of Exam Presets. Each Exam Preset contains:

- The image parameters that optimize its transducer for an intended use.
- Pointers to Application Presets for Comments, Measurements, Body Marks and Patient demographic data.

Application Preset: The Application Presets are independent from the transducer. Application Presets are used to select Comments, Body Marks, Measurements and Patient demographic data. Since they are independent from the transducer, several Exam Presets can use the same Application Preset.

Figure 10-1 shows an example of how Transducers, Exam Presets, and Application Presets are related. For simplicity, this shows just a few of the items that are on the real system. In this example the C5-2Q and the E8-4Q both have an OB Exam Preset. The C5-2Q OB Exam Preset optimizes the C5-2Q imaging for OB while the E8-4Q OB Exam Preset optimizes the E8-4Q for the same use. The parameters used for each transducer can be different, and changing one Exam preset does not change the other.

However, both OB Exam Presets point to the same OB Measurement Preset as the Application Preset. This means you can, for example, just configure OB measurements once, and both the C5-2Q and E8-4Q will have updated OB measurements.

This example just shows a single kind of Application Preset. The system actually has separate Application presets for Comments, Body Marks and Measurements. The same principle applies to each of these: application presets can be shared across exam presets and transducers.

Transducers




Figure 10-1 Preset Organization

10.2 Selecting a Preset

Pressing the **<Transducer>** key on the console will open the **Transducer** touch screen. See figure 10-2 for an example Transducer touch screen. The currently active transducer is shown at the top of the touch screen. Below it are all the presets associated with that transducer. Pressing any preset button selects that preset, recalling its parameters for system use.




Figure 10-2 Example Preset Screen

10.3 Storing and Editing a Preset

There are two ways to store or modify an exam preset: Snapshot and Editing.

Snapshot:

- Select the exam preset you want to modify or use as the basis for a new preset.
- Make any changes you want to system settings using the standard imaging UI.
- Press the **<Transducer>** key on the console.
- Press the **Save** button on the touchscreen to update the current exam preset with the new setting.
- Press the **Save As** button to create a new preset and rename the preset.

Editing:

You can directly view and change the settings for any preset using the Set-up function.



- Click the Utility icon  on the status bar.
- Press **Presets** to display the preset touch screen, as shown below, which provides access to configuring Exam, Image, Comment, Body Mark and Measure presets. See the following sections for details.




Figure 10-3 Preset Main Screen

10.3.1. Exam Preset

Figure 10-4 shows an example of the exam preset page where you can configure which Comment, Measure, Body Mark or Patient info presets are associated with each exam preset, or adjust the display order of exam presets of each transducer.




Figure 10-4 Exam Preset Page

Configure the exam presets:

- **Transducer:** Select one transducer from the list to configure its exam presets.
- **Exam List:** Select one exam preset to configure its associated Comment, Measure, Body Mark or Patient info settings.
- **Measure:** Select one of the pre-defined application measurement packages to be the default measure preset for the selected exam preset.
- **Comment:** Select one of the pre-defined comment presets to be the default comment preset for the selected exam preset.

- **Body Mark:** Select one of the pre-defined body mark presets to be the default body mark preset for the selected exam preset.
- **Patient Info:** Select one of the pre-defined patient information categories for the selected exam preset, which determines the patient information items displayed on the patient information page by default.
- **Set Default:** Set the selected exam preset as the default exam preset of the transducer. The default exam preset will be marked with "**".
- **Copy As and Rename:** Copy the selected exam preset as a new preset and then rename it.
- **Delete:** Delete the copied exam preset.
- **Restore Factory Settings:** Restore the preset data of the selected exam to factory settings.

Adjust the display order of exam presets:

The display order of exam presets of each transducer can be adjusted on the Preset Order page, as shown below. The left part shows the transducer selection and the list of supported exam presets of the selected transducer; the right part shows the display order of exam presets, which is consistent with the display order on the **Transducer** touch screen.




Figure 10-5 Preset Order Page

On the Preset Order page, you can do the following operations;

- Select a transducer from the Transducer drop-down list for adjusting the display order of its exam presets.
- Use the ">>" and "<<" arrows to determine which exam presets will be displayed.
- Select one exam preset, and use "↑", "↓", "←" and "→" arrows to adjust its display order.

10.3.2. Image Preset

Figure 10-6 shows an example set-up screen for Image Preset, where you can configure the imaging parameters for an exam preset. This example shows the screen for editing the B-mode settings for the C5-2Q OB exam preset.




Figure 10-6 Example Set-up Screen for Image Preset

Transducer and **Exam**: There are drop-downs at the top of the screen for selecting the Transducer and Exam Preset you want to edit. Each transducer has its own set of exam presets, and these two drop-downs let you select which exam preset, on which transducer, you want to edit.

TI: Select the TIB, TIS or TIC to display on main screen.

Power: Set the default acoustic output power of the current exam preset.

Image Modes: The next row of controls show tabs for each imaging mode. These let you select which imaging mode you want to edit for the current exam preset. The example shows the B-mode tab selected.

The image mode is divided into two sections. Parameters that have one value for each preset are shown on the left. Parameters that are associated with Image Types are shown on the right.

Image Type: Each imaging mode has a set of image types. For example in B-mode the types are Detail, General, and Penetration. While imaging, the image type lets you quickly change the aesthetic look of the image without changing settings like depth or invert status. The right side of the preset set-up screen shows a tab for each image look. The parameters shown below those tabs let you customize that image type for the current preset.

Restore Factory Settings: Restore the image preset of the current exam preset of the selected transducer to the factory default settings.

Restore All Factory Settings: Restore the image presets of all exam presets of all transducers to the factory default settings.

10.3.3. Comment Preset

Figure 10-7 shows an example set-up screen for Comment Preset, where you can add or edit the comment texts of each Comment preset.




Figure 10-7 Comment Preset Screen

Editing Comment Preset:

Select a comment preset from the preset list on the left side of the screen, and then you can do the followings to edit the comment texts for the selected preset.

➤ Adding a new Comment:

1. Move the cursor to a blank block and press <Set>.
2. Enter a new comment through keyboard.

➤ Editing an Exist Comment in Comment Preset:

1. Move the cursor to a comment and press <Set>.
2. Edit the selected comment through keyboard.

➤ Deleting an Exist Comment in Comment Preset:

1. Move the cursor to a comment and press <Set>.
2. Press **Delete** key on the keyboard to delete the selected comment.

General Settings:

- **Auto-erase comments when the image is unfrozen:** If this option is enabled, the comments will be erased when the image is unfrozen, otherwise the comments will only be erased on demand or at the start of a new exam.
- **Continuous Arrow:** If this option is enabled, you can add multiple arrows continuously by pressing <Set> key after **Arrow** touch button is enabled in Comment function. If this option is disabled, only one arrow can be added after **Arrow** touch button is enabled. A second arrow is added by pressing **Arrow** touch button again.
- **English Comments Library:** If this option is enabled, the system will use the comments library in English when the system language is not English.

10.3.4. Body Mark Preset

Figure 10-8 shows an example set-up screen for Body Mark Preset, where you can configure which body mark graphics appear with each Body Mark preset.




Figure 10-8 Body Mark Preset Screen

Editing Body Mark Preset:

Select a Body Mark preset from the preset list on the left side of the screen, and then you can do the followings to edit the body mark preset for the selected preset.

➤ Adding a Body Mark to a Preset:

The right of the screen provides Body Mark Library. Select one domain of Body Mark from the drop-down list, for example ABD, and its body mark graphics are displayed in the box beneath.

Move the cursor to a Body Mark in the Body Mark Library box on the right side of the screen and press **<Set>**. When a Body Mark graphic is added to the box on the middle of the screen which displays the pre-defined body mark graphics for the select preset, it is marked with a green check mark in the Body Mark Library box. When more than one page of Body Mark graphics are added to the middle box, the system will create another new page, indicating by dots at the top of the box. Clicking the dots switches the page.

➤ Deleting a Body Mark from a Preset:

Move the cursor to a Body Mark graphic in the middle box and press **<Set>**. Press the **Delete** button below the box to delete it.

Or, move the cursor to a Body Mark graphic with green check mark on it and press **<Set>** to delete it from the selected preset.

➤ Setting a Default Body Mark for a Preset:

Select a Body Mark from the box of Body Mark Graphics for Selected Preset and Press **Default**. The Body Mark graphic is set as the default Body Mark to the selected preset.

The default Body Mark cannot be deleted from a preset until another Body Mark is selected as a default one.

General Settings:

- **Auto-erase body mark when the image is unfrozen:** If this option is enabled, the body mark will be erased when the image is unfrozen, otherwise the body mark will only be erased on demand or at the start of a new exam.

10.3.5. Measure Preset

10.3.5.1. General Set-up

Figure 10-9 shows an example set-up screen for Measure Preset, where you can configure general measurement settings.




Figure 10-9 Measure Preset Screen

● Unit Settings

The system supports following unit settings:

- **Distance:** Set the default unit of distance measurement. "mm" and "cm" are available.
- **Area:** Set the default unit of area measurement. "mm²" and "cm²" are available.
- **Volume:** Set the default unit of volume measurement. "mm³" and "cm³" are available.

● Cardiac Settings

The system supports following Cardiac measurement settings:

- **LV Volume:** set the author of the formula that is used in **LV Volume** calculation. There are three options: Teichholz, Gibson and Cube.

● OB Settings

The system supports the following OB measurement settings:

- **Fetal Age:** set equation for measurements which are used for calculating fetal age.
- **Fetal Growth:** set equation for measurements which are used for calculating fetal growth.
- **Estimated Fetus Weight:** select an equation for the Estimated Fetus Weight calculation.
- **Growth Curves Display:** set single or quad curves as the default display format for the Growth Curves.
- **Default GA Display:** set the CUA (Composite Ultrasound Age) or AUA (Average Ultrasound Age) as a default result displayed in the worksheet.

- **EDD Display:** set whether to display EDD calculation result in the measurement result window.
- **GP Display Format:** set the display format of fetal growth percentage on growth curve graphic. Available display formats include: **No** (not display the growth percentage), **%** and **SD** (standard deviation).
- **Worksheet Settings:**
 - **Calc. Method:** set the calculation method for the finally displayed result in the report when multiple times of measurement operation were done for one measurement item. Available methods include Last, Average, Max. and Min..
- **Measure Caliper:**
 - **Caliper Line Display:** Set whether to display caliper line between the start point and the end point when measurement is finished.
 - **Ellipse Cross Line Display:** Set whether to display the cross line inside the ellipse when using ellipse measurement.

10.3.5.2. Application Parameters




Figure 10-10 Application Parameter Set-up Screen

On the **Application Parameter** page, you can configure the default measurement results of Doppler trace measurement for each exam application. Select one clinic application in the **Application** drop-down list, for example ABD, and then tick the measurement result items in the list below. When you perform Doppler trace measurement, the system will display all the ticked result items by default.

Active Measure Type: set whether Generic measurement or Application measurement function is invoked by default for each measurement package when pressing <Measure> hardkey on the console. This setup only takes effect on the first measurement invoking after switching the exam preset. Under the same exam preset, the measure type at next invoking corresponds with the measure type you performed before exiting the measurement function previously.

11 Utilities

To open the **Utility** screen:

1. Press **<Cursor>** key to display the cursor;



2. Move the cursor to the Utility icon displayed at the lower left corner of the screen;
3. Press **<Set>** key.

The **Utility** screen provides access to System Setup, Presets, Connectivity, Maintenance and Screen adjust. Each of these is described in separate sections.

11.1 System Set-up

System setup is used to configure parameters that are unrelated to presets. Generally, there is one value of each system setup parameter that is shared across all presets.

Entering System Set-up:

Open **Utility** screen. Press **Set up** touch screen button, and then the **System** touch screen button to access system setup.

Reloading Factory Default Settings:

1. Press "Restore Factory Settings" on the System Settings screen, you are prompted "Restore System Settings to factory default? This will erase all system data."
2. Press **Yes** to restore to factory default, and press **No** to cancel.

11.1.1. General Set-up




Figure 11-1 General Set-up Screen

Item	Options	Description
Hospital	Input freely	Set hospital name displayed on the top left of the screen and diagnosis report.
Language	Chinese, English, etc.	Set the system language (new language is effective after reboot the system).
Date Format	YYYY/MM/DD/ MM/DD/YYYY DD/MM/YYYY	Set the date format.
Date	/	Set the system date Note: If the license is invalidated because of changing the system date, please contact EDAN serviceman.
Time Format	12-AM/PM, 24-hh:mm:ss	Set the time format.
Time	/	Set the system time, format: H/M/S.
Button F1/F2	PDI, DPDI, Needle, Center Line, Full Screen, eLearn, TDI	Define the F1/F2 keys, select one of the pull-down options. The options that are available will depend on what functions are enabled on the system.
Time Zone	/	Select the time zone from the drop down list.
Video Mode	PAL/NTSC	Set the output video mode. The selected video mode should be the same as that of the s-video printer, otherwise the printer cannot work.
FootSwitch	Freeze, Image, Clip, Print, Update	Set a function for the left key or right key of footswitch. If the physical footswitch only has one button then the Left button selection applies.
Soft Keyboard Preview	✓/✗	Set whether to display the input text above the soft keyboard when typing.
Trackball Speed	Slow/ Normal/ Fast	Set the speed of the trackball.
Transducer Button	Freeze, Image, Clip	Set a function for the transducer button. There are two buttons on the biplane transducer which can be used to switch plane and set to custom function, respectively.

Table 11-1 General Set-up Description

11.1.2. Patient Set-up




Figure 11-2 Patient Set-up Screen

Item	Options	Description
Weight Unit	kg, lbs	Set the weight unit of patients
Height Unit	cm, ft/in	Set the height unit of patients
Title of custom field 1/2	/	You can define two additional fields for data entry on the Patient Information screen. The Patient Information screen only displays the data entry when you define the title of the custom field.
Time limit for exam restart	0/12h/24h/48h/72h/Unlimited	You can define the time limit for restarting exam. Only exams within the time limit can be restart. If 0 is selected, no exam can be restart.
Patient name display option	One field/Two fields	You can define the patient name display format. The patient information page displays "Patient Name" for one field and displays "Last Name" and "First Name" for two fields.
Clinical EDD	40 Weeks, 41Weeks	Select one item as the default time period of pregnancy. This will affect the calculation of clinical EDD.
Clinical GA	LMP, BBT	Select one item as the beginning date of clinical GA. The selected item will be displayed on the Patient Information Page by default.
Auto Patient ID	✓ /✗	Set whether to generate Patient ID automatically

		when entering Patient Information page or storing images.
Enter patient ID at storing	✓/✗	Set whether to display the patient information dialogue for entering patient ID when storing the image if no patient ID is entered.

Table 11-2 Patient Set-up Description

11.1.3. Storage Set-up




Figure 11-3 Storage Set-up Screen

Item	Description
Store Clip	Duration for prospective Set the cine length for prospective cine storing in live scanning status.
	Duration for retrospective Set the default cine length for retrospective cine storing in the frozen status.
	Display Time Length between Start and End Frame Set whether to display the time length between the start frame and end frame on the cine bar. The time length display is helpful for knowing the cine length when storing a clip in the frozen status.
USB storage device	Send image to USB device synchronously when storing image. Set whether to send static image to USB device synchronously when image is stored in the Thumbnail field. The available image formats are BMP, JPEG and TIFF.
Store beep	Off, Low, Med., High Set the volume level for pressing the store

		key.
Exported folder name	With Patient name With Patient ID	Set the naming rule for the exported folder.
Exam Database Send Option	Static Images/ Clips/US Report/PICC ECG Report	Select file types which can be selected to send to a network server or a USB device in exam database.

Table 11-3 Storage Set-up Description

11.1.4. Print Set-up




Figure 11-4 Print Set-up Screen

Item		Description
Video Printer	Default Printer	Select one video printer as the default printer from the list when more than one video printers are connected with the system via USB cable.
	Paper Size	Select the print paper size of Canon SELPHY_CP1300. P size(postcard), L size(large) and C size(card) are available.
Report Printer	Default Printer	Select one report printer as the default printer from the list when more than one report printers are connected with the system.
Network Printer	/	Network printers can be connected with Auto and Manual method. Note: TCP/IP network settings should be configured


		for this system prior to connecting network printers. Auto: press the Search button to search the available network printers in the same network, and select the printers from the list to connect. Manual: enter the IP address of the network printer, select the printer model name from the Printer drop-down list and then press the Search button to search the network printer. Select the printer from the search result to connect.
Proxy Printer	/	Select Enable Proxy Printer to turn the Proxy Printer function on/off. IP Address, Port: The system searches for the matching server on the internet through these settings. Verify: Verify the information of proxy printer server is input correctly.
Add Driver	/	Multiple printer drivers were included in this system. If the driver of your printer is not included, the driver files provided by the manufacturer can be imported from the USB stick to this system via the Add Driver button.
Print Test	/	Print the test page to check whether the printer is connected successfully.

Table 11-4 Print Set-up Description


To use Proxy Printer:

The system supports **Proxy Printer**, which sends the report files in the ultrasound system to the proxy printing program of the Mini PC, and then the proxy printing program performs the actual printing operation. Please operate as follows:

1. Connect the ultrasound system to the mini PC with a network cable, and connect the mini PC to the printer through USB.



2. Click **Set up > Connectivity** in the ultrasound system, set the mode of obtaining local IP to manual, and add P address and gateway information as follows:



3. Click **Set up > System > Print** to enter the page for **Proxy Printer** settings. Select **Enable Print Proxy**, set the IP address to 192.168.1.10, port number to 7000, and set the default printer of the video printer and report printer to print proxy.
4. Click **Verify** to check whether the printer proxy function can print normally. If the connection fails, restart the mini PC and try again.

Note: The printer driver is installed in the mini PC. If you need to change the default printer of the **Print Proxy**, please contact your local distributor or Edan service.

11.1.5. Report Set-up




Figure 11-5 Report Set-up Screen

	Item	Description
Report Logo	Import	Import a bmp format logo from USB disk.
	Logo Position	Set the logo position to locating at the left or right side of report header.
	Logo Size	Set the logo size to Small or Large.

	Delete	Delete the imported logo.
	Display the model and the first exam date	Set whether to display the model and the first exam date in the report and fill in the corresponding information.
	Model	
	Date	
Report Settings	Hospital, Exam Date, Report Type, Patient Name, Patient ID/AccessNum, Other Patient Info, Measurements, Growth Curve Image, Comment, Findings, Fetus Score Result, Doctor Signature, Operator, Print Time	Set whether the information is displayed in the report. Measurements, Growth Curve, Image, Fetus Score Result, Findings and Comment can be adjusted the display order in the report by pressing ↑ / ↓ button.

Table 11-5 Report Set-up Description

11.1.6. Image Set-up




Figure 11-6 Image Set-up Screen

Item	Options	Description
Hide non intra-operative indicator for L17-7SQ	✓/✗	Set whether to hide the hint of “non intra-operative” while using transducer L17-7SQ.
Auto invert while linear probe steers	✓/✗	Set whether ultrasound image inverts while the linear probe steers.
Auto zoom image on linear probe at the shallow depth	✓/✗	Set whether to auto zoom in image at the shallow depth when using linear transducers.
Color and PW/CW sync invert	✓/✗	Set whether the images and color bars in Color mode and PW/CW invert synchronously.
Spectrum keeps refreshing after sample gate moves	✓/✗	Set whether the spectrum strip keeps updating after moving the sample gate.
Auto Triplex while enter PW	✓/✗	Set whether the system automatically enters Triplex(B/C/PW) mode while in PW mode.
Show frequency point	✓/✗	Set whether the frequency of transducers is displayed in the format of frequency point.

Status after freeze		Cine/Caliper /Application/Comment/Body Mark	Set whether the system directly enters Cine, Generic measurement, Application measurement, Comment or Body Mark function after pressing Freeze button.
Scale unit		cm/s, kHz	Set the velocity units of spectrum scale.
Default zoom factor		0.8-2.0	Set the default zoom factor of the image area.
PW Mode	Gain	✓/✗	Optimize Gain or not when press Auto button on the control panel in PW mode.
	DR	✓/✗	Optimize Dynamic Range or not when press Auto button on the control panel in PW mode.
	Scale /Baseline	✓/✗	Optimize Scale/Baseline or not when press Auto button on the control panel in PW mode.

Table 11-6 Image Set-up Description

11.1.7. Power Set-up




Figure 11-7 Power Set-up Screen

Item	Options	Description
Auto-Freeze& Waiting Time	✓/✗ 1/5/10/15/20/25/30/60min	Set whether to turn on auto-freeze function by default or not; and set the waiting time to perform auto-freeze.
Turn off display & Waiting Time	✓/✗ 1/5/10/15/20/25/30/60min	Set whether to turn on the function of turning off the display by default or not;

		and set the waiting time to turn off the display.
Auto Sleep& Waiting time	✓/✗ 1/5/10/15/20/25/30/60min	Set whether to turn on system sleep function by default or not; and set the system waiting time to enter sleep mode.
Sleep Mode	Sleep Deep Sleep	Set the system sleep mode. The deep sleep mode consumes less power and therefore the system could have longer standby time.

Table 11-7 Power Set-up Description

11.1.8. User Set-up




Figure 11-8 User Set-up Screen

Item	Options	Description
Enable Password Protection	✓/✗	Show or hide the login dialog when booting up the system. Password is required to enable password protection function.
User Login at exiting Sleep mode	✓/✗	Set whether to display the User Login dialog for user login when exiting the sleep mode.
Display user name on main screen	✓/✗	Set whether to display user name on the main screen.
User List	✓/✗	Show all users displaying user name and user type. Click the dialog before the user to select this user for edit operation.

Table 11-8 User Set-up Information

User type includes Administrator and Operator.

- Administrator users have authority to enable/disable password protection, add/delete/edit users and can view all exams in the patient database. There is one pre-defined administrator user called Admin.
- Operator users can only edit their own user information, change their own password, and view exams that they created.
- There's one pre-defined operator user called Emergency for Emergency login without entering password. The exams created by Administrator and Operator cannot be viewed through Emergency login.

There's a couple of buttons for different user edit operation. It includes Add User, Delete User, Edit User, and Change Password.

- **Add User:** Click it to add user in the user list.
- **Change Password:** Click it to change the password of the users.
- **Delete User:** Click it to delete the highlighted user in user list.
- **Edit User:** Click it to modify the user information.

Caution

1. For security consideration, a password with high secure intensity is suggested for each user account, and the password should be changed periodically.
2. Please keep your user name and password safe.
3. Set a password with high security for the pre-defined administrator user "Admin" immediately at the first system powering on when you receive the ultrasound system.
4. Always enable the function of user login with password protection.
5. When the password of the pre-defined administrator user "Admin" is forgotten, please contact the serviceman for the system password reset.

11.2 Connectivity

Entering Connectivity Screen:

Open **Utility** page. Press **Set up** touchscreen button, and then the **Connectivity** touchscreen button to access Connectivity screens.

The Connectivity screens support configuration of network access and services. It is divided into 3 tabs:

- **TCP/IP:** Configures access to the network from the system.
- **DICOM:** Configures network DICOM services.
- **FTP:** Configures non-DICOM storage to a network via FTP.
- **Time Sync:** Configures time synchronization through network connections.

WARNING

1. Please build a secure network environment for your ultrasound system to protect the patient data being attacked during network transmissions.
2. Patient data transmitted by the system is encrypted with AES algorithm.
3. Please ensure the physical security of the network by trying the following measures:
 - a) Install IDS (Intrusion Defense System) and IPS (Intrusion Protection System) software in the

- network environment where your ultrasound systems are used.
- b) Use a network that is isolated from the external environment by a firewall.
 - c) Use the WPA2 protocol for authentication and encryption of wireless network, and a password with high secure intensity is required.
 - d) Do not connect the ultrasound system and non-medical devices to a same network.
 - e) Set a login password with high secure intensity at your FTP server side. Keep the login user name and password of FTP server safe. The leak of user name and password may lead to patient information and data being disclosed.
4. Anti-virus software is not installed on this device. Please take anti-virus measures in the network environment where your ultrasound systems are used.

11.2.1. TCP/IP

This screen configures access to a network.




Figure 11-9 TCP/IP settings

Wired Settings:

The following settings apply when connecting a system to a wired network via the network port on the side of the system.

Get Local IP: Either Manually entered (Static) or DHCP. The correct setting will depend on how your DICOM network is administrated. If you are unsure, try DHCP first. Generally a Static IP is only needed if the target PACS system requires it. If it is needed, contact your network IT manager.

IP Address, Subnet Mask, Gateway, DNS: These settings determine how the system communicates with your network. If you chose DHCP then your network router will set these automatically. If you chose Manually Entered IP then contact your network IT manager for the appropriate settings.

Wireless Settings:

Enable Wireless: This will turn the wireless radio on/off. No wireless networks are displayed when this is disabled.

Networks: When wireless is enabled the system will search for wireless networks that are available and display them in this list. Networks that have been previously accessed will show up with an asterisk ("*"). If there is currently an active network it will show up with a checkmark ('✓'). If the network requires a password it shows up with a lock icon. Each displayed network shows the strength of the wireless signal.

Refresh: Clicking on this button updates the list of displayed networks.

Add: Clicking on this button brings you a window for connecting a hidden WiFi network by entering its network name, security protocol, and password.

The following controls require that a wireless network has been selected from the network list. Click on the name of a network to select it.

Join: This joins the selected network. If a password is needed a dialog box will be displayed to enter it.

Forget Network: This forgets any password of the selected network that had been entered, but the network is still shown in the list.

Advanced Settings: This brings up a dialog box with additional settings for the selected wireless network. The dialog box includes the following:

- **Password:** This is useful when the network password has changed.
- **Method:** Either Manually entered (Static) or DHCP. Generally wireless networks use DHCP, and a Static address is only needed if required by the target PACS system.
- **IP Address, Subnet Mask, Gateway, DNS:** If you chose DHCP then your network router will set these automatically. If you chose Manually Entered IP then contact your network IT manager for the appropriate settings.

11.2.2. DICOM

This screen configures DICOM services, shown as the figure below.



Figure 11-10 DICOM Settings

11.2.2.1. General Settings

All the DICOM services are required to configure general settings. These settings include:

a. Local Settings:

Local AE Title: Any 16 characters that uniquely identify this system on your DICOM network. The default “STR_SCU” will work unless you have multiple Edan systems on your network.

Time Out: This determines the time after which this system will stop trying to establish a connection to the DICOM server.

b. Server Settings:

The main interaction in this section is a list of configured servers. It starts off as an empty list, and grows as servers are added. Most sites will only use one server, but if the system is moved between locations then multiple servers may be entered.

➤ **Add a new server :** Click **Add** button and type in relevant information of the new server:

- **Name:** Type in the name of the server that appears in the drop-down list of server selection.
- **AE Title, IP Address, Port, Max PDU:** These are the settings of the destination DICOM server; it's how the system finds the DICOM server on your network. The AE title and IP Address are unique to your network; contact your network IT manager for these settings.
- **Service Type:** Selects the service type of this DICOM server, including Storage, Worklist, MPPS, Print and Storage Commitment.
- **Encryption:** Check the **Encryption** box if you want to encrypt the DICOM server.

Enable the certification according to the DICOM server configurations by importing the certificate file, entering the certificate password and selecting a proper certificate type.

- c. **Test the server:** There are two tests to ensure that the server information is entered correctly. Click on any field for a given server to make that server selected, then:

- **Ping:** A successful Ping means that the system can communicate with the server at a low-level; basically that the two computers 'see' each other. As a security measure, some servers on the Internet may be configured to not respond to a Ping even if the connection is successful.
- **Verify:** A successful Verify means that the system can communicate with the server at a DICOM level; basically that the DICOM on both computers understand each other. A successful Verify will typically mean that your DICOM configuration is correct.

- d. **Other controls:**

- **Copy As:** Copies settings of the selected server. The system will pop up a dialog box to edit the content copied in the previous command. After editing, add it to a new server.
- **Edit:** Edits the information of a selected server.
- **Delete:** Deletes the selected server.

11.2.2.2. DICOM Storage Settings

Click **Storage** button on the left side of DICOM screen to configure DICOM storage settings. Specific settings include:

- **Storage Server:** Selects one configured server from the drop-down list as the default server for Auto-transfer.
- **DICOM Image Store/DICOM Clip Store:** This determines when DICOM images and clips are sent to the server. The options are:
 - **Transfer on demand:** Images and clips are only sent when you manually send them. When there is no exam in progress the Review hard key will show a list of all exams on the hard drive. Select an exam to manually send.
 - **Auto-Transfer when Store:** Each image is sent automatically when it is captured. This has the advantage that images are immediately available for review at the server while the exam is in progress. This is only available for image auto-transfer.
 - **Auto-Transfer when End Exam:** Images are sent automatically when the exam is ended. This is the most common setting.
- **Structured Report Config:** You can set the following parameter for structured reports:
 - **Report Type:** This determines the type of structured report. Select Enhanced report or Comprehensive report according to the report type your PACS system requires.
 - **Send SR with Image:** This will enable the function of sending structured report together with images to a DICOM server.

11.2.2.3. Modality Worklist

Click **Worklist** button on the left side of DICOM screen to configure Modality Worklist settings. Specific settings include:

- **Enable:** Turns Modality Worklist on/off.
- **Worklist Server:** Selects one configured server from the drop-down list as the default server

- to query for the worklist.
- **Update Worklist:** Determines when the worklist is updated. Choices are:
 - On Demand: Updates only when the Update button is pressed from the patient page.
 - On Start of Exam: Updates when the patient page is displayed at the start of each exam.
 - **Study Description Source:** Modality Worklist can fill the ultrasound comments section from the server. Depending on:
 - Requested Procedure Description: Obtains comments from DICOM tag (0x0010,0x4000);
 - Scheduled Procedure Description: Obtains comments from DICOM tag (0x0040,0x0007)
 - Comments on The Schedules Procedure Step: Obtains comments from DICOM tag (0x0040,0x0400)
 - **Display Ended Scheduled Exam:** Sets whether to display the ended exams in the worklist.
 - **Filter:** Determines query conditions which will be displayed above the worklist for entering text to quickly filter exam information. The query conditions include:
 - **Modality(US)**: Sets whether the system only filters from the ultrasound worklist server.
 - **AE Title:** Sets whether to display AE Title above the worklist. The system will only filter from the worklist of the entered AE Title. The entered AE title will be memorized across system shutdowns.
 - **Patient Info:** Sets whether to display items related to patient information above the worklist. The related patient information items include Patient ID, Patient Name, Access Num., and requested ID.
 - **Date Range:** Sets the range of dates for the worklist query. The data range options include: Today, Yesterday and Today, Today and Tomorrow, Yesterday and Tomorrow and User Define. Note, the option of “Yesterday and Tomorrow” includes today’s exams; the option of “User Define” requires to enter the start and end time on the worklist screen

11.2.2.4. MPPS Settings

Click **MPPS** button on the left side of DICOM screen to configure the MPPS settings. Specific settings include:

- Enable MPPS:** Turns MPPS (Modality Performing Procedure Step) service on/off. If MPPS service is on, the ultrasound system will send the exam status to MPPS server automatically when starting or ending an exam.
- **MPPS Server:** Selects one configured server from the drop-down list as the default server to receive the exam status..
 - **Additional Materials:** Sets whether to display **Additional Materials** item on patient information page.

11.2.2.5. Storage Commit Settings

Click **Storage Commit** button on the left side of DICOM screen to configure Storage Commitment settings. Specific settings include:

- **Enable Storage Commit:** Turns DICOM Storage Commitment function on/off.
- **Storage Commit Server:** Selects one configured server from the drop-down list to confirm whether the DICOM transfer to this server is successful. The confirmation is undergoing in the background. When an exam's transfer to the DICOM server is confirmed successfully, a small

save icon appears next to this exam on the Exam Database screen, indicating that it has been saved successfully on the DICOM server.

The system uses the port information of the storage commitment server to receive storage commitment information from the server by default, and also supports the establishment of a new association for receiving storage commitment information, that is, using the local port information of the ultrasound system to receive storage commitment information.

To establish a new association:

- Check the **New Association** box and input the **Local Port** information of the ultrasound device.
- Press **Start Server** button to connect to the network and conduct the storage commitment by the new association.
- If encryption of the new association is required, please check the **Encryption** box, import the certificate, enter the certificate password, and select a proper certificate type.

11.2.2.6. DICOM Print Settings

Click **Print** button on the left side of DICOM screen to configure the DICOM print settings. Specific settings include: **DICOM Print Server**: Determines which configured DICOM server will do the image printing.

- **Color Mode**: Determines the color mode of images. Currently only gray mode is supported.
- **Number of Copies**: Determines how many copies of files are printed in a single image printing operation.
- **Print Priority**: Determines where the image printing is inserted into the queue in the DICOM printer. Three options of High, Medium and Low are available. For High priority, the image is printed first among the queued printing tasks.
- **Image Display Format**: Determines the layout of images displayed on a printed file.
- **Medium Type**: Determines the storage medium of DICOM print. Paper and Film are available.
- **Film Orientation**: Determines the orientation of the film. Portrait and Landscape are available.
- **Film Size**: Determines the size of the film being used. Make sure the designated size is the same as the size of the currently loaded film.
- **Trim**: Determine whether a trim box to be printed around each image on the film.
- **Min Film Density**: Determines the minimum film density.
- **Max Film Density**: Determines the maximum film density.
- **Border Density**: Determines the density of the border area around the image on the film. Black and White are available.
- **Empty Image Density**: Determines the density of the empty image area on the film. Black and White are available.
- **Magnification Type**: Determines how the printer magnifies an image to fit the film. Interpolation methods of Replicate, Bilinear and Cubic are available. Generally, Cubic provides the best results, followed by Bilinear.
- **Smoothing Type**: Determines the smoothing method for the image. Default and None are available.
- **Resolution**: Determines the resolution of the image. Standard and High resolution are available.
- **Support 12 Bit**: Determines whether to use 12-bit printers to do the imaging printing.

11.2.2.7. Query/Retrieve Settings

Click **Query/Retrieve** button on the left side of DICOM screen to configure Query/Retrieve settings. Specific settings include:

- **Enable Query/Retrieve**: Turns **Query/Retrieve** on/off.
- **Query/Retrieve Server**: Selects a configured server from the drop-down list as the default server to query and retrieve history exams.
- **Local Port**: The configured server transmits exam data to the ultrasound system through the local port.

NOTE: IP, port, AE Title and other Settings of the ultrasound system should also be set on the server side.

11.2.3. FTP Server

This screen configures the system to connect to an FTP server on the local network. This allows the system to store files to a local server without using DICOM. To use this, a PC or server needs to be configured as an FTP server on the local network. The mechanism to do this depends on the operating system used. Please contact your local IT support for assistance.

Once configured, studies can be sent to the FTP server from the Exam Database shown in Review. Studies are sent to the configured folder, where each study appears in a separate folder with particular name (a combination of the patient's name and ID, the study time and the transfer time).




Figure 11-11 FTP Set-up Screen

FTP Store: Determines when images, clips and PDF report are sent to the FTP server. The options are **Transfer on demand** and **Auto Transfer when End Exam**.

FTP Server list: The main interaction in this section is a list of configured servers and directories. It starts off as an empty list, and grows as servers are added. Most sites will only use one, but if the system is moved between locations then multiple entries may be useful. Clicking in any field

in this list will select that server.

- **Name:** The name of the server that appears in the drop-down list of the patient database.
- **IP Address, Shared Directory:** These are the address of the FTP server and the directory used on that server.

Testing the server: There are two tests to ensure that the server information is entered correctly. Click on any field for a given server to make that server selected, then:

- **Ping:** A successful Ping means that the system can communicate with the FTP server at a low-level; basically that the two computers 'see' each other. As a security measure, some servers on the Internet may be configured to not respond to a Ping even if the connection is successful.
- **Connect:** A successful Connect means that the system can communicate with the FTP server, and FTP transfers will work. If this fails but Ping works it could mean:
 - The destination computer is not correctly configured as an FTP server.
 - The password on the server has changed. Use Edit to re-enter the password.
 - The Shared Directory does not exist. Use Edit to confirm the directory.

Other Controls

- **Add:** Adds another line in the list of servers. This automatically invokes Edit.
Note: To minimize the risk of disclosing patient information and data, please check the **TLS** box to encrypt the transfer process when adding a new server.
- **Edit:** Available when an FTP Server has been selected. This invokes a dialog that edits the IP address, name, directory, and password.
- **Delete:** Available when an FTP Server has been selected. This deletes the selected server.
- **Default:** Makes the selected server as the default for Auto-transfer.

11.2.4. Time Synchronization

The **Time Sync** screen configures time synchronization service, where you can set the system time to synchronize with the network time.




Figure 11-12 Time Synchronization settings

- **Address** and **Port**: Enters the Address and Port of a network server. The system searches for the server through these settings. After the server is connected to the network, the system time is updated to the standard time.
- **Sync**: Click **Sync** button to obtain the network time from the time synchronization server and synchronize the local system time.

11.3 Maintenance

Open **Utility** page and press **Maintenance** touch screen button to access Maintenance screens.

The Maintenance screen provides access to controls that are not typically needed during normal operation of the system.

11.3.1. License

The **License** page displays which features are currently licensed for use on the system. At the top of the screen is displayed the current license key as well as a license QR code. Below that is a list of all licensable features, along with its current status. The system supports temporary trial licenses. Click the **Trail** button can try the function for one time in the valid period of three months. If a feature is so licensed the expiration date is also shown.

- Press **Import** button to import a license file from a USB external storage device. Please contact your distributor or Edan service engineer to obtain a new license key.
- Press **Revert** button to restore the previous license if the imported license is not correct.

- Press **Import Config** button to import config file from a USB external storage device.
- Press **Show Config** button to view the config file showing whether a feature is enabled or not.




Figure 11-13 System License Screen

11.3.2. Version

The **Version** screen shows the current version of software, firmware, and selected hardware for the system. This information is only needed if requested by an Edan service engineer. This page also includes an **Upgrade** and **Export Logs** button.

Caution

1. Anti-virus measures such as USB device virus scanning should be carried out prior to using USB flash drive.
2. Do not connect an USB device with unknown provenance to the ultrasound system.
3. To avoid loss of patient data, please backup the patient data prior to software upgrade.

11.3.3. Export/Import

The Export/Import screen provides access for you to export/import user-configured presets, settings and Findings using an external storage device.




Figure 11-14 Export/Import Screen

To export user data:

1. Select an external USB storage device.
2. Check the items to be exported: Presets, Set Up, and Findings.
 - Presets include the preset data about Exam, imaging parameters, Body Mark, Comments, etc.
 - Set Up includes the setting data about system set-up, connectivity, etc.
3. Press **Export** button to begin the export process.

To import user data:

1. Select an external USB storage device
2. Press **Import** button to bring you a dialog. All the user data on the USB disk will be loaded and displayed. The use data must have been previously exported from a system.
3. Check the items to be imported: Presets, Set Up or Findings.
4. Press **Import** button to begin the import process.

Note:

The Presets and Set-up setting data are only supported to import across ultrasound systems loaded with the same software version.

11.3.4. Demo

The Demo screen provides access for you to show a set of images you collected for demonstration purpose.

Import: Imports a collection of images to the ultrasound system.

1. Before import, you need create any a folder in USB disk and put the images inside.
2. Connect the USB disk to the ultrasound system.
3. Open the **Demo** screen and press **Import** button.
4. Find the path of the folder and press **OK** to import.

SlideShow: Shows an imported collection of images slide by slide.

Export: Exports the imported images to USB storage device.

Delete: Deletes the imported images.




Figure 11-15 Demo Screen

11.3.5. Self-Check

The Self Check screen provides access to the following functions:

- Checking the fan status,
- Testing the LCD screen,
- Checking the transducer element, and
- Testing the touch screen.

11.3.6. Tool


The Tool screen provides access to system maintenance which must be performed by authorized service personnel. Please refer to the Service Manual for the details.

11.3.7. Transducer Element Check

Proper performance of the transducer is the prerequisites for acquiring images or signals that provide the intended information for the users. To ensure the proper performance of a transducer, it is suggested to implement the transducer element check each time a transducer is activated for use or at regular transducer performance check.

To perform transducer element check:

1. Activate a transducer from the **Transducer** touch screen.
2. Open the **Self-Check** screen.
3. Press the **Probe Check** button, and the system will bring you a confirmation dialogue.
4. Ensure the residual coupling gel is removed from the transducer. Place the transducer on a flat table without any object around the transducer. Then press **OK** on the dialogue to run the test.
5. If the transducer element is in malfunction, dark strips will be displayed, shown as the left figure below; if the transducer element functions well, no dark strips will be displayed, shown as the right figure below.



11.4 Screen Adjust

Entering Screen Adjust Screen:

Open **Utility** page. Press **Set up** touch screen button, and then the **Screen Adjust** touch screen button to access Screen Setup touch screen.

The brightness and contrast of the monitor and touch screen in the system can be customized.

- **Main Screen Brightness:** adjusts the brightness value of the monitor.
- **Main Screen Contrast:** adjusts the contrast value of the monitor.
- **Main Screen Color Temp.:** adjusts the color temperature of the monitor.
- **Touch Screen Brightness:** adjusts the brightness value of the touch screen.

Press **Restore all settings** button to restore the factory settings for all brightness and contrast values.

12 In Between Exams

12.1 Unpacking

Visually examine the package prior to unpacking. If any signs of mishandling or damage are detected, contact the carrier to claim for damage. After unpacking the device, you should follow the packing list to check the product carefully and to make sure that no damage has occurred during transportation. For installation, please contact your local distributor or the EDAN service department at: support@edan.com.

WARNING

1. Do not use the device if it is found to be damaged or defective.
 2. Do not drop or collide with the transducer. Otherwise you shall give up using it.
-

12.2 Transport

The system is designed to be portable and easily transported. Power off the system and secure all accessories before moving it to another location.

CAUTION

- 1 Switch off the ultrasound system. Unplug the AC adapter from the power source and secure the power cable.
 - 2 Remove the transducer and place them in a safe place.
 - 3 Disconnect and secure the connecting cable.
 - 4 Connect optional system accessories.
 - 5 Secure the system and complete the system setup, and then perform all the daily checking before using it.
-

To prepare the system for shipment over long distances or rough terrain, repack the system in the factory packing

To prepare the system for transport over distances: load the system into a vehicle using a lift gate.

To prevent lateral movement of the system, secure the system with cargo straps. To prevent sudden jarring of the system during transport, provide anti-shock cushions beneath the system.

It is suitable for transportation by air, railway, highway and ship. Protect the system from inversion, collision, and splashing with rain and snow.

12.3 Storage

- ◆ Do not place the device near the ground, walls or the roof.
- ◆ Keep good indoor ventilation. Avoid strong and direct sunlight, and erosive gas.

13 Troubleshooting and Maintenance

In order to ensure proper system operation and function, a maintenance and inspection plan should be established to periodically check the safety of the system. If any system malfunction is experienced, contact EDAN or authorized representatives.

13.1 Daily Checklist

Check before the system is switched on, if any system malfunction is experienced, eliminate the malfunction before use, or contact EDAN or authorized representatives for service if needed.

- ◆ Visually inspect all the transducers for unintended rough surfaces, sharp edges or protrusions. Do not use any damaged transducer.
- ◆ Visually inspect all the transducer assembly cables and associated connectors.
- ◆ Visually inspect all the cords. Do not turn on the power if a cord is frayed or split, or shows signs of wear.
- ◆ Verify that the controls are clean and free from gel or contaminants.

Check after the system is switched on:

- ◆ Visually check the on-screen display and lighting. Verify that the monitor displays the current date and time and there isn't any error message.
- ◆ Verify that the transducer identification and indicated frequency on the screen are correct for the activated transducer.
- ◆ Ensure that there isn't obvious abnormal noise, discontinuous image or dark area.
- ◆ Ensure that it isn't smelly or too hot.
- ◆ Ensure that the ultrasound window isn't too hot, checking with your hand.
- ◆ Verify that the buttons on the keyboard are good to operate.
- ◆ Ensure that there isn't obvious abnormal noise from the loudspeakers.
- ◆ Ensure that there isn't obvious abnormal noise from the air fan.
- ◆ Contact your local distributor or Edan service if there is excessive noise from the system speaker or fans.

13.2 Troubleshooting

If any persistent system malfunction is experienced, e.g. an onscreen error message, blank imaging screen, absent menus, please refer to the following table below. If the failure cannot be eliminated, please contact EDAN or authorized representatives.

Item	Problem	Solution
1.	When the power switch is on, there isn't any image displayed.	<ol style="list-style-type: none"> 1. Check power supply. 2. Check wires and plugs. 3. Check transducers are connected properly.

2.	Strip-shape or snowflake-shape disturbance occurs on the display screen.	<ol style="list-style-type: none"> 1. Inspect the power supply. 2. Check whether it is disturbed by the ignition action of any other device. 3. Check the disturbance of electric or magnetic field in the surrounding environment. 4. Check whether the plug and socket of power supply and transducer are properly connected.
3.	Image is not displayed clearly on the screen.	<ol style="list-style-type: none"> 1. Adjust overall gain (Gain). 2. Adjust eight TGC slide controls. 3. Adjust focus (the number and the position).
4.	Image window is dark.	<ol style="list-style-type: none"> 1. Adjust the brightness and slide the TGC controls on the touch screen. 2. Check whether the transducer is connected correctly.
5.	The button is unresponsive	<ol style="list-style-type: none"> 1. Check the control panel to see whether the button is blocked and press it several times to release it. 2. Clean the button

Troubleshooting for high system temperature:

1. Check whether system vents are clear and unobstructed. See section 3.2.1 for the location of system vents. Too much dust on the vents or obstructed vents could cause high temperature to the system.
2. Check whether the ambient temperature where the system is used is above 40°C. The system must be used in the ambient temperature lower than 40°C.
3. Check whether the five fans at the system vents are working.

If all these troubles above are cleared, but the system still displays high temperature warning, please contact the Service.

13.3 System Cleaning and Disinfection

Use only the EDAN-approved substances and methods listed in this chapter to clean the system. The warranty does not cover damage caused by using unapproved substances or methods.

Edan Instruments has validated the cleaning and disinfection instructions included in this User Manual. It is the responsibility of the healthcare professional to ensure that the instructions are followed so as to ensure adequate cleaning and disinfection.

General Points:

Keep your monitor, cables and accessories free of dust and dirt. To prevent the device from damage, please follow the procedure:

- Use only recommended cleaning substances and disinfectants listed in this manual. Others may cause damage (not covered by warranty), reduce product lifetime or cause safety hazards.
- Always dilute according to the manufacturer's instructions.
- Unless otherwise specified, do not immerse any part of the equipment or any accessories in liquid.

- Do not pour liquid onto the system.
- Do not allow liquid to enter the case.
- Never use abrasive material (such as steel wool or silver polish).
- Inspect the monitor and reusable accessories after they are cleaned and disinfected.

WARNING

The console is not waterproof. Do not immerse or expose to extended moisture. Splash resistance does not extend to transducer connectors. Keep connectors dry.

13.3.1. Cleaning and Disinfecting the System Surface

System Surface Cleaning

The validated cleaning agents for cleaning the system are:

- Ethanol (75%)
- Isopropanol (70%)

To clean the system surface:

1. Switch off the system and unplug it.
2. Wear sterile protective gloves to prevent infection.
3. Remove all residual foreign matters from the system surface using sterile cloth or paper towel immediately after examination.
4. Use a sterile cloth dampened with cleaning agent to gently wipe the entire exterior surface, including the screen, of the equipment thoroughly until no visible contaminants remain.
5. After cleaning, wipe off the cleaning agent with a sterile cloth dampened with tap water until no visible cleaning agent remains.
6. Wipe off with a dry sterile cloth to remove residual moisture.
7. Leave the system to air dry.
8. If the system is not visually clean at the end of the cleaning steps, please repeat the cleaning steps through step 4 to step 7.
9. Inspect the system to ensure that there is no damage.

NOTE:

1. Make sure the system is free of gel and any other visible residue.
2. Use a soft dry cloth without chemicals for cleaning. The monitor surface is easily scratched.

To clean the trackball:

1. Remove the front panel bezel.
2. Remove the trackball as shown in *Figure 13-1*.
3. Wipe the trackball, X and Y rollers, and the auxiliary idler wheel with a sterile cloth dampened with the cleaning solution until no visible contaminants remain.
4. Wipe off the cleaning solution with a new sterile cloth dampened with tap water after cleaning until no visible cleaning agent remains.
5. Wipe off with a dry sterile cloth to remove residual moisture.
6. Leave the trackball, X and Y rollers and the auxiliary idler wheel to air dry.

7. Assemble the trackball and front panel bezel after the assembly parts completely dry.



Figure 13-1 Assembling and Disassembling Trackball




Figure 13-2 X, Y and the Auxiliary Idler Wheels

CAUTION

1. Do not drop or place foreign objects inside the trackball assembly or it may affect the trackball operation and damage the system.

NOTE:

Be sure to clean the X and Y idler wheels and the auxiliary idler wheel.

System Surface Disinfection

The validated disinfecting agents for disinfecting the system are:

- Ethanol (75%)
- Isopropanol (70%)

To disinfect the system surface:

1. Switch off the system and unplug it.
2. Wear protective gloves to prevent infection.
3. Clean the system prior to disinfection.
4. Prepare the disinfectant solution.
5. Wipe the entire exterior surface of the equipment thoroughly with a soft sterile cloth dampened with the disinfectant solution. Follow the disinfectant manufacturer's recommended contact time and mode.
6. After disinfection, wipe off the disinfecting agent with a new sterile cloth dampened with sterile water.
7. Wipe the system with a dry sterile cloth or leave the system to air dry.
8. Inspect the system to ensure that there is no damage.

13.3.2. Cleaning and Disinfecting the ECG Module and Cable

ECG module and cable cleaning

The validated cleaning agents for cleaning the ECG module and cable are:

- Ethanol (75%)
- Isopropanol (70%)

To clean the ECG cable:

1. Disconnect ECG cable from the patient and disconnect the ECG module from the ultrasound system.
2. Wear sterile protective gloves to prevent infection.
3. Remove all residual foreign matters from the ECG module and cable using sterile cloth or paper towel immediately after examination.
4. Use a sterile cloth dampened with cleaning agent to wipe the entire exterior surface of the ECG module and cable thoroughly until no visible contaminants remain.
5. After cleaning, wipe off the cleaning agent with a sterile cloth dampened with tap water until no visible cleaning agent remains.
6. Wipe off with a dry sterile cloth to remove residual moisture.
7. Leave the ECG module and cable to air dry.
8. If the ECG module and cable is not visually clean at the end of the cleaning steps, please repeat the cleaning steps through step 4 to step 7.
9. Inspect the ECG module and cable to ensure that there is no damage.

ECG module and cable disinfection

The validated disinfecting agents for disinfecting the ECG module and cable are:

- Ethanol (75%)
- Isopropanol (70%)

To disinfect the ECG module and cable:

1. Disconnect ECG cable from the patient and disconnect the ECG module from the ultrasound system.
2. Wear protective gloves to prevent infection.
3. Clean the ECG module and cable prior to disinfection.
4. Prepare the disinfectant solution.
5. Wipe the entire exterior surface of ECG module and cable thoroughly with a soft sterile cloth dampened with the disinfectant solution. Follow the disinfectant manufacturer's recommended contact time and mode.
6. After disinfection, wipe off the disinfecting agent with a new sterile cloth dampened with sterile water.
7. Wipe the ECG module and cable with a dry sterile cloth or leave the system to air dry.
8. Inspect the system to ensure that there is no damage.

13.4 Maintenance

The system should be maintained regularly, at least annually, by a qualified technician who has adequate training, knowledge and experience. That person should be familiar with the Service Manual, available from your Edan representative.

Appendix A Specifications

A.1 Electrical Safety Classifications

According to the type of protection against electric shock	Internally powered equipment, Class I equipment
According to the degree of protection against electric shock	Type BF Type CF(ECG module)
According to the degree of protection against harmful ingress of liquid	Whole device: IPX0 Transducer (not including the transducer connector): IPX7; Footswitch: IP68
According to the degree of safety of application in the presence of a flammable gas	Equipment not suitable for use in the presence of a flammable gas
According to the mode of operation	Continuous operation
According to the grade of EMC	CISPR 11 Group 1, Class A
Standards Compliance	EN 60601-1:2006/A1:2013 idt IEC 60601-1: 2005/A1:2012 EN 60601-1-2: 2015 idt IEC 60601-1-2: 2014 EN 60601-2-37:2008/A1:2015 idt IEC 60601-2-37:2007/A1:2015

A.2 Power Supply

Operating Voltage	100 -240 V~
Operating Frequency	50 Hz/60 Hz
AC Input Current	2.5A-1.5A
DC Input Current	19V=7.8A MAX
TWSLB-018 Lithium battery	
Capacity	6800 mAh
Voltage	14.4V
Working time	Proximately 1.5 hours for one fully charged battery; Proximately 3.0 hours for two fully charged batteries. (Condition of use = 1/2 scanning+1/2 frozen)
Charging time	About 3.5 hours for one battery; About 6.5 hours for two batteries.

A.3 Machine Specifications

Main unit dimensions	395 mmx385 mmx64mm(without cushion)
Weight	≤4.5kg (without battery and any other accessory)

A.4 Display Specifications

Display	TFT-LCD
Diagonal Size	15.6 inches
Open Angle	0°-180°
Pixel Number	1920x1080
White Luminance	300 cd/m ² (typ)
Contrast Ratio	700 (typ)

A.5 General Specifications

Display Modes	<p>B Mode: B, 2B, 4B</p> <p>Color Mode: B/C(Single, Dual); B+B/C(Dual Live); B/C/PW (triplex mode)</p> <p>PDI/DPDI Mode:</p> <p>B/PDI(DPDI) (Single, Dual); B+B/PDI(DPDI) (Dual Live); B/PDI(DPDI)/PW (triplex mode)</p> <p>PW Mode:</p> <p>B/PW;(Update) B/PW; (duplex, simultaneous) B/C/PW(Update) B/C/PW, B/PDI(DPDI)/PW; (triplex mode)</p> <p>CW Mode:</p> <p>B/CW; B/C/CW, B/PDI(DPDI)/CW;</p> <p>M Mode: B/M (Display layout: Up/down, Left/right)</p> <p>TDI Mode:</p> <p>B+ TVI (Dual Live) B+ TVI + TEI (Dual Live) B+ TVI + TVD (Update) B+TVI + TVD ((triplex mode) B+TVM</p> <p>3D/4D: 3D Rendering, 3 Sectional Planes</p> <p>Elastography:</p> <p>E, B+E(Display layout: Up/down, Left/right, 1:1);</p>
---------------	---

Hard Drive Storage	120GB or 512GB or 1TB
Report Packages	Abdomen, Obstetrics, Small Parts, Vascular, Cardiac, Gynecology, Urology, Pediatrics, Emergency.

A.6 Wi-Fi Specifications

Standard Conformance	802.11b, 802.11g ,802.11n
Frequency Band	2.412-2.484GHz(@2.4GHz band)
Modulation Technique	OFDM DSSS CCK
Typical Power($\pm 2\text{dBm}$)	Transmit 2.4G Transmit 1MbpsDSSS :17.3dBm 2MbpsDSSS :17.3dBm 5.5MbpsCCK :17.3dBm 11MbpsCCK :17.3dBm 6MbpsOFDM: 17.1dBm 9MbpsOFDM :17.1dBm 12MbpsOFDM: 17.1dBm 18MbpsOFDM :17.1dBm 24MbpsOFDM :16.2dBm 36MbpsOFDM :15.3dBm 48MbpsOFDM :14.6dBm 54MbpsOFDM: 13.8dBm
Wi-Fi Quality of Service	
Data rate	802.11b: up to 11 Mbps @ 2.4 Ghz 802.11g: up to 54 Mbps @ 2.4 Ghz 802.11n: up to 65 Mbps @ 2.4 Ghz
Data security	WPA2 encryption
Application-layer delay	No requirement. It's not used in real time.
Application-layer reliability	No requirement. Application failure will be notified to the user immediately.
System capacity	No more than one device will be allowed to connect with the ultrasound system.
System anti-interference	Can be coexistent with other Wi-Fi devices.
Network interruption alarm	Network interruption is notified by disconnection icon and failure in transmission is notified in Transfer Status window.
EMC test process	Wi-Fi function is not affected when the system is imposed with radiation interference complied with IEC60601-1-2:2014 standard.

A.7 ECG Specifications

Patient Cable	IEC, AHA
Lead Mode	3-Lead: I, II, III
AC Filter	50 Hz, 60 Hz
HR Range and Accuracy	Adult: 15 bpm to 300 bpm Pediatric: 15 bpm to 350 bpm Resolution: 1 bpm Accuracy: $\pm 1\%$ or 1 bpm, whichever is greater.
QRS Detection	Range: 40 ms~120 ms Amplitude: 0.5 mV~5 mV
Patient Leakage Current	< 10 μ A

A.8 Operating, Storage and Transportation Environment

A.8.1 Operating Environment

Temperature	0 °C ~ +40 °C(+32 °F~+104 °F)
Relative humidity range	15% RH ~ 95% RH(non-condensing)
Atmospheric pressure range	86kPa ~ 106kPa

A.8.2 Storage and Transportation Environment

Temperature	-20 °C ~ +55 °C(-4 °F~+131 °F)
Relative humidity range	15% RH ~ 95% RH(non-condensing)
Atmospheric pressure range	70kPa ~ 106kPa

A.9 Transducer Specifications

No.	Transducer	Center Frequency	No.	Transducer	Center Frequency
1	L17-7HQ	12.0MHz	2	E8-4Q	6.2MHz
3	C6-2MQ	3.9MHz	4	C5-1Q	3.25MHz
5	C5-2Q	3.5MHz	6	L12-5Q	8.0MHz
7	L17-7SQ	12.0MHz	8	MC8-4Q	6.2MHz
9	P5-1Q	2.7MHz	10	P7-3Q	5.0MHz
11	MC9-3TQ	6.4MHz	12	L12-5WQ	8.0MHz
13	E10-3BQ	6.5MHz	14	E10-3HQ	6.5MHz
15	L17-7Q	11.0MHz	16	L12-5HQ	8.0MHz
17	ECL12-3Q	Convex: 6.5 MHz Linear :8.0 MHz			

A.10 Configuration Difference

Models	Configuration Difference			
	Feature 1	Feature 2	Feature 3	Feature 4
	Seminal Vesicle Meas.	Testis Meas.	Fluid POD	3D/4D
Acclarix AX3	√	√	√	√
Acclarix AX3 Exp	√	X	√	√
Acclarix AX3 Super	X	X	√	√
Acclarix AX25	X	√	√	√
Acclarix AX28	√	X	X	√
Acclarix AX2	√	√	√	X
Acclarix AX2 Exp	√	X	√	X
Acclarix AX2 Super	X	X	√	X
Acclarix AX15	X	√	√	X
Acclarix AX18	√	X	X	X

Appendix B Ultrasound Intensity and Safety

B.1 Ultrasound in Medicine

The use of diagnostic ultrasound has proved to be a valuable tool in medical practice. Given its known benefits for non-invasive investigations and medical diagnosis, including investigation of the human fetus, the question of clinical safety with regards to ultrasound intensity arises.

There is no easy answer to the question of safety surrounding the use of diagnostic ultrasound equipment. Application of the ALARA (As Low As Reasonably Achievable) principle serves as a rule-of-thumb that will help you to get reasonable results with the lowest possible ultrasonic output.

The American Institute of Ultrasound in Medicine (AIUM) states that given its track record of over 25 years of use and no confirmed biological effects on patients or instrument operators, the benefits of the prudent use of diagnostic ultrasound clearly outweigh any risks.

B.2 Ultrasound Safety and the ALARA Principle

Ultrasound waves dissipate energy in the form of heat and can therefore cause tissue warming. Although this effect is extremely low with Transcranial Doppler, it is important to know how to control and limit patient exposure. Major governing bodies in ultrasound have issued statements to the effect that there are no known adverse effects from the use of diagnostic ultrasound, however, exposure levels should always be limited to As Low As Reasonably Achievable (the ALARA principle).

Imaging Functions Affecting Acoustic Output

In addition to the level of voltage transmitted, adjustment of the following imaging functions and /or controls may affect the acoustic output.

Item	Affection
Probe	Acoustic output will be changed with the change of probe.
Imaging mode	There are different parameters applied in B mode, Color mode, M mode, and PW mode, so acoustic output will be changed with the change of among B mode, Color mode, M mode, and PW mode.
Field of view (scan angle or scan width)	Frame rate may be changed with the change of the scan angle or the scan width, and the acoustic output will also be changed.
Image depth	Pulse repeated frequency will be changed with the change of the image depth, and the acoustic output will be changed.
Focus number	Frame rate and focus position will be changed with the change of the focus number, and acoustic output will also be changed.
Focus position	Beam power level and the beam aperture will be changed with the change of the focus position, and acoustic output will also be changed
Freeze	When freezing the system, it will stop transmitting ultrasonic wave.
Transmission power	The output of probe will be changed with the change of the transmission power, and acoustic output will be changed.
Multi-frequency	The character of the wave focus will be changed with the change of the frequency, and acoustic output will be changed.

Line density	The acoustic output will be changed with the change of the number of the scanning line (line density).
PRF	The acoustic power will be changed with the change of PRF.
Sample volume	The pulsed wave and the power will be changed with the change of the sample volume, and acoustic output will be changed.
Presets	Presets contain all the parameters above, so any change of the presetting will change acoustic output.
Restart, or power on/off	System will return to the default setting when restarting, or powering on/off the system, and acoustic output will be changed.

B.3 Explanation of MI/TI

B.3.1 MI (Mechanical Index)

Cavitations will be generated when ultrasound wave passes through and contacts tissues, resulting in instantaneous local overheating. This phenomenon is determined by acoustic pressure, spectrum, focus, transmission mode, and factors such as states and properties of the tissue and boundary. This mechanical bioeffect is a threshold phenomenon that occurs when a certain level of ultrasound output is exceeded. The threshold is related to the type of tissue. Although no confirmed adverse mechanical effects on patients or mammals caused by exposure at intensities typical of present diagnostic ultrasound instruments have ever been reported, the threshold for cavitation is still undetermined. Generally speaking, the higher the acoustic pressure, the greater the potential for mechanical bioeffects; the lower the acoustic frequency, the greater the potential for mechanical bioeffects.

The AIUM and NEMA formulate mechanical index (MI) in order to indicate the potential for mechanical effects. The MI is defined as the ratio of the peak-rarefactional acoustic pressure (should be calculated by tissue acoustic attenuation coefficient 0.3dB/cm/MHz) to the square root of acoustic frequency.

$$MI = \frac{P_{r,a}}{\sqrt{f_{awf}} \times C_{MI}}$$

Where, $C_{MI} = 1 \text{ Mpa. MHz}^{-1/2}$, $P_{r,a}$ is the Attenuated Peak-rare-factional Acoustic Pressure and f_{awf} is Acoustic Working Frequency.

B.3.2 TI (Thermal Index)

Heating of tissues is caused by absorption of ultrasound when the ultrasound energy is applied. The temperature rise is determined by the acoustic intensity, exposed area and thermophysical properties of the tissue.

In order to indicate the potential for temperature rise caused by thermal effects, the AIUM and NEMA formulate thermal index (TI). It is defined as the ratio of the total acoustic power to the acoustic power required to raise the tissue temperature by 1°C.

According to different thermophysical properties of the tissue, TI is divided into three kinds: TIS, TIB and TIC.

TIS (Soft Tissue Thermal Index): It provides an estimate of potential temperature rise in soft or similar tissues.

TIB (Bone Thermal Index): It provides an estimate of potential temperature rise when the ultrasound beam passes through soft tissue and a focal region is in the immediate vicinity of bone.

TIC (Cranial Bone Thermal Index): It provides an estimate of potential temperature rise in the cranial bones or superficial bones.

B.3.3 Display of MI/TI

The system provides real-time display of MI/TI values in the upper right part of the screen. The start point of MI/TI value is 0.0.

The operator should monitor these values during examinations and keep the exposure time and output level at the minimum amounts needed for effective diagnosis.

The display precision is 0.1.

MI display error:

When measured $MI \leq 0.5$, the absolute display error ≤ 0.25 ;

When measured $MI > 0.5$, the relative display error $\leq \pm 50\%$.

TI display error:

When measured $TI \leq 2.0$, the absolute display error ≤ 1.0 ;

When measured $TI > 2.0$, the relative display error $\leq \pm 50\%$.

B.4 Acoustic Output

B.4.1 Factors that Contribute to Uncertainty in the Output Display

A number of factors should be considered in display accuracy determination methods, such as:

- Transducer variability
- System variability
- Measurement variability and accuracy
- The number of operating conditions of which the system is capable and the number tested in obtaining display accuracy results
- Whether display accuracy will be determined by specific combinations of system, mode, transducer assembly and transmit patterns, or all allowed combinations of them
- Accuracy of system software MI and TI calculation algorithms.
- Engineering approximations for real-time calculations

B.4.2 Differences between Actual and Displayed MI/TI

Actually, many assumptions adopted in the process of measurement and calculations are relatively conservative. Over-estimation of actual in situ intensity exposure, for the majority of tissue paths, is made to the measurement and calculation process. For example, attenuation coefficient of 0.3 dB/cm·MHz, which is much lower than the actual value for most tissues of the body, is adopted. And conservative values of tissue characteristics are selected for use in TI models. Therefore, the display of MI and TI should be used as relative information to assist operator in prudent use of ultrasound system and implementation of ALARA principle, and the values should not be interpreted as the actual physical values in tissues or organs examined.

B.4.3 Measurement Uncertainty

Measurement uncertainties table

	Intensity	Pressure	Power	Center frequency	MI
Uncertainty($K=2$)	$\pm 29.32\%$	$\pm 14.66\%$	$\pm 29.32\%$	$\pm 0.20\%$	$\pm 14.66\%$

B.4.4 Acoustic Power Default Settings

The ultrasound system allows direct control of acoustic power by the Power paddle key on the touch screen. The range can be adjusted is 10% to 100%. The higher the acoustic power number, the greater the acoustic output.

The factory default settings of acoustic power is 100%. The default settings can be reconfigured by



the operator through the Acoustic Power item on **->Preset->Image Preset** page. The ultrasound system switch to default settings upon power up, new patient, new exam or new transducer.

B.4.5 Acoustic Output Limits

In accordance with the FDA Track 3 requirements, the maximum acoustic output level from any transducer in any operating mode is expected to fall below the limits as listed below.

FDA Maximum Acoustic Output Limits for Track 3(Attenuated Values)

Application	$I_{spta.3}(mW/cm^2)$	MI	TIS/TIB/TIC
Regions(except eyes)	≤ 720	≤ 1.9	≤ 6.0

B.5 Operator Control Features

The possibility of producing mechanical/thermal biological effects can be influenced by three kinds of controls: Direct Controls, Indirect Controls, and Receiver Controls. The qualified operator may use the system controls to minimize the ultrasound output while acquiring necessary clinical information.

◆ Direct Controls

The acoustic output of the system can be controlled directly through the level of voltage transmitted. In this case, the maximum acoustic output never exceeds the limits in any mode of operation.

◆ Indirect Controls

The acoustic output of the system can be controlled indirectly through many imaging parameters, including imaging modes, field of view, line density, probe frequency, focus number/position, depth and pulse repetition frequency (PRF).

The imaging mode determines whether the ultrasound beam is scanning or non-scanning. Thermal bioeffect is closely associated with B, M, PW and Color mode.

Acoustic attenuation of tissue is directly connected to probe frequency.

The focus number/position is related to active aperture of probe, beam width and frame rate.

The higher PRF (pulse repetition frequency), the more output pulses occur over a period of time.

◆ Receiver Controls

The receiver controls (such as gain, TGC, dynamic range and image processing), which are used to improve image quality, have no effect on acoustic output. Thus these controls should be optimized before increasing acoustic output.

B.6 Prudent Use Statement

Although no confirmed bioeffects on patients caused by exposure from present diagnostic ultrasound equipment have ever been reported, the potential exists that such bioeffects may be identified in the future. Therefore, the ultrasound should be used prudently. High levels of acoustic output and long exposure time should be avoided while acquiring necessary clinical information.

B.7 References for Acoustic Output and Safety

1. "Bioeffects and Safety of Diagnostic Ultrasound" issued by AIUM in 1993
2. "Medical Ultrasound Safety" issued by AIUM in 1994
3. IEC 62359:2017, Ultrasonics - Field characterization - Test methods for the determination of thermal and mechanical indices related to medical diagnostic ultrasonic fields.
4. Guidance for Industry and FDA Staff: Information for Manufacturers Seeking Marketing Clearance of Diagnostic Ultrasound Systems and Transducers, June 27, 2019 by U.S. Department of Health and Human Services, Food and Drug Administration.
5. .IEC60601-2-37, Medical electrical equipment - Part 2-37:2007+AMD1:2015 Particular requirements for the basic safety and essential performance of ultrasonic medical diagnostic and monitoring equipment, International Electro technical Commission.
6. Roy C. Preston, David R. Bacon, and Robert A. Smith, Calibration of Medical Ultrasonic Equipment - Procedures and Accuracy Assessment, IEEE Transactions on Ultrasonics, Ferroelectrics, and Frequency Control, Vol. 35, No. 2, page110, March 1988.

B.8 Transducer Acoustic Output Data

Please refer to the User Manual Advanced Volume (P/N: 01.54.458907) for details acoustic output data of each transducer.

Appendix C Order List

The following accessories are recommended for use on the system.

WARNING

Only accessories supplied or recommended by EDAN can be used, the battery and transducers of EDAN can be only used on EDAN's systems. Otherwise, the performance and electric shock protection cannot be guaranteed. If electrical or mechanical equipment from other companies need to be connected to the device, please contact EDAN or authorized representatives before connection.

The following accessories are recommended for use on the ultrasound system.

Part Name	Model	Part Number
Ultrasonic Transducer	L17-7HQ	02.01.211856
	E8-4Q	02.01.214513
	C5-2Q	02.01.212622
	L12-5Q	02.01.212623
	L17-7SQ	02.01.211857
	MC8-4Q	02.01.212625
	P5-1Q	02.01.213916
	P7-3Q	02.01.214038
	MC9-3TQ	02.01.213995
	E10-3BQ	02.01.214793
	E10-3HQ	02.01.214791
	C6-2MQ	02.01.214776
	C5-1Q	02.01.214783
	L17-7Q	02.01.214800
	L12-5HQ	02.22.002982
Needle Guide Bracket Kit	L12-5WQ	02.22.003416
	ECL12-3Q	02.22.003276
	BGK-C5-2	02.01.211006
	BGK-CR10UA	02.01.102963

	BGK-L40UB	02.01.210407
	BGK-001	02.01.215191
	BGK-002	02.01.215192
	BGK-003	02.01.215193
	BGK-004	02.01.215194
	BGK-005	02.01.215372
	BGK-006	02.01.215373
	BGK-007	02.01.215514
	BGK-008	02.01.215468
	BGK-009	02.01.215834
	BGK-010	02.01.215835
	BGK-012	02.01.216312
Power Cable, European Standard	FG-L23X-003-04	01.13.036638
Power Cable, American Standard	FG-L23X-20150323-001	01.13.037122
Lithium-Ion battery	TWSLB-018	01.21.064404
Adaptor	MENB1150A1949F02	21.21.064243
Ultrasound Gel	M-250B	01.57.078008
	Aquasonic 100	01.57.078001
USB Disk	/	01.18.052245
Footswitch(single button)	FS-81-SP-USB	01.10.000910
Footswitch(doule button)	FS-81-SP(TWIN)-USB	01.10.027323
Suitcase	/	01.56.466572
Trolley	MT-808	83.63.560455
Multi-Transducer Connector(MTC)	MTC-801	83.63.560613
ECG Module	/	02.01.214642

ECG USB signal cable	/	01.13.037636
Mini PC	/	01.18.052605
ECG patient cable, 3-lead, IEC, Defib, Snap	EC03DIS121	01.57.471379
ECG patient cable, 3-lead, AHA, Defib, Snap	EC03DAS121	01.57.471380
ECG patient cable, 5-lead, IEC, Defib, Snap	EC05DIS121	01.57.471467
ECG patient cable, 5-lead, AHA, Defib, Snap	EC03DIS121	01.57.471379
ECG electrodes, disposable	H99SG	01.57.471858
Mini PC	/	01.18.052605

NOTE: The part name may vary depending on context, but the part number is constant.

Appendix D EMC Information

Electromagnetic emissions

Guidance and manufacturer's declaration – electromagnetic emission		
The system is intended for use in the electromagnetic environment specified below; The customer or the user of the system should assure that it is used in such an environment.		
Emission test	Compliance	Electromagnetic environment – guidance
RF emissions CISPR 11	Group 1	The system uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment.
RF emissions CISPR 11	Class A	
Harmonic emissions IEC 61000-3-2	Class A	The system is suitable for use in all establishments other than domestic and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.
Voltage fluctuations/flicker emissions IEC61000-3-3	Complies	

NOTE:

The EMISSIONS characteristics of the system make it suitable for use in industrial areas and hospitals (CISPR 11 class A). If it is used in a residential environment (for which CISPR 11 class B is normally required) the system might not offer adequate protection to radio-frequency communication services. The user might need to take mitigation measures, such as relocating or re-orienting the equipment.

Electromagnetic immunity

Guidance and manufacture's declaration – electromagnetic immunity			
The system is intended for use in the electromagnetic environment specified below. The customer or the user of the system should assure that they are used in such an environment.			
Immunity test	IEC/EN 60601 test level	Compliance level	Electromagnetic environment - guidance
Electrostatic discharge (ESD) IEC/EN 61000-4-2	± 8 kV contact ± 15 kV air	± 8 kV contact ± 15 kV air	Floors should be wood, concrete or ceramic tile. If floor are covered with synthetic material, the relative humidity should be at least 30%.
Electrical fast transient/burst IEC/EN 61000-4-4	±2 kV for power supply lines	±2kV for power supply lines	Mains power quality should be that of a typical commercial or hospital environment.
Surge IEC/EN 61000-4-5	±1 kV for line to line ±2 kV for line to ground	±1 kV for line to line ±2 kV for line to ground	Mains power quality should be that of a typical commercial or hospital environment.
Power frequency (50/60Hz) magnetic field IEC/EN 61000-4-8	30 A/m	30 A/m	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment.
Voltage dips, short interruptions and voltage variations on power supply input lines IEC/EN 61000-4-11	0 % U _T ; 0.5 cycle At 0°, 45°, 90°, 135°, 180°, 225°, 270° and 315° 0 % U _T ; 1 cycle and 70 % U _T ; 25/30 cycles) Single phase: at 0° 0 % U _T ; 250/300 cycle	0 % U _T ; 0.5 cycle At 0°, 45°, 90°, 135°, 180°, 225°, 270° and 315° 0 % U _T ; 1 cycle and 70 % U _T ; 25/30 cycles Single phase: at 0° 0 % U _T ; 250/300 cycle	Mains power quality should be that of a typical commercial or hospital environment. If the user of the system requires continued operation during power mains interruptions, it is recommended that the system be powered from an uninterruptible power supply or a battery.
NOTE U _T is the a.c. mains voltage prior to application of the test level.			

Electromagnetic immunity

Guidance and manufacture's declaration – electromagnetic immunity

The system is intended for use in the electromagnetic environment specified below. The customer or the user of the system should assure that they are used in such an environment.

Immunity test	IEC/EN 60601 test level	Compliance level	Electromagnetic environment - guidance
Conducted RF IEC/EN 61000-4-6 Radiated RF IEC/EN 61000-4-3	3 V _{rms} 150 kHz to 80 MHz 6Vrms ^c in ISM bands between 0.15 MHz and 80 MHz 3 V/m 80 MHz to 2.7 GHz See table 1	3 V _{rms} 150 kHz to 80 MHz 6Vrms ^c in ISM bands between 0.15 MHz and 80 MHz 3 V/m 80 MHz to 2.7 GHz Comply with table 1	<p>Portable and mobile RF communications equipment should be used no closer to any part of the system, including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter.</p> <p>Recommended separation distance</p> $d = 1.2\sqrt{P} \quad 150\text{KHz to } 80\text{MHz}$ $d = 1.2\sqrt{P} \quad 80 \text{ MHz to } 800 \text{ MHz}$ $d = 2.3\sqrt{P} \quad 800 \text{ MHz to } 2.7 \text{ GHz}$ <p><i>d</i> = $6\sqrt{P/E}$ at RF wireless communications equipment bands (Portable RF communications equipment (including peripherals such as antenna cables and external antennas) should be used no closer than 30 cm (12 inches) to any part of the system, including cables specified by the manufacturer).</p> <p>Where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in meters (m).</p> <p>Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey,^a should be less than the compliance level in each frequency range.^b</p> <p>Interference may occur in the vicinity of equipment marked with the following symbol:</p> 

NOTE 1 At 80 MHz and 800 MHz, the higher frequency range applies.

NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

- a Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the system is used exceeds the applicable RF compliance level above, the system should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the system.
- b Over the frequency range 150kHz to 80MHz, field strengths should be less than 3V/m.
- c The ISM (industrial, scientific and medical) bands between 0.15 MHz and 80 MHz are 6.765 MHz to 6.795 MHz; 13.553 MHz to 13.567 MHz; 26.957 MHz to 27.283 MHz; and 40.66 MHz to 40.70 MHz. The amateur radio bands between 0.15 MHz and 80 MHz are 1.8 MHz to 2.0 MHz, 3.5 MHz to 4.0 MHz, 5.3 MHz to 5.4 MHz, 7 MHz to 7.3 MHz, 10.1 MHz to 10.15 MHz, 14 MHz to 14.2 MHz, 18.07 MHz to 18.17 MHz, 21.0 MHz to 21.4 MHz, 24.89 MHz to 24.99 MHz, 28.0 MHz to 29.7 MHz and 50.0 MHz to 54.0 MHz.

Table 1 Test specifications for ENCLOSURE PORT IMMUNITY to RF wireless communications equipment

Test frequency (MHz)	Band ^{a)} (MHz)	Service ^{a)}	Modulation ^{b)}	Maximum power (W)	Distance (m)	Immunity test level (V/m)
385	380-390	TETRA 400	Pulse modulation ^{b)} 18 Hz	1.8	0.3	27
450	430-470	GMRS 460, FRS 460	FM ^{c)} ± 5 kHz deviation 1 kHz sine	2	0.3	28
710	704-787	LTE Band 13, 17	Pulse modulation ^{b)} 217 Hz	0.2	0.3	9
745						
780						
810	800-960	GSM 800/900, TETRA 800, iDEN 820, CDMA 850, LTE Band 5	Pulse modulation ^{b)} 18 Hz	2	0.3	28
870						
930						
1720	1700-1990	GSM 1800; CDMA 1900; GSM 1900; DECT; LTE Band 1, 3, 4, 25; UMTS	Pulse modulation ^{b)} 217 Hz	2	0.3	28
1845						
1970						

2450	2400-2570	Bluetooth, WLAN, 802.11 b/g/n, RFID 2450, LTE Band 7	Pulse modulation ^{b)} 217 Hz	2	0.3	28						
5240	5100-5800	WLAN 802.11 a/n	Pulse modulation ^{b)} 217 Hz	0.2	0.3	9						
5500												
5785												
NOTE If necessary to achieve the IMMUNITY TEST LEVEL, the distance between the transmitting antenna and the ME EQUIPMENT or ME SYSTEM may be reduced to 1 m. The 1 m test distance is permitted by IEC 61000-4-3.												
<p>a) For some services, only the uplink frequencies are included.</p> <p>b) The carrier shall be modulated using a 50 % duty cycle square wave signal.</p> <p>c) As an alternative to FM modulation, 50 % pulse modulation at 18 Hz may be used because while it does not represent actual modulation, it would be worst case.</p>												

Recommended Separation Distances

Recommended separation distances between portable and mobile RF communications equipment and the system			
Rated maximum output power of transmitter (W)	Separation distance according to frequency of transmitter(m)		
	150 kHz to 80 MHz $d = 1.2\sqrt{P}$	80 MHz to 800 MHz $d = 1.2\sqrt{P}$	800 MHz to 2.7 GHz $d = 2.3\sqrt{P}$
0.01	0.12	0.12	0.23
0.1	0.38	0.38	0.73
1	1.2	1.2	2.3
10	3.8	3.8	7.3
100	12	12	23

For transmitters rated at a maximum output power not listed above, the recommended separation distance d in meters (m) can be determined using the equation applicable to the frequency of the transmitter, where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.

NOTE 1: At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies.

NOTE 2: These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

P/N: 01.54.458117
MPN: 01.54.458117024



EDAN INSTRUMENTS, INC.

#15 Jinhui Road, Jinsha Community, Kengzi Sub-District
Pingshan District, 518122 Shenzhen, P.R.China
Email: info@edan.com.cn
TEL: +86-755-2689 8326 FAX: +86-755-2689 8330
Website: www.edan.com

EC REPRESENTATIVE

Shanghai International Holding Corp. GmbH
Eiffestrasse 80, 20537 Hamburg Germany
TEL: +49-40-2513175
E-mail: shholding@hotmail.com

