FLAT RATE TIME MANUAL – 21MY EXPRESS VAN		
CODE	**DESCRIPTION**	**TIME**
110010 00	ENGINE ASSEMBLY … REMOVAL AND INSTALLATION	7.6
	[Additional operation]	
	AH … Cooling system drain - refill - bleed - flushing	1.1
110010 10	ENGINE ASSEMBLY … REPLACEMENT	10.9
	[Additional operation]	
	AH … Cooling system drain - refill - bleed - flushing	1.1
110010 20	ENGINE ASSEMBLY … OVERHAUL	28.9
	[Additional operation]	
	AH … Cooling system drain - refill - bleed - flushing	1.1
110010 62	ENGINE ASSEMBLY … COMPRESSION MEASUREMENT	0.5
110010 63	ENGINE ASSEMBLY … HYDRAULIC PRESSURE MEASUREMENT	0.9
110012 00	LONG ENGINE ASSEMBLY … REMOVAL AND INSTALLATION	13.3
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
110012 10	LONG ENGINE ASSEMBLY … REPLACEMENT	13.3
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
111110 00	CYLINDER BLOCK ASSEMBLY … REMOVAL AND INSTALLATION	19.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
111110 10	CYLINDER BLOCK ASSEMBLY … REPLACEMENT	19.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
111210 00	CYLINDER HEAD ASSEMBLY … REMOVAL AND INSTALLATION	13.9
111210 10	CYLINDER HEAD ASSEMBLY … REPLACEMENT	15.4
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
111310 00	ROCKER COVER ASSEMBLY … REMOVAL AND INSTALLATION	4.2
111310 10	ROCKER COVER ASSEMBLY … REPLACEMENT	4.2
111311 00	ROCKER COVER GASKET … REMOVAL AND INSTALLATION	4.2
111311 10	ROCKER COVER GASKET … REPLACEMENT	4.2
111320 00	OIL PAN ASSEMBLY … REMOVAL AND INSTALLATION	1.2
111320 10	OIL PAN ASSEMBLY … REPLACEMENT	1.2
111321 00	OIL PAN GASKET (LIQUID GASKET) … REMOVAL AND INSTALLATION	1.2
111321 10	OIL PAN GASKET (LIQUID GASKET) … REPLACEMENT	1.2
111336 00	TIMING CHAIN (GEAR) CASE … REMOVAL AND INSTALLATION	9.9
111336 10	TIMING CHAIN (GEAR) CASE … REPLACEMENT	9.9
111337 00	TIMING CHAIN (GEAR) CASE GASKET … REMOVAL AND INSTALLATION	9.9
111337 10	TIMING CHAIN (GEAR) CASE GASKET … REPLACEMENT	9.9
112110 00	PISTON … REMOVAL AND INSTALLATION (All)	17.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112110 10	PISTON … REPLACEMENT (All)	17.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112120 00	PISTON RING … REMOVAL AND INSTALLATION (All)	17.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112120 10	PISTON RING … REPLACEMENT (All)	17.0

	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112210 00	CONNECTING ROD ASSEMBLY … REMOVAL AND INSTALLATION (All)	17.1
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112210 10	CONNECTING ROD ASSEMBLY … REPLACEMENT (All)	17.1
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112220 00	CONNECTING ROD BEARING (BIG END) … REMOVAL AND INSTALLATION (All)	17.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112220 10	CONNECTING ROD BEARING (BIG END) … REPLACEMENT (All)	17.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112310 00	CRANKSHAFT ASSEMBLY … REMOVAL AND INSTALLATION	18.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112310 10	CRANKSHAFT ASSEMBLY … REPLACEMENT	18.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112320 00	CRANKSHAFT MAIN BEARING … REMOVAL AND INSTALLATION	18.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112320 10	CRANKSHAFT MAIN BEARING … REPLACEMENT	18.0
	[Additional operation]	
	AT … Cooling system drain - refill - bleed - flushing	1.1
112342 00	CRANKSHAFT OIL SEAL (FRONT) … REMOVAL AND INSTALLATION	0.7
112342 10	CRANKSHAFT OIL SEAL (FRONT) … REPLACEMENT	0.7
112352 00	CRANKSHAFT OIL SEAL (REAR) … REMOVAL AND INSTALLATION	8.1
112352 10	CRANKSHAFT OIL SEAL (REAR) … REPLACEMENT	8.1
112370 00	CRANKSHAFT PULLEY … REMOVAL AND INSTALLATION	0.6
112370 10	CRANKSHAFT PULLEY … REPLACEMENT	0.6
112410 00	FLYWHEEL … REMOVAL AND INSTALLATION	7.9
112410 10	FLYWHEEL … REPLACEMENT	7.9
113110 00	INLET VALVE … REMOVAL AND INSTALLATION (All)	17.0
113110 10	INLET VALVE … REPLACEMENT (All)	17.0
113230 00	TAPPET … REMOVAL AND INSTALLATION	12.1
113230 10	TAPPET … REPLACEMENT	12.1
113310 00	CAMSHAFT ASSEMBLY … REMOVAL AND INSTALLATION	12.0
113310 10	CAMSHAFT ASSEMBLY … REPLACEMENT	12.0
113420 00	TIMING CHAIN … REMOVAL AND INSTALLATION	10.3
113420 10	TIMING CHAIN … REPLACEMENT	10.3
113520 00	TIMING CHAIN TENSIONER ASSEMBLY … REMOVAL AND INSTALLATION	10.3
113520 10	TIMING CHAIN TENSIONER ASSEMBLY … REPLACEMENT	10.3
113610 00	CRANKSHAFT SPROCKET … REMOVAL AND INSTALLATION	10.3
113610 10	CRANKSHAFT SPROCKET … REPLACEMENT	10.3
113620 00	CAMSHAFT SPROCKET … REMOVAL AND INSTALLATION (One piece)	10.5
113620 10	CAMSHAFT SPROCKET … REPLACEMENT (One piece)	10.5
113640 00	OIL PUMP SPROCKET … REMOVAL AND INSTALLATION	12.3
113640 10	OIL PUMP SPROCKET … REPLACEMENT	12.3

117001 00	ENGINE BRAKE VACUUM PUMP ASSEMBLY … REMOVAL AND INSTALLATION	0.7
117001 10	ENGINE BRAKE VACUUM PUMP ASSEMBLY … REPLACEMENT	0.7
121010 00	OIL PUMP ASSEMBLY … REMOVAL AND INSTALLATION	12.3
121010 10	OIL PUMP ASSEMBLY … REPLACEMENT	12.3
121021 00	OIL PUMP CHAIN TENSIONER … REMOVAL AND INSTALLATION	12.3
121021 10	OIL PUMP CHAIN TENSIONER … REPLACEMENT	12.3
122010 00	OIL FILTER BRACKET ASSEMBLY … REMOVAL AND INSTALLATION	1.0
122010 10	OIL FILTER BRACKET ASSEMBLY … REPLACEMENT	1.0
122020 00	OIL FILTER ASSEMBLY … REMOVAL AND INSTALLATION	0.5
122020 10	OIL FILTER ASSEMBLY … REPLACEMENT	0.5
128301 00	OIL PRESSURE GAUGE UNIT … REMOVAL AND INSTALLATION	0.3
128301 10	OIL PRESSURE GAUGE UNIT … REPLACEMENT	0.3
128321 00	ENGINE OIL LEVEL SENSOR … REMOVAL AND INSTALLATION	0.3
128321 10	ENGINE OIL LEVEL SENSOR … REPLACEMENT	0.3
134113 00	FUEL RETURN PIPE … REMOVAL AND INSTALLATION	0.7
134113 10	FUEL RETURN PIPE … REPLACEMENT	0.7
134215 00	CRANKSHAFT POSITION SENSOR … REMOVAL AND INSTALLATION	0.3
134215 10	CRANKSHAFT POSITION SENSOR … REPLACEMENT	0.3
134310 00	COMMON RAIL INJECTOR … REMOVAL AND INSTALLATION (All)	1.3
	[Additional operation]	
	A3 … Injectors cleaning	0.2
	01 … Per 1 pc.	0.2
134310 10	COMMON RAIL INJECTOR … REPLACEMENT (All)	1.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
134320 00	COMMON RAIL … REMOVAL AND INSTALLATION	1.7
134320 10	COMMON RAIL … REPLACEMENT	1.7
134330 00	COMMON RAIL SUPPLY PUMP … REMOVAL AND INSTALLATION	1.7
134330 10	COMMON RAIL SUPPLY PUMP … REPLACEMENT	1.7
136010 00	FUEL TANK ASSEMBLY … REMOVAL AND INSTALLATION	1.0
136010 10	FUEL TANK ASSEMBLY … REPLACEMENT	1.2
136020 00	FUEL TANK FILLER NECK ASSEMBLY … REMOVAL AND INSTALLATION	0.8
136020 10	FUEL TANK FILLER NECK ASSEMBLY … REPLACEMENT	0.8
136041 00	FUEL TANK FUEL PIPE … REMOVAL AND INSTALLATION	0.3
136041 10	FUEL TANK FUEL PIPE … REPLACEMENT	0.3
136041 25	FUEL TANK FUEL PIPE … REPAIR	0.3
137010 00	FUEL FILTER (STRAINER) ASSEMBLY … REMOVAL AND INSTALLATION	0.3
137010 10	FUEL FILTER (STRAINER) ASSEMBLY … REPLACEMENT	0.3
137010 15	FUEL FILTER (STRAINER) ASSEMBLY … AIR BLEEDING	0.3
138301 00	FUEL TANK GAUGE UNIT … REMOVAL AND INSTALLATION (One piece)	1.2
138301 10	FUEL TANK GAUGE UNIT … REPLACEMENT (One piece)	1.2
138312 30	OXYGEN SENSOR … INSPECTION	0.3
138314 00	AIR FLOW SENSOR … REMOVAL AND INSTALLATION	0.2
138314 10	AIR FLOW SENSOR … REPLACEMENT	0.2
138322 00	MANIFOLD ABSOLUTE PRESSURE SENSOR … REMOVAL AND INSTALLATION	0.3
138322 10	MANIFOLD ABSOLUTE PRESSURE SENSOR … REPLACEMENT	0.3
138325 00	RAIL PRESSURE SENSOR … REMOVAL AND INSTALLATION	0.3
138325 10	RAIL PRESSURE SENSOR … REPLACEMENT	0.3
138351 00	OXYGEN SENSOR (BEFORE FCC) … REMOVAL AND INSTALLATION	0.2
138351 10	OXYGEN SENSOR (BEFORE FCC) … REPLACEMENT	0.2
138352 00	OXYGEN SENSOR (AFTER FCC) … REMOVAL AND INSTALLATION	0.3

138352 10	OXYGEN SENSOR (AFTER FCC) … REPLACEMENT	0.3
138502 00	ENGINE CONTROL UNIT (DIESEL) … REMOVAL AND INSTALLATION	0.2
138502 10	ENGINE CONTROL UNIT (DIESEL) … REPLACEMENT	0.2
	[Additional operation]	
	A9 … Inspection by multi - use tester	0.3
138502 13	ENGINE CONTROL UNIT (DIESEL) … REPROGRAMMING	0.3
141010 00	WATER PUMP ASSEMBLY … REMOVAL AND INSTALLATION	0.7
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
141010 10	WATER PUMP ASSEMBLY … REPLACEMENT	0.7
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
141016 00	WATER PUMP GASKET … REMOVAL AND INSTALLATION	0.7
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
141016 10	WATER PUMP GASKET … REPLACEMENT	0.7
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
141021 00	WATER PUMP DRIVE BELT … REMOVAL AND INSTALLATION	0.5
141021 10	WATER PUMP DRIVE BELT … REPLACEMENT	0.5
142000 15	ENGINE WATER LINE GENERAL … AIR BLEEDING	0.4
142110 00	THERMOSTAT … REMOVAL AND INSTALLATION	3.3
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
142110 10	THERMOSTAT … REPLACEMENT	3.3
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
142212 00	WATER SUCTION (INLET) PIPE … REMOVAL AND INSTALLATION	2.9
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
142212 10	WATER SUCTION (INLET) PIPE … REPLACEMENT	2.9
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
142215 00	WATER SUCTION (INLET) FITTING … REMOVAL AND INSTALLATION	2.8
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
142215 10	WATER SUCTION (INLET) FITTING … REPLACEMENT	2.8
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
144031 00	COOLING FAN (ELECTRIC) … REMOVAL AND INSTALLATION	1.7
144031 10	COOLING FAN (ELECTRIC) … REPLACEMENT	1.7
145010 00	RADIATOR ASSEMBLY … REMOVAL AND INSTALLATION	1.7
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
145010 10	RADIATOR ASSEMBLY … REPLACEMENT	1.7
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
145010 25	RADIATOR ASSEMBLY … REPAIR	0.9
145050 00	RESERVOIR (CONDENSE) TANK ASSEMBLY … REMOVAL AND INSTALLATION	0.2
146012 00	RADIATOR LOWER PIPE … REMOVAL AND INSTALLATION	1.6
	[Additional operation]	

	AQ … Cooling system drain - refill - bleed - flushing	1.1
146012 10	RADIATOR LOWER PIPE … REPLACEMENT	1.6
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
148301 00	WATER TEMPERATURE GAUGE UNIT … REMOVAL AND INSTALLATION	1.2
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
148301 10	WATER TEMPERATURE GAUGE UNIT … REPLACEMENT	1.2
	[Additional operation]	
	AQ … Cooling system drain - refill - bleed - flushing	1.1
148902 00	MOTOR COOLING FAN RESISTOR … REMOVAL AND INSTALLATION	0.2
148902 10	MOTOR COOLING FAN RESISTOR … REPLACEMENT	0.2
151110 00	INTAKE MANIFOLD ASSEMBLY … REMOVAL AND INSTALLATION	4.4
151110 10	INTAKE MANIFOLD ASSEMBLY … REPLACEMENT	4.4
151120 00	INTAKE MANIFOLD GASKET … REMOVAL AND INSTALLATION	4.4
151120 10	INTAKE MANIFOLD GASKET … REPLACEMENT	4.4
151210 00	AIR CLEANER ASSEMBLY … REMOVAL AND INSTALLATION	0.3
151210 10	AIR CLEANER ASSEMBLY … REPLACEMENT	0.3
151211 00	AIR CLEANER ELEMENT … REMOVAL AND INSTALLATION	0.2
151211 10	AIR CLEANER ELEMENT … REPLACEMENT	0.2
151410 00	INTERCOOLER ASSEMBLY … REMOVAL AND INSTALLATION	0.7
151410 10	INTERCOOLER ASSEMBLY … REPLACEMENT	0.7
151521 00	INTAKE HOSE … REMOVAL AND INSTALLATION	0.5
151521 10	INTAKE HOSE … REPLACEMENT	0.5
151524 00	INTAKE PIPE (TURBO TO INTER COOLER) … REMOVAL AND INSTALLATION	0.8
151524 10	INTAKE PIPE (TURBO TO INTER COOLER) … REPLACEMENT	0.8
153110 00	EXHAUST MANIFOLD ASSEMBLY … REMOVAL AND INSTALLATION	5.4
153110 10	EXHAUST MANIFOLD ASSEMBLY … REPLACEMENT	5.4
153120 00	EXHAUST MANIFOLD GASKET … REMOVAL AND INSTALLATION	5.4
153120 10	EXHAUST MANIFOLD GASKET … REPLACEMENT	5.4
153512 00	MAIN MUFFLER HANGER … REMOVAL AND INSTALLATION	0.3
153512 10	MAIN MUFFLER HANGER … REPLACEMENT	0.3
153732 00	CATALYTIC CONVERTER COVER … REMOVAL AND INSTALLATION	0.3
153732 10	CATALYTIC CONVERTER COVER … REPLACEMENT	0.3
153901 00	DIESEL PARTICULATE FILTER (DPF) … REMOVAL AND INSTALLATION	3.5
153901 10	DIESEL PARTICULATE FILTER (DPF) … REPLACEMENT	3.5
153901 5F	DIESEL PARTICULATE FILTER (DPF) … CLEANING WITH RACING	1.3
155010 00	TURBOCHARGER ASSEMBLY … REMOVAL AND INSTALLATION	4.2
155010 10	TURBOCHARGER ASSEMBLY … REPLACEMENT	4.2
155051 00	TURBO OIL FEED PIPE … REMOVAL AND INSTALLATION	0.4
155051 10	TURBO OIL FEED PIPE … REPLACEMENT	0.4
155052 00	TURBO OIL RETURN PIPE … REMOVAL AND INSTALLATION	3.7
155052 10	TURBO OIL RETURN PIPE … REPLACEMENT	3.7
158303 00	EXHAUST PRESSURE SENSOR … REMOVAL AND INSTALLATION	0.2
158303 10	EXHAUST PRESSURE SENSOR … REPLACEMENT	0.2
158604 00	VGT SOLENOID VALVE … REMOVAL AND INSTALLATION	0.3
158604 10	VGT SOLENOID VALVE … REPLACEMENT	0.3
161000 30	CHARGING EQUIPMENT GENERAL … INSPECTION	0.3
161110 00	ALTERNATOR ASSEMBLY … REMOVAL AND INSTALLATION	2.1
161110 10	ALTERNATOR ASSEMBLY … REPLACEMENT	2.1
162110 00	STARTER ASSEMBLY … REMOVAL AND INSTALLATION	2.2

162110 10	STARTER ASSEMBLY … REPLACEMENT	2.2
162110 30	STARTER ASSEMBLY … INSPECTION	0.3
168204 00	INTERLOCK SWITCH … REMOVAL AND INSTALLATION	0.2
168204 10	INTERLOCK SWITCH … REPLACEMENT	0.2
	[Additional operation]	
	A9 … Inspection by multi - use tester	0.3
171110 00	ACCELERATOR PEDAL ASSEMBLY … REMOVAL AND INSTALLATION	0.2
171110 10	ACCELERATOR PEDAL ASSEMBLY … REPLACEMENT	0.2
173312 00	EGR PIPE … REMOVAL AND INSTALLATION	0.8
173312 10	EGR PIPE … REPLACEMENT	0.8
173313 00	EGR COOLER … REMOVAL AND INSTALLATION	1.8
173313 10	EGR COOLER … REPLACEMENT	1.8
173315 00	EGR VALVE LOW PRESSURE … REMOVAL AND INSTALLATION	1.4
173315 10	EGR VALVE LOW PRESSURE … REPLACEMENT	1.4
173316 00	EGR VALVE HIGH PRESSURE … REMOVAL AND INSTALLATION	0.3
173316 10	EGR VALVE HIGH PRESSURE … REPLACEMENT	0.3
173801 00	UREA TANK ASSY … REMOVAL AND INSTALLATION	0.3
173801 10	UREA TANK ASSY … REPLACEMENT	0.5
173803 00	UREA INJECTOR … REMOVAL AND INSTALLATION	0.3
173803 10	UREA INJECTOR … REPLACEMENT	0.3
173803 30	UREA INJECTOR … INSPECTION	0.5
	[Additional operation]	
	A1 … Urea injector - R&I	0.4
178301 00	HIGH TEMPERATURE SENSOR … REMOVAL AND INSTALLATION	0.2
178301 10	HIGH TEMPERATURE SENSOR … REPLACEMENT	0.2
178331 00	No.1 EXHAUST GAS TEMPERATURE SENSOR … REMOVAL AND INSTALLATION	0.9
178331 10	No.1 EXHAUST GAS TEMPERATURE SENSOR … REPLACEMENT	0.9
178334 00	EXHAUST DIFFERENTIAL PRESSURE SENSOR (FOR DIESEL PARTICULATE FILTER)	0.9
	… REMOVAL AND INSTALLATION	
178334 10	EXHAUST DIFFERENTIAL PRESSURE SENSOR (FOR DIESEL PARTICULATE FILTER)	0.9
	… REPLACEMENT	
178341 00	NOX SENSOR No.1 … REMOVAL AND INSTALLATION	0.3
178341 10	NOX SENSOR No.1 … REPLACEMENT	0.3
178342 00	NOX SENSOR No.2 … REMOVAL AND INSTALLATION	0.3
178342 10	NOX SENSOR No.2 … REPLACEMENT	0.3
178501 00	AUTO CRUISE (AUTO SPEED) CONTROL UNIT … REMOVAL AND INSTALLATION	0.2
178501 10	AUTO CRUISE (AUTO SPEED) CONTROL UNIT … REPLACEMENT	0.2
178571 00	DOSING CONTROL UNIT … REMOVAL AND INSTALLATION	0.2
	[Additional operation]	
	A1 … Computer reprogramming	0.5
178571 10	DOSING CONTROL UNIT … REPLACEMENT	0.2
	[Additional operation]	
	A1 … Computer reprogramming	0.5
178571 13	DOSING CONTROL UNIT … REPROGRAMMING	0.3
211110 00	CLUTCH DISC … REMOVAL AND INSTALLATION	7.8
211110 10	CLUTCH DISC … REPLACEMENT	7.8
211120 00	CLUTCH COVER ASSEMBLY … REMOVAL AND INSTALLATION	7.8
211120 10	CLUTCH COVER ASSEMBLY … REPLACEMENT	7.8
212030 00	CLUTCH MASTER CYLINDER ASSEMBLY … REMOVAL AND INSTALLATION	0.6
212030 10	CLUTCH MASTER CYLINDER ASSEMBLY … REPLACEMENT	0.6
212071 00	CLUTCH RELEASE BEARING … REMOVAL AND INSTALLATION	7.7

212071 10	CLUTCH RELEASE BEARING … REPLACEMENT	7.7
212082 00	CLUTCH PIPE … REMOVAL AND INSTALLATION	0.9
212082 10	CLUTCH PIPE … REPLACEMENT	0.9
221110 00	T/M SHIFT LEVER ASSEMBLY … REMOVAL AND INSTALLATION	0.3
221110 10	T/M SHIFT LEVER ASSEMBLY … REPLACEMENT	0.3
221115 00	T/M SHIFT LEVER BOOT (COVER) … REMOVAL AND INSTALLATION	0.2
221115 10	T/M SHIFT LEVER BOOT (COVER) … REPLACEMENT	0.2
221171 00	T/M CONTROL CABLE … REMOVAL AND INSTALLATION	0.4
221171 10	T/M CONTROL CABLE … REPLACEMENT	0.4
221171 40	T/M CONTROL CABLE … ADJUSTMENT	0.2
222010 00	T/M ASSEMBLY … REMOVAL AND INSTALLATION	7.6
222010 20	T/M ASSEMBLY … OVERHAUL	7.7
222113 00	T/M DRIVE SHAFT OIL SEAL … REMOVAL AND INSTALLATION (One side)	1.1
	[Additional operation]	
	01 … Per 1 pc.	0.7
222113 10	T/M DRIVE SHAFT OIL SEAL … REPLACEMENT (One side)	1.1
	[Additional operation]	
	01 … Per 1 pc.	0.7
223112 00	T/A INPUT SHAFT OIL SEAL … REMOVAL AND INSTALLATION	8.4
223112 10	T/A INPUT SHAFT OIL SEAL … REPLACEMENT	7.7
228201 00	BACK-UP LAMP SWITCH … REMOVAL AND INSTALLATION	0.3
228201 10	BACK-UP LAMP SWITCH … REPLACEMENT	0.3
238213 00	POWER/ECONOMY SWITCH … REMOVAL AND INSTALLATION	0.2
238501 13	T/M ELC CONTROL UNIT … REPROGRAMMING	0.3
266121 00	FRONT DRIVE KNUCKLE … REMOVAL AND INSTALLATION (One side)	1.0
	[Additional operation]	
	A5 … Wheel alignment adjustment	0.3
	01 … Per 1 pc.	1.2
266121 10	FRONT DRIVE KNUCKLE … REPLACEMENT (One side)	1.0
	[Additional operation]	
	A5 … Wheel alignment adjustment	0.3
	01 … Per 1 pc.	1.2
266140 00	FRONT DRIVE WHEEL HUB ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.9
	[Additional operation]	
	01 … Per 1 pc.	0.9
266140 10	FRONT DRIVE WHEEL HUB ASSEMBLY … REPLACEMENT (One side)	0.9
	[Additional operation]	
	01 … Per 1 pc.	0.9
266180 00	FRONT DRIVE SHAFT ASSEMBLY … REMOVAL AND INSTALLATION (One side)	1.1
	[Additional operation]	
	01 … Per 1 pc.	0.7
266180 10	FRONT DRIVE SHAFT ASSEMBLY … REPLACEMENT (One side)	1.1
	[Additional operation]	
	01 … Per 1 pc.	0.7
266183 00	DRIVE SHAFT BOOT … REMOVAL AND INSTALLATION (One side)	1.6
	[Additional operation]	
	01 … Per 1 pc.	1.1
266183 10	DRIVE SHAFT BOOT … REPLACEMENT (One side)	1.6
	[Additional operation]	
	01 … Per 1 pc.	1.1

266184 00	DRIVE SHAFT CENTER BEARING … REMOVAL AND INSTALLATION	1.6
266184 10	DRIVE SHAFT CENTER BEARING … REPLACEMENT	1.6
266189 00	FRONT DRIVE SHAFT BOOT (HUB SIDE) … REMOVAL AND INSTALLATION	1.5
266189 10	FRONT DRIVE SHAFT BOOT (HUB SIDE) … REPLACEMENT	1.5
271121 00	REAR KNUCKLE … REMOVAL AND INSTALLATION (One side)	1.0
271121 10	REAR KNUCKLE … REPLACEMENT (One side)	1.0
311010 00	WHEEL ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.2
	[Additional operation]	
	01 … Per 1 pc.	0.1
311010 67	WHEEL ASSEMBLY・・・BALANCE (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.4
311011 00	TYRE … REMOVAL AND INSTALLATION (One piece)	0.5
	[Additional operation]	
	01 … Per 1 pc.	0.6
311011 10	TYRE … REPLACEMENT (One piece)	0.5
	[Additional operation]	
	01 … Per 1 pc.	0.6
312012 00	CENTER CAP … REMOVAL AND INSTALLATION (One piece)	0.2
312012 10	CENTER CAP … REPLACEMENT (One piece)	0.2
314021 00	SPARE TYRE CARRIER (HANGER) … REMOVAL AND INSTALLATION	0.3
314021 10	SPARE TYRE CARRIER (HANGER) … REPLACEMENT	0.3
321110 00	CROSSMEMBER (SUB FRAME) ASSEMBLY … REMOVAL AND INSTALLATION	1.5
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
321110 10	CROSSMEMBER (SUB FRAME) ASSEMBLY … REPLACEMENT	2.0
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
321222 00	ENGINE MOUNTING … REMOVAL AND INSTALLATION	0.7
321222 10	ENGINE MOUNTING … REPLACEMENT	0.7
321223 00	T/M MOUNTING … REMOVAL AND INSTALLATION	1.4
321223 10	T/M MOUNTING … REPLACEMENT	1.4
321228 00	ROLL ROD ASSEMBLY … REMOVAL AND INSTALLATION	0.3
321228 10	ROLL ROD ASSEMBLY … REPLACEMENT	0.3
333110 00	LOWER ARM ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.5
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
333110 10	LOWER ARM ASSEMBLY … REPLACEMENT (One side)	0.5
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	01 … Per 1 pc.	0.5
333211 00	FRONT COIL SPRING … REMOVAL AND INSTALLATION (One side)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.7

333211 10	FRONT COIL SPRING … REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.7
333215 00	FRONT STRUT HELPER RUBBER … REMOVAL AND INSTALLATION (One side)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.7
333215 10	FRONT STRUT HELPER RUBBER … REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.7
333311 00	FRONT STRUT SHOCK ABSORBER … REMOVAL AND INSTALLATION (One side)	0.8
	[Additional operation]	
	01 … Per 1 pc.	0.7
333311 10	FRONT STRUT SHOCK ABSORBER … REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 … Per 1 pc.	0.7
333411 00	FRONT STABILIZER BAR … REMOVAL AND INSTALLATION	1.3
333411 10	FRONT STABILIZER BAR … REPLACEMENT	1.3
333412 00	FRONT STABILIZER BUSHING … REMOVAL AND INSTALLATION (All)	0.3
333412 10	FRONT STABILIZER BUSHING … REPLACEMENT (All)	0.3
333414 00	FRONT STABILIZER LINK KIT … REMOVAL AND INSTALLATION (One side)	0.3
333414 10	FRONT STABILIZER LINK KIT … REPLACEMENT (One side)	0.3
346010 00	TORSION AXLE ASSEMBLY … REMOVAL AND INSTALLATION	2.3
346010 10	TORSION AXLE ASSEMBLY … REPLACEMENT	2.9
346211 00	REAR COIL SPRING … REMOVAL AND INSTALLATION (One side)	0.4
	[Additional operation]	
	01 … Per 1 pc.	0.4
346211 10	REAR COIL SPRING … REPLACEMENT (One side)	0.4
	[Additional operation]	
	01 … Per 1 pc.	0.4
346311 00	REAR SHOCK ABSORBER … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
346311 10	REAR SHOCK ABSORBER … REPLACEMENT (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
346510 00	LATERAL ROD ASSEMBLY … REMOVAL AND INSTALLATION	0.4
346510 10	LATERAL ROD ASSEMBLY … REPLACEMENT	0.4
350000 94	BRAKE SYSTEM … BLEED	0.3
351110 00	BRAKE MASTER CYLINDER ASSEMBLY … REMOVAL AND INSTALLATION	0.6
351110 10	BRAKE MASTER CYLINDER ASSEMBLY … REPLACEMENT	0.6
351210 00	BRAKE BOOSTER ASSEMBLY … REMOVAL AND INSTALLATION	1.3
351210 10	BRAKE BOOSTER ASSEMBLY … REPLACEMENT	1.3
352211 00	FRONT BRAKE DISC (ROTOR) … REMOVAL AND INSTALLATION (One side)	0.9
352211 10	FRONT BRAKE DISC (ROTOR) … REPLACEMENT (One side)	0.9
352220 00	DISC BRAKE CALIPER ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.5
	[Additional operation]	
	01 … Per 1 pc.	0.3
352220 10	DISC BRAKE CALIPER ASSEMBLY … REPLACEMENT (One side)	0.5
	[Additional operation]	
	01 … Per 1 pc.	0.3
352220 20	DISC BRAKE CALIPER ASSEMBLY … OVERHAUL (One side)	0.7

	[Additional operation]	
	01 … Per 1 pc.	0.5
352222 00	DISC BRAKE CALIPER SUPPORT … REMOVAL AND INSTALLATION (One side)	0.5
352226 00	DISC BRAKE PAD ASSEMBLY … REMOVAL AND INSTALLATION	0.5
352226 10	DISC BRAKE PAD ASSEMBLY … REPLACEMENT	0.5
352600 55	REAR DISC BRAKE GENERAL … CLEANING	0.5
352611 00	REAR BRAKE DISC … REMOVAL AND INSTALLATION (One side)	0.6
	[Additional operation]	
	01 … Per 1 pc.	0.5
352611 10	REAR BRAKE DISC … REPLACEMENT (One side)	0.6
	[Additional operation]	
	01 … Per 1 pc.	0.5
352620 00	DISC BRAKE CALIPER ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.3
352620 10	DISC BRAKE CALIPER ASSEMBLY … REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.3
352622 00	DISC BRAKE CALIPER SUPPORT … REMOVAL AND INSTALLATION	0.5
352626 00	DISC BRAKE PAD ASSEMBLY … REMOVAL AND INSTALLATION	0.8
352626 10	DISC BRAKE PAD ASSEMBLY … REPLACEMENT	0.8
352641 00	DISC BRAKE DUST COVER … REMOVAL AND INSTALLATION	0.5
352641 10	DISC BRAKE DUST COVER … REPLACEMENT	0.5
353121 00	BRAKE HOSE (FRONT) … REMOVAL AND INSTALLATION (One side)	0.5
353121 10	BRAKE HOSE (FRONT) … REPLACEMENT (One side)	0.5
353123 00	BRAKE HOSE (REAR) … REMOVAL AND INSTALLATION (One side)	0.5
353123 10	BRAKE HOSE (REAR) … REPLACEMENT (One side)	0.5
353140 00	OIL RESERVOIR TANK ASSEMBLY … REMOVAL AND INSTALLATION	0.5
353140 10	OIL RESERVOIR TANK ASSEMBLY … REPLACEMENT	0.5
354010 00	BRAKE PEDAL ASSEMBLY … REMOVAL AND INSTALLATION	0.4
354010 10	BRAKE PEDAL ASSEMBLY … REPLACEMENT	0.4
354520 00	HYDRAULIC UNIT ASSEMBLY … REMOVAL AND INSTALLATION	1.0
354520 10	HYDRAULIC UNIT ASSEMBLY … REPLACEMENT	1.0
358201 00	STOP LAMP SWITCH … REMOVAL AND INSTALLATION	0.2
358201 10	STOP LAMP SWITCH … REPLACEMENT	0.2
358308 00	STEERING WHEEL ANGULAR VELOCITY SENSOR … REMOVAL AND INSTALLATION	0.7
358308 10	STEERING WHEEL ANGULAR VELOCITY SENSOR … REPLACEMENT	0.7
358308 4B	STEERING WHEEL ANGULAR VELOCITY SENSOR … ZERO-CALIBRATION	0.3
358311 00	FRONT SPEED SENSOR (ABS,AYC,ACD) … REMOVAL AND INSTALLATION (One piece)	0.3
358311 10	FRONT SPEED SENSOR (ABS,AYC,ACD) … REPLACEMENT (One piece)	0.3
358312 00	REAR SPEED SENSOR (ABS,AYC,ACD) … REMOVAL AND INSTALLATION (One piece)	0.3
358312 10	REAR SPEED SENSOR (ABS,AYC,ACD) … REPLACEMENT (One piece)	0.3
358501 13	ANTI-SKID (ABS) CONTROL UNIT … REPROGRAMMING	0.3
358501 14	ANTI-SKID (ABS) CONTROL UNIT … SYSTEM REGISTRATION	0.3
361010 00	PARKING BRAKE LEVER ASSEMBLY … REMOVAL AND INSTALLATION	0.9
361010 10	PARKING BRAKE LEVER ASSEMBLY … REPLACEMENT	0.9
361010 40	PARKING BRAKE LEVER ASSEMBLY … ADJUSTMENT	0.3
361040 00	FRONT PARKING BRAKE CABLE ASSEMBLY … REMOVAL AND INSTALLATION	0.4
361040 10	FRONT PARKING BRAKE CABLE ASSEMBLY … REPLACEMENT	0.4
361050 00	REAR PARKING BRAKE CABLE ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.4
	[Additional operation]	

	01 … Per 1 pc.	0.1
361050 10	REAR PARKING BRAKE CABLE ASSEMBLY … REPLACEMENT (One piece)	0.4
	[Additional operation]	
	01 … Per 1 pc.	0.1
371010 00	STEERING WHEEL ASSEMBLY … REMOVAL AND INSTALLATION	0.3
371010 10	STEERING WHEEL ASSEMBLY … REPLACEMENT	0.3
372030 00	STEERING COLUMN ASSEMBLY … REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
372030 10	STEERING COLUMN ASSEMBLY … REPLACEMENT	0.5
	[Additional operation]	
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
372070 00	STEERING COLUMN COVER ASSEMBLY … REMOVAL AND INSTALLATION	0.2
372070 10	STEERING COLUMN COVER ASSEMBLY … REPLACEMENT	0.2
372090 00	STEERING LOCK … REMOVAL AND INSTALLATION	0.4
	[Additional operation]	
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
372090 10	STEERING LOCK … REPLACEMENT	0.4
	[Additional operation]	
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
374050 00	STEERING GEAR ASSEMBLY (RACK & PINION) … REMOVAL AND INSTALLATION	1.4
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
374050 10	STEERING GEAR ASSEMBLY (RACK & PINION) … REPLACEMENT	1.4
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
374058 00	STEERING GEAR BOX BELLOWS … REMOVAL AND INSTALLATION (One side)	0.4
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
	01 … Per 1 pc.	0.4
374058 10	STEERING GEAR BOX BELLOWS … REPLACEMENT (One side)	0.4
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
	01 … Per 1 pc.	0.4
376041 00	TIE ROD … REMOVAL AND INSTALLATION (One side)	0.5
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
	01 … Per 1 pc.	0.5
376041 10	TIE ROD … REPLACEMENT (One side)	0.5
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1

	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
	01 … Per 1 pc.	0.5
376042 00	TIE ROD END … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
	01 … Per 1 pc.	0.2
376042 10	TIE ROD END … REPLACEMENT (One side)	0.3
	[Additional operation]	
	AA … Front and rear suspension geometry check and adjust	1.1
	AB … Wheel alignment adjustment	0.3
	A8 … Steering wheel angular velocity sensor zero - calibration	0.3
	01 … Per 1 pc.	0.2
422025 00	FRONT FENDER SPLASH SHIELD PANEL … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
422025 10	FRONT FENDER SPLASH SHIELD PANEL … REPLACEMENT (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
422031 00	REAR SPLASH SHIELD … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
422031 10	REAR SPLASH SHIELD … REPLACEMENT (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.2
423121 00	FRONT WINDOW GLASS … REMOVAL AND INSTALLATION	2.0
423121 10	FRONT WINDOW GLASS … REPLACEMENT	2.0
423121 25	FRONT WINDOW GLASS … REPAIR	0.3
423321 00	SIDE WINDOW GLASS … REMOVAL AND INSTALLATION (One side)	0.9
423321 10	SIDE WINDOW GLASS … REPLACEMENT (One side)	0.9
423421 00	QUARTER WINDOW GLASS … REMOVAL AND INSTALLATION (One side)	0.3
423421 10	QUARTER WINDOW GLASS … REPLACEMENT (One side)	0.3
424110 00	FRONT DOOR ASSEMBLY・・・ REMOVAL AND INSTALLATION (One side)	1.2
424110 40	FRONT DOOR ASSEMBLY … ADJUSTMENT (One side)	0.9
424111 00	FRONT DOOR PANEL … REMOVAL AND INSTALLATION (One side)	2.7
424111 10	FRONT DOOR PANEL … REPLACEMENT (One side)	2.7
424113 00	FRONT DOOR HINGE … REMOVAL AND INSTALLATION (One side)	1.3
424113 10	FRONT DOOR HINGE … REPLACEMENT (One side)	1.3
424114 00	FRONT DOOR CHECK … REMOVAL AND INSTALLATION (One side)	0.3
424114 10	FRONT DOOR CHECK … REPLACEMENT (One side)	0.3
424121 00	FRONT DOOR GLASS … REMOVAL AND INSTALLATION (One side)	0.5
424121 10	FRONT DOOR GLASS … REPLACEMENT (One side)	0.5
424125 00	FRONT DOOR RUNCHANNEL … REMOVAL AND INSTALLATION (One side)	0.6
424125 10	FRONT DOOR RUNCHANNEL … REPLACEMENT (One side)	0.6
424129 00	TRIANGLE COVER (INNER) … REMOVAL AND INSTALLATION (One side)	0.2
424129 10	TRIANGLE COVER (INNER) … REPLACEMENT (One side)	0.2
424132 00	FRONT DOOR WEATHERSTRIP (DOOR SIDE) … REMOVAL AND INSTALLATION (One side)	0.2

424132 10	FRONT DOOR WEATHERSTRIP (DOOR SIDE) … REPLACEMENT (One side)	0.2
424133 00	FRONT DOOR WEATHERSTRIP (BELT INNER) … REMOVAL AND INSTALLATION (One side)	0.3
424133 10	FRONT DOOR WEATHERSTRIP (BELT INNER) … REPLACEMENT (One side)	0.3
424134 00	FRONT DOOR WEATHERSTRIP (BELT OUTER) … REMOVAL AND INSTALLATION (One side)	0.5
424134 10	FRONT DOOR WEATHERSTRIP (BELT OUTER) … REPLACEMENT (One side)	0.5
424141 00	FRONT DOOR LATCH (LOCK) … REMOVAL AND INSTALLATION (One side)	0.4
424141 10	FRONT DOOR LATCH (LOCK) … REPLACEMENT (One side)	0.4
424142 00	FRONT DOOR STRIKER … REMOVAL AND INSTALLATION (One side)	0.2
424142 10	FRONT DOOR STRIKER … REPLACEMENT (One side)	0.2
424142 40	FRONT DOOR STRIKER … ADJUSTMENT (One side)	0.2
424143 00	FRONT DOOR LOCK CYLINDER … REMOVAL AND INSTALLATION (One side)	0.3
424143 10	FRONT DOOR LOCK CYLINDER … REPLACEMENT (One side)	0.3
424144 00	FRONT DOOR OUTSIDE HANDLE … REMOVAL AND INSTALLATION (One side)	0.4
424144 10	FRONT DOOR OUTSIDE HANDLE … REPLACEMENT (One side)	0.4
424145 00	FRONT DOOR INSIDE HANDLE … REMOVAL AND INSTALLATION (One side)	0.3
424145 10	FRONT DOOR INSIDE HANDLE … REPLACEMENT (One side)	0.3
424161 00	FRONT DOOR REGULATOR … REMOVAL AND INSTALLATION (One side)	0.5
424161 10	FRONT DOOR REGULATOR … REPLACEMENT (One side)	0.5
424183 00	FRONT DOOR STATIONARY GLASS … REMOVAL AND INSTALLATION (One side)	0.5
424183 10	FRONT DOOR STATIONARY GLASS … REPLACEMENT (One side)	0.5
424210 00	REAR (SLIDE) DOOR ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.7
424210 40	REAR (SLIDE) DOOR ASSEMBLY … ADJUSTMENT (One side)	0.4
424211 00	REAR (SLIDE) DOOR PANEL … REMOVAL AND INSTALLATION (One side)	1.5
424211 10	REAR (SLIDE) DOOR PANEL … REPLACEMENT (One side)	1.5
	[Additional operation]	
	A4 … Door glass - R&I	0.9
424221 00	REAR (SLIDE) DOOR GLASS … REMOVAL AND INSTALLATION (One side)	0.9
424221 10	REAR (SLIDE) DOOR GLASS … REPLACEMENT (One side)	0.9
424231 00	REAR (SLIDE) DOOR WEATHERSTRIP (BODY) … REMOVAL AND INSTALLATION (One side)	0.2
424231 10	REAR (SLIDE) DOOR WEATHERSTRIP (BODY) … REPLACEMENT (One side)	0.2
424232 00	REAR (SLIDE) DOOR WEATHERSTRIP (DOOR) … REMOVAL AND INSTALLATION (One side)	0.2
424232 10	REAR (SLIDE) DOOR WEATHERSTRIP (DOOR) … REPLACEMENT (One side)	0.2
424241 00	REAR (SLIDE) DOOR LATCH … REMOVAL AND INSTALLATION (One side)	0.3
424241 10	REAR (SLIDE) DOOR LATCH … REPLACEMENT (One side)	0.3
424242 00	REAR (SLIDE) DOOR STRIKER … REMOVAL AND INSTALLATION (One side)	0.2
424242 10	REAR (SLIDE) DOOR STRIKER … REPLACEMENT (One side)	0.2
424242 40	REAR (SLIDE) DOOR STRIKER … ADJUSTMENT (One side)	0.3
424244 00	REAR (SLIDE) DOOR OUTSIDE HANDLE … REMOVAL AND INSTALLATION (One side)	0.2
	[Additional operation]	
	A1 … Door trim - R&I	0.2
424244 10	REAR (SLIDE) DOOR OUTSIDE HANDLE … REPLACEMENT (One side)	0.2
	[Additional operation]	
	A1 … Door trim - R&I	0.2
424245 00	REAR (SLIDE) DOOR INSIDE HANDLE … REMOVAL AND INSTALLATION (One side)	0.2
424245 10	REAR (SLIDE) DOOR INSIDE HANDLE … REPLACEMENT (One side)	0.2
424247 00	REAR (SLIDE) DOOR INSIDE LOCK KNOB … REMOVAL AND INSTALLATION (One side)	0.2
424247 10	REAR (SLIDE) DOOR INSIDE LOCK KNOB … REPLACEMENT (One side)	0.2
424249 00	REAR (SLIDE) DOOR LOCK REMOTE CONTROL … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	A1 … Door trim - R&I	0.2
424249 10	REAR (SLIDE) DOOR LOCK REMOTE CONTROL … REPLACEMENT (One side)	0.3

	[Additional operation]	
	A1 … Door trim - R&I	0.2
424271 00	REAR (SLIDE) DOOR UPPER RAIL … REMOVAL AND INSTALLATION (One side)	0.3
424271 10	REAR (SLIDE) DOOR UPPER RAIL … REPLACEMENT (One side)	0.3
424272 00	REAR (SLIDE) DOOR CENTER RAIL … REMOVAL AND INSTALLATION (One side)	0.3
424272 10	REAR (SLIDE) DOOR CENTER RAIL … REPLACEMENT (One side)	0.3
424273 00	REAR (SLIDE) DOOR LOWER RAIL … REMOVAL AND INSTALLATION (One side)	0.3
424273 10	REAR (SLIDE) DOOR LOWER RAIL … REPLACEMENT (One side)	0.3
424274 00	REAR (SLIDE) DOOR ROLLER ARM (UPPER) … REMOVAL AND INSTALLATION (One side)	0.2
424274 10	REAR (SLIDE) DOOR ROLLER ARM (UPPER) … REPLACEMENT (One side)	0.2
424275 00	REAR (SLIDE) DOOR ROLLER ARM (CENTER) … REMOVAL AND INSTALLATION (One side)	0.3
424275 10	REAR (SLIDE) DOOR ROLLER ARM (CENTER) … REPLACEMENT (One side)	0.3
424276 00	REAR (SLIDE) DOOR ROLLER ARM (LOWER) … REMOVAL AND INSTALLATION (One side)	0.3
424276 10	REAR (SLIDE) DOOR ROLLER ARM (LOWER) … REPLACEMENT (One side)	0.3
424310 00	BACK DOOR (TAILGATE) ASSEMBLY … REMOVAL AND INSTALLATION	0.6
424310 10	BACK DOOR (TAILGATE) ASSEMBLY … REPLACEMENT	1.3
424310 40	BACK DOOR (TAILGATE) ASSEMBLY … ADJUSTMENT	0.3
424311 00	BACK DOOR (TAILGATE) PANEL … REMOVAL AND INSTALLATION (One piece)	2.1
424311 10	BACK DOOR (TAILGATE) PANEL … REPLACEMENT (One piece)	2.1
424321 00	BACK DOOR (TAILGATE) GLASS … REMOVAL AND INSTALLATION	1.2
424321 10	BACK DOOR (TAILGATE) GLASS … REPLACEMENT	0.7
424341 00	BACK DOOR (TAILGATE) LATCH … REMOVAL AND INSTALLATION	0.2
424341 10	BACK DOOR (TAILGATE) LATCH … REPLACEMENT	0.2
424342 00	BACK DOOR (TAILGATE) STRIKER … REMOVAL AND INSTALLATION	0.2
424342 10	BACK DOOR (TAILGATE) STRIKER … REPLACEMENT	0.2
424343 00	BACK DOOR (TAILGATE) LOCK CYLINDER … REMOVAL AND INSTALLATION	0.2
424343 10	BACK DOOR (TAILGATE) LOCK CYLINDER … REPLACEMENT	0.2
424344 00	BACK DOOR (TAILGATE) OUTER HANDLE … REMOVAL AND INSTALLATION	0.2
424344 10	BACK DOOR (TAILGATE) OUTER HANDLE … REPLACEMENT	0.2
424345 00	BACK DOOR (TAILGATE) LATCH (UPPER) … REMOVAL AND INSTALLATION	0.2
424345 10	BACK DOOR (TAILGATE) LATCH (UPPER) … REPLACEMENT	0.2
424346 00	BACK DOOR (TAILGATE) LATCH (LOWER) … REMOVAL AND INSTALLATION	0.2
424346 10	BACK DOOR (TAILGATE) LATCH (LOWER) … REPLACEMENT	0.2
424353 00	BACK DOOR (TAILGATE) STOPPER … REMOVAL AND INSTALLATION (One piece)	0.2
424353 10	BACK DOOR (TAILGATE) STOPPER … REPLACEMENT (One piece)	0.2
425110 00	HOOD ASSEMBLY … REMOVAL AND INSTALLATION	0.5
425110 10	HOOD ASSEMBLY … REPLACEMENT	0.7
425121 00	HOOD GAS SPRING … REMOVAL AND INSTALLATION (One piece)	0.6
	[Additional operation]	
	01 … Per 1 pc.	0.1
425121 10	HOOD GAS SPRING … REPLACEMENT (One piece)	0.6
	[Additional operation]	
	01 … Per 1 pc.	0.1
425141 40	HOOD CATCH … ADJUSTMENT	0.2
425151 00	HOOD OPENER CABLE … REMOVAL AND INSTALLATION	0.3
425151 10	HOOD OPENER CABLE … REPLACEMENT	0.3
425152 00	HOOD OPENER LEVER … REMOVAL AND INSTALLATION	0.2
425152 10	HOOD OPENER LEVER … REPLACEMENT	0.2
425153 00	HOOD OPENER STOPPER … REMOVAL AND INSTALLATION	0.3
425153 10	HOOD OPENER STOPPER … REPLACEMENT	0.3
425311 00	FUEL FILLER LID … REMOVAL AND INSTALLATION	0.2

425311 10	FUEL FILLER LID … REPLACEMENT	0.2
428201 00	POWER WINDOW SWITCH (MAIN) … REMOVAL AND INSTALLATION	0.2
428201 10	POWER WINDOW SWITCH (MAIN) … REPLACEMENT	0.2
428202 00	POWER WINDOW SWITCH (SUB) … REMOVAL AND INSTALLATION	0.2
428202 10	POWER WINDOW SWITCH (SUB) … REPLACEMENT	0.2
428711 00	KEYLESS OPERATION ANTENNA (FRONT INNER) … REMOVAL AND INSTALLATION	1.0
428711 10	KEYLESS OPERATION ANTENNA (FRONT INNER) … REPLACEMENT	1.0
428713 00	KEYLESS OPERATION ANTENNA (REAR INNER) … REMOVAL AND INSTALLATION	0.2
428713 10	KEYLESS OPERATION ANTENNA (REAR INNER) … REPLACEMENT	0.2
428717 00	KEYLESS OPERATION KEY … REMOVAL AND INSTALLATION	0.2
428717 10	KEYLESS OPERATION KEY … REPLACEMENT	0.2
511120 00	FRONT WINDOW WIPER ARM ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.2
511120 10	FRONT WINDOW WIPER ARM ASSEMBLY … REPLACEMENT (One side)	0.2
511130 00	FRONT WINDOW WIPER BLADE ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.2
511130 10	FRONT WINDOW WIPER BLADE ASSEMBLY … REPLACEMENT (One side)	0.2
511140 00	FRONT WINDOW WIPER LINK ASSEMBLY … REMOVAL AND INSTALLATION	0.3
511140 10	FRONT WINDOW WIPER LINK ASSEMBLY … REPLACEMENT	0.3
511220 00	REAR WINDOW WIPER ARM ASSEMBLY … REMOVAL AND INSTALLATION	0.2
511220 10	REAR WINDOW WIPER ARM ASSEMBLY … REPLACEMENT	0.2
511230 00	REAR WINDOW WIPER BLADE ASSEMBLY … REMOVAL AND INSTALLATION	0.2
511230 10	REAR WINDOW WIPER BLADE ASSEMBLY … REPLACEMENT	0.2
512120 00	FRONT WINDOW WASHER TANK ASSEMBLY … REMOVAL AND INSTALLATION	0.3
512120 10	FRONT WINDOW WASHER TANK ASSEMBLY … REPLACEMENT	0.3
512131 00	FRONT WINDOW WASHER NOZZLE … REMOVAL AND INSTALLATION (One piece)	0.2
512131 10	FRONT WINDOW WASHER NOZZLE … REPLACEMENT (One piece)	0.2
512231 00	REAR WINDOW WASHER NOZZLE … REMOVAL AND INSTALLATION	0.2
512231 10	REAR WINDOW WASHER NOZZLE … REPLACEMENT	0.2
513010 00	REAR VIEW MIRROR ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.2
513010 10	REAR VIEW MIRROR ASSEMBLY … REPLACEMENT (One side)	0.2
513014 00	REAR VIEW MIRROR … REMOVAL AND INSTALLATION (One side)	0.2
513014 10	REAR VIEW MIRROR … REPLACEMENT (One side)	0.2
513015 00	REAR VIEW MIRROR COVER … REMOVAL AND INSTALLATION (One side)	0.2
513015 10	REAR VIEW MIRROR COVER … REPLACEMENT (One side)	0.2
514110 00	FRONT BUMPER ASSEMBLY … REMOVAL AND INSTALLATION	0.5
514121 00	FRONT BUMPER FACE … REMOVAL AND INSTALLATION	1.1
514121 10	FRONT BUMPER FACE … REPLACEMENT	1.1
514131 00	FRONT BUMPER (INERTIA ABSORBER) STAY … REMOVAL AND INSTALLATION	0.6
514131 10	FRONT BUMPER (INERTIA ABSORBER) STAY … REPLACEMENT	0.6
514135 00	FRONT BUMPER SIDE BRACKET … REMOVAL AND INSTALLATION	0.6
514135 10	FRONT BUMPER SIDE BRACKET … REPLACEMENT	0.6
514210 00	REAR BUMPER ASSEMBLY … REMOVAL AND INSTALLATION	0.4
514210 25	REAR BUMPER ASSEMBLY … REPAIR	0.3
	[Additional operation]	
	A1 … Rear bumper assembly - R&I	0.6
514221 00	REAR BUMPER FACE … REMOVAL AND INSTALLATION	0.7
514221 10	REAR BUMPER FACE … REPLACEMENT	0.7
514223 00	REAR BUMPER CENTER … REMOVAL AND INSTALLATION	0.3
514223 10	REAR BUMPER CENTER … REPLACEMENT	0.3
514251 00	REAR BUMPER MOULDING … REMOVAL AND INSTALLATION	0.5
514251 10	REAR BUMPER MOULDING … REPLACEMENT	0.5
515011 00	FRONT AIR DAM SKIRT … REMOVAL AND INSTALLATION	0.3

515011 10	FRONT AIR DAM SKIRT … REPLACEMENT	1.0
515011 40	FRONT AIR DAM SKIRT … ADJUSTMENT	0.2
	[Additional operation]	
	A1 … Air dam - R&I	0.4
516111 00	FRONT GRILLE … REMOVAL AND INSTALLATION	0.2
516111 10	FRONT GRILLE … REPLACEMENT	0.2
516131 00	SIDE (CENTER PILLAR) GARNISH … REMOVAL AND INSTALLATION (One side)	0.2
516131 10	SIDE (CENTER PILLAR) GARNISH … REPLACEMENT (One side)	0.2
516134 00	SIDE GARNISH (REAR QUARTER) … REMOVAL AND INSTALLATION (One side)	0.2
516134 10	SIDE GARNISH (REAR QUARTER) … REPLACEMENT (One side)	0.2
516215 00	FRONT WINDOW MOULDING (UPPER) … REMOVAL AND INSTALLATION	0.2
516215 10	FRONT WINDOW MOULDING (UPPER) … REPLACEMENT	0.2
516252 00	FRONT DOOR BELT LINE MOULDING … REMOVAL AND INSTALLATION (One side)	0.2
516252 10	FRONT DOOR BELT LINE MOULDING … REPLACEMENT (One side)	0.2
516253 00	FRONT DOOR PROTECTOR MOULDING … REMOVAL AND INSTALLATION (One side)	0.2
516253 10	FRONT DOOR PROTECTOR MOULDING … REPLACEMENT (One side)	0.2
516263 00	REAR DOOR PROTECTOR MOULDING … REMOVAL AND INSTALLATION (One side)	0.2
516263 10	REAR DOOR PROTECTOR MOULDING … REPLACEMENT (One side)	0.2
516282 00	REAR QUARTER PROTECTOR MOULDING … REMOVAL AND INSTALLATION (One side)	0.2
516282 10	REAR QUARTER PROTECTOR MOULDING … REPLACEMENT (One side)	0.2
516411 00	FRONT MARK … REMOVAL AND INSTALLATION (One piece)	0.2
516411 10	FRONT MARK … REPLACEMENT (One piece)	0.2
517011 00	FRONT MUDGUARD … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.1
517011 10	FRONT MUDGUARD … REPLACEMENT (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.1
518102 00	WIPER MOTOR (REAR WINDOW) … REMOVAL AND INSTALLATION	0.3
518102 10	WIPER MOTOR (REAR WINDOW) … REPLACEMENT	0.3
518111 00	WASHER MOTOR (FRONT WINDOW) … REMOVAL AND INSTALLATION	0.3
518111 10	WASHER MOTOR (FRONT WINDOW) … REPLACEMENT	0.3
518201 00	WIPER SWITCH (FRONT WINDOW) … REMOVAL AND INSTALLATION	0.2
518201 10	WIPER SWITCH (FRONT WINDOW) … REPLACEMENT	0.2
521110 00	FRONT SEAT ASSEMBLY (DRIVER) … REMOVAL AND INSTALLATION	0.3
521111 00	FRONT SEAT FRAME ASSEMBLY (DRIVER) … REMOVAL AND INSTALLATION	1.0
521111 10	FRONT SEAT FRAME ASSEMBLY (DRIVER) … REPLACEMENT	1.0
521112 00	FRONT SEAT CUSHION FRAME ASSEMBLY (DRIVER) … REMOVAL AND INSTALLATION	0.5
521112 10	FRONT SEAT CUSHION FRAME ASSEMBLY (DRIVER) … REPLACEMENT	0.5
521113 00	FRONT SEAT BACK FRAME ASSEMBLY (DRIVER) … REMOVAL AND INSTALLATION	0.8
521113 10	FRONT SEAT BACK FRAME ASSEMBLY (DRIVER) … REPLACEMENT	0.8
521121 00	FRONT SEAT CUSHION COVER (DRIVER) … REMOVAL AND INSTALLATION	0.3
521121 10	FRONT SEAT CUSHION COVER (DRIVER) … REPLACEMENT	0.3
521123 00	FRONT SEAT CUSHION PAD (DRIVER) … REMOVAL AND INSTALLATION	0.3
521123 10	FRONT SEAT CUSHION PAD (DRIVER) … REPLACEMENT	0.3
521131 00	FRONT SEAT BACK COVER (DRIVER) … REMOVAL AND INSTALLATION	0.5
521131 10	FRONT SEAT BACK COVER (DRIVER) … REPLACEMENT	0.5
521133 00	FRONT SEAT BACK PAD (DRIVER) … REMOVAL AND INSTALLATION	0.5
521133 10	FRONT SEAT BACK PAD (DRIVER) … REPLACEMENT	0.5
521141 00	FRONT SEAT HEAD RESTRAINT (DRIVER) … REMOVAL AND INSTALLATION	0.2
521141 10	FRONT SEAT HEAD RESTRAINT (DRIVER) … REPLACEMENT	0.2

521145 00	FRONT SEAT ARMREST (DRIVER) … REMOVAL AND INSTALLATION	0.2
521145 10	FRONT SEAT ARMREST (DRIVER) … REPLACEMENT	0.2
521155 00	FRONT SEAT LUMBAR SUPPORT ADJUSTER (DRIVER) … REMOVAL AND INSTALLATION	0.7
521155 10	FRONT SEAT LUMBAR SUPPORT ADJUSTER (DRIVER) … REPLACEMENT	0.7
521171 00	FRONT SEAT HEATER (DRIVER) … REMOVAL AND INSTALLATION	0.4
521171 10	FRONT SEAT HEATER (DRIVER) … REPLACEMENT	0.4
521172 00	FRONT SEAT BACK HEATER (DRIVER) … REMOVAL AND INSTALLATION	0.6
521172 10	FRONT SEAT BACK HEATER (DRIVER) … REPLACEMENT	0.6
521181 00	FRONT SEAT UNDER TRAY (DRIVER) … REMOVAL AND INSTALLATION	0.2
521181 10	FRONT SEAT UNDER TRAY (DRIVER) … REPLACEMENT	0.2
521410 00	FRONT SEAT ASSEMBLY (BENCH) … REMOVAL AND INSTALLATION	0.3
521411 00	FRONT SEAT FRAME ASSEMBLY (BENCH) … REMOVAL AND INSTALLATION	1.2
521411 10	FRONT SEAT FRAME ASSEMBLY (BENCH) … REPLACEMENT	1.2
521421 00	FRONT SEAT CUSHION COVER (BENCH) … REMOVAL AND INSTALLATION	0.3
521421 10	FRONT SEAT CUSHION COVER (BENCH) … REPLACEMENT	0.3
521431 00	FRONT SEAT BACK COVER (BENCH) … REMOVAL AND INSTALLATION	0.4
521431 10	FRONT SEAT BACK COVER (BENCH) … REPLACEMENT	0.4
521441 00	FRONT SEAT HEAD RESTRAINT (BENCH) … REMOVAL AND INSTALLATION (One piece)	0.2
521441 10	FRONT SEAT HEAD RESTRAINT (BENCH) … REPLACEMENT (One piece)	0.2
521445 00	FRONT SEAT ARMREST (BENCH) … REMOVAL AND INSTALLATION	0.2
521445 10	FRONT SEAT ARMREST (BENCH) … REPLACEMENT	0.2
522011 00	FRONT SEAT BELT RETRACTOR (DRIVER) … REMOVAL AND INSTALLATION	0.3
522011 10	FRONT SEAT BELT RETRACTOR (DRIVER) … REPLACEMENT	0.3
522012 00	FRONT SEAT BELT BUCKLE STALK (DRIVER) … REMOVAL AND INSTALLATION	0.3
522012 10	FRONT SEAT BELT BUCKLE STALK (DRIVER) … REPLACEMENT	0.3
522013 00	FRONT SEAT BELT ANCHOR PLATE … REMOVAL AND INSTALLATION	0.2
522013 10	FRONT SEAT BELT ANCHOR PLATE … REPLACEMENT	0.2
522021 00	FRONT SEAT BELT RETRACTOR (PASSENGER) … REMOVAL AND INSTALLATION	0.3
522021 10	FRONT SEAT BELT RETRACTOR (PASSENGER) … REPLACEMENT	0.3
522022 00	FRONT SEAT BELT BUCKLE STALK (PASSENGER) … REMOVAL AND INSTALLATION	0.2
522022 10	FRONT SEAT BELT BUCKLE STALK (PASSENGER) … REPLACEMENT	0.2
522023 00	FRONT SEAT BELT ANCHOR PLATE (PASSENGER) … REMOVAL AND INSTALLATION	0.2
522023 10	FRONT SEAT BELT ANCHOR PLATE (PASSENGER) … REPLACEMENT	0.2
522031 00	FRONT SEAT BELT RETRACTOR (CENTER) … REMOVAL AND INSTALLATION	0.3
522031 10	FRONT SEAT BELT RETRACTOR (CENTER) … REPLACEMENT	0.3
522032 00	FRONT SEAT BELT BUCKLE STALK (CENTER) … REMOVAL AND INSTALLATION	0.2
522032 10	FRONT SEAT BELT BUCKLE STALK (CENTER) … REPLACEMENT	0.2
523110 00	INSTRUMENT PANEL ASSEMBLY … REMOVAL AND INSTALLATION	1.3
523111 00	INSTRUMENT PANEL … REMOVAL AND INSTALLATION	1.4
523111 10	INSTRUMENT PANEL … REPLACEMENT	1.4
523117 00	INSTRUMENT CENTER PANEL ASSEMBLY … REMOVAL AND INSTALLATION	0.3
523117 10	INSTRUMENT CENTER PANEL ASSEMBLY … REPLACEMENT	0.3
523130 00	INSTRUMENT PANEL GLOVEBOX ASSEMBLY … REMOVAL AND INSTALLATION	0.2
523130 10	INSTRUMENT PANEL GLOVEBOX ASSEMBLY … REPLACEMENT	0.2
523162 00	INSTRUMENT PANEL OUTLET (GARNISH) (SIDE) … REMOVAL AND INSTALLATION (One piece)	0.2
523162 10	INSTRUMENT PANEL OUTLET (GARNISH) (SIDE) … REPLACEMENT (One piece)	0.2
523210 00	CENTER CONSOLE ASSEMBLY … REMOVAL AND INSTALLATION	0.4
523210 10	CENTER CONSOLE ASSEMBLY … REPLACEMENT	0.4
524105 00	HEADLINING (FRONT) … REMOVAL AND INSTALLATION	0.3
524105 10	HEADLINING (FRONT) … REPLACEMENT	0.3
524107 00	HEADLINING (REAR) … REMOVAL AND INSTALLATION	0.3

524107 10	HEADLINING (REAR) … REPLACEMENT	0.3
524110 00	FLOOR CARPET (MAT) ASSEMBLY … REMOVAL AND INSTALLATION (All)	0.8
524110 10	FLOOR CARPET (MAT) ASSEMBLY … REPLACEMENT (All)	0.8
524112 00	REAR (LAP LIGHT) FLOOR CARPET (MAT) … REMOVAL AND INSTALLATION	0.5
524112 10	REAR (LAP LIGHT) FLOOR CARPET (MAT) … REPLACEMENT	0.5
524231 00	FRONT PILLAR TRIM … REMOVAL AND INSTALLATION (One piece)	0.2
524231 10	FRONT PILLAR TRIM … REPLACEMENT (One piece)	0.2
524233 00	REAR PILLAR TRIM … REMOVAL AND INSTALLATION (One piece)	0.2
524233 10	REAR PILLAR TRIM … REPLACEMENT (One piece)	0.2
524237 00	SCUFF PLATE (REAR) … REMOVAL AND INSTALLATION (One piece)	0.2
524237 10	SCUFF PLATE (REAR) … REPLACEMENT (One piece)	0.2
524241 00	REAR WHEELHOUSE TRIM (FRONT) … REMOVAL AND INSTALLATION	0.2
524241 10	REAR WHEELHOUSE TRIM (FRONT) … REPLACEMENT	0.2
524260 00	FRONT DOOR TRIM ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.3
524260 10	FRONT DOOR TRIM ASSEMBLY … REPLACEMENT (One piece)	0.3
524270 00	REAR (SLIDE) DOOR TRIM ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.2
524270 10	REAR (SLIDE) DOOR TRIM ASSEMBLY … REPLACEMENT (One piece)	0.2
524280 00	TAILGATE (BACK DOOR) TRIM ASSEMBLY … REMOVAL AND INSTALLATION	0.2
524280 10	TAILGATE (BACK DOOR) TRIM ASSEMBLY … REPLACEMENT	0.2
525000 95	SUPPLEMENTAL RESTRAINT SYSTEM (SRS) … Inspection by multi-use tester	0.3
525010 00	SRS MODULE … REMOVAL AND INSTALLATION	0.3
525010 10	SRS MODULE … REPLACEMENT	0.3
525020 00	SRS MODULE (PASSENGER SIDE) … REMOVAL AND INSTALLATION	0.5
525020 10	SRS MODULE (PASSENGER SIDE) … REPLACEMENT	0.5
525030 00	CURTAIN AIR BAG MODULE … REMOVAL AND INSTALLATION (One piece)	0.7
525030 10	CURTAIN AIR BAG MODULE … REPLACEMENT (One piece)	0.7
525031 00	SIDE AIR BAG MODULE … REMOVAL AND INSTALLATION (One side)	0.6
525031 10	SIDE AIR BAG MODULE … REPLACEMENT (One side)	0.6
527074 00	ASSIST GRIP … REMOVAL AND INSTALLATION (One piece)	0.2
527074 10	ASSIST GRIP … REPLACEMENT (One piece)	0.2
527077 00	ROOM MIRROR … REMOVAL AND INSTALLATION	0.2
527077 10	ROOM MIRROR … REPLACEMENT	0.2
527078 00	SUN VISOR & SUNSHADE … REMOVAL AND INSTALLATION (One piece)	0.2
527078 10	SUN VISOR & SUNSHADE … REPLACEMENT (One piece)	0.2
528271 00	PASSENGER SIDE AIR BAG CUT OFF SWITCH … REMOVAL AND INSTALLATION	0.3
528271 10	PASSENGER SIDE AIR BAG CUT OFF SWITCH … REPLACEMENT	0.3
528511 00	SRS DIAGNOSIS UNIT … REMOVAL AND INSTALLATION	0.4
528511 10	SRS DIAGNOSIS UNIT … REPLACEMENT	0.4
528511 14	SRS DIAGNOSIS UNIT … SYSTEM REGISTRATION	0.3
541010 00	HEADLAMP ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.6
	[Additional operation]	
	01 … Per 1 pc.	0.1
541010 10	HEADLAMP ASSEMBLY … REPLACEMENT (One piece)	0.7
	[Additional operation]	
	01 … Per 1 pc.	0.2
541010 47	HEADLAMP ASSEMBLY … AIMING	0.3
541013 00	HEADLAMP BULB … REMOVAL AND INSTALLATION (One piece)	0.2
541013 10	HEADLAMP BULB … REPLACEMENT (One piece)	0.2
541070 00	FRONT FOG LAMP ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.1

541070 10	FRONT FOG LAMP ASSEMBLY … REPLACEMENT (One side)	0.3
	[Additional operation]	
	01 … Per 1 pc.	0.1
541071 00	FRONT FOG LAMP BULB … REMOVAL AND INSTALLATION (One side)	0.3
541071 10	FRONT FOG LAMP BULB … REPLACEMENT (One side)	0.3
541073 00	DAYTIME RUNNING LAMP ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.3
541073 10	DAYTIME RUNNING LAMP ASSEMBLY … REPLACEMENT (One side)	0.3
541310 00	REAR COMBINATION LAMP ASSEMBLY … REMOVAL AND INSTALLATION (One side)	0.2
541310 10	REAR COMBINATION LAMP ASSEMBLY … REPLACEMENT (One side)	0.2
541312 00	REAR COMBINATION LAMP BULB … REMOVAL AND INSTALLATION (One side)	0.2
541312 10	REAR COMBINATION LAMP BULB … REPLACEMENT (One side)	0.2
541351 00	LICENCE PLATE LAMP BULB … REMOVAL AND INSTALLATION (One piece)	0.2
541351 10	LICENCE PLATE LAMP BULB … REPLACEMENT (One piece)	0.2
541390 00	HIGH MOUNT STOP LAMP … REMOVAL AND INSTALLATION	0.2
541390 10	HIGH MOUNT STOP LAMP … REPLACEMENT	0.2
541810 00	ROOM LAMP ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.2
541810 10	ROOM LAMP ASSEMBLY … REPLACEMENT (One piece)	0.2
541830 00	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.2
541830 10	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP ASSEMBLY … REPLACEMENT (One piece)	0.2
542026 00	CENTER DISPLAY … REMOVAL AND INSTALLATION	0.2
542026 10	CENTER DISPLAY … REPLACEMENT	0.2
542026 13	CENTER DISPLAY … REPROGRAMMING	0.3
542026 14	CENTER DISPLAY … SYSTEM REGISTRATION	0.3
543010 00	BATTERY … REMOVAL AND INSTALLATION (One piece)	0.2
543010 10	BATTERY … REPLACEMENT (One piece)	0.3
543010 30	BATTERY … INSPECTION	0.2
543010 52	BATTERY … ELECTRICAL CHARGE (One piece)	0.3
543541 00	INSTRUMENT PANEL HARNESS (WIRING HARNESS A) … REMOVAL AND INSTALLATION	6.2
543541 10	INSTRUMENT PANEL HARNESS (WIRING HARNESS A) … REPLACEMENT	6.2
543555 80	REAR GATE HARNESS (LEFT SIDE) … REPLACEMENT	0.5
543555 82	REAR GATE HARNESS (RIGHT SIDE) … REPLACEMENT	0.3
543566 00	FRONT DOOR HARNESS … REMOVAL AND INSTALLATION (One side)	0.6
543566 10	FRONT DOOR HARNESS … REPLACEMENT (One side)	0.6
543567 00	REAR DOOR HARNESS … REMOVAL AND INSTALLATION (One side)	0.3
543567 10	REAR DOOR HARNESS … REPLACEMENT (One side)	0.3
544011 00	HORN … REMOVAL AND INSTALLATION (One piece)	0.3
544011 10	HORN … REPLACEMENT (One piece)	0.3
545011 00	RADIO (INCLUDE CASSETTE) … REMOVAL AND INSTALLATION	0.2
545011 10	RADIO (INCLUDE CASSETTE) … REPLACEMENT	0.2
545011 13	RADIO (INCLUDE CASSETTE) … REPROGRAMMING	0.3
545011 14	RADIO (INCLUDE CASSETTE) … SYSTEM REGISTRATION	0.3
545031 00	FRONT SPEAKER … REMOVAL AND INSTALLATION (One piece)	0.3
545031 10	FRONT SPEAKER … REPLACEMENT (One piece)	0.3
545032 00	REAR SPEAKER … REMOVAL AND INSTALLATION (One piece)	0.3
545032 10	REAR SPEAKER … REPLACEMENT (One piece)	0.3
545051 00	ANTENNA ASSEMBLY … REMOVAL AND INSTALLATION	0.3
545051 10	ANTENNA ASSEMBLY … REPLACEMENT	0.3
545055 00	ANTENNA FEEDER … REMOVAL AND INSTALLATION	0.6
545055 10	ANTENNA FEEDER … REPLACEMENT	0.6
545093 00	USB ADAPTOR … REMOVAL AND INSTALLATION	0.6

545093 10	USB ADAPTOR … REPLACEMENT	0.6
547015 00	CLOCK SPRING (SRS) … REMOVAL AND INSTALLATION	0.3
547015 10	CLOCK SPRING (SRS) … REPLACEMENT	0.3
547020 00	CIGARETTE LIGHTER ASSEMBLY … REMOVAL AND INSTALLATION (One piece)	0.2
547020 10	CIGARETTE LIGHTER ASSEMBLY … REPLACEMENT (One piece)	0.2
547022 00	ACCESSORY SOCKET … REMOVAL AND INSTALLATION	0.3
547022 10	ACCESSORY SOCKET … REPLACEMENT	0.3
547025 25	REAR WINDOW DEFOGGER … REPAIR	0.2
547035 00	AC INVERTER … REMOVAL AND INSTALLATION	0.3
547035 10	AC INVERTER … REPLACEMENT	0.3
547042 00	MICROPHONE … REMOVAL AND INSTALLATION	0.2
547042 10	MICROPHONE … REPLACEMENT	0.2
547053 00	NAVIGATION UNIT … REMOVAL AND INSTALLATION	0.7
547053 10	NAVIGATION UNIT … REPLACEMENT	0.7
547053 13	NAVIGATION UNIT … REPROGRAMMING	0.3
547053 14	NAVIGATION UNIT … SYSTEM REGISTRATION	0.3
547054 00	GPS ANTENNA … REMOVAL AND INSTALLATION	0.4
547054 10	GPS ANTENNA … REPLACEMENT	0.4
547070 00	REAR VIEW MONITOR CAMERA … REMOVAL AND INSTALLATION	0.2
	[Additional operation]	
	AX … Multi around monitor calibration	0.4
547070 10	REAR VIEW MONITOR CAMERA … REPLACEMENT	0.2
	[Additional operation]	
	AX … Multi around monitor calibration	0.4
547070 4B	REAR VIEW MONITOR CAMERA … ZERO-CALIBRATION	0.3
547091 00	IMMOBILIZER KEY RING ANTENNA … REMOVAL AND INSTALLATION	0.2
547091 10	IMMOBILIZER KEY RING ANTENNA … REPLACEMENT	0.2
548122 00	HEADLAMP LEVELING UNIT … REMOVAL AND INSTALLATION (One piece)	0.3
548122 10	HEADLAMP LEVELING UNIT … REPLACEMENT (One piece)	0.3
548212 00	TURN SIGNAL & LIGHTING SWITCH … REMOVAL AND INSTALLATION	0.2
548212 10	TURN SIGNAL & LIGHTING SWITCH … REPLACEMENT	0.2
548215 00	HAZARD WARNING LAMP SWITCH … REMOVAL AND INSTALLATION	0.2
548215 10	HAZARD WARNING LAMP SWITCH … REPLACEMENT	0.2
548261 00	IGNITION SWITCH / ELECTRIC MOTOR SWITCH … REMOVAL AND INSTALLATION	0.3
548261 10	IGNITION SWITCH / ELECTRIC MOTOR SWITCH … REPLACEMENT	0.3
548271 00	RADIO REMOTE CONTROL SWITCH … REMOVAL AND INSTALLATION	0.2
548271 10	RADIO REMOTE CONTROL SWITCH … REPLACEMENT	0.2
548273 00	AUDIO CONTROL SWITCH … REMOVAL AND INSTALLATION	0.2
548273 10	AUDIO CONTROL SWITCH … REPLACEMENT	0.2
548275 00	NAVIGATION FUNCTION SWITCH … REMOVAL AND INSTALLATION	0.3
548275 10	NAVIGATION FUNCTION SWITCH … REPLACEMENT	0.3
548305 00	BATTERY CURRENT SENSOR … REMOVAL AND INSTALLATION	0.2
548305 10	BATTERY CURRENT SENSOR … REPLACEMENT	0.2
548311 00	AUTO LIGHTING CONTROL SENSOR … REMOVAL AND INSTALLATION	0.2
548311 10	AUTO LIGHTING CONTROL SENSOR … REPLACEMENT	0.2
548353 00	BACK SONAR SENSOR … REMOVAL AND INSTALLATION (One piece)	0.3
548353 10	BACK SONAR SENSOR … REPLACEMENT (One piece)	0.3
548515 00	HEAD LAMP AUTO LEVELING ECU … REMOVAL AND INSTALLATION	0.2
548515 10	HEAD LAMP AUTO LEVELING ECU … REPLACEMENT	0.2
548515 14	HEAD LAMP AUTO LEVELING ECU … SYSTEM REGISTRATION	0.2
548524 00	TELEMATICS CONTROL UNIT … REMOVAL AND INSTALLATION	0.3

548524 10	TELEMATICS CONTROL UNIT … REPLACEMENT	0.3
548524 13	TELEMATICS CONTROL UNIT … REPROGRAMMING	0.3
548524 14	TELEMATICS CONTROL UNIT … SYSTEM REGISTRATION	0.3
548536 00	PARKING ASSIST ECU … REMOVAL AND INSTALLATION	0.2
548536 10	PARKING ASSIST ECU … REPLACEMENT	0.2
548536 14	PARKING ASSIST ECU … SYSTEM REGISTRATION	0.3
550000 90	REFRIGERANT CHARGE, AIR CONDITIONER	0.3
551110 00	FRONT HEATER ASSEMBLY … REMOVAL AND INSTALLATION	5.2
551110 10	FRONT HEATER ASSEMBLY … REPLACEMENT	5.8
551111 00	HEATER CORE … REMOVAL AND INSTALLATION	1.1
551111 10	HEATER CORE … REPLACEMENT	1.1
551114 00	ADDITIONAL HEATER … REMOVAL AND INSTALLATION	2.0
551114 10	ADDITIONAL HEATER … REPLACEMENT	2.0
551211 00	HEATER CORE … REMOVAL AND INSTALLATION	0.9
551211 10	HEATER CORE … REPLACEMENT	0.9
551512 00	EXPANSION VALVE … REMOVAL AND INSTALLATION	0.9
551512 10	EXPANSION VALVE … REPLACEMENT	0.9
551610 00	AIR CONDITIONER UNIT (REAR) … REMOVAL AND INSTALLATION	1.0
551610 10	AIR CONDITIONER UNIT (REAR) … REPLACEMENT	1.0
551612 00	EXPANSION VALVE (REAR) … REMOVAL AND INSTALLATION	0.9
551612 10	EXPANSION VALVE (REAR) … REPLACEMENT	0.9
552025 00	SIDE VENTILATOR AIR DUCT … REMOVAL AND INSTALLATION	3.1
552025 10	SIDE VENTILATOR AIR DUCT … REPLACEMENT	3.1
552026 00	REAR HEATER AIR DUCT … REMOVAL AND INSTALLATION	0.2
552026 10	REAR HEATER AIR DUCT … REPLACEMENT	0.2
552027 00	LAP HEATER AIR DUCT … REMOVAL AND INSTALLATION	0.2
552027 10	LAP HEATER AIR DUCT … REPLACEMENT	0.2
552515 00	AIR PURIFIER FILTER … REMOVAL AND INSTALLATION	0.2
552515 10	AIR PURIFIER FILTER … REPLACEMENT	0.2
553110 00	COMPRESSOR ASSEMBLY … REMOVAL AND INSTALLATION	2.0
553110 10	COMPRESSOR ASSEMBLY … REPLACEMENT	2.0
553210 00	FRONT CONDENSER ASSEMBLY … REMOVAL AND INSTALLATION	2.1
553210 10	FRONT CONDENSER ASSEMBLY … REPLACEMENT	2.1
554010 00	HEATER CONTROL ASSEMBLY … REMOVAL AND INSTALLATION	0.2
554010 10	HEATER CONTROL ASSEMBLY … REPLACEMENT	0.2
554011 00	HEATER CONTROL WIRE … REMOVAL AND INSTALLATION	0.3
	[Additional operation]	
	A4 … Instrument panel assembly - R&I	2.9
554011 10	HEATER CONTROL WIRE … REPLACEMENT	0.3
	[Additional operation]	
	A4 … Instrument panel assembly - R&I	2.9
555500 33	PIPING GENERAL (COOLER) … LEAK CHECK	0.4
558101 00	FRONT BLOWER MOTOR … REMOVAL AND INSTALLATION	3.6
558101 10	FRONT BLOWER MOTOR … REPLACEMENT	3.6
558102 00	REAR BLOWER MOTOR … REMOVAL AND INSTALLATION	1.1
558102 10	REAR BLOWER MOTOR … REPLACEMENT	1.1
558121 00	SUCTION PORT CHANGE OVER DAMPER MOTOR … REMOVAL AND INSTALLATION	1.9
	[Additional operation]	
	A1 … Instrument panel assembly - R&I	1.2
558121 10	SUCTION PORT CHANGE OVER DAMPER MOTOR … REPLACEMENT	1.9
	[Additional operation]	

	A1 … Instrument panel assembly - R&I	1.2
558122 00	MODE SELECTION DAMPER MOTOR … REMOVAL AND INSTALLATION	0.3
558122 10	MODE SELECTION DAMPER MOTOR … REPLACEMENT	0.3
558123 00	AIR MIX DAMPER CONTROL MOTOR … REMOVAL AND INSTALLATION	0.3
558123 10	AIR MIX DAMPER CONTROL MOTOR … REPLACEMENT	0.3
558202 00	REAR HEATER (BLOWER) SWITCH … REMOVAL AND INSTALLATION	0.2
558202 10	REAR HEATER (BLOWER) SWITCH … REPLACEMENT	0.2
558302 00	A/C PRESSURE SENSOR … REMOVAL AND INSTALLATION	0.8
558302 10	A/C PRESSURE SENSOR … REPLACEMENT	0.8
558312 00	ROOM TEMPERATURE SENSOR (FOOT) … REMOVAL AND INSTALLATION	0.2
558312 10	ROOM TEMPERATURE SENSOR (FOOT) … REPLACEMENT	0.2
558321 00	AIR-INLET SENSOR … REMOVAL AND INSTALLATION	0.3
558321 10	AIR-INLET SENSOR … REPLACEMENT	0.3
558331 00	FIN SENSOR … REMOVAL AND INSTALLATION	0.3
558331 10	FIN SENSOR … REPLACEMENT	0.3
558511 13	AUTO AIR CONDITIONER CONTROL UNIT … REPROGRAMMING	0.3
558511 14	AUTO AIR CONDITIONER CONTROL UNIT … SYSTEM REGISTRATION	0.3
558512 00	AIR CONDITIONER CONTROLLER … REMOVAL AND INSTALLATION	0.3
	[Additional operation]	
	A1 … Instrument panel assembly - R&I	1.2
558512 10	AIR CONDITIONER CONTROLLER … REPLACEMENT	0.3
	[Additional operation]	
	A1 … Instrument panel assembly - R&I	1.2
558901 00	HEATER BLOWER RESISTOR … REMOVAL AND INSTALLATION	0.2
558901 10	HEATER BLOWER RESISTOR … REPLACEMENT	0.2
558914 00	REAR HEATER RESISTOR … REMOVAL AND INSTALLATION	0.4
558914 10	REAR HEATER RESISTOR … REPLACEMENT	0.4