

1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

Issue	Possible Solution
1. Keyboard or mouse is not detected	Unplug the device and reconnect it to another USB port.
2. Device stops working intermittently	Check for loose connections and update USB drivers.
3. Mouse cursor is not moving properly	Clean the mouse sensor and use it on a suitable surface.
4. Some keyboard keys are not responding	Clean the keyboard and restart the laptop.
5. USB device works slowly or lags	Update device drivers and try a different USB port.

2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step 1: Check Battery Level

- Ensure the Bluetooth headphones are charged.
- Look for the **power LED indicator** on the headphones.
- If the battery is low, charge the headphones and try again.

Step 2: Verify Bluetooth is Enabled

- Open **Settings** → **Bluetooth** on the phone.
- Make sure Bluetooth is turned **ON**.
- Check if the Bluetooth icon appears in the status bar.

Step 3: Put Headphones in Pairing Mode

- Turn on the headphones.
- Press and hold the Bluetooth/Power button until the LED flashes (usually blue/red or white).
- This indicates the headphones are in pairing mode.

Step 4: Search for the Device

- On the phone, go to **Bluetooth Settings**.
- Tap **Scan** or **Pair New Device**.
- Wait for the headphone name to appear in the list of available devices.

Step 5: Connect the Headphones

- Select the headphone name from the list.
- If prompted, confirm the pairing request.
- Check if the status changes to **Connected**.

Step 6: Remove Previous Pairing

If the device does not connect:

- In Bluetooth settings, tap the gear/settings icon next to the headphone name.
- Select **Forget Device** or **Unpair**.
- Put the headphones back into pairing mode and reconnect.

Step 7: Restart Devices

- Turn off the headphones and the phone.
- Wait 10–15 seconds.
- Turn them back on and try pairing again.

Step 8: Check for Other Connected Devices

- Ensure the headphones are not already connected to another phone, laptop, or tablet.
- Disconnect them from other devices if necessary.

Step 9: Test Bluetooth Functionality

- Try connecting another Bluetooth device to the phone.
- If other devices also fail to connect, the issue may be with the phone's Bluetooth.

Step 10: Update Software

- Check for phone software updates.
- Install any available updates and restart the phone.

Step 11: Reset the Headphones

- Follow the manufacturer's reset procedure (usually holding the Power button for 10–15 seconds).
- Re-enter pairing mode and reconnect.

Step 12: Confirm Successful Connection

- Verify that:
 - Bluetooth status shows **Connected**.
 - Headphone LED indicates a successful connection.
 - Audio plays through the headphones.

3.A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.

No.	Check / Action	Purpose
1	Check USB Connection – Unplug and reconnect the webcam or try a different USB port.	Ensures the webcam is properly connected and receiving power.
2	Verify in Device Manager – Open <i>Device Manager</i> → <i>Cameras/Imaging Devices</i> and check if the webcam appears without warning symbols.	Confirms Windows detects the webcam and drivers are working.
3	Check Camera Privacy Settings – Go to <i>Settings</i> → <i>Privacy</i> → <i>Camera</i> and ensure camera access is enabled.	Allows Windows and apps to use the webcam.
4	Allow Zoom Camera Permission – In Camera Privacy Settings, make sure Zoom is allowed to access the camera.	Ensures Zoom has permission to use the webcam.
5	Select the Correct Camera in Zoom – Open <i>Zoom</i> → <i>Settings</i> → <i>Video</i> and choose the external webcam from the camera list.	Prevents Zoom from using the wrong camera device.
6	Update or Reinstall Webcam Drivers – In Device Manager, update the driver or uninstall and reconnect the webcam.	Fixes driver-related issues that may prevent detection.

4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Step 1: Open Windows Settings

- Click the **Start** button.
- Select **Settings** ().
- Click **Update & Security**.
- Select **Troubleshoot** from the left menu.

Step 2: Open Additional Troubleshooters

- Click **Additional Troubleshooters**.
- Find and select **Printer**.
- Click **Run the Troubleshooter**.

Step 3: Select the Problem Printer

- Windows will display a list of installed printers.
- Choose the printer showing **Offline** status.
- Click **Next**.

Step 4: Allow Windows to Diagnose the Problem

The Troubleshooter will automatically check:

- Printer connection status (USB or network).
- Printer spooler service.
- Printer driver issues.
- Default printer settings.
- Network communication problems.
- Pending or stuck print jobs.

Step 5: Review Suggested Fixes

Windows may automatically:

- Restart the Print Spooler service.
- Clear stuck print jobs.
- Set the printer as the default printer.
- Reinstall or update printer settings.
- Reconnect the printer to the network.

Step 6: Apply Recommended Fixes

- If Windows suggests a fix, click **Apply this Fix**.
- Wait for the repair process to complete.

Step 7: Check Results

After troubleshooting, Windows displays:

- Problems found.
- Problems fixed.
- Problems not fixed.
- Additional recommendations if needed.