

1 2 3 4 5 6


Seed Picker Control V1

PWM INPUT

*FC Aux Ports
or
Servo Tester Pwm Out
or
Tx Pwm*

PWM Ground

PWM Signal





Nano




Encoder Knob (HW -040)

TB6600 Stepper Driver



Nema17 JK42HS48 1684



Nano



1 2 3 4 5 6