

SSTV on 11 m quick-start (sdroxide — CB/11 m)

A short, task-oriented walkthrough for sending and receiving **SSTV pictures on the 11 m (27 MHz) citizens' band** with **sdroxide**: which frequency, how to set it up, how to receive a picture and how to send one. SSTV is an analogue image mode — a picture is sent as tones, line by line, over a normal sideband — and on 11 m it is the community's picture mode, alongside the FT8 traffic. For the reference detail behind each control see [USER_MANUAL.md](#) §3.6 and the 11 m band in §6.1; for the why of this fork see the [README](#).

This is the CB/SWL fork of sdroxide. SSTV itself is upstream's; what this fork adds on 11 m is the band, the per-country channel plans, the 11 m SSTV calling channels and the CB callsign in the banner.

Nederlands: [sstv-11m-quickstart.nl.md](#). Français: [sstv-11m-quickstart.fr.md](#). Italiano: [sstv-11m-quickstart.it.md](#). PDF: [sstv-11m-quickstart.en.pdf](#).

Bold names such as **SETTINGS** and **Callsign** are buttons and fields exactly as they appear on screen. Settings > Radio is a menu path.

The frequency (read this first)

- **27.700 MHz is the 11 m SSTV calling frequency** — the one the community actually uses. It sits in the “freeband” above the forty channels (the band runs to 27.860 so that channel is inside it).
 - The in-band picture channels are **27.255 (channel 23)** and **27.375 (channel 37)**.
 - Choose the mode **SSTV** — not **SSTV-FM**, which is for VHF/UHF. SSTV follows phone practice rather than the digital modes' fixed USB: **LSB on 80 and 40 m, USB on 20 m and up**, and 11 m is up, so the radio is put in **USB**.
 - **A picture is slow.** From about a minute (Robot 36) and two (Martin 1, PD120) to four and a half (Scottie DX). One station holds the frequency for that whole time — listen before you send, and move off the calling frequency to chat so others can call.
-

What you need

- **An SDR or radio sdroxide supports:** RTL-SDR, RX-888, Airspy HF+, SDRplay RSP, HackRF, ELAD, PlutoSDR, a **CAT rig** over serial + sound card, TCI, OpenHPSDR or SoapySDR.
- **A 27 MHz antenna** suited to your receiver.

- **sdroxide installed** (below).
- **To send a picture you need a transceiver**, keyed by **VOX** (a sound-card rig) or **CAT**. A receive-only dongle hears and decodes pictures but cannot send them.

Installing

- **Windows** — the installer (.msi) or the portable .zip: see the [Releases page](#).
- **Linux** — the **AppImage** (one file, chmod +x and run), the .deb, or the portable tarball.
- **macOS** — the .dmg.

You can also run sdroxide as a **server** and open it in a browser: `sdroxide --server`, then `http://localhost:4950`.

Part A — One-time setup

Everything here is saved under `~/.config/sdroxide/`, so you do it once.

1. Pick your radio

Open **SETTINGS** and go to the **Radio** tab. Pick your interface (for example **RTL-SDR**, **RX-888** or **Airspy HF+**), then the **sample rate** and the **gain**. Changes apply right after **Apply / reconnect**.

- **Linux — USB receivers:** install the bundled udev rules, or sdroxide will see the device but fail to open it: `sudo cp 60-sdroxide-*.rules /usr/lib/udev/rules.d/ && sudo udevadm control --reload`, then replug.
- **Windows — RX-888:** bind the device to **WinUSB** once with [Zadig](#) — for **both** USB ids (04B4:00F3 and 04B4:00F1).

2. Fill in your details

Go to the **General** tab:

- **Callsign** — your CB identifier, for example 26AT715. It is drawn into the picture's banner and sent as the **FSK ID**, which is how another station or a repeater reads who is sending.
- **Locator / grid** — your Maidenhead grid, used for the map and the great-circle paths; it is **not** sent on 11 m.
- **CB plan** — **World / freeband**, **CEPT/EU**, **Germany 80 channels**, **UK 27/81**, **USA** or **Australia**. It fixes the channels and the channel numbers.

3. Only to send: allow 11 m

11 m transmit is off by default — see *Sending*. To send a picture, switch on **Allow transmit on 11 m (CB)** on the General tab and confirm the note once. Receiving needs no switch.

Part B — Receiving a picture

1. Press **11M** on the band bar.
 2. Open the **Band / Mode** popup and choose **SSTV** from the **DIGITAL** row. The SSTV panel appears under the waterfall: a **RECEIVED** gallery on the left, a transmit compositor on the right and a row of mode buttons on top.
 3. Tune to **27.700 MHz** (or 27.255 / 27.375). The band buttons land on the band's SSTV calling frequencies, so the 11M band's SSTV dials take you there.
 4. An incoming picture builds up **scanline by scanline** in the **LIVE** view as it arrives, then drops into the **RECEIVED** gallery, newest first.
 5. **Auto** (the default) reads the mode from the VIS header — or the sync cadence if you tuned in mid-picture — so you do not have to pick one. The **Signal** meter shows the receive audio level, so you can confirm audio is reaching the decoder. If a header was misread as a slow mode, **Restart RX** drops the half-picture and starts hunting again.
 6. Received pictures are saved as PNG under `~/.config/sdroxide/sstv_rx/` and reload into the gallery next time.
-

Part C — Sending a picture

1. **You need a transceiver** (VOX or CAT) — a receive-only dongle cannot send. Set **Allow transmit on 11 m (CB)** first (Part A.3).
 2. On the **TRANSMIT** side, the five slots work like tabs. **Load image...** (or double-click a slot) picks a picture; it is cropped and scaled to the mode's size and stored under `~/.config/sdroxide/sstv_tx/`.
 3. Type a **message** for the active slot — the **first line is drawn at double size as a title**, and a live preview shows exactly what goes out. The **banner** carries your callsign.
 4. Choose a mode, or leave **Auto** (which sends **Martin 1** until it has detected one). **PD120** and **PD180** give a 640×496 picture for about the same air time as the smaller modes — worth using for a nicer image.
 5. Press **TX** to send; **ABORT TX** stops a picture in progress. **FSK ID** is on by default and sends your callsign as tones after each picture; **TX lead** covers the rig's key-up delay (raise it if a WebSDR hears you but shows no picture); **TX slant** trims the transmit clock in ppm.
 6. **Listen before you send**, and on the calling frequency keep it short and move aside for a chat — a picture is one long transmission.
-

Part D — Keeping a record

- Received pictures live as **PNG** files under `~/.config/sdroxide/sstv_rx/`; the gallery is stored on the machine the radio is plugged into, so every screen sees the same collection. Right-click a thumbnail to delete it.

- **Profiles (Settings > Profiles)** save a whole working setup — dial and mode, gain, drive, the digital identity and the band stacks — under a name.
 - The SSTV panel is the same in the **browser client**; decode and encode run in the server engine.
-

Sending

- **CB is meant for sending *and* receiving, and in most countries it needs no licence** — the licence-free CEPT channels, at limited power. This fork treats 11 m as a full band.
 - **To send SSTV you need a transceiver**, keyed by **VOX** (a sound-card rig — the program plays the audio to its mic input and the radio keys itself) or over **CAT**. A receive-only dongle — most RTL-SDR, RX-888 and Airspy HF+ setups — decodes pictures beautifully but cannot send them.
 - **To transmit, switch on Allow transmit on 11 m (CB)** on the General tab and confirm the note once. It is a switch only because the program's amateur-band lockout is generic and refuses every non-amateur allocation; CB is a separate radio service, so it is opted into rather than assumed.
 - The switch opens **11 m and nothing else** — the broadcast bands stay receive-only.
 - Keep to your country's channels, power and modes — ordinary CB courtesy.
Check the current rules where you are.
 - This fork is for the whole of CB — voice and the digital modes — alongside SWL and decoding. CB and amateur radio are neighbours on the same spectrum.
-

Help and links

- [README](#) — the full overview of the fork.
- [USER_MANUAL.md](#) — the manual; §3.6 is SSTV in full.
- [Releases](#) — the latest build for every platform.

See you on 27.700! 73