

How to remove and install the Hand Rear Brake Sensor on your Stark VARG EX

Video link: <https://www.youtube.com/watch?v=37Nlq-xu0bg>

Source video: How to remove and install the Hand Rear Brake Sensor on your Stark VARG EX by Stark Future Official

Applicable models: EX

Scope

This guide follows the same step-by-step workshop structure as the MX tutorials, but it is derived as a visual sequence from the official Stark Future ASMR video. Because the EX video does not provide usable captions or narration, the procedure is documented through curated screenshots and concise action guidance.

Preparation

- Place the bike on a stable stand or work area before starting the procedure.
- Prepare the correct tools for the fasteners, clips, brackets, and components shown in the video.
- Keep removed hardware organized in sequence so reassembly follows the same order as the video.
- Have a torque wrench ready for any tightening steps that specify a torque value.

Removal Procedure

1. Remove the fasteners or panels that block access to the Hand Rear Brake Sensor

Move the front mask or access panel aside as needed to expose the hand-rear-brake-sensor connector and lever-area routing.

Keep the removed hardware organized in sequence so the same covers and brackets can be returned during assembly.



2. Release the clips and routing points for the Hand Rear Brake Sensor

Move the front access area into a service position so the sensor lead and connector block can be reached cleanly.

Document the original routing so the same path and slack are restored during installation.



3. Disconnect the Hand Rear Brake Sensor

Continue exposing the connector block and free enough lead slack to unplug the sensor without straining the wiring.

Release the connector lock first and avoid pulling on the wire itself.



4. Remove the retaining hardware for the Hand Rear Brake Sensor

Free the remaining retainer or clip that secures the sensor lead at the rear-hand-brake master-cylinder assembly.

Support the component as the last fastener is removed so it does not drop or hang on the wiring.



5. Remove the Hand Rear Brake Sensor from the bike

Remove the hand-rear-brake sensor from the lever assembly and withdraw the lead cleanly.

Keep any washers, spacers, sleeves, or rubber mounts with the removed component for reassembly.



Installation Procedure

6. Position the Hand Rear Brake Sensor for installation

Position the hand-rear-brake sensor back at the lever assembly and route the lead toward the original connector path.

Confirm that no cable is trapped behind the component before the fasteners are started.



7. Reconnect the Hand Rear Brake Sensor and route the wiring correctly

Reconnect the hand-rear-brake-sensor lead and return it to the original clips and guides under the access panel and around the handlebar area.

Check that the wiring has enough slack for steering, suspension, and normal component movement.



8. Install the retaining hardware for the Hand Rear Brake Sensor

Install the remaining retainer or clip for the sensor lead and refit any access hardware removed to reach the connector.

Reinstall any removed clips, covers, or brackets after the main hardware is secure.



9. Verify the operation of the Hand Rear Brake Sensor

Verify the hand-rear-brake sensor is seated correctly and that the brake-light function responds as expected.

Inspect the surrounding routing and hardware one more time before returning the bike to service.



Critical Checks Before Riding

- Confirm the serviced component is fully seated and all fasteners are tightened in the correct order.
- Recheck all torque-critical hardware before riding.
- Make sure all routed cables, clips, brackets, and surrounding parts are returned to their original positions.
- Inspect the bike visually for any missing hardware before returning it to service.