RECIPE CARDS

Recipe *cards*

Every recipe from the site on one printable page each, with a QR code to the full recipe.



Contents

Lighting automation: recipes and first steps (12 recipes) 3

Safety and security (8 recipes) 15

Appliance (7 recipes) 23

Climate and comfort (8 recipes) 30

Notification and alert (13 recipes) 38

Daily routine (6 recipes) 51

Entertainment (7 recipes) 57

Index 64

How to use these cards

Each page is a short version of one web recipe. Page numbers are printed at the bottom of every page.

When is the trigger. **Only if** lists the conditions. **Do** is the action. **Stop** is what ends it.

Scan the QR code, or type the short link, for the full recipe with setup notes, failure modes, and device options.

Devices are examples of what fits the job, not requirements. Any device that does the same job and works with your hub is fine. Local options like Z-Wave, Zigbee, Matter over Thread, and HomeKit keep working when the internet is down.

Test every rule before you rely on it. Safety devices such as smoke, CO, and leak alarms must keep working without automation.

Automate outdoor lights at dusk

Have outdoor lights come on at sunset and turn off at a sensible hour, so nobody has to remember the switch and the lights do not burn all night.

DEVICES

- See the full recipe for device options.

LOGIC

When	Sunset occurs, with an optional offset if the property becomes dark earlier or later.
Only if	The outdoor-lighting schedule is enabled. Seasonal lights also require their seasonal toggle to be on.
Do	Turn on the selected outdoor lights.
Stop	Sunrise or the chosen off time turns the lights off.

Scan for the full recipe

TIP

Group lights by job: safety, path, decorative, and seasonal.

Bathroom night-light automation

Find the bathroom at night without a blinding light. Motion turns on a dim night light, and the wall switch still works if anything fails.

DEVICES

- See the full recipe for device options.

LOGIC

When	Bathroom or entry motion is detected.
Only if	Night mode is active or it is within your chosen night window, and optionally the room is dark enough.
Do	Turn on the bathroom light at 10 percent. Set a warm color temperature only if the light supports it.
Stop	New motion cancels the shutoff. A manual wall-switch change wins.

Scan for the full recipe

Control lights with a wireless button or linked switch

Control several lights from one button, remote, or smart switch, while every room keeps a manual control that guests and family understand.

DEVICES

- See the full recipe for device options.

LOGIC

When	A distinct button press, remote action, or scene event.
Only if	The control is available, the command is allowed for the current time or mode, and no manual override is active.
Do	Send an explicit on, off, dim, or scene command to the selected lights.
Stop	The command completes once the target lights report their expected state, or the platform reports that confirmation is unavailable.

Scan for the full recipe

TIP

Choose one narrow job, such as turning off the downstairs lights from the bedroom.

Garage lights that follow doors, motion, and the TV

Garage lights that turn on with the door or motion, stay on while you work, dim for the garage TV, and turn off only once the garage is empty.

DEVICES

- See the full recipe for device options.

LOGIC

When	A garage door opening, motion, or a change in the TV's power draw.
Only if	Lights only turn on if they were off. Turning off needs all three "empty" signals at the same time.
Do	80% for normal use, 25% for movies, off when empty.
Stop	All three empty signals together.

Scan for the full recipe

TIP

Measure the TV's power draw when off, in standby, on a menu, and playing a movie. Set the thresholds from real numbers.

Office lights that stay on while you work

Office lights that turn on with motion at the right level for the time of day and stay on while you sit still, using the monitor's power draw.

DEVICES

- See the full recipe for device options.

LOGIC

When	Office motion, the monitor's power, or the lights turning off.
Only if	Lights only turn on if they were off.
Do	Set the lights, start or pause the music.
Stop	Both "empty" signals together turn off the lights.



Scan for the full recipe

TIP

In Windows power settings, set the screen to turn off after a short idle time.

Set up gradual wake-up lighting

Wake up gently with a sunrise effect. Slowly brighten a bedroom light before your set wake time so mornings feel easier than a jarring alarm.

DEVICES

- See the full recipe for device options.

LOGIC

When	A fixed time before the desired wake time, such as 30 minutes prior.
Only if	The day matches the intended schedule, such as weekdays only, and any vacation or skip setting is off.
Do	Set the light to a low starting brightness, then gradually raise it toward full brightness over the chosen duration.
Stop	The transition ends once it reaches full brightness, or is cancelled by a manual override.

Scan for the full recipe

TIP

Decide on the wake time and the transition length, then calculate the start time by subtracting the two, for example 6:00 AM start for a 6:30 AM wake time with a 30 minute transition.

Turn lights off after motion stops

Stop paying to light empty rooms. Turn lights off after motion stops, with a forgiving timeout that respects people sitting still and wall switches.

DEVICES

- See the full recipe for device options.

LOGIC

When	The room sensor reports no motion for the chosen timeout.
Only if	The light was turned on by this automation, no other room sensor is active, and no manual override is active.
Do	Turn the light off.
Stop	New motion, another active sensor, or a manual wall-switch change cancels the shutoff.

Scan for the full recipe

TIP

Quick access spaces: One to two minutes can work for a closet or hallway.

Turn lights on when a door opens

Light closets, pantries, and utility rooms the moment the door opens, using a door sensor, while the regular wall switch still works.

DEVICES

- See the full recipe for device options.

LOGIC

When	The contact sensor changes from closed to open.
Only if	The space is dark enough, or it is within the hours when automatic light makes sense.
Do	Turn on the light at the desired brightness.
Stop	A manual wall-switch change is an explicit choice and should not be immediately reversed.

Scan for the full recipe

Turn lights on with motion sensors

Walk into a lit room without reaching for the switch. Turn lights on with motion while the wall switch keeps working for everyone in the house.

DEVICES

- See the full recipe for device options.

LOGIC

When	The entry sensor changes from clear to motion detected.
Only if	The room is dark enough, or it is within the hours you want automatic light.
Do	Turn on the light. Use a dim level at night if the light supports it.
Stop	A manual wall-switch change should prevent the off recipe from undoing the person's choice.

Scan for the full recipe

TIP

Daytime: Leave the light off when daylight is sufficient.

Turn off closet lights on door close

Never leave the closet light on again. Turn it off when the door closes, but only if the automation turned it on, and cancel if the door reopens.

DEVICES

- See the full recipe for device options.

LOGIC

When	The contact sensor changes from open to closed.
Only if	The paired door-open recipe turned this light on, the sensor remains available, and no manual light change has canceled automation ownership.
Do	Start a short off delay, then turn off the light and clear the ownership marker.
Stop	The light turns off, the door reopens, or a person changes the light manually.

Scan for the full recipe

TIP

Complete and test the door-open lighting recipe first.

Video call lighting button

Look good on video calls with one press. Turn on a warm backlight, dim the overhead lights, and pause music, then put it all back after the call.

DEVICES

- See the full recipe for device options.

LOGIC

When	A button press toggles the backlight. The backlight turning on or off drives everything else.
Only if	After the call, music resumes only if it was playing when the call started.
Do	Dim or restore the ceiling lights, pause or resume the office speaker.
Stop	Turning the backlight off ends call mode.

TIP

Put the button where you can reach it from your chair. You will press it with a call already ringing.



Scan for the full recipe

Welcome arrivals with path lighting

Get a lit path from the driveway to the door after dark, while the lock and the lights you control by hand are left alone.

DEVICES

- See the full recipe for device options.

LOGIC

When	A pending-arrival state is followed by a tested physical entry signal within a short confirmation window.
Only if	It is dark, the home was Away before the candidate arrival, no safety mode blocks the action, and the target light is not already on.
Do	Turn on the approved entry or path light and mark only that light as owned by this welcome run.
Stop	The pending arrival expires without a physical signal, the person returns to Away, or a manual light change cancels ownership.



Scan for the full recipe

TIP

Complete the safe arrival routine and use its Home, Away, and pending-arrival states.

Alert when a door is left unlocked

Go to bed knowing the doors are locked. See when an outside door is unlocked, get a bedtime lock check, and add auto-locking only with real feedback.

DEVICES

- See the full recipe for device options.

LOGIC

When	A lock remains unlocked past a delay, or the household intentionally starts the bedtime check.
Only if	The lock report is current, no approved temporary-unlocked period is active, and any automatic lock command has a confirmed closed-door state.
Do	Create persistent status, send one named notification, and at bedtime summarize every lock needing attention.
Stop	Clear the incident only when the lock reports locked or a person explicitly acknowledges an unresolved manual check.

Scan for the full recipe

TIP

Name each lock and door by location.

Dog-bark intrusion deterrent

Make an empty house sound guarded. Play a barking dog through a speaker when motion is detected while you are away, as an extra layer of deterrence.

DEVICES

- See the full recipe for device options.

LOGIC

When	A motion sensor covering an entry point detects movement.
Only if	The home is in Away mode and, optionally, the time is within a defined nighttime window.
Do	Play a dog barking audio clip on a nearby speaker at a moderate volume, and send a notification.
Stop	A cooldown period, such as several minutes, prevents repeat playback from continued motion in the same area.

Scan for the full recipe

TIP

Confirm the platform can play a specific audio file or sound effect on the target speaker; test this manually before wiring it into an automation.

Garage door left open alarm and alerts

Get a phone alert when the garage door is left open too long, plus a bedtime check. A simple open-door alarm that alerts only; closing stays manual.

DEVICES

- See the full recipe for device options.

LOGIC

When	The garage door sensor reports "open" and stays in that state for a set duration, such as 10 minutes.
Only if	The door is still open at the time the duration elapses.
Do	Send a notification stating how long the door has been open.
Stop	The door being closed manually clears the alert.

Scan for the full recipe

TIP

Install a tilt sensor on the garage door, or confirm an existing smart garage controller already reports open and closed state to the platform.

Safer automatic garage closing

Close the garage door safely. Get an alert first, keep people in control, and close unattended only with equipment built for it and entrapment protection.

DEVICES

- See the full recipe for device options.

LOGIC

When	The door remains open longer than the household expects.
Only if	The position sensor is recent and available.
Do	Send a persistent alert naming the door and its reported state.
Stop	The position sensor reports closed after a person closes it, or a person explicitly dismisses the reminder.

Scan for the full recipe

TIP

Test the opener, wall control, remote, photo-eyes, auto-reverse, audible warning, and visual warning according to manufacturer instructions.

Set a persistent cooking reminder

Stop worrying that the stove was left on. Keep a cooking reminder on screen until someone clears it, using a timer or approved appliance status.

DEVICES

- See the full recipe for device options.

LOGIC

When	A person deliberately starts Cooking mode or an approved appliance signal reports active cooking.
Only if	Record which signal started the reminder. Do not require missing motion or Away mode.
Do	Start a visible timer and send a persistent reminder when the chosen interval expires.
Stop	A person checks the appliance controls and clears the reminder.

TIP

Put a physical timer or one-tap Cooking control next to the normal cooking workflow.

Scan for the full recipe

Supplemental fire evacuation support

Help everyone get out faster in a fire. Turn on useful lights the moment listed smoke alarms sound, while those alarms stay the primary warning.

DEVICES

- See the full recipe for device options.

LOGIC

When	A supported alarm integration reports smoke or carbon monoxide.
Only if	None. Do not add mode, time, occupancy, or multi-sensor confirmation conditions.
Do	Turn on fixed path and exterior lights that are safe to operate, then send a supplemental alert naming the reported alarm.
Stop	A responsible person manually resets the supplemental response after emergency services or a qualified person says it is safe.

Scan for the full recipe

TIP

Install, place, interconnect, test, and replace alarms according to local requirements and manufacturer instructions.

Turn on away lights to look occupied

Make the house look lived in while you are away. Turn on a few well-chosen lights in a natural pattern, not every light at once.

DEVICES

- See the full recipe for device options.

LOGIC

When	The home enters Away mode, or the time reaches sunset while already in Away mode.
Only if	The home is currently in Away mode, and the time is between sunset and a set cutoff, such as 11:00 PM.
Do	Turn on the selected away lights, ideally as a single scene rather than individually.
Stop	The cutoff time is reached, or the home leaves Away mode because someone returns.

Scan for the full recipe

TIP

Choose two or three lights that a person home alone would realistically use, such as a living room lamp and one bedroom light; avoid lighting every room.

Water leak detection alerts

Catch water leaks early. Know which sensor got wet, alert the household right away, and add automatic water shutoff only after careful testing.

DEVICES

- See the full recipe for device options.

LOGIC

When	Any leak sensor reports wet.
Only if	None for the first alert. Leak alerts run in Home, Away, Night, and guest modes.
Do	Send a persistent high-priority notification naming the sensor and location, alert at least two responsible people, and turn on a local indicator if it is safe and useful.
Stop	A person inspects the source, stops the water if necessary, and manually clears the incident.

Scan for the full recipe

TIP

Name each sensor for the response location, such as "Laundry supply hoses" instead of "Leak sensor 3."

Automate morning coffee safely

Wake up to coffee you know is ready. Set up the coffee maker the night before and get a clear morning result, with no guessing about whether it brewed.

DEVICES

- See the full recipe for device options.

LOGIC

When	Evening preparation time or the household bedtime routine.
Only if	None for the reminder.
Do	Remind a person to load the machine, set its approved delayed-brew controls, and deliberately mark Ready for morning.
Stop	A person cancels Ready or the morning window ends.

Scan for the full recipe

TIP

Read the coffee maker's instructions for delayed brew, auto-off, cleaning, water level, basket, and carafe placement.

Dishwasher finished notification

Know when the dishes are clean without checking. Get one reliable alert when the dishwasher finishes, based on its power or vibration pattern.

DEVICES

- See the full recipe for device options.

LOGIC

When	Measured power or vibration stays above the dishwasher's calibrated running threshold long enough to prove a cycle started.
Only if	Monitoring data is current and the dishwasher was not already marked as running.
Do	Mark the dishwasher as running and clear any previous waiting-dishes state.
Stop	Mark the cycle finished, send one notification, and set a waiting-dishes state.

Scan for the full recipe

TIP

Check the dishwasher manual and nameplate before connecting any inline monitoring device.

Fridge and freezer door alerts

Save food when a fridge or freezer door is left ajar. Get an alert after a short delay, with a quicker one for the freezer and a check for missing data.

DEVICES

- See the full recipe for device options.

LOGIC

When	The fridge or freezer door sensor reports open.
Only if	The sensor is available and reporting current data.
Do	Start a timer specific to that appliance.
Stop	The door closes before the delay elapses, which cancels the alert.

Scan for the full recipe

TIP

Mount the sensor body on the door frame and the magnet on the door edge, where the gap stays smallest when closed.

Get notified when the dryer finishes

Get one alert when the dryer finishes so clothes do not sit and wrinkle. A vibration sensor spots the end of the cycle without touching dryer power.

DEVICES

- See the full recipe for device options.

LOGIC

When	Vibration remains active long enough to prove the dryer started.
Only if	The sensor is available and the dryer was not already marked as running.
Do	Mark the dryer as running and clear any previous waiting-laundry state.
Stop	Mark the cycle finished, send one notification, and set a waiting-laundry state.

TIP

Find a fixed exterior panel that remains cool and does not block vents, labels, controls, or service access.

Scan for the full recipe

Get notified when the washer finishes

Never forget wet laundry in the washer. Get one reliable alert when the cycle ends, based on the washer's power pattern, without cutting its power.

DEVICES

- See the full recipe for device options.

LOGIC

When	Measured power stays above the washer's calibrated running threshold long enough to prove a cycle started.
Only if	Monitoring data is current and the washer was not already marked as running.
Do	Mark the washer as running and clear any previous waiting-laundry state.
Stop	Mark the cycle finished, send one notification, and set a waiting-laundry state.

TIP

Check the washer manual and nameplate before connecting any inline monitoring device.



Scan for the full recipe

Start the vacuum when everyone leaves

Come home to clean floors. Start the robot vacuum only once everyone has left and only during the day, using a presence signal you have tested.

DEVICES

- See the full recipe for device options.

LOGIC

When	The tested presence signal reports the home as empty.
Only if	The time is within the chosen daytime window, Guest mode is off, and the vacuum has not already run today.
Do	Wait briefly to confirm the departure is real, then start the vacuum's existing cleaning cycle.
Stop	The vacuum finishes, or the tested presence signal reports that someone returned; in either case, send it back to its dock.

TIP

Confirm the presence signal against at least a week of real household comings and goings before using it to start anything.

Scan for the full recipe

Vacuum while the house is empty

Let the robot vacuum clean only while nobody is home, then send it back to the dock the moment someone walks in. No more vacuum underfoot.

DEVICES

- See the full recipe for device options.

LOGIC

When	The tested presence signal reports the home as empty during the chosen daytime window.
Only if	The vacuum has not already completed a cycle today.
Do	Wait briefly to confirm the departure is real, then start cleaning.
Stop	As soon as the presence signal reports anyone home, send the vacuum back to its dock immediately, whether or not the room it was cleaning is finished.

Scan for the full recipe

TIP

Confirm the presence signal against a week of real comings and goings for every household member before using it here.

Automate a bathroom exhaust fan

Run the bathroom fan when a shower starts and turn it off once the steam clears, with nothing to remember and no fan left running all morning.

DEVICES

- See the full recipe for device options.

LOGIC

When	The shower light turns on, or bathroom humidity rises above its calibrated baseline.
Only if	The time falls within the household's normal waking hours, unless overnight ventilation is specifically wanted.
Do	Turn on the bathroom fan.
Stop	The light turns off, or humidity drops back to baseline, for the confirmation period.

Scan for the full recipe

TIP

Choose one primary trigger, either the shower light or a humidity sensor, and treat the other as a backup rather than combining them in a way that confuses troubleshooting.

Automate an indoor air purifier

Breathe cleaner air automatically. Run a plug-in air purifier when the air quality sensor shows a lasting drop, and stop once the air clears.

DEVICES

- See the full recipe for device options.

LOGIC

When	The air quality sensor reports an unhealthy reading.
Only if	The sensor is available and the reading has held at an unhealthy level for several minutes.
Do	Turn on the purifier, choosing a higher speed for a worse reading if the purifier supports it.
Stop	Turn off the purifier once the air has stayed clear through the confirmation period.

Scan for the full recipe

TIP

Place the sensor away from the kitchen, a litter box, or other constant local sources so it reflects the room's general air rather than one corner.

Automate blinds at sunrise and sunset

Open motorized blinds near sunrise and close them near sunset for privacy, with bedtime limits and the normal blind controls still working.

DEVICES

- See the full recipe for device options.

LOGIC

When	Sunrise, with a comfortable offset, or sunset.
Only if	The blind schedule is enabled. A bedroom may also require the household to be awake before opening.
Do	Open blinds after the sunrise offset. Close them at sunset, or no later than a fixed bedtime for privacy-sensitive rooms.
Stop	The blinds reach their commanded position.

Scan for the full recipe

TIP

Group blinds by job: privacy-sensitive, general living space, and solar-gain windows.

Cold-room temperature alerts

Get warned before a cold room drops out of its safe temperature range, without running a portable heater from a general smart plug.

DEVICES

- See the full recipe for device options.

LOGIC

When	The room remains outside its chosen temperature range, or the sensor stops reporting.
Only if	The reading is recent and the sensor has been compared with a known thermometer.
Do	Send an alert naming the room and show the current reading.
Stop	A person inspects the room and acknowledges the alert.

TIP

Put the sensor away from direct sunlight, supply vents, exterior doors, and the heater itself.

Scan for the full recipe

Limit an IR-controlled mini-split

Keep an IR-controlled mini-split from being set too hot or too cold. Send only capped setpoints, never trust blaster state, and keep the remote.

DEVICES

- See the full recipe for device options.

LOGIC

When	The room temperature stays outside the band you chose for that mode.
Only if	The reading is recent, the command is inside the hard cap, heat or cool was chosen on purpose, and the physical remote has not been used since the last send.
Do	Send one discrete setpoint code. Prefer a single code that means the mode and temperature together.
Stop	The room is back inside the band, the sensor goes stale, someone uses the remote, or the command would fall outside the cap.

Scan for the full recipe

TIP

Write the heat ceiling and the cool floor on a card by the remote, and put the same numbers in the rule. The rule refuses to send anything outside them.

Pause HVAC when a window stays open

Stop heating or cooling the outdoors. Pause the HVAC when a window stays open and resume only after every watched window and door is closed.

DEVICES

- See the full recipe for device options.

LOGIC

When	Any monitored window or door remains open for two minutes.
Only if	Heating or cooling is active, climate pause is enabled, and no safety condition requires HVAC to continue.
Do	Record that this recipe owns the pause, save the current thermostat mode if the system can do so reliably, pause HVAC, and identify the opening in a notification.
Stop	Every monitored opening has remained closed briefly.

TIP

Start with windows people intentionally leave open. Exclude exterior doors used for quick trips.



Scan for the full recipe

Safe thermostat auto-away

Save energy while the house is empty with a modest thermostat setback that still protects pets and pipes and respects manual holds.

DEVICES

- See the full recipe for device options.

LOGIC

When	The shared house state changes to Away after its confirmation delay.
Only if	Guest or Staying Home is off, no uncertain presence remains, thermostat data is current, and the requested setting is inside approved safety limits.
Do	Apply the approved daily setback and record that this recipe made the change.
Stop	Someone returns, a person selects Home or Guest, a safety boundary is approached, or thermostat data becomes unavailable.



Scan for the full recipe

Window ventilation notifications

Know when to open or close the windows to save energy. Compare indoor and outdoor temperature and get a nudge when fresh air would help.

DEVICES

- See the full recipe for device options.

LOGIC

When	The gap between indoor and outdoor temperature crosses a chosen threshold in the useful direction for the current season.
Only if	The gap has held for several minutes, and any tracked windows are currently closed.
Do	Send one notification suggesting windows be opened or closed.
Stop	The notification is sent once; the household decides whether to act on it.

TIP

Confirm both the indoor and outdoor temperature readings are current and reasonably accurate before using them.

Scan for the full recipe

Get front-door motion alerts

Get a quick heads-up when someone or something moves near the front door, using an outdoor motion sensor, so you can check for a package.

DEVICES

- See the full recipe for device options.

LOGIC

When	The entrance motion sensor detects movement.
Only if	No motion has already been detected within a short cooldown window, to avoid repeat notifications for the same visit.
Do	Send a phone notification, such as "Motion detected at the front door."
Stop	Not applicable; each motion event is a separate notification, subject to any cooldown.

Scan for the full recipe

TIP

Mount a motion sensor rated for the entrance's actual exposure, whether that is a covered porch or a fully exposed area.

Home maintenance reminder dashboard

Remember filter changes and other home upkeep without relying on memory. Track recurring tasks on a shared dashboard the whole household can see.

DEVICES

- See the full recipe for device options.

LOGIC

When	A fixed interval since the task was last marked done, such as every 60 to 90 days for an HVAC filter.
Only if	The task has not already been marked done within that interval.
Do	Mark the dashboard tile for that task as overdue.
Stop	Marking the task done resets the interval and clears the tile.

TIP

List the recurring maintenance tasks worth tracking, along with a rough interval for each one.



Scan for the full recipe

House status check on demand

Press one button and get a single message about the house: mode, open windows and doors, the front lock, air quality, rain, and running appliances.

DEVICES

- See the full recipe for device options.

LOGIC

When	A button press, a dashboard tile, or a voice command. Nothing triggers it on its own.
Only if	Each line has its own check.
Do	Send one push message.
Stop	The message is sent once per request.

TIP

Group the window sensors by floor, so the message can say where the open window is.

Scan for the full recipe

Kids' teeth-brushing reminder

Know the kids brushed their teeth. A power-monitoring plug on the toothbrush charger notices brushing and sends a reminder if it did not happen.

DEVICES

- See the full recipe for device options.

LOGIC

When	The smart plug's reported power draw drops, indicating the toothbrush was removed from the charger, or a scheduled check runs near a target brushing time.
Only if	A removal has not already been detected within the current brushing window, such as morning or evening.
Do	Log the brushing window as complete when a removal is detected; send a reminder notification if the target time passes without one.
Stop	A detected removal for the current window clears any pending reminder for that window.

TIP

Plug the toothbrush charger into a smart plug that supports power or wattage monitoring, not just basic on/off control.



Scan for the full recipe

Monitor freezer temperature and outbuilding power

Save the food in a garage or shed freezer. Get alerts when it warms up or power may be out, and tell real problems apart from a dropped sensor.

DEVICES

- See the full recipe for device options.

LOGIC

When	Sustained high temperature, loss of a dedicated powered heartbeat, or stale sensor data.
Only if	The reading is current, the relevant monitoring path is healthy enough to evaluate, and the condition lasts long enough to reject a brief fluctuation.
Do	Send a persistent alert naming the freezer or building, current reading, threshold duration, and what remains unknown.
Stop	Keep the incident visible until a person inspects the freezer or power source and acknowledges it.

Scan for the full recipe

TIP

Name each freezer and monitored building by location.

Set a nursery quiet mode

Keep the house quiet during naps and bedtime with a nursery quiet mode a caregiver turns on, while urgent safety alerts still get through.

DEVICES

- See the full recipe for device options.

LOGIC

When	A caregiver deliberately selects Quiet.
Only if	None based on inferred sleep, motion, sound, or device power.
Do	Use the household's chosen dim lighting and lower only optional chimes or media.
Stop	A caregiver selects Normal.

Scan for the full recipe

TIP

Name the state Nursery Quiet, not Baby sleeping.

Set up a garbage day reminder tile

Never miss garbage day. A dashboard tile turns red the day before pickup and goes green once someone marks the bins as done.

DEVICES

- See the full recipe for device options.

LOGIC

When	A fixed time the evening before collection, such as 6:00 PM on the day before pickup.
Only if	None required for the basic version; a calendar check can be added if the collection schedule varies.
Do	Turn on the virtual switch tied to the dashboard tile, which turns the tile red.
Stop	Tapping the tile, or an optional auto-reset the morning after collection, turns the virtual switch off again.

TIP

Create a virtual switch or variable to represent the reminder's state.

Scan for the full recipe

Set up a pet feeding reminder

Stop wondering whether the pet was fed. A smart button logs each feeding so everyone can see it, with a reminder when a meal time is missed.

DEVICES

- See the full recipe for device options.

LOGIC

When	The feeding button is pressed, or a scheduled check runs to see how long it has been since the last press.
Only if	More time has passed than the expected feeding interval, such as 8 to 12 hours.
Do	Send a reminder notification if feeding has not been logged within the expected window; reset the "last fed" timestamp when the button is pressed.
Stop	Pressing the feeding button clears the reminder and resets the timer.

Scan for the full recipe

TIP

Choose a smart button, or repurpose a contact sensor, as the physical feeding-log trigger, placed somewhere convenient near the feeding area.

Shared whole-home music controls

Pause a speaker or change its volume in another room from one shared dashboard, without switching between manufacturer apps.

DEVICES

- See the full recipe for device options.

LOGIC

When	A dashboard tile is tapped, such as play, pause, or a volume adjustment.
Only if	The targeted speaker is online and reachable by the platform.
Do	Send the corresponding playback or volume command to that speaker.
Stop	Not applicable; each tile press is a separate command.

Scan for the full recipe

TIP

Confirm the platform already integrates with each speaker brand in use; this recipe only adds a dashboard layer on top of that integration.

Smart home low-battery alerts

Replace batteries before automations quietly stop working. Get notified when a sensor, lock, or button drops below the level you choose.

DEVICES

- See the full recipe for device options.

LOGIC

When	A monitored device's battery level drops below its set threshold, or reports a "low battery" state.
Only if	The device has not already been flagged within the last several days, to avoid repeat alerts for the same drop.
Do	Send a notification naming the device and its battery level.
Stop	The alert resets once the battery is replaced and reports a normal level again.

Scan for the full recipe

TIP

Confirm which devices actually report battery data in the platform; some devices only expose a simple low-battery flag rather than a percentage.

Smart home status tiles

See what needs attention at a glance. Dashboard tiles stay visible until a door, leak, or battery issue is fixed, instead of a push you swipe away.

DEVICES

- See the full recipe for device options.

LOGIC

When	The underlying condition for a given tile changes, such as a scheduled reminder becoming due.
Only if	None beyond the specific condition each tile is tracking.
Do	Update the tile's virtual switch or variable to reflect the new state, changing its color or label on the dashboard.
Stop	The condition being tracked resolves, either automatically or by a household member marking it done.

Scan for the full recipe

TIP

Identify recurring status information currently sent as one-time notifications that would work better as a persistent tile.

Spoken school morning reminders

Keep school mornings on time. A kitchen speaker says when to brush teeth and put on shoes, then goes back to the music that was playing.

DEVICES

- See the full recipe for device options.

LOGIC

When	Two fixed times in the morning.
Only if	Monday through Friday, and the home mode is Home.
Do	A spoken announcement at a fixed volume that interrupts and then resumes music.
Stop	Each reminder plays once.

TIP

Pick the times by working backward from when you need to leave. Our two reminders are five minutes apart.



Scan for the full recipe

Traditional doorbell phone alerts

Get a phone alert when someone rings your wired doorbell. A contact sensor wired beside the existing chime sends the alert and the chime still rings.

DEVICES

- See the full recipe for device options.

LOGIC

When	The contact sensor changes state when the doorbell press closes its dry terminals.
Only if	None; every press should notify.
Do	Send a phone notification, such as "Someone is at the front door."
Stop	Not applicable; each press is a separate event.

Scan for the full recipe

TIP

Turn off power to the doorbell transformer before doing any wiring.

Build a family-safe bedtime routine

Wind down the house at night with a gentle dimming step and a clear good-night action, while occupied rooms and safety alerts stay untouched.

DEVICES

- See the full recipe for device options.

LOGIC

When	A scheduled wind-down prompt or an intentional good-night button, phrase, or control.
Only if	The home is occupied, no emergency mode is active, and the selected stage is allowed in the current Home or Guest mode.
Do	For wind-down, gently adjust only approved shared-room lights. For good night, set Night mode, turn off approved unoccupied lights, preserve path lighting, apply an approved climate setting, and report unresolved door or appliance status.
Stop	Complete one pass, report anything needing a person, and do not repeat until Night mode ends.

Scan for the full recipe

TIP

List the devices the final routine may change. Leave everything else out.

Guest-friendly smart home mode

Make the house easy for guests. Keep lights and switches simple, stop a false Away mode, and quiet only non-urgent personal automations.

DEVICES

- See the full recipe for device options.

LOGIC

When	A host explicitly starts Guest mode and optionally records an expected departure time.
Only if	No emergency mode is active, and the host confirms which rooms or routines the visit affects.
Do	Mark guests present, prevent phone-only Away activation, keep simple lighting and physical controls active, mute non-urgent personal announcements, and pause routines that expose private information or assume resident schedules.
Stop	A host confirms that the visit ended, then normal Home behavior resumes without replaying missed actions.

Scan for the full recipe

TIP

Create one Guest-present state with a responsible host and expected end time.

Manage wall tablets with home modes

Wake, dim, mute, and turn off wall-mounted dashboard tablets when the home mode changes, and let one tablet light the way to the bathroom at night.

DEVICES

- See the full recipe for device options.

LOGIC

When	A home mode change, or a bathroom light changing while the mode is Night.
Only if	The bathroom guide behavior only runs in Night mode.
Do	Screen on or off, load the start URL, set brightness, and mute.
Stop	The next mode change sets the tablets to that mode's state.

TIP

Turn on Remote Admin in Fully Kiosk Browser and set a password. The hub talks to the tablet over the local network.

Scan for the full recipe

Prepare the house when someone arrives

Come home to a lit path and normal comfort settings. Switch back to Home mode on arrival without treating phone location as proof of who it is.

DEVICES

- See the full recipe for device options.

LOGIC

When	A tracked household member changes from Away to Home.
Only if	The house was actually in Away mode, the arrival remains stable briefly, and this is the first person home.
Do	Set the house to Home, turn on entry or path lights if it is dark, restore the approved thermostat setting, and send a concise status notification.
Stop	The presence signal returns to Away before the confirmation delay ends.

Scan for the full recipe

TIP

Make the arrival routine consume the same Home and Away states used by the away-mode recipe.

Set away mode when everyone leaves

Leave without running through a checklist. Switch the home to Away once it is confirmed empty, then adjust lights, climate, and security for you.

DEVICES

- See the full recipe for device options.

LOGIC

When	The last tracked household member leaves the home area.
Only if	Everyone has remained away for 10 to 15 minutes, Guest or Staying Home mode is off, and no recent indoor activity suggests someone remains.
Do	Set the shared house state to Away, turn off nonessential lights, apply a safe thermostat setback, and notify the household.
Stop	Someone returns, indoor activity appears during the delay, or a person selects Home, Guest, or Staying Home.

Scan for the full recipe

TIP

Create one shared state with at least Home, Away, and Guest values.

Start a quiet good-morning routine

Start the day with lights only where you need them. A morning routine begins when you choose and leaves everyone still sleeping undisturbed.

DEVICES

- See the full recipe for device options.

LOGIC

When	A person intentionally presses the morning button, uses the morning phrase, or dismisses a verified wake alarm.
Only if	The home is in Night mode, no Guest, Vacation, Away, or safety override is active, and the routine is enabled for that person or schedule.
Do	Change Night to Home, light only the needed route at a gentle level, and restore previously approved morning comfort settings.
Stop	The routine finishes after its one-time actions and cannot run again until the next Night-mode cycle.

Scan for the full recipe

TIP

Choose an intentional trigger that works without opening an app.

Control music with a physical switch

Start, stop, or adjust music with a wall switch or button instead of shouting at a voice assistant. Simple music control anyone in the house can use.

DEVICES

- See the full recipe for device options.

LOGIC

When	The button is pressed, or the switch changes position.
Only if	None required; an instant response is usually the point.
Do	Toggle playback, or start a specific playlist at a preset volume, on the chosen speaker.
Stop	A second press toggles playback off, or a separate button stops it.

Scan for the full recipe

TIP

Confirm the button or switch is paired and reports a press reliably in the platform's automation log before building the automation around it.

Dim lights when the TV turns on

Get movie lighting automatically. Dim the living room lights when the TV turns on and bring them back afterward, using a power or status signal.

DEVICES

- See the full recipe for device options.

LOGIC

When	Power draw on the TV's smart plug rises above a threshold, or the TV/streaming device reports it is playing.
Only if	The current time is after a chosen hour, such as sunset, if daytime dimming is not wanted.
Do	Save the current light brightness, then dim the living room lights to a low level.
Stop	Power draw drops below a lower threshold, or the TV reports it has stopped, for a couple of minutes.

Scan for the full recipe

TIP

If using power monitoring, test the TV's actual wattage in both standby and active playback so the "on" and "off" thresholds are set apart from real values, not guessed.

Play music when a shower starts

Hear music or a podcast in the bathroom as soon as the shower starts. A light or door sensor starts playback, so there is nothing to tap or say.

DEVICES

- See the full recipe for device options.

LOGIC

When	The bathroom light turns on, or a door sensor reports the shower door opening.
Only if	The current time is within normal waking hours, and the household is not in a sleeping or quiet-hours state.
Do	Start music or the last-used podcast on the bathroom speaker at a preset volume.
Stop	The light stays off, or the door stays closed, for a couple of minutes.

TIP

Choose one trigger, the light switch or a door sensor, and treat the other as an optional backup rather than combining both in a way that is hard to troubleshoot.



Scan for the full recipe

Play music when arriving home

Walk in to your favorite music. Start playback when you arrive home, using a presence signal you have tested, for the same welcome every time.

DEVICES

- See the full recipe for device options.

LOGIC

When	The household's presence state changes from away to home.
Only if	The current time falls within hours the household wants a welcome-home moment, and music is not already playing.
Do	Start the welcome playlist on the main speaker at a preset volume.
Stop	Manual, or a separate automation that stops music after a set duration if desired.

Scan for the full recipe

TIP

Confirm the presence signal being used, phone location, lock, or garage sensor, has been tested and works reliably for every regular household member, not just one phone.

Set smart-speaker volume presets

Set every speaker to quiet, normal, or loud with one choice instead of adjusting each one by hand whenever the household changes activities.

DEVICES

- See the full recipe for device options.

LOGIC

When	A button, voice command, or scheduled time selects a preset (low, medium, or loud).
Only if	None required; the chosen preset applies immediately.
Do	Set every speaker in the group to the percentage defined for that preset.
Stop	Not applicable; a preset simply sets a level rather than starting or stopping something.

Scan for the full recipe

TIP

Decide on a small number of presets, such as low, medium, and loud, rather than a long list that becomes hard to remember.

Set up one-tap pool party mode

Start the music and party lights for a pool or backyard get-together with one button press, while safety alarms stay exactly as they were.

DEVICES

- See the full recipe for device options.

LOGIC

When	A button press, voice command, or dashboard tile for "pool party mode."
Only if	The current time falls within hours the household considers reasonable for outdoor music.
Do	Set outdoor lighting to a party scene, start the party playlist at a set volume, and pause only non-critical outdoor notifications, such as routine motion alerts.
Stop	A separate "end party" trigger, or the automatic timeout, restores normal lighting and stops music.

TIP

Confirm outdoor lighting and the speaker both respond reliably to platform commands before wiring them into a single scene.



Scan for the full recipe

Whole-home music with favorite station switches

Start a Sonos favorite on grouped speakers by flipping a virtual switch, then let a nightly reset ungroup them and set every volume back to normal.

DEVICES

- See the full recipe for device options.

LOGIC

When	A station switch, a mode change to Home, the stop switch, a mode change to Night or Away, or a reset switch.
Only if	None beyond which switch or mode triggered it.
Do	Group, load a favorite, pause, or reset.
Stop	The stop switch, or the next mode change.

TIP

Save each station as a Sonos favorite first. The automation loads favorites by name or ID, so the favorite has to exist.

Scan for the full recipe

Index

Alert when a door is left unlocked 15
Automate a bathroom exhaust fan 30
Automate an indoor air purifier 31
Automate blinds at sunrise and sunset 32
Automate morning coffee safely 23
Automate outdoor lights at dusk 3
Bathroom night-light automation 4
Build a family-safe bedtime routine 51
Cold-room temperature alerts 33
Control lights with a wireless button or linked switch 5
Control music with a physical switch 57
Dim lights when the TV turns on 58
Dishwasher finished notification 24
Dog-bark intrusion deterrent 16
Fridge and freezer door alerts 25
Garage door left open alarm and alerts 17
Garage lights that follow doors, motion, and the TV 6
Get front-door motion alerts 38
Get notified when the dryer finishes 26
Get notified when the washer finishes 27
Guest-friendly smart home mode 52
Home maintenance reminder dashboard 39
House status check on demand 40
Kids' teeth-brushing reminder 41
Limit an IR-controlled mini-split 34
Manage wall tablets with home modes 53
Monitor freezer temperature and outbuilding power 42
Office lights that stay on while you work 7
Pause HVAC when a window stays open 35
Play music when a shower starts 59
Play music when arriving home 60
Prepare the house when someone arrives 54
Safe thermostat auto-away 36
Safer automatic garage closing 18
Set a nursery quiet mode 43
Set a persistent cooking reminder 19
Set away mode when everyone leaves 55
Set smart-speaker volume presets 61
Set up a garbage day reminder tile 44
Set up a pet feeding reminder 45
Set up gradual wake-up lighting 8
Set up one-tap pool party mode 62
Shared whole-home music controls 46
Smart home low-battery alerts 47
Smart home status tiles 48
Spoken school morning reminders 49
Start a quiet good-morning routine 56
Start the vacuum when everyone leaves 28
Supplemental fire evacuation support 20
Traditional doorbell phone alerts 50
Turn lights off after motion stops 9
Turn lights on when a door opens 10
Turn lights on with motion sensors 11
Turn off closet lights on door close 12
Turn on away lights to look occupied 21
Vacuum while the house is empty 29
Video call lighting button 13
Water leak detection alerts 22
Welcome arrivals with path lighting 14
Whole-home music with favorite station switches 63
Window ventilation notifications 37