RECIPE CARDS

Recipe cards

Every recipe from the site on one printable page each, with a QR code to the full recipe.



Contents

Smart lighting (12 recipes) 3

Safety and security (8 recipes) 15

Appliance (7 recipes) 23

Climate and comfort (8 recipes) 30

Notification and alert (13 recipes) 38

Daily routine (6 recipes) 51

Entertainment (7 recipes) 57

Index 64

How to use these cards

Each page is a short version of one web recipe. Page numbers are printed at the bottom of every card.

When is the trigger. **Only if** lists the conditions. **Do** is the action. **Stop** is what ends it.

Scan the QR code, or type the short link, for the full recipe with setup notes, failure modes, and device options.

Devices are examples of what fits the job. Check compatibility with your own hub before you buy.

Test every rule before you rely on it. Safety devices such as smoke, CO, and leak alarms must keep working without automation.

SMART LIGHTING

1 Automate outdoor lights at dusk

A platform-neutral outdoor-lighting recipe that follows sunset, avoids unnecessary overnight runtime, and keeps physical control available.

DEVICES

- Control outdoor plug-in lighting: Minoston Outdoor Smart Plug
- Switch a fixed outdoor circuit: Leviton DG15S Zigbee switch

LOGIC

When	Sunset occurs, with an optional offset if the property becomes dark earlier or later.
Only if	The outdoor-lighting schedule is enabled. Seasonal lights also require their seasonal toggle to be on.
Do	Turn on the selected outdoor lights.
Stop	Sunrise or the chosen off time turns the lights off.

Tip: Group lights by job: safety, path, decorative, and seasonal.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/outdoor-night-lights.html

SMART LIGHTING

2 Bathroom night-light automation

A local-first bathroom night-light recipe that uses motion, low brightness, and a reliable wall-switch fallback.

DEVICES

- Detect bathroom motion, humidity, temperature, and light: Aeotec TriSensor 8
- Dim a fixed light: TP-Link Tapo S505D Matter Smart Dimmer Switch

LOGIC

When	Bathroom or entry motion is detected.
Only if	Night mode is active or it is within your chosen night window, and optionally the room is dark enough.
Do	Turn on the bathroom light at 10 percent. Set a warm color temperature only if the light supports it.
Stop	New motion cancels the shutoff. A manual wall-switch change wins.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/bathroom-night-light.html

SMART LIGHTING

3 Control lights with a wireless button or linked switch

Let a physical button, remote, or smart switch control other lights while every room keeps an understandable manual fallback.

DEVICES

- Provide a physical input: SONOFF SNZB-01P Zigbee wireless button
- Control fixed lighting: A smart wall switch or dimmer that keeps its paddle working locally

LOGIC

When	A distinct button press, remote action, or scene event.
Only if	The control is available, the command is allowed for the current time or mode, and no manual override is active.
Do	Send an explicit on, off, dim, or scene command to the selected lights.
Stop	The command completes once the target lights report their expected state, or the platform reports that confirmation is unavailable.

Tip: Choose one narrow job, such as turning off the downstairs lights from the bedroom.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/wireless-button-linked-lights.html

SMART LIGHTING

4 Garage lights that follow doors, motion, and the TV

Garage lights turn on when a garage door opens or someone moves, stay on while the space is in use, dim for movies on the garage TV, and turn off only when the garage is really empty.

DEVICES

- Know when a garage door opens: A sensor on each garage door
- Know someone is in the garage: Motion sensors in the garage and in the loft.
- Know the TV is on: A smart plug with power metering on the TV
- Light the garage: Dimmable smart lights or a smart dimmer for the garage lights.

LOGIC

When	A garage door opening, motion, or a change in the TV's power draw.
Only if	Lights only turn on if they were off. Turning off needs all three "empty" signals at the same time.
Do	80% for normal use, 25% for movies, off when empty.
Stop	All three empty signals together.

Tip: Measure the TV's power draw when off, in standby, on a menu, and playing a movie. Set the thresholds from real numbers.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/garage-lights-doors-motion-tv.html

SMART LIGHTING

5 Office lights that stay on while you work

Office lights turn on with motion at a level that fits the time of day, and stay on while you sit still because the monitor's power draw shows someone is at the desk.

DEVICES

- Know someone is at the desk: A smart plug with power metering on the monitor
- Know someone walked in: A motion sensor in the office, and an outdoor light sensor in the front yard for the dark check.
- Know I am home: Phone presence from the UniFi network.
- Play the music: A Sonos speaker in the office.

LOGIC

When	Office motion, the monitor's power, or the lights turning off.
Only if	Lights only turn on if they were off.
Do	Set the lights, start or pause the music.
Stop	Both "empty" signals together turn off the lights.

Tip: In Windows power settings, set the screen to turn off after a short idle time.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/office-motion-lights.html

SMART LIGHTING

6 Set up gradual wake-up lighting

A platform-neutral recipe that gradually brightens a bedroom light before a set wake time, simulating a sunrise instead of a jarring alarm.

DEVICES

- Gradually brighten the light: TP-Link Tapo S505D Matter Smart Dimmer Switch

LOGIC

When	A fixed time before the desired wake time, such as 30 minutes prior.
Only if	The day matches the intended schedule, such as weekdays only, and any vacation or skip setting is off.
Do	Set the light to a low starting brightness, then gradually raise it toward full brightness over the chosen duration.
Stop	The transition ends once it reaches full brightness, or is cancelled by a manual override.

Tip: Decide on the wake time and the transition length, then calculate the start time by subtracting the two, for example 6:00 AM start for a 6:30 AM wake time with a 30 minute transition.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/wake-up-lights.html

SMART LIGHTING

7 Turn lights off after motion stops

A conservative motion-lighting off recipe that respects still occupants, manual wall-switch choices, and local-first control.

DEVICES

- Detect fast entry motion: Shelly BLU Motion ZB
- Dim a fixed light: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Switch a fixed light on or off: Leviton DG15S Zigbee switch

LOGIC

When	The room sensor reports no motion for the chosen timeout.
Only if	The light was turned on by this automation, no other room sensor is active, and no manual override is active.
Do	Turn the light off.
Stop	New motion, another active sensor, or a manual wall-switch change cancels the shutoff.

Tip: Quick access spaces: One to two minutes can work for a closet or hallway.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/lights-off-after-motion.html

SMART LIGHTING

8 Turn lights on when a door opens

A local-first contact-sensor lighting recipe for closets, pantries, and utility rooms that keeps the familiar wall switch usable.

DEVICES

- Detect an open door: SONOFF SenseGuard Gen2 Zigbee contact sensor
- Dim a fixed light: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Switch a fixed light on or off: Leviton DG15S Zigbee switch

LOGIC

When	The contact sensor changes from closed to open.
Only if	The space is dark enough, or it is within the hours when automatic light makes sense.
Do	Turn on the light at the desired brightness.
Stop	A manual wall-switch change is an explicit choice and should not be immediately reversed.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/toggle-lights-door.html

SMART LIGHTING

9 Turn lights on with motion sensors

A local-first motion-lighting recipe for turning lights on when someone enters, while keeping the familiar wall switch in control.

DEVICES

- Detect fast entry motion: Shelly BLU Motion ZB
- Dim a fixed light: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Switch a fixed light on or off: Leviton DG15S Zigbee switch

LOGIC

When	The entry sensor changes from clear to motion detected.
Only if	The room is dark enough, or it is within the hours you want automatic light.
Do	Turn on the light. Use a dim level at night if the light supports it.
Stop	A manual wall-switch change should prevent the off recipe from undoing the person's choice.

Tip: Daytime: Leave the light off when daylight is sufficient.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/lights-on-motion.html

SMART LIGHTING

10 Turn off closet lights on door close

A platform-neutral follow-up to door-triggered lighting that turns off only the light the automation turned on and cancels when the door reopens.

DEVICES

- Detect the door closing: SONOFF SenseGuard Gen2 Zigbee contact sensor
- Dim a fixed light: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Switch a fixed light on or off: Leviton DG15S Zigbee switch

LOGIC

When	The contact sensor changes from open to closed.
Only if	The paired door-open recipe turned this light on, the sensor remains available, and no manual light change has canceled automation ownership.
Do	Start a short off delay, then turn off the light and clear the ownership marker.
Stop	The light turns off, the door reopens, or a person changes the light manually.

Tip: Complete and test the door-open lighting recipe first.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/disable-on-door-close.html

SMART LIGHTING

11 Video call lighting button

One button press turns on a warm backlight behind you, dims the overhead lights, and pauses the music for a video call, then puts everything back when the call ends.

DEVICES

- Start and end the call: Any smart button the hub can see
- Light you from behind: Any warm smart light, or a lamp on a smart plug, on the wall behind your chair.
- Pause the music: A speaker the hub can pause and resume

LOGIC

When	A button press toggles the backlight. The backlight turning on or off drives everything else.
Only if	After the call, music resumes only if it was playing when the call started.
Do	Dim or restore the ceiling lights, pause or resume the office speaker.
Stop	Turning the backlight off ends call mode.

Tip: Put the button where you can reach it from your chair. You will press it with a call already ringing.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/video-call-lighting-button.html

SMART LIGHTING

12 Welcome arrivals with path lighting

Make the final steps to the door easier after dark while leaving the lock and manually controlled lights alone.

DEVICES

- Control plug-in exterior lighting: Minoston Outdoor Smart Plug
- Switch a fixed entry light: Leviton DG15S Zigbee switch
- Confirm entry-door activity: SONOFF SenseGuard Gen2 Zigbee contact sensor
- Suggest that someone is approaching: Use your platform's built-in presence feature, driven by phone location, only to open a short pending-arrival window.

LOGIC

When	A pending-arrival state is followed by a tested physical entry signal within a short confirmation window.
Only if	It is dark, the home was Away before the candidate arrival, no safety mode blocks the action, and the target light is not already on.
Do	Turn on the approved entry or path light and mark only that light as owned by this welcome run.
Stop	The pending arrival expires without a physical signal, the person returns to Away, or a manual light change cancels ownership.

Scan for the full recipe

homeautomationcookbook.com/automation/lighting/driveway-welcome-wave.html

Tip: Complete the safe arrival routine and use

its Home, Away, and pending-arrival states.

13 Alert when a door is left unlocked

Keep an unlocked exterior door visible, check locks at bedtime, and add automatic locking only with current door and lock feedback.

DEVICES

- Report lock state: Kwikset HomeConnect 620 Z-Wave Long Range keypad lock
- Report door position: A compatible contact sensor can report open or closed when an automatic lock command is being considered

LOGIC

When	A lock remains unlocked past a delay, or the household intentionally starts the bedtime check.
Only if	The lock report is current, no approved temporary-unlocked period is active, and any automatic lock command has a confirmed closed-door state.
Do	Create persistent status, send one named notification, and at bedtime summarize every lock needing attention.
Stop	Clear the incident only when the lock reports locked or a person explicitly acknowledges an unresolved manual check.

Scan for the full recipe

homeautomationcookbook.com/automation/security/door-unlocked-bedtime-check.html

Tip: Name each lock and door by location.

SAFETY AND SECURITY

14 Dog-bark intrusion deterrent

A platform-neutral recipe that plays a dog barking sound through a speaker when motion is detected while away, as a supplementary deterrent layer.

DEVICES

- Detect fast entry motion: Shelly BLU Motion ZB
- Play the barking sound on a speaker: Any speaker the platform can control works, for example a Sonos speaker

LOGIC

When	A motion sensor covering an entry point detects movement.
Only if	The home is in Away mode and, optionally, the time is within a defined nighttime window.
Do	Play a dog barking audio clip on a nearby speaker at a moderate volume, and send a notification.
Stop	A cooldown period, such as several minutes, prevents repeat playback from continued motion in the same area.

Tip: Confirm the platform can play a specific audio file or sound effect on the target speaker; test this manually before wiring it into an automation.

Scan for the full recipe

homeautomationcookbook.com/automation/security/fake-dog-deterrent.html

SAFETY AND SECURITY

15 Garage door left-open alerts

A platform-neutral recipe that alerts when a garage door has been left open too long. Alerting only; closing stays manual or with equipment built for it.

DEVICES

- Know whether a garage door is open: THIRDREALITY Zigbee Smart Garage Door Tilt Sensor

LOGIC

When	The garage door sensor reports "open" and stays in that state for a set duration, such as 10 minutes.
Only if	The door is still open at the time the duration elapses.
Do	Send a notification stating how long the door has been open.
Stop	The door being closed manually clears the alert.

Tip: Install a tilt sensor on the garage door, or confirm an existing smart garage controller already reports open and closed state to the platform.

Scan for the full recipe

homeautomationcookbook.com/automation/security/garage-door-notification.html

SAFETY AND SECURITY

16 Safer automatic garage closing

Alert first, keep people in control, and allow unattended closing only through equipment designed for it with working entrapment protection and warnings.

DEVICES

- Know door position: THIRDREALITY Zigbee Smart Garage Door Tilt Sensor
- Close the door: Existing wall control and opener remote
- Detect an obstruction: The opener's required, tested entrapment protection

LOGIC

When	The door remains open longer than the household expects.
Only if	The position sensor is recent and available.
Do	Send a persistent alert naming the door and its reported state.
Stop	The position sensor reports closed after a person closes it, or a person explicitly dismisses the reminder.

Tip: Test the opener, wall control, remote, photo-eyes, auto-reverse, audible warning, and visual warning according to manufacturer instructions.

Scan for the full recipe

homeautomationcookbook.com/automation/security/garage-auto-close.html

SAFETY AND SECURITY

17 Set a persistent cooking reminder

Keep a cooking reminder visible until someone clears it, using a deliberate timer or approved appliance status signal.

DEVICES

- Start a cooking reminder: A physical kitchen timer or deliberate phone timer
- Read appliance status: Manufacturer-supported status for the exact appliance
- Shut off cooking equipment: A person uses the appliance controls

LOGIC

When	A person deliberately starts Cooking mode or an approved appliance signal reports active cooking.
Only if	Record which signal started the reminder. Do not require missing motion or Away mode.
Do	Start a visible timer and send a persistent reminder when the chosen interval expires.
Stop	A person checks the appliance controls and clears the reminder.

Tip: Put a physical timer or one-tap Cooking control next to the normal cooking workflow.

Scan for the full recipe

homeautomationcookbook.com/automation/security/stove-left-on-alert.html

SAFETY AND SECURITY

18 Supplemental fire evacuation support

A conservative fire-response recipe that treats listed smoke alarms as primary, turns on useful lighting immediately, and never infers that a fire is over.

DEVICES

- Detect smoke and carbon monoxide: Listed alarms installed and maintained for the home
- Expose an alarm event to the hub: Manufacturer-supported integration or a listed listener approved for the installed alarm type
- Light an exit path: Existing fixed lights with working wall controls
- Reach the household: Alarm sound and practiced evacuation plan

LOGIC

When	A supported alarm integration reports smoke or carbon monoxide.
Only if	None. Do not add mode, time, occupancy, or multi-sensor confirmation conditions.
Do	Turn on fixed path and exterior lights that are safe to operate, then send a supplemental alert naming the reported alarm.
Stop	A responsible person manually resets the supplemental response after emergency services or a qualified person says it is safe.

Tip: Install, place, interconnect, test, and replace alarms according to local requirements

Scan for the full recipe

homeautomationcookbook.com/automation/security/fire-safety.html

and manufacturer instructions.

19 Turn on away lights to look occupied

A platform-neutral recipe that turns on a few strategic lights while away to make the home look occupied, without an unnatural all-lights-on pattern.

DEVICES

- Switch a fixed light on or off: Leviton DG15S Zigbee switch
- Dim a fixed light: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Control a plug-in light or appliance: Minoston 800 Series Z-Wave plug

Scan for the full recipe

homeautomationcookbook.com/automation/security/away-lights.html

LOGIC

When	The home enters Away mode, or the time reaches sunset while already in Away mode.
Only if	The home is currently in Away mode, and the time is between sunset and a set cutoff, such as 11:00 PM.
Do	Turn on the selected away lights, ideally as a single scene rather than individually.
Stop	The cutoff time is reached, or the home leaves Away mode because someone returns.

Tip: Choose two or three lights that a person home alone would realistically use, such as a living room lamp and one bedroom light; avoid lighting every room.

SAFETY AND SECURITY

20 Water leak detection alerts

A platform-neutral leak recipe that identifies the wet sensor, alerts the household immediately, and adds automatic water shutoff only after verified testing.

DEVICES

- Detect water: THIRDREALITY WL2 Zigbee water leak sensor
- Stop incoming water: Manual main-water shutoff
- Reach the household: Persistent phone notification to at least two adults

Scan for the full recipe

homeautomationcookbook.com/automation/security/water-leak-response.html

LOGIC

When	Any leak sensor reports wet.
Only if	None for the first alert. Leak alerts run in Home, Away, Night, and guest modes.
Do	Send a persistent high-priority notification naming the sensor and location, alert at least two responsible people, and turn on a local indicator if it is safe and useful.
Stop	A person inspects the source, stops the water if necessary, and manually clears the incident.

Tip: Name each sensor for the response location, such as "Laundry supply hoses" instead of "Leak sensor 3."

APPLIANCE

21 Automate morning coffee safely

Prepare the coffee maker the night before and get a clear morning result without wondering whether it was actually made ready.

DEVICES

- Brew on a schedule: Coffee maker with a documented delayed-brew feature
- Record readiness: A visible note or physical checklist
- Remind the household: Evening phone reminder

LOGIC

When	Evening preparation time or the household bedtime routine.
Only if	None for the reminder.
Do	Remind a person to load the machine, set its approved delayed-brew controls, and deliberately mark Ready for morning.
Stop	A person cancels Ready or the morning window ends.

Tip: Read the coffee maker's instructions for delayed brew, auto-off, cleaning, water level, basket, and carafe placement.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/coffee-maker-morning.html

APPLIANCE

22 Dishwasher finished notification

Learn the dishwasher's power or vibration pattern and send one reliable completion alert without controlling appliance power.

DEVICES

- Observe dishwasher power or vibration: No personally verified recommendation yet
- Clear the waiting-dishes state: A manual dashboard or phone action

LOGIC

When	Measured power or vibration stays above the dishwasher's calibrated running threshold long enough to prove a cycle started.
Only if	Monitoring data is current and the dishwasher was not already marked as running.
Do	Mark the dishwasher as running and clear any previous waiting-dishes state.
Stop	Mark the cycle finished, send one notification, and set a waiting-dishes state.

Tip: Check the dishwasher manual and nameplate before connecting any inline monitoring device.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/dishwasher-done-notification.html

APPLIANCE

23 Fridge and freezer door alerts

Alert the household when a fridge or freezer door stays open, using a shorter delay for the freezer and safe handling of missing data.

DEVICES

- Detect an open refrigerator or freezer door: SONOFF SenseGuard Gen2 Zigbee contact sensor

LOGIC

When	The fridge or freezer door sensor reports open.
Only if	The sensor is available and reporting current data.
Do	Start a timer specific to that appliance.
Stop	The door closes before the delay elapses, which cancels the alert.

Tip: Mount the sensor body on the door frame and the magnet on the door edge, where the gap stays smallest when closed.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/fridge-door-alert.html

APPLIANCE

24 Get notified when the dryer finishes

A platform-neutral laundry recipe that detects sustained dryer vibration and sends one completion alert without controlling appliance power.

DEVICES

- Detect dryer vibration: A battery vibration sensor mounted on a cool, fixed exterior panel
- Clear the waiting-laundry state: A manual dashboard or phone action

LOGIC

When	Vibration remains active long enough to prove the dryer started.
Only if	The sensor is available and the dryer was not already marked as running.
Do	Mark the dryer as running and clear any previous waiting-laundry state.
Stop	Mark the cycle finished, send one notification, and set a waiting-laundry state.

Tip: Find a fixed exterior panel that remains cool and does not block vents, labels, controls, or service access.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/dryer-done-notification.html

APPLIANCE

25 Get notified when the washer finishes

A platform-neutral laundry recipe that learns the washer's power pattern and sends one reliable completion alert without controlling appliance power.

DEVICES

- Observe washer power: Zooz ZEN15 Power Switch
- Clear the waiting-laundry state: A manual dashboard or phone action

LOGIC

When	Measured power stays above the washer's calibrated running threshold long enough to prove a cycle started.
Only if	Monitoring data is current and the washer was not already marked as running.
Do	Mark the washer as running and clear any previous waiting-laundry state.
Stop	Mark the cycle finished, send one notification, and set a waiting-laundry state.

Tip: Check the washer manual and nameplate before connecting any inline monitoring device.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/washer-done-notification.html

APPLIANCE

26 Start the vacuum when everyone leaves

A platform-neutral recipe that starts a robot vacuum only after a tested presence signal confirms the home is empty, and only during a daytime window.

DEVICES

- Confirm the whole household has left: Use your platform's built-in presence feature (phone location or network connection) rather than a dedicated product
- Robot vacuum with app control: No personally verified recommendation yet

LOGIC

When	The tested presence signal reports the home as empty.
Only if	The time is within the chosen daytime window, Guest mode is off, and the vacuum has not already run today.
Do	Wait briefly to confirm the departure is real, then start the vacuum's existing cleaning cycle.
Stop	The vacuum finishes, or the tested presence signal reports that someone returned; in either case, send it back to its dock.

Tip: Confirm the presence signal against at least a week of real household comings and goings before using it to start anything.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/robot-vacuum-auto-start.html

APPLIANCE

27 Vacuum while the house is empty

A platform-neutral recipe that starts a robot vacuum only after confirming the home is empty and sends it back to the dock the moment anyone returns.

DEVICES

- Confirm the whole household has left and returned: Use your platform's built-in presence feature (phone location or network connection) rather than a dedicated product
- Robot vacuum with remote dock command: No personally verified recommendation yet

LOGIC

When	The tested presence signal reports the home as empty during the chosen daytime window.
Only if	The vacuum has not already completed a cycle today.
Do	Wait briefly to confirm the departure is real, then start cleaning.
Stop	As soon as the presence signal reports anyone home, send the vacuum back to its dock immediately, whether or not the room it was cleaning is finished.

Tip: Confirm the presence signal against a week of real comings and goings for every household member before using it here.

Scan for the full recipe

homeautomationcookbook.com/automation/appliances/vacuum-when-empty.html

CLIMATE AND COMFORT

28 Automate a bathroom exhaust fan

Run the bathroom fan when a shower starts and turn it off once the steam clears, with nothing to remember and no fan left running all morning.

DEVICES

- Detect bathroom motion with humidity, temperature, and light: Aeotec TriSensor 8
- Switch the bathroom fan independently: No personally verified recommendation yet

LOGIC

When	The shower light turns on, or bathroom humidity rises above its calibrated baseline.
Only if	The time falls within the household's normal waking hours, unless overnight ventilation is specifically wanted.
Do	Turn on the bathroom fan.
Stop	The light turns off, or humidity drops back to baseline, for the confirmation period.

Tip: Choose one primary trigger, either the shower light or a humidity sensor, and treat the other as a backup rather than combining them in a way that confuses troubleshooting.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/fan-shower.html

CLIMATE AND COMFORT

29 Automate an indoor air purifier

A platform-neutral recipe that runs a plug-controlled air purifier when an air quality sensor reports a sustained drop, and stops nagging once the air clears.

DEVICES

- Control a plug-in air purifier: Minoston 800 Series Z-Wave plug
- Measure indoor air quality: No personally verified recommendation yet

LOGIC

When	The air quality sensor reports an unhealthy reading.
Only if	The sensor is available and the reading has held at an unhealthy level for several minutes.
Do	Turn on the purifier, choosing a higher speed for a worse reading if the purifier supports it.
Stop	Turn off the purifier once the air has stayed clear through the confirmation period.

Tip: Place the sensor away from the kitchen, a litter box, or other constant local sources so it reflects the room's general air rather than one corner.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/air-quality-purifier.html

CLIMATE AND COMFORT

30 Automate blinds at sunrise and sunset

Open motorized blinds near sunrise and close them near sunset while preserving privacy, bedtime limits, and physical control.

DEVICES

- Motorize existing blinds or shades

LOGIC

When	Sunrise, with a comfortable offset, or sunset.
Only if	The blind schedule is enabled. A bedroom may also require the household to be awake before opening.
Do	Open blinds after the sunrise offset. Close them at sunset, or no later than a fixed bedtime for privacy-sensitive rooms.
Stop	The blinds reach their commanded position.

Tip: Group blinds by job: privacy-sensitive, general living space, and solar-gain windows.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/blinds-sunset-sunrise.html

CLIMATE AND COMFORT

31 Cold-room temperature alerts

Get an alert before a cold room leaves its safe temperature range without controlling a portable heater through a general smart plug.

DEVICES

- Measure room temperature: THIRDREALITY Zigbee Temperature and Humidity Sensor Lite
- Control central heating: ecobee Smart Thermostat Enhanced
- Add supplemental heat: Manually operated equipment used exactly as instructed

LOGIC

When	The room remains outside its chosen temperature range, or the sensor stops reporting.
Only if	The reading is recent and the sensor has been compared with a known thermometer.
Do	Send an alert naming the room and show the current reading.
Stop	A person inspects the room and acknowledges the alert.

Tip: Put the sensor away from direct sunlight, supply vents, exterior doors, and the heater itself.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/room-heater-maintain-temp.html

CLIMATE AND COMFORT

32 Limit an IR-controlled mini-split

Send only a capped infrared setpoint. Never trust blaster state, and keep the physical remote.

DEVICES

- Send infrared commands: No personally verified recommendation yet
- Read the room: No personally verified recommendation on this page
- Control the unit by hand: The remote that came with the mini-split or window unit

LOGIC

When	The room temperature stays outside the band you chose for that mode.
Only if	The reading is recent, the command is inside the hard cap, heat or cool was chosen on purpose, and the physical remote has not been used since the last send.
Do	Send one discrete setpoint code. Prefer a single code that means the mode and temperature together.
Stop	The room is back inside the band, the sensor goes stale, someone uses the remote, or the command would fall outside the cap.

Tip: Write the heat ceiling and the cool floor on a card by the remote, and put the same numbers in the rule. The rule refuses to send anything outside them.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/mini-split-ir-setpoint-limit.html

CLIMATE AND COMFORT

33 Pause HVAC when a window stays open

A platform-neutral climate recipe that pauses HVAC after a window remains open and resumes only when every monitored opening is closed.

DEVICES

- Control heating and cooling: ecobee Smart Thermostat Enhanced
- Detect an open window or door: SONOFF SenseGuard Gen2 Zigbee contact sensor

LOGIC

When	Any monitored window or door remains open for two minutes.
Only if	Heating or cooling is active, climate pause is enabled, and no safety condition requires HVAC to continue.
Do	Record that this recipe owns the pause, save the current thermostat mode if the system can do so reliably, pause HVAC, and identify the opening in a notification.
Stop	Every monitored opening has remained closed briefly.

Tip: Start with windows people intentionally leave open. Exclude exterior doors used for quick trips.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/thermostat-windows-open.html

CLIMATE AND COMFORT

34 Safe thermostat auto-away

Use a modest thermostat setback when the home is empty without risking pets, frozen pipes, manual holds, or an unsafe recovery.

DEVICES

- See the full recipe for device options.

LOGIC

When	The shared house state changes to Away after its confirmation delay.
Only if	Guest or Staying Home is off, no uncertain presence remains, thermostat data is current, and the requested setting is inside approved safety limits.
Do	Apply the approved daily setback and record that this recipe made the change.
Stop	Someone returns, a person selects Home or Guest, a safety boundary is approached, or thermostat data becomes unavailable.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/safe-thermostat-away.html

CLIMATE AND COMFORT

35 Window ventilation notifications

A platform-neutral recipe that compares indoor and outdoor temperature and notifies the household when opening or closing windows would save energy.

DEVICES

- Track whether a window is open: SONOFF SenseGuard Gen2 Zigbee contact sensor
- Compare indoor and outdoor temperature: Many platforms already provide an outdoor reading through an existing weather integration, so a dedicated outdoor purchase may not be needed

LOGIC

When	The gap between indoor and outdoor temperature crosses a chosen threshold in the useful direction for the current season.
Only if	The gap has held for several minutes, and any tracked windows are currently closed.
Do	Send one notification suggesting windows be opened or closed.
Stop	The notification is sent once; the household decides whether to act on it.

Tip: Confirm both the indoor and outdoor temperature readings are current and reasonably accurate before using them.

Scan for the full recipe

homeautomationcookbook.com/automation/climate/window-notifications.html

NOTIFICATION AND ALERT

36 Get front-door motion alerts

Use an outdoor motion sensor to prompt a quick check when someone or something moves near the entrance, without claiming that every alert is a delivery.

DEVICES

- Detect motion near the front entrance: Ecolink Z-Wave PIR Motion Detector, Pet Immune

LOGIC

When	The entrance motion sensor detects movement.
Only if	No motion has already been detected within a short cooldown window, to avoid repeat notifications for the same visit.
Do	Send a phone notification, such as "Motion detected at the front door."
Stop	Not applicable; each motion event is a separate notification, subject to any cooldown.

Tip: Mount a motion sensor rated for the entrance's actual exposure, whether that is a covered porch or a fully exposed area.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/package-delivery-alert.html

NOTIFICATION AND ALERT

37 Home maintenance reminder dashboard

A platform-neutral recipe that tracks recurring home maintenance tasks, such as filter changes, on a shared dashboard instead of relying on memory.

DEVICES

- Track and display maintenance tasks: No personally verified recommendation yet

LOGIC

When	A fixed interval since the task was last marked done, such as every 60 to 90 days for an HVAC filter.
Only if	The task has not already been marked done within that interval.
Do	Mark the dashboard tile for that task as overdue.
Stop	Marking the task done resets the interval and clears the tile.

Tip: List the recurring maintenance tasks worth tracking, along with a rough interval for each one.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/maintenance-reminder-dashboard.html

NOTIFICATION AND ALERT

38 House status check on demand

Press a button and get one push message that sums up the house, with the mode, open windows and doors, the front door lock, air quality, rain, and appliances that are still running.

DEVICES

- Know what is open: Contact sensors on the windows and doors, grouped by floor.
- Know the outside conditions: An outdoor air quality sensor and a weather service
- Know the appliance status: A way to report whether the dishwasher, dryer, and washer are running or ready

LOGIC

When	A button press, a dashboard tile, or a voice command. Nothing triggers it on its own.
Only if	Each line has its own check.
Do	Send one push message.
Stop	The message is sent once per request.

Tip: Group the window sensors by floor, so the message can say where the open window is.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/house-status-on-demand.html

NOTIFICATION AND ALERT

39 Kids' teeth-brushing reminder

A platform-neutral recipe that uses a power-monitoring smart plug on an electric toothbrush charger to confirm brushing happened, with a reminder if it did not.

DEVICES

- Detect the toothbrush being removed from its charger: No personally verified recommendation yet

LOGIC

When	The smart plug's reported power draw drops, indicating the toothbrush was removed from the charger, or a scheduled check runs near a target brushing time.
Only if	A removal has not already been detected within the current brushing window, such as morning or evening.
Do	Log the brushing window as complete when a removal is detected; send a reminder notification if the target time passes without one.
Stop	A detected removal for the current window clears any pending reminder for that window.

Tip: Plug the toothbrush charger into a smart plug that supports power or wattage monitoring, not just basic on/off control.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/teeth-brushing-reminder.html

NOTIFICATION AND ALERT

40 Monitor freezer temperature and outbuilding power

Alert when a freezer warms unexpectedly or a garage or shed may have lost power, while distinguishing temperature, power, and communications failures.

DEVICES

- Measure freezer temperature: THIRDREALITY Zigbee Temperature and Humidity Sensor Lite
- Detect possible outbuilding power loss: No personally verified recommendation yet

LOGIC

When	Sustained high temperature, loss of a dedicated powered heartbeat, or stale sensor data.
Only if	The reading is current, the relevant monitoring path is healthy enough to evaluate, and the condition lasts long enough to reject a brief fluctuation.
Do	Send a persistent alert naming the freezer or building, current reading, threshold duration, and what remains unknown.
Stop	Keep the incident visible until a person inspects the freezer or power source and acknowledges it.

Tip: Name each freezer and monitored building by location.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/freezer-temperature-power-loss.html

NOTIFICATION AND ALERT

41 Set a nursery quiet mode

Let a caregiver explicitly request nursery quiet mode while urgent safety alerts, manual controls, and normal emergency behavior remain active.

DEVICES

- Request quiet mode: A physical control or deliberate app button
- Provide low light: Existing dimmable room or hallway light
- End quiet mode: The same visible control

LOGIC

When	A caregiver deliberately selects Quiet.
Only if	None based on inferred sleep, motion, sound, or device power.
Do	Use the household's chosen dim lighting and lower only optional chimes or media.
Stop	A caregiver selects Normal.

Tip: Name the state Nursery Quiet, not Baby sleeping.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/baby-sleep-mode.html

NOTIFICATION AND ALERT

42 Set up a garbage day reminder tile

A platform-neutral recipe that turns a dashboard tile red before garbage day and green again once the task is marked done.

DEVICES

- Track and display the reminder: No personally verified recommendation yet

LOGIC

When	A fixed time the evening before collection, such as 6:00 PM on the day before pickup.
Only if	None required for the basic version; a calendar check can be added if the collection schedule varies.
Do	Turn on the virtual switch tied to the dashboard tile, which turns the tile red.
Stop	Tapping the tile, or an optional auto-reset the morning after collection, turns the virtual switch off again.

Tip: Create a virtual switch or variable to represent the reminder's state.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/garbage-day-reminder.html

NOTIFICATION AND ALERT

43 Set up a pet feeding reminder

A platform-neutral recipe that uses a smart button or repurposed sensor to track and remind about pet feeding times.

DEVICES

- Log a feeding event: No personally verified recommendation yet

LOGIC

When	The feeding button is pressed, or a scheduled check runs to see how long it has been since the last press.
Only if	More time has passed than the expected feeding interval, such as 8 to 12 hours.
Do	Send a reminder notification if feeding has not been logged within the expected window; reset the "last fed" timestamp when the button is pressed.
Stop	Pressing the feeding button clears the reminder and resets the timer.

Tip: Choose a smart button, or repurpose a contact sensor, as the physical feeding-log trigger, placed somewhere convenient near the feeding area.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/pet-feeding-reminder.html

NOTIFICATION AND ALERT

44 Shared whole-home music controls

Stop switching between manufacturer apps just to pause a speaker or change its volume in another room.

DEVICES

- Control connected speakers from a dashboard: Any speaker the platform can control works, for example a Sonos speaker

LOGIC

When	A dashboard tile is tapped, such as play, pause, or a volume adjustment.
Only if	The targeted speaker is online and reachable by the platform.
Do	Send the corresponding playback or volume command to that speaker.
Stop	Not applicable; each tile press is a separate command.

Tip: Confirm the platform already integrates with each speaker brand in use; this recipe only adds a dashboard layer on top of that integration.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/music-controls.html

NOTIFICATION AND ALERT

45 Smart home low-battery alerts

A platform-neutral recipe that notifies when a battery-powered sensor, lock, or button drops below a set level, before it fails silently.

DEVICES

- Detect low battery levels: No personally verified recommendation yet

LOGIC

When	A monitored device's battery level drops below its set threshold, or reports a "low battery" state.
Only if	The device has not already been flagged within the last several days, to avoid repeat alerts for the same drop.
Do	Send a notification naming the device and its battery level.
Stop	The alert resets once the battery is replaced and reports a normal level again.

Tip: Confirm which devices actually report battery data in the platform; some devices only expose a simple low-battery flag rather than a percentage.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/low-battery-alerts.html

NOTIFICATION AND ALERT

46 Smart home status tiles

A platform-neutral recipe that replaces one-time push notifications with persistent dashboard tiles for household status information.

DEVICES

- Display persistent status information: No personally verified recommendation yet

LOGIC

When	The underlying condition for a given tile changes, such as a scheduled reminder becoming due.
Only if	None beyond the specific condition each tile is tracking.
Do	Update the tile's virtual switch or variable to reflect the new state, changing its color or label on the dashboard.
Stop	The condition being tracked resolves, either automatically or by a household member marking it done.

Tip: Identify recurring status information currently sent as one-time notifications that would work better as a persistent tile.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/status-tiles.html

NOTIFICATION AND ALERT

47 Spoken school morning reminders

On school days, a kitchen speaker announces when it is time to brush teeth and put on shoes, then goes back to the music that was playing.

DEVICES

- Speak the reminder: A Sonos speaker in the kitchen

LOGIC

When	Two fixed times in the morning.
Only if	Monday through Friday, and the home mode is Home.
Do	A spoken announcement at a fixed volume that interrupts and then resumes music.
Stop	Each reminder plays once.

Tip: Pick the times by working backward from when you need to leave. Our two reminders are five minutes apart.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/school-morning-reminders.html

NOTIFICATION AND ALERT

48 Traditional doorbell phone alerts

A platform-neutral recipe that wires a contact sensor in parallel with an existing wired doorbell chime so ringing it sends a phone notification.

DEVICES

- Detect the doorbell press: Ecolink Z-Wave Plus Door/Window Sensor (DWZWAVE2.5-ECO)

LOGIC

When	The contact sensor changes state when the doorbell press closes its dry terminals.
Only if	None; every press should notify.
Do	Send a phone notification, such as "Someone is at the front door."
Stop	Not applicable; each press is a separate event.

Tip: Turn off power to the doorbell transformer before doing any wiring.

Scan for the full recipe

homeautomationcookbook.com/automation/notifications/doorbell-notification.html

DAILY ROUTINE

49 Build a family-safe bedtime routine

Separate a gentle wind-down from an intentional good-night action while preserving occupied rooms, safety alerts, and manual control.

DEVICES

- Start bedtime: A "Good night" phrase or manual scene control
- Dim selected lights: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Apply an approved sleep setting: ecobee Smart Thermostat Enhanced
- Report open doors or windows: SONOFF SenseGuard Gen2 Zigbee contact sensor

LOGIC

When	A scheduled wind-down prompt or an intentional good-night button, phrase, or control.
Only if	The home is occupied, no emergency mode is active, and the selected stage is allowed in the current Home or Guest mode.
Do	For wind-down, gently adjust only approved shared-room lights. For good night, set Night mode, turn off approved unoccupied lights, preserve path lighting, apply an approved climate setting, and report unresolved door or appliance status.
Stop	Complete one pass, report anything needing a person, and do not repeat until Night mode ends.

Scan for the full recipe

homeautomationcookbook.com/automation/daily-routines/bedtime-routine.html

Tip: List the devices the final routine may change, and leave everything else out.

DAILY ROUTINE

50 Guest-friendly smart home mode

A platform-neutral guest mode that keeps lights and physical controls simple, prevents false Away mode, and quiets only non-urgent personal automation.

DEVICES

- Start and end Guest mode: A clearly labeled dashboard control or voice phrase
- Keep fixed lights familiar: Leviton DG15S Zigbee switch
- Keep climate adjustable: ecobee Smart Thermostat Enhanced

Scan for the full recipe

homeautomationcookbook.com/automation/daily-routines/guest-mode.html

LOGIC

When	A host explicitly starts Guest mode and optionally records an expected departure time.
Only if	No emergency mode is active, and the host confirms which rooms or routines the visit affects.
Do	Mark guests present, prevent phone-only Away activation, keep simple lighting and physical controls active, mute non-urgent personal announcements, and pause routines that expose private information or assume resident schedules.
Stop	A host confirms that the visit ended, then normal Home behavior resumes without replaying missed actions.

Tip: Create one Guest-present state with a responsible host and expected end time.

DAILY ROUTINE

51 Manage wall tablets with home modes

Wake, dim, mute, and turn off wall-mounted dashboard tablets when the home mode changes, and let one tablet double as a night guide to the bathroom.

DEVICES

- Show the dashboard: Wall-mounted tablets
- Control the screen from the hub: Fully Kiosk Browser

LOGIC

When	A home mode change, or a bathroom light changing while the mode is Night.
Only if	The bathroom guide behavior only runs in Night mode.
Do	Screen on or off, load the start URL, set brightness, and mute.
Stop	The next mode change sets the tablets to that mode's state.

Tip: Turn on Remote Admin in Fully Kiosk Browser and set a password. The hub talks to the tablet over the local network.

Scan for the full recipe

homeautomationcookbook.com/automation/daily-routines/wall-tablet-modes.html

DAILY ROUTINE

52 Prepare the house when someone arrives

Restore Home mode, light a safe path, and resume normal comfort without treating phone location as proof of identity.

DEVICES

- Detect the first return home: Use your platform's built-in presence feature (phone location or network connection) rather than a dedicated product
- Light the entry path: Leviton DG15S Zigbee switch
- Restore heating and cooling: ecobee Smart Thermostat Enhanced

Scan for the full recipe

homeautomationcookbook.com/automation/daily-routines/unlock-door-arrival.html

LOGIC

When	A tracked household member changes from Away to Home.
Only if	The house was actually in Away mode, the arrival remains stable briefly, and this is the first person home.
Do	Set the house to Home, turn on entry or path lights if it is dark, restore the approved thermostat setting, and send a concise status notification.
Stop	The presence signal returns to Away before the confirmation delay ends.

Tip: Make the arrival routine consume the same Home and Away states used by the away-mode recipe.

DAILY ROUTINE

53 Set away mode when everyone leaves

A conservative, platform-neutral away-mode recipe that verifies the home is empty before changing lights, climate, or security behavior.

DEVICES

- Decide who is home: Use your platform's built-in presence feature, usually driven by each family member's phone location or its connection to the home network, rather than a dedicated product
- Detect recent indoor activity: Aeotec SmartThings Motion Sensor
- Adjust heating and cooling: ecobee Smart Thermostat Enhanced
- Control fixed lights: Leviton DG15S Zigbee switch

LOGIC

When	The last tracked household member leaves the home area.
Only if	Everyone has remained away for 10 to 15 minutes, Guest or Staying Home mode is off, and no recent indoor activity suggests someone remains.
Do	Set the shared house state to Away, turn off nonessential lights, apply a safe thermostat setback, and notify the household.
Stop	Someone returns, indoor activity appears during the delay, or a person selects Home, Guest, or Staying Home.

Tip: Create one shared state with at least Home, Away, and Guest values.

Scan for the full recipe

homeautomationcookbook.com/automation/daily-routines/away-mode.html

DAILY ROUTINE

54 Start a quiet good-morning routine

A platform-neutral morning routine that starts from an intentional signal, lights only the needed path, and leaves sleeping household members undisturbed.

DEVICES

- Start the routine: A "Good morning" voice phrase or manual scene control
- Light the morning path: TP-Link Tapo S505D Matter Smart Dimmer Switch
- Restore approved comfort: ecobee Smart Thermostat Enhanced

Scan for the full recipe

homeautomationcookbook.com/automation/daily-routines/morning-routine.html

LOGIC

When	A person intentionally presses the morning button, uses the morning phrase, or dismisses a verified wake alarm.
Only if	The home is in Night mode, no Guest, Vacation, Away, or safety override is active, and the routine is enabled for that person or schedule.
Do	Change Night to Home, light only the needed route at a gentle level, and restore previously approved morning comfort settings.
Stop	The routine finishes after its one-time actions and cannot run again until the next Night-mode cycle.

Tip: Choose an intentional trigger that works without opening an app.

ENTERTAINMENT

55 Control music with a physical switch

A platform-neutral recipe that uses a wall switch or button to start, stop, or adjust music instead of relying on a voice assistant.

DEVICES

- Trigger the automation: No personally verified recommendation yet
- Play the music: Any speaker the platform can control works, for example a Sonos speaker.

LOGIC

When	The button is pressed, or the switch changes position.
Only if	None required; an instant response is usually the point.
Do	Toggle playback, or start a specific playlist at a preset volume, on the chosen speaker.
Stop	A second press toggles playback off, or a separate button stops it.

Tip: Confirm the button or switch is paired and reports a press reliably in the platform's automation log before building the automation around it.

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/music-switch-control.html

ENTERTAINMENT

56 Dim lights when the TV turns on

Dim living-room lights when the TV turns on, then restore them afterward using a tested power or device-status signal.

DEVICES

- Detect the TV turning on: Zooz ZEN15 Power Switch
- Dim the living room lights: TP-Link Tapo S505D Matter Smart Dimmer Switch

LOGIC

When	Power draw on the TV's smart plug rises above a threshold, or the TV/streaming device reports it is playing.
Only if	The current time is after a chosen hour, such as sunset, if daytime dimming is not wanted.
Do	Save the current light brightness, then dim the living room lights to a low level.
Stop	Power draw drops below a lower threshold, or the TV reports it has stopped, for a couple of minutes.

Tip: If using power monitoring, test the TV's actual wattage in both standby and active playback so the "on" and "off" thresholds are set apart from real values, not guessed.

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/tv-dim-lights.html

ENTERTAINMENT

57 Play music when a shower starts

A platform-neutral recipe that starts music or a podcast in the bathroom when a shower begins, using a light or door sensor as the trigger.

DEVICES

- Trigger the automation: Leviton DG15S Zigbee switch
- Play the music: Any speaker the platform can control works, for example a Sonos speaker

LOGIC

When	The bathroom light turns on, or a door sensor reports the shower door opening.
Only if	The current time is within normal waking hours, and the household is not in a sleeping or quiet-hours state.
Do	Start music or the last-used podcast on the bathroom speaker at a preset volume.
Stop	The light stays off, or the door stays closed, for a couple of minutes.

Tip: Choose one trigger, the light switch or a door sensor, and treat the other as an optional backup rather than combining both in a way that is hard to troubleshoot.

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/shower-music.html

ENTERTAINMENT

58 Play music when arriving home

A platform-neutral recipe that starts music on arrival, using a tested presence signal, to create a consistent welcome-home moment.

DEVICES

- Detect arrival: Use your platform's built-in presence feature (phone location or network connection), a smart lock, or a garage door sensor; use whichever the household has already tested.
- Play the music: Any speaker the platform can control works, for example a Sonos speaker.

LOGIC

When	The household's presence state changes from away to home.
Only if	The current time falls within hours the household wants a welcome-home moment, and music is not already playing.
Do	Start the welcome playlist on the main speaker at a preset volume.
Stop	Manual, or a separate automation that stops music after a set duration if desired.

Tip: Confirm the presence signal being used, phone location, lock, or garage sensor, has been tested and works reliably for every regular household member, not just one phone.

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/welcome-home-music.html

ENTERTAINMENT

59 Set smart-speaker volume presets

Choose a quiet, normal, or loud preset once instead of adjusting each speaker by hand whenever the household changes activities.

DEVICES

- Store and apply the preset: No personally verified recommendation yet
- Play and adjust audio: Any speaker the platform can control works, for example a Sonos speaker.

LOGIC

When	A button, voice command, or scheduled time selects a preset (low, medium, or loud).
Only if	None required; the chosen preset applies immediately.
Do	Set every speaker in the group to the percentage defined for that preset.
Stop	Not applicable; a preset simply sets a level rather than starting or stopping something.

Tip: Decide on a small number of presets, such as low, medium, and loud, rather than a long list that becomes hard to remember.

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/speaker-volume-presets.html

ENTERTAINMENT

60 Set up one-tap pool party mode

A platform-neutral recipe that starts music and lighting for a pool or backyard party with one button press, without touching safety alarms.

DEVICES

- Outdoor party lighting: No personally verified recommendation yet
- Outdoor music playback: Any speaker the platform can control works, for example a Sonos speaker
- Trigger the scene: No personally verified recommendation yet

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/pool-party-mode.html

LOGIC

When	A button press, voice command, or dashboard tile for "pool party mode."
Only if	The current time falls within hours the household considers reasonable for outdoor music.
Do	Set outdoor lighting to a party scene, start the party playlist at a set volume, and pause only non-critical outdoor notifications, such as routine motion alerts.
Stop	A separate "end party" trigger, or the automatic timeout, restores normal lighting and stops music.

Tip: Confirm outdoor lighting and the speaker both respond reliably to platform commands before wiring them into a single scene.

ENTERTAINMENT

61 Whole-home music with favorite station switches

Virtual switches for favorite stations group the downstairs speakers and start a Sonos favorite, and a nightly reset ungroups them and puts every speaker back at a sensible volume.

DEVICES

- Play the music: Sonos speakers downstairs, with one chosen as the group coordinator.
- Control groups and favorites from the hub: community Sonos Advanced Controller
- Pick a station: Virtual switches on the hub, one per station, plus a stop switch.

LOGIC

When	A station switch, a mode change to Home, the stop switch, a mode change to Night or Away, or a reset switch.
Only if	None beyond which switch or mode triggered it.
Do	Group, load a favorite, pause, or reset.
Stop	The stop switch, or the next mode change.

Tip: Save each station as a Sonos favorite first. The automation loads favorites by name or ID, so the favorite has to exist.

Scan for the full recipe

homeautomationcookbook.com/automation/entertainment/sonos-favorite-switches.html

Index

Alert when a door is left unlocked 15
Automate a bathroom exhaust fan 30
Automate an indoor air purifier 31
Automate blinds at sunrise and sunset 32
Automate morning coffee safely 23
Automate outdoor lights at dusk 3
Bathroom night-light automation 4
Build a family-safe bedtime routine 51
Cold-room temperature alerts 33
Control lights with a wireless button or linked switch 5
Control music with a physical switch 57
Dim lights when the TV turns on 58
Dishwasher finished notification 24
Dog-bark intrusion deterrent 16
Fridge and freezer door alerts 25
Garage door left-open alerts 17
Garage lights that follow doors, motion, and the TV 6
Get front-door motion alerts 38
Get notified when the dryer finishes 26
Get notified when the washer finishes 27
Guest-friendly smart home mode 52
Home maintenance reminder dashboard 39
House status check on demand 40
Kids' teeth-brushing reminder 41
Limit an IR-controlled mini-split 34
Manage wall tablets with home modes 53
Monitor freezer temperature and outbuilding power 42
Office lights that stay on while you work 7
Pause HVAC when a window stays open 35
Play music when a shower starts 59
Play music when arriving home 60
Prepare the house when someone arrives 54
Safe thermostat auto-away 36
Safer automatic garage closing 18
Set a nursery quiet mode 43
Set a persistent cooking reminder 19
Set away mode when everyone leaves 55
Set smart-speaker volume presets 61
Set up a garbage day reminder tile 44
Set up a pet feeding reminder 45
Set up gradual wake-up lighting 8
Set up one-tap pool party mode 62
Shared whole-home music controls 46
Smart home low-battery alerts 47
Smart home status tiles 48
Spoken school morning reminders 49
Start a quiet good-morning routine 56
Start the vacuum when everyone leaves 28
Supplemental fire evacuation support 20
Traditional doorbell phone alerts 50
Turn lights off after motion stops 9
Turn lights on when a door opens 10
Turn lights on with motion sensors 11
Turn off closet lights on door close 12
Turn on away lights to look occupied 21
Vacuum while the house is empty 29
Video call lighting button 13
Water leak detection alerts 22
Welcome arrivals with path lighting 14
Whole-home music with favorite station switches 63
Window ventilation notifications 37