## Maintenance Procedure No. MP560

Page 1 of 2

TASK DESCRIPTION			
CLEAN LUBE OIL SEPARATOR ELEMENT			
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS			
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 5			
SPECIAL TOOLS REQUIRED:			
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.			
SAFETY PRECAUTIONS:			
CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.			
PREPARATION:			

## **PROCEDURE**


- 1. Shut down the engine.
- 2. Remove bolts from the separator cover.
- 3. Disconnect the flexible exhaust tube assembly from the eductor tubes and remove the housing cover and exhaust tube elbow as an assembly.
- 4. Remove eductor assembly tubes from stack.
- 5. Separate inner eductor tube from outer tube by inserting a screwdriver at the top of the eductor flanges.
- 6. Clean carbon deposits from inside and outside of both eductor tubes.

**Note:** On applications where exhaust stack is connected to an elbow or silencer which prevents viewing down stack, inspection of diffuser can be performed using a light and mirror through the eductor tube connection when eductor assembly is removed for cleaning.

- 7. Remove screen element from separator cover and wash in petroleum solvent. Rinse element in hot water and blow dry with compressed air.
- 8. Insert inner tube into outer tube with hole in inner tube flange aligned with pin in outer tube flange.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment

- 9. Place eductor assembly into stack with the word TOP stamped on the inner tube flange facing upward.
- 10. Install screen element into cover and mount cover to separator with mounting bolts.
- 11. Attach exhaust elbow and educator assembly to exhaust stack with four mounting bolts.
- 12. Run engine and check for leaks.



DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment