Maintenance Procedure No. MP1017

Page 1 of 1

| TASK DESCRIPTION | | | |
|--|--|--|--|
| CHECK HIGH VOLTAGE CABINET AIR FILTER AND TAKE MANOMETER READING | | | |
| BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS | | | |
| MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 10 | | | |
| SPECIAL TOOLS REQUIRED: | | | |
| | | | |
| RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC. | | | |
| | | | |
| SAFETY PRECAUTIONS: | | | |
| CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE. | | | |
| PREPARATION: | | | |
| | | | |

PROCEDURE

The manometer should indicate greater than 1-1/2" of water pressure.

- a. If less than 1-1/2" of water, check the electrical cabinet air filter housing for leaks.
- b. If greater than 10" of water, clean the air filter element.

| DATE OF FIRST ISSUE | September 2007 | AUTHORIZED BY: |
|---------------------|----------------|--------------------------------|
| REVISION 1 | August 2009 | TITLE: Manager, Rail Equipment |