

- 1) The **reply frames** have two parts- called header and data. The header will be first and data will next one as shown in table below.

Header	Data
--------	------

- 2) The header is divided in multiple sections as follows and having fix length of 10 bytes. The version is fixed constant value. The data format is in little endian. The CRC is calculated for header only, its type is CRC-CCITT (0xFFFF) and already available in file test.py.

Version	Service type	Data length	Remote Serial Number	Header CRC
one byte	one byte	two bytes	four bytes	two bytes
0	1	2, 3	4, 5, 6, 7	8, 9
0x15	0x00	0x0A, 0x00	0xD2, 0x04, 0x00, 0x00	0x9D, 0x5B

Version = 0x15

Service type = 0x00

The service types are defined in dictionary called - SERVICE_TYPE of current canvas.

Data length without header = 0x000A

Remote Serial Number = 0x000004D2

Header CRC = 0x5B9D

- 3) The data section of frame is divided in multiple sub-sections as follows and its length is given in header at location marked “Data length without header”, i.e., 3rd section of header of frame. The definition of data sections is given below.

Module Name	Module's Parameter Name	Parameter value
ASCII chars	ASCII chars	Variable length: ASCII or number in little endian
ADC	SRATE	0x00, 0x08

The module name and its parameter are extract from dictionary CMD_LOOKUP in current file.

ADC Module's SRATE Parameter value = 0x0800

As above example is of ADC module and SRATE to set. The service type will define, what is status of reply, if it is 'CMD_OK', ie 0x00, the remote received command rightly, acted on it and replied. Other cases, there will be issues – 0x01 means error at remote due to some reasons, like crc, unknown command or parameter etc.