Aurora-7 Wireless Router - User Manual

Setup

Connect the Aurora-7 to your modem with the yellow Ethernet cable and plug in the power adapter. Wait about two minutes until the status light turns solid green. On a phone or laptop, join the network named Aurora-7-Setup; the initial password is printed on the label under the router. Open the address 192.168.50.1 in a browser to start the setup wizard, which asks you to choose a new network name, a new Wi-Fi password and a new administrator password. The wizard finishes by checking for firmware updates.

Aurora-7 Wireless Router - User Manual

Firmware and maintenance

To update the firmware manually, open the administration page, choose Maintenance and then Firmware, and upload the file downloaded from the support site. Do not unplug the router during the update, which takes about four minutes. The router restarts twice. Automatic updates are enabled by default and run at 03:00 local time on Sundays. A factory reset is performed by holding the recessed reset button for ten seconds with a paperclip until the status light flashes white. A factory reset erases all settings, including the Wi-Fi password.

Aurora-7 Wireless Router - User Manual

Troubleshooting

A slowly blinking orange light means the router cannot reach the internet; check the cable between the router and the modem, then restart both devices. A solid red light indicates a hardware fault and the device should be returned under warranty. If the Wi-Fi signal is weak in distant rooms, place the router in a central, elevated location away from microwave ovens and metal shelves, and switch to the 5 GHz band for short distances and the 2.4 GHz band for longer distances. Up to 32 devices can be connected at the same time. The warranty period is 24 months from the date of purchase.