

Manitowoc Ice PO Box 1720 Manitowoc, WI 54221-1720 T 920-682-0161 www.manitowocice.com

Instructions for upgrading Firmware for Indigo Ice Machines

<u>Step 1:</u> You must use a formatted 2 GB or smaller Flash drive for "E" Indigo Control Boards and 32 GB or smaller Flash Drive for all other control boards. NOTE: when choosing allocation unit size 512 may not always be available. If this is the case, choose the smallest allocation size available. This procedure can be downloaded from the Manitowoc Ice website www.manitowocice.com

Caution: Not following this procedure may impede the upgrade process.

Note: The following instruction for Upgrading Firmware applies to upgrades for the Indigo E, G, and H Control boards.



Indigo E Board (Green) 2.XXX



Indigo G Board (Blue) 4.XXX



Indigo H Board (Red) 5.XXX

At a Windows Based Computer (PC)

Step 2: Download Firmware from website, www.manitowocice.com to your computer.

Step 3: Insert Flash drive into computer and Format according to Parts and Service Communicator MII-070 (06/11)



Inserting Flash Drive into Computer



Manitowoc Ice PO Box 1720 Manitowoc, WI 54221-1720 T 920-682-0161 www.manitowocice.com


Step 4: Open Firmware Zip and then open the folder.

Do not change or rename the files as that will impede the upgrade process.

1. Copy the eighteen (18) files and paste them onto your properly sized and formatted flash drive.







Copy all 18 files from your Computer

Paste all 18 files on to your Flash Drive

Confirm that all 18 files are on the Flash Drive

*Note: All revisions (for Indigo E, G & H and Indigo NXT Firmware) will be loaded onto one flash drive. The Indigo and Indigo NXT Ice Machine control board will automatically select and load the correct files from the flash drive.

<u>Step 6:</u> Remove Flash drive from computer (suggestion: mark flash drive with the firmware revision to identify at a later date.)



To Upgrade Firmware on the Indigo Ice machine

1. Press Menu Button



2. Scroll Brackets down to Service and press the right Arrow.



3. Scroll Brackets down to USB Setup and press the Right Arrow.



Manitowoc Ice

PO Box 1720 Manitowoc, WI 54221-1720 T 920-682-0161 www.manitowocice.com

4. With Brackets around USB Stick, press



5. Insure Brackets are around Download Frm and press the Right Arrow



6. Insert Flash Drive with loaded firmware into the USB port on the Control board





Manitowoc Ice PO Box 1720 Manitowoc, WI 54221-1720 T 920-682-0161 www.manitowocice.com

- 7. Press Check after the flash drive is inserted
- 8. Wait for Completion (this may take up to 5-10 min)




Caution, Not following the instructions may impede upgrade process. While upgrading firmware:

- Do Not Disconnect power
- Do Not Remove Flash Drive
- Do Not press any of the interface buttons

Once complete the display goes back to the home screen and the Control Board's green LED lights begin to flash again.





- 9. Remove flash drive and check Firmware Revision under Machine information for proper loading, refer to Menu navigation diagram.
- 10. Cycle Power (disconnect power and reapply power) to the ice machine.
- 11. Check for Proper Ice Machine Operation.

Indigo H Board (Red)