1/13/25, 10:30 PM Trigger macros


You are here: IoT Gateway User Guide > Projects and triggers > Defining a trigger > Trigger macros

Topic updated on September 21, 2023

Trigger macros

All triggers have access to a set of trigger macros that provide information related to the execution of the trigger. These trigger macros are available to trigger actions as a source or input variable.

The following example shows the reference to the trigger macros as the source to a **Set** action:



Trigger macros are never available to trigger actions as a destination or output variable. The trigger macros are:

Trigger macro	Data type	Description
\$EVENT_TIME	TIMESTAMP	The date and time that the trigger event occurred.
\$EXECUTION_EVENT_TIME	TIMESTAMP	The date and time that the trigger execution occurred. In most cases, this will be the same as \$EVENT_TIME. When the execution of the trigger is delayed because of trigger instance queuing, the two times could vary.
\$TIME_IN_QUEUE	INT4	The time that the trigger instance waited in the trigger instance queue before starting execution.
\$LAST_ERROR	INT4	The last error value encountered by the trigger.
\$LAST_ERROR_STRING	STRING	The last error value encountered by the trigger in a STRING data type.
\$PROJECT	STRING	The name of the project that this trigger belongs to.
\$TRIGGER	STRING	The name of the trigger.
\$MODULE_NAME	STRING	The node name where this trigger is executing.
\$NULL	STRING	Use this macro to specify a NULL value to an input variable of an action. This can be used to set a column or stored procedure parameter value to NULL when executing a database transaction action.

About Telit | Contact Us | Legal Notices | Terms of Service | Privacy Policy

Copyright © 2025, Telit IoT Solutions Holding Ltd.. All rights reserved.