1/13/25, 10:33 PM Listener

You are here: IoT Gateway User Guide > Projects and triggers > Trigger event type reference > Listener

Topic updated on September 21, 2023

Listener

A Listener event trigger executes when a message arrives from an external application.

A Listener event trigger is part of a listener component and can optionally send date back to the external application in a reply message.

See Listeners for more information on the listener feature.

Defining a listener event trigger

To define a listener event trigger, follow these steps:


- 1. From the Workbench left pane, expand the node where you want to define the listener event trigger.
- 2. Select the **Project** icon to display the **Projects** window, right click a specific project tab to display its pop-up menu, and then select **New**.

You also can select the New button at the bottom of the Projects window when a specific project tab has already been selected.

3. The new Trigger window appears.

Name the trigger. The trigger name can be up to 64 characters and include letters, numbers, and the underscore character. Spaces are allowed.

4. From the Event tab, select the Trigger Event Type down-arrow, and then select Listener.



The **Event** tab becomes active with parameters that accommodate the listener event.

Parameter Description

Listener Map Definition

Select a listener map from the list of listener maps currently defined on the node.

The listener map contains the definition of the input message's format and variables, and any optional output message's format and variables.

Listener event type trigger event variables

The event variables available to a listener event trigger are based on the definition of the listener map:

Input variables The data type of the listener map input variable will be available as an input event variable in the listener event trigger. These input event variables can be used as the source variable in the trigger's actions.

The data type of the listener map input event variable in the listener event trigger. These input event variables can be used as the source variable in the listener event trigger. These input event variables can be used as the source variable in the listener event trigger. These input event variables can be used as the source variable in the listener event trigger. These input event variables can be used as the source variable in the listener event trigger. These input event variables can be used as the source variable in the listener event trigger.

Output The data type variables of the listener map out variable

Data type

If the corresponding listener definition includes the Send reply message option, then the listener map can define output variables. Each listener map output variable will be available as an output event variable in the listener event trigger. These output event variables can be used as the destination variable in the trigger's actions.

Description

Related Topics

Event variable

Listeners

About Telit | Contact Us | Legal Notices | Terms of Service | Privacy Policy

Copyright © 2025, Telit IoT Solutions Holding Ltd.. All rights reserved.