

## 3 CHANNEL DUAL / TRIPLE RECTIFIER SOLO HEAD

#### FRONT PANEL

CHANNEL 1 (GREEN)		
<b>Control Function</b>	Type	Mesa Part#
Gain	Pot	593792
	Knob	408110
Master	Pot	593792
	Knob	408110
Presence	Pot	592738
	Knob	408110
Treble	Pot	593148
	Knob	408110
Middle	Pot	593736
	Knob	408110
Bass	Pot	593148
	Knob	408110
Cln/Pushed	Switch	607101
Green LED	LED	395538
	Lens	703300

CHANNEL 2 (ORANGE)		
Control Function	n Type	Mesa Part#
Gain	Pot	592794
	Knob	408110
Master	Pot	593792
	Knob	408110
Presence	Pot	593737
	Knob	408110
Treble	Pot	592738
	Knob	408110
Middle	Pot	593737
	Knob	408110
Bass	Pot	593739
	Knob	408110
Raw/Vtg/Mdrn	Switch	607303
Orange LED	LED	395433
	Lens	703300

CHANNEL 3 (RED)		
<b>Control Function</b>	Type	Mesa Part#
Gain	Pot	592794
	Knob	408110
Master	Pot	593792
	Knob	408110
Presence	Pot	592151
	Knob	408110
Treble	Pot	592738
	Knob	408110
Middle	Pot	593737
	Knob	408110
Bass	Pot	593148
	Knob	408110
Raw/Vtg/Mdrn	Switch	607303
Red LED	LED	395753
	Lens	703300

MISC PARTS		
<b>Control Function</b>	Type	Mesa Part#
Input	Jack	610120
Output	Pot	593148
	Knob	408110
Solo	Pot	593148
	Knob	408110
Pilot Light	Bulb	703047
	Lens	703782
	Light Holder	703850
Standby	Switch	602112
Power	Switch	602112

#### REAR PANEL

MISC PARTS	
------------	--


MICC	PARTS
MISC	IANIS


## 3 CHANNEL DUAL / TRIPLE RECTIFIER SOLO HEAD

<b>Control Function</b>	Type	Mesa Part#
Slave		
	Pot	592378
	Knob	408111
	Jack	618112
Speaker Outs (5)	Jack	618112
FX Loop		
Assign	Rotary Sw	608110
	Knob	408111
Send	Jack	618112
Return	Jack	618112
Send Level	Pot	593736
	Knob	408113
Mix Level	Pot	593737
	Knob	408113
<b>Channel Select</b>		
	Rotary Sw	608226
	Knob	408111
Foot Switch	Jack	613607

<b>Control Function</b>	Туре	Mesa Part#
External Swtch (5)	Jack	618112
Bias Select		
Select	Switch	602000
Grn LED	LED	395550
Red LED	LED	395520
Rectifier Select	Switch	602112
Bold/Spongy	Switch	600115
Fuse Holder		
Domestic	Cap/Holder	790347
	Fuse	790403
Export	Cap/Holder	790346
	Fuse	795200
AC Receptacle	Jack	613713


# MESA-BOOGIE DUAL RECTIFIER 3 CHANNEL







### MESA-BOOGIE DUAL RECTIFIER SOLO HEAD 3 CHANNEL

PREAMP PT1 FILE RECEPRI. 501






MESA-BOOGIE DUAL RECTIFIER SOLO HEAD 3 CHANNEL



#### 2 CH3 VOICING

MESA-BOOGIE DUAL RECTIFIER SOLO HEAD 3CHANNEL

CH2 CH3 UDICING



MESA-BOOGIE DUAL RECTIFIER SOLO HEAD 3 CHANNEL

