

- Connect to the PLC network via Lowe's Guest & vpn or ssiplc.
- Click button labeled C01 C12 to read from each area.
- Search for text within the table, don't have to specify a column. Will automatically return matching results.
- Click to toggle between "condensed" & "extended" column view.
- Navigation
 - o Default only displays 10 rows, you can select 5, 10, or 20 rows.
 - Use arrows to navigate between pages.
- Drag & drop column headers to group data fields together. Click the fields to change between ascending and descending order.

