# **LipSync Macro: User Guide**

#### Introduction

The LipSync Macro is a sip-and-puff joystick that emulates keystrokes from a keyboard. It allows users to interact with their electronic device without having to physically touch it through a series of recorded touchscreen interactions. This works on phones and tablets that have switch access (Switch Accessibility in iOS devices, Universal Switch in Android).

### **Device Compatibility**







iPad (iOS 7-13.1)

iPhone (iOS 7-13.1) Phone (Android 5.0+) Tablet (Android 5.0+)

Windows MacOS

#### Powering the LipSync Macro

The LipSync Macro needs to be powered at all times with an external power source as there's no internal battery. There are several options:





USB power adapter

Computer USB port





Power bank (>5000 mAh)

USB-C/Lightning to **USB** adapter

## Connecting via USB

For computers and Android & Windows devices, connect the LipSync Macro USB into the device. Use an adapter if necessary.

For iOS devices, connect the LipSync Macro USB into a USB hub. Use a USB to USB C/Lightning (depending on the device used) to connect the USB hub to your device.

For more information, see LipSync Macro: Setup Guide.

### Connecting Wirelessly

- 1. Open Settings > Bluetooth > Turn it on.
- 2. Tap on LipSyncMacro to connect.
- 3. A Connected message will show beside the device name when it successfully connects.

#### Default Functions for PC

Action	Action Time (seconds)	Function
MOUTHPIECE RIGHT	N/A	† + + +
MOUTHPIECE LEFT	N/A	† + + +
MOUTHPIECE UP	N/A	† + + +
MOUTHPIECE DOWN	N/A	† + <b>+</b> +
PUFF	1	[ ] DEL
SIP	1	C V B SPACE

<sup>\*</sup>No setup is required for the Macro to be used with computers.

## Custom Functions on the Phone/Tablet

After the LipSync Switch is setup with a phone or tablet, users can modify the programmed functions within the device. For visual instructions and advanced setups, please see Part 3 in the LipSync Switch: Setup Guide.

- 1. Open Settings > (iOS) Accessibility or (Android) Accessibility > Dexterity & Interactions
- 2. Go to (iOS) Switch Control/ (Android) Universal Switch
- 3. Tap on Switches to bring up the list of functions already programmed.
- 4. Tap on a saved function you want to modify and select the new function you want to assign it.

