

Asst.Prof.Dr.Santi Nuratch

Embedded Computing and Control Lab. @ INC-KMUTT


santi.inc.kmutt@gmail.com

Department of Control System and Instrumentation Engineering, King Mongkut's University of Technology Thonburi, **KMUTT**


Install ECC-Uart-WebSockets




- 1) Download the ecc-uart-websockets-cli-installer-v1.0.2.rar from the GitHub/resources/software-tools
- 2) Extract the download file using WinRAR or 7-Zip to a temporal directory
- 3) Run the installer, ecc-uart-websockets-cli-installer-v1.0.2.exe by Right-click and choose Run as administrator



4) Go to directory C:\ecc-lab\tools, Right-click on the ecc-system-init.bat and click the Run as administrator



5) Open a Command prompt (cmd.exe) and give it a command ecc-uart-websockets-cli, it will print information like this.





Asst.Prof.Dr.Santi Nuratch

Embedded Computing and Control Lab. @ INC-KMUTT

santi.inc.kmutt@gmail.com

Department of Control System and Instrumentation Engineering, King Mongkut's University of Technology Thonburi, **KMUTT**