

Product Manuals — RetailHub Technologies Pvt. Ltd.

Document Type: Product User Manual Compilation **Applicable To:** Products sold under RetailHub-fulfilled and partner-brand catalogs **Last Updated:** July 2026 **Policy Owner:** Product Support & Technical Documentation Team

Introduction

This document compiles user manuals for a representative selection of products across RetailHub's major categories: Electronics, Laptops, Smartphones, Home Appliances, and Furniture accessories. Each manual includes an overview, features, specifications, setup instructions, safe operating guidelines, maintenance advice, troubleshooting steps, warranty information, and frequently asked questions. Always refer to the physical manual included in your product box for model-specific details, as this document covers general operating principles applicable across most models in each category.

1. Laptop — RetailHub Volt 14 Laptop

Overview

The RetailHub Volt 14 is a mid-range productivity laptop designed for everyday computing, remote work, and light creative tasks. It ships with a pre-installed operating system, a full-size backlit keyboard, and a lightweight aluminum chassis suited for portability.

Features

- 14-inch Full HD anti-glare display
- Backlit keyboard with 1.5mm key travel
- Fingerprint reader for secure login
- Dual-band Wi-Fi 6 and Bluetooth 5.2
- Up to 10 hours of battery life on a single charge

Specifications

Component	Specification
Processor	Up to 12th Gen Intel Core i5
RAM	8GB/16GB LPDDR5
Storage	512GB NVMe SSD
Display	14" FHD, 300 nits
Battery	53Wh, fast charge to 50% in 30 minutes
Weight	1.4 kg
Ports	2x USB-C, 1x USB-A, HDMI, 3.5mm audio jack

Installation

1. Remove the laptop from its protective sleeve and packaging.
2. Connect the included 65W USB-C charger and charge for at least 30 minutes before first use.
3. Press and hold the power button for 2 seconds to switch on.

First-Time Setup

1. Select your preferred language, region, and Wi-Fi network.
2. Sign in with an existing account or create a new one when prompted.
3. Register your fingerprint under Settings > Accounts > Sign-in Options for faster future logins.
4. Allow the system to complete initial driver and update installation, which may take 10–15 minutes on first boot.

Operating Instructions

- Use the function key combination (Fn + F5/F6) to adjust screen brightness.
- Charge the battery between 20% and 80% for optimal long-term battery health where possible.
- Close the lid to enter sleep mode; the laptop resumes instantly when reopened.

Safety Precautions

- Do not place the laptop on soft surfaces (bedding, cushions) for extended periods, as this can block ventilation and cause overheating.
- Use only the original 65W charger; third-party chargers with incorrect voltage may damage internal components.

- Avoid exposing the laptop to liquids or extreme temperatures (below 0°C or above 40°C).

Maintenance

- Clean the screen with a dry microfiber cloth; avoid ammonia-based cleaners.
- Run a system update check monthly under Settings > Updates.
- Keep vents free of dust by gently cleaning air intakes every few months with compressed air.

Troubleshooting

Issue	Suggested Fix
Laptop won't power on	Charge for 30 minutes, then hold power button for 10 seconds to force restart
Overheating during use	Close background applications, ensure vents are unobstructed
Wi-Fi not connecting	Toggle Airplane Mode on/off, restart router, forget and rejoin network
Battery draining quickly	Check Task Manager for high-usage background apps, reduce screen brightness

Warranty Information

The Volt 14 carries a 1-year standard manufacturer warranty covering hardware defects, extendable up to 3 years. See our [Warranty Policy](#) document for full terms.

FAQs

Q: Can I upgrade the RAM later? A: RAM is soldered on this model and cannot be upgraded post-purchase; consider the 16GB variant at checkout if you anticipate heavier workloads. **Q: Does it support external monitors?** A: Yes, via the HDMI port or USB-C with DisplayPort Alt Mode, supporting up to a 4K external display.

Technical Support

Contact laptop-support@retailhub.in or call 1800-102-4070 for driver downloads, diagnostic tools, and service center locations.

2. Smartphone — RetailHub Pulse X5

Overview

The Pulse X5 is a mid-range smartphone offering a balance of camera performance, battery life, and everyday reliability, aimed at users upgrading from entry-level devices.

Features

- 6.5-inch AMOLED display with 90Hz refresh rate
- Triple rear camera system (50MP main, ultra-wide, macro)
- 5000mAh battery with 33W fast charging
- In-display fingerprint sensor and face unlock

Specifications

Component	Specification
Display	6.5" AMOLED, 90Hz
Processor	Octa-core, up to 2.4GHz
RAM/Storage	6GB/128GB, 8GB/256GB
Battery	5000mAh, 33W fast charging
Rear Camera	50MP + 8MP + 2MP
Front Camera	16MP
OS	Latest Android, 2 major OS upgrades promised

Installation

1. Insert the SIM card(s) using the included ejector tool.
2. Press and hold the power button for 3 seconds to switch on.
3. Connect to Wi-Fi or mobile data to begin setup.

First-Time Setup

1. Choose language and region, then connect to a network.
2. Transfer data from an old device via cable or cloud backup, if applicable.
3. Register fingerprint and/or face unlock under Settings > Security.

- 4. Complete account sign-in and allow initial app updates to install.

Operating Instructions

- Swipe down from the top for quick settings; swipe up from the bottom for the home screen and app drawer.
- Use the camera app's Night Mode for low-light photography.
- Enable Battery Saver under Settings > Battery when charge falls below 20%.

Safety Precautions

- Avoid charging the phone under a pillow or blanket, which can trap heat.
- Use only certified 33W-compatible chargers to avoid battery degradation.
- The device is IP53 rated (splash-resistant only) — do not submerge in water.

Maintenance

- Update software regularly under Settings > System > Software Update.
- Use a screen protector and case to prevent scratches and drop damage, which are not covered under warranty.
- Restart the device weekly to clear background memory buildup.

Troubleshooting

Issue	Suggested Fix
Phone overheating	Close unused apps, avoid direct sunlight while charging
Slow performance	Clear cache under Settings > Storage, uninstall unused apps
Camera app crashing	Update the camera app, restart device, clear app cache
Battery draining fast	Check Settings > Battery > Usage to identify high-drain apps

Warranty Information

1-year manufacturer warranty on the device, 6 months on the in-box charger and cable. Screen damage from drops is not covered.

FAQs

Q: Is the Pulse X5 5G-enabled? A: Yes, it supports 5G on compatible network bands, configurable under Settings > Network & Internet. **Q: Can I expand storage with a memory card?** A: No, this model does not support expandable storage; choose the 256GB variant if you need more space.

Technical Support

Contact mobile-support@retailhub.in or use the in-app chat for firmware updates and repair scheduling.

3. Television — RetailHub Vista 43" Smart LED TV

Overview

The Vista 43" is a Full HD Smart TV with built-in streaming apps, voice remote support, and multiple connectivity options for home entertainment setups.

Features

- 43-inch Full HD LED display with wide viewing angle
- Built-in smart OS with major streaming app support
- Voice-command remote compatibility
- Dolby Audio-enhanced built-in speakers

Specifications

Component	Specification
Screen Size	43 inches
Resolution	1920x1080 Full HD
Refresh Rate	60Hz
Ports	3x HDMI, 2x USB, 1x Optical Audio, Ethernet
Speaker Output	24W, Dolby Audio
Wi-Fi	Dual-band 802.11ac

Installation

1. Attach the included table stand using the provided screws, or mount using a VESA-compatible wall bracket (sold separately).
2. Connect the power cable to a grounded socket.
3. Connect any external devices (set-top box, gaming console) via HDMI before powering on.

First-Time Setup

1. Power on and follow the on-screen setup wizard to select language, region, and Wi-Fi network.
2. Sign in to your streaming accounts or create new profiles as prompted.
3. Run the auto-channel scan if using an antenna or cable input.
4. Allow the TV to complete a software update check before use.

Operating Instructions

- Use the remote's home button to access the app launcher.
- Adjust picture mode (Standard, Vivid, Movie, Game) under Settings > Picture for different content types.
- Enable Game Mode for reduced input lag when connecting a gaming console.

Safety Precautions

- Ensure adequate ventilation space around the TV, especially when wall-mounted.
- Do not place heavy objects on top of the stand-mounted unit.
- Unplug during thunderstorms or extended periods of non-use to prevent surge damage.

Maintenance

- Clean the screen with a dry or slightly damp microfiber cloth; never spray liquid directly onto the screen.
- Keep firmware updated under Settings > System > Software Update for security and app compatibility.
- Dust rear ports periodically to maintain good connections.

Troubleshooting

Issue	Suggested Fix
No picture, power light on	Check HDMI/input source selection, try a different HDMI port
Apps freezing or crashing	Restart the TV, clear app cache, ensure stable internet connection
No sound	Check mute status and external soundbar connection settings
Remote not responding	Replace batteries, re-pair via Settings > Remote & Accessories

Warranty Information

1-year comprehensive warranty on panel and internal components. Physical screen damage (cracks, pressure marks) is not covered.

FAQs

Q: Can I mirror my phone screen to the TV? A: Yes, using the built-in screen mirroring feature under Settings > Connections, compatible with most Android and iOS devices. **Q: Does the TV support external soundbars?** A: Yes, via HDMI ARC or the optical audio output port.

Technical Support

Contact appliance-support@retailhub.in or call 1800-102-4080 for installation assistance and service requests.

4. Microwave — RetailHub ChefWave 23L Convection Microwave

Overview

The ChefWave 23L combines microwave, grill, and convection functions in a single unit, suitable for reheating, baking, and grilling in compact kitchens.

Features

- 23-litre capacity with convection, grill, and microwave modes
- 10 auto-cook menu presets for Indian and international dishes

- Child safety lock
- Easy-clean interior coating

Specifications

Component	Specification
Capacity	23 litres
Power Output	900W (microwave), 1200W (grill)
Modes	Microwave, Grill, Convection, Combination
Control Type	Touch panel with digital display
Turntable	315mm glass turntable

Installation

1. Place the microwave on a flat, stable surface with at least 10cm clearance on all sides for ventilation.
2. Remove all packaging material from inside the cavity, including the turntable protective film.
3. Insert the glass turntable and support ring before plugging in.

First-Time Setup

1. Plug into a dedicated grounded socket; avoid using extension cords for high-wattage appliances.
2. Set the clock using the touch panel as prompted on first power-on.
3. Run an empty convection cycle at 180°C for 10 minutes to burn off manufacturing residue before first cooking use.

Operating Instructions

- Select the desired mode (Microwave/Grill/Convection/Combination) using the mode dial or touch panel.
- Use microwave-safe containers only; avoid metal or aluminum foil in microwave mode.
- For convection baking, preheat for 5–10 minutes before placing food inside.

Safety Precautions

- Never operate the microwave empty in microwave mode, as this can damage the magnetron.
- Do not use sealed containers, as pressure buildup can cause them to burst.
- Allow the unit to cool down after grill/convection use before cleaning.

Maintenance

- Wipe the interior with a damp cloth after each use to prevent food residue buildup.
- Clean the turntable and support ring weekly with mild soap and water.
- Check the door seal periodically for damage, which can affect cooking efficiency and safety.

Troubleshooting

Issue	Suggested Fix
Turntable not rotating	Check turntable is seated correctly on the support ring
Uneven heating	Ensure food is arranged in a single layer, use combination mode for dense items
Display not responding	Check power socket, reset via the power button for 10 seconds
Sparking inside cavity	Immediately stop use; check for metal objects or foil inside

Warranty Information

1-year warranty on the full unit; magnetron component covered separately for up to 3 years on select models.

FAQs

Q: Can I bake a cake in this microwave? A: Yes, using Convection or Combination mode with the appropriate auto-cook preset or manual temperature setting. **Q: Is the turntable dishwasher safe?** A: Yes, the glass turntable is dishwasher safe on a gentle cycle.

Technical Support

Contact appliance-support@retailhub.in for installation guidance, spare parts, and service center bookings.

5. Air Conditioner — RetailHub CoolBreeze 1.5 Ton Split AC

Overview

The CoolBreeze 1.5 Ton Split AC is designed for medium-sized rooms (up to 150 sq. ft.), offering energy-efficient cooling with inverter technology and multiple fan speed settings.

Features

- Inverter compressor for energy savings
- 4-in-1 convertible cooling modes
- Anti-bacterial filter with dust collection
- Remote control with sleep mode timer

Specifications

Component	Specification
Capacity	1.5 Ton
Energy Rating	5-Star (BEE certified)
Compressor	Inverter type
Cooling Coil	Copper
Noise Level	As low as 38dB in sleep mode

Installation

Note: Installation must be performed by a certified RetailHub-authorized technician. Self-installation may void the warranty.

1. Schedule installation via My Orders > Schedule Installation after delivery.
2. The technician mounts the indoor and outdoor units, completes refrigerant piping, and performs a leak test.
3. A demonstration of remote functions is provided at the end of installation.

First-Time Setup

1. Insert batteries into the remote control.
2. Power on via the main switch, then use the remote to select Cool mode and desired temperature.
3. Allow the unit to run for 10 minutes on first use to stabilize cooling performance.

Operating Instructions

- Use the 4-in-1 mode dial to switch between Cool, Dry, Fan, and Auto modes based on weather conditions.
- Set the sleep timer for energy savings during nighttime use.
- Clean the display filter indicator light signals when a filter clean is due.

Safety Precautions

- Do not block the outdoor unit's airflow with furniture or covers during operation.
- Turn off the main power switch before cleaning any part of the unit.
- Avoid operating during electrical storms; consider a stabilizer for areas with unstable voltage.

Maintenance

- Clean the air filter every 2 weeks during heavy usage months for optimal cooling efficiency.
- Schedule professional servicing every 4–6 months to check refrigerant levels and clean coils.
- Cover the outdoor unit during monsoon season if installed in an exposed area.

Troubleshooting

Issue	Suggested Fix
AC not cooling effectively	Clean filters, check if outdoor unit airflow is obstructed
Water leakage from indoor unit	Check drainage pipe for blockage, ensure correct installation slope
Unusual noise from outdoor unit	Check for loose panels or debris; contact service if noise persists
Remote not responding	Replace batteries, ensure clear line of sight to the indoor unit sensor

Warranty Information

1-year comprehensive warranty on the unit, 5-year warranty on the inverter compressor. Installation-related damage claims require proof of RetailHub-authorized installation.

FAQs

Q: How often should I service my AC? A: We recommend professional servicing every 4–6 months, and more frequently in dusty environments. **Q: What temperature range is optimal for energy savings?** A: Setting the thermostat to 24–26°C typically offers the best balance of comfort and energy efficiency.

Technical Support

Contact appliance-support@retailhub.in or call 1800-102-4080 to schedule installation, servicing, or repair visits.

6. Office Chair — RetailHub ErgoFlex Mesh Office Chair

Overview

The ErgoFlex is an ergonomic mesh-back office chair designed for extended desk work, featuring adjustable lumbar support and multi-directional armrests.

Features

- Breathable mesh backrest for airflow
- Adjustable lumbar support and seat height
- 4D adjustable armrests
- 360-degree swivel with smooth-rolling casters

Specifications

Component	Specification
Material	Mesh back, high-density foam seat
Weight Capacity	Up to 120 kg
Seat Height Range	45cm–54cm (adjustable)
Recline	Up to 135 degrees with tilt lock
Base	5-star nylon base with dual-wheel casters

Installation

1. Unpack all components and identify parts using the included assembly diagram.
2. Attach the base to the gas lift cylinder, then the seat unit, followed by the backrest and armrests using the provided Allen key.
3. Insert the assembled seat into the gas cylinder with firm downward pressure until it clicks into place.

First-Time Setup

1. Adjust seat height using the lever beneath the seat while seated, aiming for feet flat on the floor with knees at 90 degrees.
2. Adjust lumbar support height to align with your lower back curve.
3. Set armrest height so shoulders remain relaxed while typing.

Operating Instructions

- Use the tilt-lock lever to recline or lock the chair in an upright position.
- Rotate the lumbar knob clockwise to increase lower back support firmness.
- Use the seat depth slider (if equipped) to adjust for thigh length.

Safety Precautions

- Do not exceed the maximum weight capacity of 120 kg.
- Ensure all bolts are fully tightened during assembly to prevent wobbling.
- Avoid standing on the chair seat, as the gas lift is not designed to bear standing weight.

Maintenance

- Vacuum the mesh backrest periodically to remove dust.
- Check and re-tighten screws every few months, especially with daily heavy use.
- Lubricate caster wheels occasionally if rolling resistance increases.

Troubleshooting

Issue	Suggested Fix
Chair sinks slowly during use	Gas lift cylinder may need replacement; contact support for a warranty claim
Wobbling base	Check and tighten all base bolts; ensure caster wheels are fully inserted
Armrest loose or tilted	Re-tighten armrest mounting screws using the included Allen key
Recline mechanism stuck	Check tilt-lock lever position; avoid forcing recline while locked

Warranty Information

1-year structural warranty covering frame, gas lift, and mechanism defects under normal use. Fabric wear from daily use is covered for the first 6 months only.

FAQs

Q: Is assembly required, or does it arrive fully built? A: Some self-assembly is required; estimated assembly time is 20–30 minutes with the included tools. **Q: Can the armrests be removed?** A: Yes, armrests can be unscrewed and removed if a lower desk clearance is needed.

Technical Support

Contact furniture-support@retailhub.in for spare parts (casters, gas lift cylinders) and assembly assistance.

7. Gaming Mouse — RetailHub StrikeShot Pro Gaming Mouse

Overview

The StrikeShot Pro is a wired gaming mouse built for precision and responsiveness, featuring a high-DPI optical sensor and customizable RGB lighting.

Features

- Up to 16,000 DPI optical sensor with on-the-fly adjustment
- 6 programmable buttons via companion software

- RGB lighting with customizable zones
- Braided cable for durability

Specifications

Component	Specification
Sensor	Optical, up to 16,000 DPI
Buttons	6 programmable
Polling Rate	1000Hz
Connection	USB-A wired
Weight	85g

Installation

1. Connect the USB cable to an available USB-A port on your computer.
2. Download the RetailHub Gaming Hub software from retailhub.in/support/downloads for full customization features.
3. Install the software and allow it to detect the connected device automatically.

First-Time Setup

1. Open the Gaming Hub software and update the mouse firmware if prompted.
2. Customize DPI stages, button assignments, and RGB lighting profiles under Device Settings.
3. Save your profile; settings are stored on the device's onboard memory for use across computers.

Operating Instructions

- Use the DPI button beneath the scroll wheel to cycle through preset sensitivity stages during gameplay.
- Access onboard profile switching via the software or a assigned hotkey.
- RGB lighting effects can be synced with compatible keyboards from the same product line.

Safety Precautions

- Avoid exposing the mouse to liquids; spills can damage the internal sensor and switches.
- Do not forcibly bend or pull the braided cable at sharp angles, which can damage internal wiring over time.

Maintenance

- Clean the sensor lens periodically with a dry cotton swab to maintain tracking accuracy.
- Keep the mousepad surface clean and free of debris for consistent sensor performance.
- Update firmware periodically via the Gaming Hub software for performance improvements.

Troubleshooting

Issue	Suggested Fix
Mouse not detected	Try a different USB port, check cable connection, restart computer
Erratic cursor movement	Clean sensor lens, try a different mousepad surface
Buttons not responding correctly	Reset profile to default in Gaming Hub software, reprogram buttons
RGB lighting not working	Update firmware, check RGB settings are enabled in software

Warranty Information

1-year manufacturer warranty covering switch and sensor defects under normal use. Cable damage from misuse is not covered.

FAQs

Q: Does the mouse work without installing the software? A: Yes, it functions as a standard mouse out of the box; the software is only needed for customization. **Q: Is the DPI setting saved without the software running?** A: Yes, settings are stored in onboard memory and persist across different computers.

Technical Support

Contact electronics-support@retailhub.in for firmware downloads and software troubleshooting.

8. Smart Watch — RetailHub FitTrack Pulse Smartwatch

Overview

The FitTrack Pulse is a fitness-focused smartwatch offering continuous heart rate monitoring, sleep tracking, and smartphone notification support, compatible with both Android and iOS.

Features

- 24/7 heart rate and SpO2 monitoring
- Built-in GPS for outdoor activity tracking
- 7-day battery life on a single charge
- 5ATM water resistance rating

Specifications

Component	Specification
Display	1.4" AMOLED touchscreen
Battery Life	Up to 7 days (typical use)
Water Resistance	5ATM (suitable for swimming, not diving)
Sensors	Heart rate, SpO2, accelerometer, GPS
Compatibility	Android 8.0+, iOS 13+

Installation

1. Charge the watch fully using the included magnetic charging dock before first use.
2. Download the RetailHub Fit companion app from your device's app store.
3. Enable Bluetooth on your smartphone and open the app to begin pairing.

First-Time Setup

1. Create a profile in the Fit app with your height, weight, and age for accurate calorie tracking.
2. Follow in-app instructions to pair the watch via Bluetooth.
3. Customize the watch face and enable desired notification types (calls, messages, apps) under app settings.

Operating Instructions

- Swipe down on the watch face for quick settings; swipe up for notifications.
- Press and hold the side button to access the power menu.
- Start a workout by selecting the desired activity type from the Exercise app on the watch.

Safety Precautions

- Avoid wearing the watch too tightly for extended periods, which may cause skin irritation.
- While water-resistant to 5ATM, avoid pressing buttons underwater to maintain the seal's integrity.
- Consult a physician before relying on heart rate data for medical decisions; the device is not a medical-grade instrument.

Maintenance

- Clean the strap and sensor area with a damp cloth weekly, especially after workouts.
- Keep the charging contacts free of dust and moisture for reliable charging.
- Update the watch firmware regularly through the companion app for improved accuracy and new features.

Troubleshooting

Issue	Suggested Fix
Watch not pairing with phone	Ensure Bluetooth is enabled, restart both devices, forget and re-pair
Inaccurate heart rate readings	Ensure snug fit on wrist, clean sensor area, avoid wearing over tattoos
Battery draining quickly	Disable always-on display, reduce notification frequency
Screen unresponsive	Restart the watch by holding the side button for 10 seconds

Warranty Information

1-year manufacturer warranty covering internal components. Strap wear and screen scratches from daily use are not covered.

FAQs

Q: Can I make calls directly from the watch? A: Yes, if paired with a compatible smartphone, you can accept and reject calls, though dialing requires the connected phone's contact list to be synced. **Q: Is**

the GPS accurate without my phone nearby? A: Yes, the built-in GPS allows standalone location tracking during outdoor workouts without needing your phone present.

Technical Support

Contact electronics-support@retailhub.in or use the in-app Help Center within the RetailHub Fit app for pairing and sync issues.

General Technical Support

For any product not covered in this document, or for issues beyond the troubleshooting steps listed above:

- **General Technical Support:** 1800-102-4090 (9 AM – 9 PM, all days)
- **Email:** techsupport@retailhub.in
- **In-app:** My Orders > Select Product > Technical Support

Manuals for additional products are available as downloadable PDFs on individual product pages under the "Manuals & Documents" tab.