Make sure that the drive is compatible with the grounding system

You can connect all drives to a symmetrically grounded TN-S system (center-grounded wye). If you install the drive to a different system, you must disconnect the EMC screws (disconnect the EMC filter) and/or disconnect the VAR screw (disconnect the varistor circuit).

Frame size	Symmetrically grounded TN-S systems (center-grounded wye)	Corner-grounded delta and mid-point-grounded delta systems	IT systems (ungrounded or high-resistance grounded)	TT systems [1) 2)]
R1…R3 **R4 v2** **R5 v2**	Do not disconnect EMC or VAR screw.	Disconnect EMC screw. Do not disconnect VAR screw.	Disconnect EMC and VAR screws.	Disconnect EMC and VAR screws.
R4…R5	Do not disconnect EMC or VAR screw.	**Note:** The drive is not evaluated for use on these systems by IEC standards.	Disconnect EMC screws (2 pieces) and VAR screw.	Disconnect EMC screws (2 pieces) and VAR screw.
R6…R9	Do not disconnect EMC or VAR screw.	Do not disconnect EMC AC or VAR screws. Disconnect EMC DC screw.	Disconnect EMC screws (2 pieces) and VAR screw.	Disconnect EMC screws (2 pieces) and VAR screw.

EN

1) A residual current device must be installed in the supply system.

2) ABB does not guarantee the EMC category or the operation of the ground leakage detector built inside the drive.