

COT320-CFK03

32" Open-Frame Touch Monitor

Projected Capacitive Touch screens



DongGuan CJTOUCH Electronic Co., Ltd.
PUBLISHED DATE:2016-05-28

Safety Instructions

- 1. Read these safety instructions carefully.
- 2. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 3. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 4. Keep this equipment away from humidity.
- 5. Put this equipment on a reliable surface during installation. Dropping it or letting if fall may cause damage.
- 6. The openings on the enclosure are for air convection. Protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 8. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 9. All cautions and warnings on the equipment should be noted.
- 10. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient over voltage.
- 11. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 12. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
- 13. If one of the following situations arises, get the equipment checked by service personnel:
 - A) The power cord or plug is damaged.
 - B) Liquid has penetrated into the equipment.
 - C) The equipment has been exposed to moisture.
 - D) The equipment does not work well, or you cannot get it to work according to the user's Manuel.
 - E) The equipment has been dropped and damaged.
 - F) The equipment has obvious signs of breakage.
- 14. DO NOT LEAVE THIS EQUIPMENT IN AN UNCONTROLLED ENVIRONMENT WHERE THE STORAGE TEMPERATURE IS BELOW -10 $^{\circ}$ C OR ABOVE 50 $^{\circ}$ C. THIS MAY DAMAGE THE EQUIPMENT.

Display Specific	ations			
Characteristic		Value		Comment
LCD Size/Type		32" a-Si TFT-LCD		
Aspect Ratio		16:9		
Active Area		Horizontal	700.4mm	
		Vertical	394.9mm	
Pixel		Horizontal	0.36375	
		Vertical	0.36375	
Panel Resolution		1920(RGB)×1080 (FHD)(60Hz)		Native
Display Color		16.7 Million		6-bits + Hi-FRC
Contrast Ratio		1100:1		Typical
Brightness		400 nits		Typical
Response Time		9 1	9 ms Typical	
YY:		Horizontal	178	Typical
Viewing Angle		Vertical	178	
Video Signal Input		VGA and DV	/I and HDMI	
Physical Specific	cations			
Dimensions		Width	757.8 mm	
		Height	452.3 mm	
		Depth	76mm	
Weight		Net Weight 15 kgs	Shipping Weight 21 kgs	
Box Dimensions		Length	890 mm	
		Width	590 mm	
		Height	140 mm	
Electrical Specif	fications			
Power Supply		DC 12V 4A		Power Adapter Included
		100-240 VAC, 50-60 Hz		Plug Input
Power Consumption		Operating	38 W	Typical
		Sleep	3 W	
		Off	1 W	
Touch Screen Sp	pecification	1S		
Touch Technolo	gy		Project Capacitive Touch Screen 10 Touch Point	
Touch Interface			USB (Type B)	
OS Supported Plug and		Play	Windows All (HID) ,Linux (H	HID) (Android Option)
Driver			Driver Offered	
Environmental	Specificati	ons		
Con		dition	Specification	
Temperature Humidity		Operating	-10°C ~+ 50°C	
		Storage	-20°C ∼ +70°C	
		Operating	20% ~ 80%	
		Storage	10% ~ 90%	
MTBF			30000 Hrs at 25°C	

1.2 Warranty and Components

1 Year Free Warranty for Monitor and all components.

USB Cable *1 Pcs,

VGA Cable *1 Pcs,

Power Cord with Switching Adapter *1 Pcs,


Bracket*2 Pcs

RS232 Cable & DVI Cable Sold Separately



1.3 OSD Control

1.3.10SD buttons



1.3.2 Adjusting with OSD control

Five different keys are well-defined for operation. They are labeled on the keypad.


- A) [Power] Key is designated for Power On/Off
- B) [Menu] Key is designated for Menu/Enter function depending on the selected item. Pressing [Menu] can invoke OSD menu. After that, [Menu] is also an entry key.
- C) [+] key is designated for selection function in up direction in OSD menu and also to increase the value on selected function, Directly use + Key is to increase brightness.
- D) [-] key is designated for selection function in down direction in OSD menu and also to decrease the value on selected function, Directly use Key is to decrease brightness.
- E) **[AUTO]** key is designated for invoking AUTO ADJUST function at any time once is pressed for H-position, V-position, Pixel Clock and Phase for an optimal image.


<u>www.cjtouch.com</u> Sales & Technical Support:<u>pearl@cjtouch.cn</u> Skype: pearlhuangpei Tel: +86-13412829349 **4 -**Block B, 3rd/5th floor,Building 6,Anjia industrial park, WuLian,FengGang, DongGuan,P.R.China 523000

1.4 Setup the driver

1. Plug and play USB port under win 7 win 8 win 10.For Andriod and Linux need using driver pls contact the sales for support.

1.5 Mechanical Drawing






1.6 Mounting guide

- 1. Build 16 screw studs along the four sides of the cut out opening based on the dimension given on the drawing above.
- 2. Tighten the screw stud with hex nut and make sure it is stable.

1.7 Electrical Block Diagram

The LCD touch monitor is constructed based on steel open frame architecture. It consists of a 15.6" LED panel, an DC to AC inverter board to support a set of cold cathode fluorescent light, an analog to digital converter board (AD Board) to convert analog RGB signals to digital ones, and a touchscreen used as a pointing device. A metal chassis supports the whole module.

1.7.1 Block Diagram



2 Solutions to Common Problems

Problem	Suggestion(s)	
The monitor does not respond	1)Check that the monitor's Power Switch is on.	
after you turn on the system	2)Turn off the power and check the monitor's power cord	
	and signal cable for proper connection.	
Characters on the screen are dim	Refer to the About Touch monitor Adjustments section to	
	adjust the brightness.	
The screen is blank	1)During operation, the monitor screen may automatically	
	turn off as a result of the Power Saving feature. Press any	
	key to see if the screen reappears.	
	2) Refer to the About Touch monitor Adjustments section	
	to adjust the brightness.	
Screen flashes when initialized	Turn the monitor off then turn it on again.	
"Out of Range" display	Check to see if the resolution of your computer is higher	
	than that of the LCD display. Reconfigure the resolution of	
	your computer to make it less than or equal to 1920×1080.	
	See Appendix A for more information on resolution.	
Touch doesn't work	Make sure the touch cable is securely attached at both	
	ends.	

3 Typical Application

Gaming/Casino Systems
Outdoor and indoor Kiosks
Entertainment
Transport and Ticketing
Hospitality
Banking
Customizsed Solutions

4 How to contact us

www.cjtouch.com

Add: Block B, 5th floor, Building 6, Anjia industrial park, WuLian, FengGang, DongGuan, P.R. China

Tel: +86-13412829349 Fax: +86-769-82522517

Sales & Marketing: pearl@cjtouch.cn