





Pickup is active


If humbucker: internally wired in series



Humbucker wired in parallel



Pickup is out-of-phase



Single Coil Simulation engaged

//: connected in parallel between each other

(*): with Single Coil Simulation if Tone Push Pull knob is UP

Rotary-switch

Position -2: Bridge pickup is wired in parallel.
 Position 1: Middle pickup only - superswitch is off.
 Position 0: Bridge pickup is wired in series - default operation.
 Position 1: Middle pickup is parallel to superswitch's output.
 Position 2: Middle pickup is out-of-phase.

Single Coil Simulation circuit
RC filter for bridge pickup and single capacitor for neck pickup.
Bridge pickup requires the resistor for its volume drop compensation since its impedance is higher in this guitar's setup (Dimarzio Tone Zone in bridge position and Dimarzio PAF Pro in neck position).

Treble bleed circuit: RC filter in series.

Blower

Tone

Killswitch

Output

Schematic	JDR94 Custom Remake		Create at	2026-03-17
Board			Update at	2026-03-17
Drawn	Marco Ramírez	Page		P1
Reviewed	Marco Ramírez			
		Version	Size	Page 1 Total 1
		V3.3	A3	EasyEDA.com

EasyEDA

Schematic	JDR94 Custom Remake				Create at	2026-03-17
					Update at	2026-03-17
Board					Page	P1
Drawn	Marco Ramirez	Guitars				
Reviewed	Marco Ramirez					
		Version	Size	Page 1 Total 1		
		V3.3	A3	EasyEDA.com		