



- 1. ENABLE CHARGING: EN "1"
- 2. CHECK FB VOLTAGE
- 3. IF CHARGING COMPLETE FB = 2.5V; VF = 11V
- 4. DISABLE CHARGING: EN "0"
- 5. READY TO POWER THE FLIP-DISC

PULSE CURRENT POWER SUPPLY	WWW.FLIPO.IO	
VIN: 5V	F-PCPS	V1
DEFAULT VF = 11V; FB = 2.5V	DATE: 15.03	DATE: 15.03.2022