DATA COLLECTION/CALCULATION

. Maximum Occupant Capacity: These lines are measured in 90 NSF increments within the inventory. This will ONLY change when buildings come on-line from new construction, demolition of existing facility, or spaces/rooms have been redesignated or diverted from billeting to other uses. **This is a "space" count.**

. To determine the maximum occupant capacity per person room use the following chart:

ROOM SIZE (NSF)	E1-E3	Officers/ Civilians
ROOMS 180 nsf & below	2 @ 90 nsf per person	0
ROOMS 180-269 nsf	Up TO 3 @ 90 nsf per person	0
ROOMS 270-359 nsf	Up to 3 @ 90 nsf per person	0
ROOMS 360 nsf or greater	Up to 4 @ 90 nsf per person	1 @ 360 nsf per person

NOTE: Net living area (NSF) is measured from inside face of wall in living and sleeping area. Do not include bathrooms, closets, service areas, and/or corridors.

. Personnel Actually Housed: Personnel housed shall include the actual number of personnel residing in or assigned to the billeting spaces on the last day of the reporting period. Report these numbers under the appropriate section heading that matches both the occupant's permanent party or transient status, and under the column heading that matches the occupant's rank (i.e.), permanent party, E4).

. Utilization: This is Personnel Actually Housed divided by Maximum Occupant Capacity. The electronic version has formulas to complete this calculation.

. Open Squad Bay Inventory: Open bay assets and occupants shall be reported only in the open bay section of the form. Spaces are measured in 72 NSF increments, and student/trainee barracks are measured in 90 NSF increments.