## AT Keyboard Scan Codes (Set 3)

KEY	MAKE	BREAK	 KEY	MAKE	BREAK	 KEY	MAKE	BREAK
А	1C	F0,1C	9	46	F0,46	[	54	F0,54
В	32	F0,32	`	0E	F0,0E	INSERT	67	F0,67
С	21	F0,21	-	4E	F0,4E	HOME	6E	F0,6E
D	23	F0,23	=	55	F0,55	PG UP	6F	F0,6F
Е	24	F0,24	\	5C	F0,5C	DELETE	64	F0,64
F	2В	F0,2B	BKSP	66	F0,66	END	65	F0,65
G	34	F0,34	SPACE	29	F0,29	PG DN	6D	F0,6D
Н	33	F0,33	TAB	0D	F0,0D	U ARROW	63	F0,63
I	43	F0,48	CAPS	14	F0,14	L ARROW	61	F0,61
J	3B	F0,3B	L SHFT	12	F0,12	D ARROW	60	F0,60
K	42	F0,42	L CTRL	11	F0,11	R ARROW	6A	F0,6A
L	4B	F0,4B	L WIN	8B	F0,8B	NUM	76	F0,76
М	3A	F0,3A	L ALT	19	F0,19	KP /	4A	F0,4A
N	31	F0,31	R SHFT	59	F0,59	KP *	7E	F0,7E
0	44	F0,44	R CTRL	58	F0,58	KP -	4E	F0,4E
P	4 D	F0,4D	R WIN	8C	F0,8C	KP +	7C	F0,7C
Q	15	F0,15	R ALT	39	F0,39	KP EN	79	F0,79
R	2D	F0,2D	APPS	8D	F0,8D	KP.	71	F0,71
S	1B	F0,1B	ENTER	5A	F0,5A	KP 0	70	F0,70
Т	2C	F0,2C	ESC	08	F0,08	KP 1	69	F0,69
U	3C	F0,3C	F1	07	F0,07	KP 2	72	F0,72
V	2A	F0,2A	F2	0F	F0,0F	KP 3	7A	F0,7A
W	1D	F0,1D	F3	17	F0,17	KP 4	6B	F0,6B
Х	22	F0,22	F4	1F	F0,1F	KP 5	73	F0,73
Y	35	F0,35	F5	27	F0,27	KP 6	74	F0,74
Z	1A	F0,1A	F6	2F	F0,2F	KP 7	6C	F0,6C
0	45	F0,45	F7	37	F0,37	KP 8	75	F0,75
1	16	F0,16	F8	3F	F0,3F	KP 9	7 D	F0,7D
2	1E	F0,1E	F9	47	F0,47	]	5B	F0,5B
3	26	F0,26	F10	4F	F0,4F	;	4C	F0,4C
4	25	F0,25	F11	56	F0,56	'	52	F0,52
5	2E	F0,2E	F12	5E	F0,5E	,	41	F0,41
6	36	F0,36	PRNT SCRN	57	F0,57		49	F0,49
	3D	F0,3D	SCROLL	5F	F0,5F	/	4A	F0,4A
8	3E	F0,3E	PAUSE	62	F0,62			