

JIDAI Patch Cookbook

Step-by-step patches for JIDAI RACK · Martial Systems

Contents

1. About this cookbook
 2. How to read a recipe
 3. Recipe: EDM Starter
-

1. About this cookbook

Each recipe in this cookbook builds one complete patch in JIDAI RACK, starting from an empty rack. You add the devices, make the cables one at a time and set a few knobs. Every cable comes with a line on what it does, so you learn the patch as you build it.

Every recipe is also a starter rack. Load it from **RACKS ▼** to hear the finished patch first, or to check your own cables against it.

You need JIDAI RACK in your DAW (see section 7 of the JIDAI RACK User Manual). The recipes use the device names and jack names printed on the rack, and the patching moves from section 4 of the manual.

2. How to read a recipe

Every recipe has the same parts, in the same order.

What you'll build. What the patch does and what you'll hear.

What you need. The DAW setup: for example, a track with JIDAI RACK, the project tempo and the transport running.

Devices. The devices to add, in order. Start from **RACKS ▼ > INIT**, then click each device in the device browser. Hold **Shift** while you click, so the rack adds the device without its automatic cables. The recipe tells you to make every cable yourself, so none are missing and none are extra. Devices land at the bottom of the rack, in the order you add them.

Cables. Numbered steps, each written as:

From DEVICE: JACK to DEVICE: JACK. Why this cable is there.

- Patch on the back: press **Tab** to flip the rack. Every jack of every device is there.
- A jack is named by its section and its label, as printed on the back. *RONIN: VCA 1 ENV* is the ENV jack in RONIN's VCA 1 box.
- Drag from the first jack to the second. If the second jack already has a cable, the new cable is added to it: two cables into one input are summed.
- To start a second cable from a jack that's already patched, **Option-drag** it (Mac) or **Alt-drag** it (Windows). A plain drag from a patched jack picks up its top cable and reroutes it instead.
- Got one wrong? Drag its end to the right jack (it stays the same cable), or drag the end into empty space to remove it, or press **Cmd+Z** (Mac) or **Ctrl+Z** (Windows) to undo.

- The colour of each cable comes from its output jack: red for audio, blue for pitch, green for gates and clocks, yellow for CV. To find the jacks for a step quickly, click that colour on the cable bar under the header: the jacks that can't take it are dimmed. Click **ANY** to clear it.

Knob settings. Only the settings that matter for the patch. Leave everything else where it is. Knob positions are given as a percentage of the knob's travel, with the value it shows where that helps.

Try this. A few changes to make once the patch is playing.

Diagram. The back of the finished rack, rendered by JIDAI RACK. A numbered badge sits next to the jack each step plugs into, so you can find step 7 at a glance.

Load it. The starter rack with the same patch, so you can compare.

3. Recipe: EDM Starter



The finished EDM Starter from the back. Each number sits next to the jack that cable step plugs into.

What you'll build

A four-on-the-floor groove at 125 BPM that plays with your DAW. Every device in the rack works together:

- **SHOGUN** plays the drums: a kick on every beat, a clap on 2 and 4, closed hats on the eighth notes and open hats on the offbeats.
- **BUSHIDO** plays a 12-step acid bass line on **RONIN**, with slides, a snappy filter and accents.
- **ORIGAMI** folds the bass for grit.
- Every kick ducks the bass, so the low end pumps with the beat.
- SHOGUN restarts BUSHIDO on every downbeat, so the two stay locked even when you jump around in your song.

What you need

- JIDAI RACK on an audio track in your DAW (in FL Studio: an insert track in the Mixer).
- The project tempo at **125 BPM**.
- Press play in your DAW once the cables are done. SHOGUN and BUSHIDO follow your DAW's transport.

Devices

From **RACKS ▾ > INIT**, Shift-click these in the device browser, in this order:

1. **SHOGUN** (DRUMS)
2. **BUSHIDO** (SEQUENCER)
3. **RONIN** (VOICE)
4. **ORIGAMI** (EFFECT)

You can double-click each name to rename it. The starter rack calls them DRUMS, ACID SEQ, ACID BASS and BASS FOLD.

Before you patch: RONIN's own cables

A new RONIN comes with eight cables of its own, its INIT voice. Keep these two:

- **RONIN: EG 1 OUT A to RONIN: VCA 1 ENV**. The note envelope opens the VCA.
- **RONIN: VCA 1 OUT to RONIN: OUTPUT WET**. The voice to RONIN's output.

Remove each of the other six: click it and press **Delete**, or drag one of its ends into empty space:

- RONIN: EXT IN MONO to RONIN: VCF IN
- RONIN: VCF OUT to RONIN: VCA 1 IN
- RONIN: EXT IN L to RONIN: OUTPUT L
- RONIN: EXT IN R to RONIN: OUTPUT R
- RONIN: EXT IN GATE to RONIN: EG 1 TRIG
- RONIN: EG 1 OUT A to RONIN: VCF CUTOFF

Cables

Lock the sequencers

1. From **SHOGUN: CLOCK RST OUT to BUSHIDO: INPUTS RESET**. SHOGUN pulses RST OUT on every downbeat, which restarts BUSHIDO at step 1, so the bass line starts with the bar.

Notes and slide

2. From **BUSHIDO: OUTPUTS CV A to RONIN: INT IN**. Row A plays the notes. INT smooths each step into the next: that's the slide.
3. From **RONIN: INT OUT to RONIN: VCO V/OCT**. The slid pitch plays the oscillator.
4. From **RONIN: VCO SAW to RONIN: VCF IN**. The saw wave is the raw sound of the bass.

Gates and filter

5. **From BUSHIDO: OUTPUTS GATE A to RONIN: EG 1 TRIG.** Each step starts the note envelope, which opens VCA 1.
6. **From BUSHIDO: OUTPUTS GATE A to RONIN: EG 2 TRIG.** Each step also starts EG 2, the filter snap. Option-drag (Mac) or Alt-drag (Windows) from GATE A for this second cable.
7. **From RONIN: EG 2 OUT + to RONIN: VCF CUTOFF.** EG 2 sweeps the filter on every note.
8. **From BUSHIDO: OUTPUTS CV C to RONIN: VCF CUTOFF.** Row C is the accent: it adds to EG 2 on the same jack, so accented steps open the filter further.

Fold, then duck

9. **From RONIN: VCF OUT to ORIGAMI: INPUT IN L.** The filtered bass goes out to the folder.
10. **From ORIGAMI: OUTPUT OUT L to RONIN: VCA 1 IN.** The folded bass comes back into RONIN's VCA, so the envelopes and the duck shape it after the fold.
11. **From SHOGUN: BD1 ENV to RONIN: MIX IN 1.** The kick's envelope, which jumps up on every kick and dies away with it.
12. **From RONIN: MIX OUT to RONIN: VCA 1 ENV.** RONIN's MIX turns the kick's envelope upside down. Added to EG 1 on VCA 1's ENV jack, it pulls the bass down on every kick: that's the duck.

To your DAW

13. **From RONIN: HOST OUT L to RACK I/O: MAIN OUT L.** The bass to the left output.
14. **From RONIN: HOST OUT R to RACK I/O: MAIN OUT R.** The bass to the right output.
15. **From SHOGUN: MIX L to RACK I/O: MAIN OUT L.** The drums join the bass on the left.
16. **From SHOGUN: MIX R to RACK I/O: MAIN OUT R.** The drums join the bass on the right.

That's 18 cables in all: your 16 and RONIN's two.

Knob settings

SHOGUN

Setting	Value	Why
KIT	INIT	Click the KIT display and choose INIT for an empty pattern. SRC stays on HOST.
SYNC SRC	HOST	SHOGUN follows your DAW's tempo and song position. A new SHOGUN starts here.
CLOCK BAR	16	RST OUT pulses every 16 steps: once a bar.
BD1 steps	1, 5, 9, 13 (Shift-click step 1 for an accent)	Four on the floor.
CP steps	5, 13	The clap on 2 and 4.
CH steps	1, 3, 5, 7, 9, 11, 13, 15, and 16 accented	Eighth-note hats, with a lift into the next bar.
OH steps	3, 7, 11, 15	Open hats on the offbeats.
BD1 LEVEL	80 %	A strong kick.
CP LEVEL · CH LEVEL · OH LEVEL	48 % · 40 % · 34 %	Clap and hats sit under the kick and the bass.
MASTER VOLUME · GLUE	86 % · 30 %	Drum level, and a little bus glue.

To set a voice's steps, click its name key (for example BD1) and click the step keys.

BUSHIDO

Setting	Value	Why
SOURCE (MAIN)	EXT	Clocked from outside.
EXT SOURCE (CLOCK page)	HOST, HOST DIV 1/16	One step per sixteenth note from your DAW. A BUSHIDO added while the DAW plays starts here.
MODE	A	Row A loops its 12 steps.
RANGE A · QUANT A	1V · SEMI	One octave of notes, snapped to semitones.
C MODE	CV	Row C is a CV, for the accents.
Row A, steps 1-12	C3 C3 C4 C3 D#3 C3 G3 A#3 C3 C4 F3 D#3	The bass line. RONIN plays it an octave lower.
Row C, steps 1-12	2.5 V on steps 1 and 7, 2.0 V on 4, 1.5 V on 10, 2.25 V on 12, 0 on the rest	The accents.

RONIN

Setting	Value	Why
VCO RANGE	16'	One octave down, into bass range.
VCF CUTOFF · PEAK · MOD	40 % (about 300 Hz) · 92 % (Q 7.4) · 75 % (3 octaves per 5 V)	A dark, ringing filter that EG 2 and the accents open wide.
VCA 1 MOD · INITIAL	85 % · 0 %	The bass level, and silence between notes.
EG 1 ATTACK · DECAY · SUSTAIN · RELEASE	2 ms · 300 ms · 80 % (4.0 V) · 20 ms	A punchy note that holds while the gate is open.
EG 2 HOLD · ATTACK · RELEASE	1 ms (fully left) · 2 ms · 120 ms	A short filter snap.
INT TIME	30 % (about 10 ms)	A quick slide between notes.
MIX LEVEL 1	100 %	How deep the kick ducks the bass.
OUTPUT LEVEL	68 %	Just under unity, to leave room for the drums.

ORIGAMI

Setting	Value	Why
Preset	RONIN · Acid Grit	A medium fold with emphasis, at 2× quality. Pick it from the preset box in ORIGAMI's jack row.

What you should hear

Press play. The kick and the bass line start together on the downbeat. Every kick pushes the bass down by about 8 dB, and the bass comes back up before the next beat. The mix peaks at about −4 dBFS, so you can add more on top.

Jump to any bar in your song: the bass line starts again at step 1 on the next downbeat and stays locked to the drums.

Good to know

- **The +23 comp tags.** RACK I/O shows the rack's latency as LAT 46. ORIGAMI at 2× quality takes 46 samples, SHOGUN at 2× takes 23, and the rack delays the drums by another 23 samples so the kick and the bass reach your DAW together. Your DAW's delay compensation takes care of

the rest.

- **The Δ46 tag on RONIN's VCA 1 ENV.** The kick's envelope reaches VCA 1 about 1 ms before the folded bass gets back from ORIGAMI, so the duck starts a hair before the kick. You won't hear the difference.
- **Why fold first, then duck.** A folder evens out level changes, so a duck in front of ORIGAMI would only change its tone. Ducking in VCA 1, after the fold, keeps the dip.

Try this

- **A lighter pump.** Turn RONIN's MIX LEVEL 1 down to about 50 %. Turn it to 0 and the kick no longer ducks the bass.
- **Duck on the clap too.** Patch **SHOGUN: CP ENV to RONIN: MIX IN 2** and turn MIX LEVEL 2 up. Now the bass dips on 2 and 4 as well.
- **Slide.** Turn RONIN's INT TIME up for a slower, rubbery slide, or fully left for none.
- **More or less grit.** Turn ORIGAMI's WAVE up for a harder fold, or step its preset box through the other RONIN presets. Set ORIGAMI's QUALITY to 1× and the rack's latency drops to 23 samples.

Load it

The finished patch is the starter rack **RACKS ▾ > EDM > EDM Starter**. Load it, press **Tab** and compare it with your rack: it has the same 18 cables.