

FasterCap Output

Output header

The header provides basic informations about the simulation that is going to be run.

```
Running FasterCap version 5.0.2
Copyright 2013 FastFieldSolvers S.r.l. http://www.fastfieldsolvers.com, All Rights reserved
Starting capacitance extraction with the following parameters:
Input file: C:\Documents and Settings\All Users\Documents\FastFieldSolvers\FasterCap
\cubes.lst
Auto calculation with max error: 0.01
Remark: Auto option overrides all other Manual settings

Solution scheme (-g): Collocation, GMRES tolerance (-t): 0.005
Out-of-core free memory to link memory condition (-f): 5
Potential interaction coefficient to mesh refinement ratio (-d): 1
Mesh curvature (-mc): 3
Number of input panels to solver engine: 24
```

In particular, besides the version and copyright information, you have:

- The input file name (root file), including the full path
- The dump of the run options, as shown in [Run Menu dialog box](#) section
- The total number of input panels, as found in the input files structure