

Yarbo Control Panel — Raspberry Pi Quick Reference

Pi: `admin@192.168.9.253` | Panel URL: `http://192.168.9.253:8080`

SSH into the Pi

```
ssh admin@192.168.9.253
```

Edit configuration

```
nano ~/yarbo/config.php
```

Common settings: `broker_host`, `serial`, `cameras_enabled`

- **Save:** Ctrl+O, then Enter
- **Exit:** Ctrl+X

Restart the service (after saving config)

```
sudo systemctl restart yarbo-panel
```

Check the service is running

```
sudo systemctl status yarbo-panel
```

Press **q** to exit.

View recent logs

```
sudo journalctl -u yarbo-panel -n 30
```

Follow logs live

```
sudo journalctl -u yarbo-panel -f
```

Press **Ctrl+C** to stop.

Test API from the Pi

```
curl -s http://127.0.0.1:8080/api/status.php
```

Test connection to Yarbo MQTT

```
nc -zv 192.168.1.223 1883
```

Replace 192.168.1.223 with your Yarbo IP if it has changed.

Edit the systemd service (rare)

```
sudo nano /etc/systemd/system/yarbo-panel.service
```

After changing the service file:

```
sudo systemctl daemon-reload  
sudo systemctl restart yarbo-panel
```

Handy commands

Task	Command
Stop service	<code>sudo systemctl stop yarbo-panel</code>
Start service	<code>sudo systemctl start yarbo-panel</code>
Disable auto-start on boot	<code>sudo systemctl disable yarbo-panel</code>
Enable auto-start on boot	<code>sudo systemctl enable yarbo-panel</code>
Reboot Pi	<code>sudo reboot</code>