



Wi-Fi Setup Start Guide

Step1 Turn on the Wi-Fi Router

Press and hold the power button for about 10 seconds.



Aterm WM3600R

If LCD is shown, turning on the power is completed.

Power Button



Aterm WM3800R

Power Button

※NOTE !

To prevent heating of the adapter,
There is the case that can not be
charged more than 90%.
There is not a malfunction.



It takes about 30 seconds
to boot completely.

Step2 Connect the Wi-Fi Router to your device such as a PC or a smartphone.

※The **PASSWORD** is an 13 digits (numbers and alphabetical characters) of **AES key**.

A Sticker with the password is attached to the back of the rental router.

The connection to an iPhone / iPad

1. Click the "Settings" icon.
2. Select "Wi-Fi".
3. turn on "Wi-Fi".
4. Select the network of 『aterm-...』.
5. Input password.

"The password is an 13 digit **AES key** on the seal located at the back of the rental router."

6. The connection is complete.

The connection to Andorid smartphone

1. Click the "Settings" icon.
2. Turn on "Wi-Fi".
3. Select the network of 『aterm-...』.
4. Input password.

"The password is an 13 digit **AES key** on the back of the rental router."

5. The connection is complete.

The connection to Windows8 PC

1. Move the mouse cursor to the upper-right or the lower-right corner of the screen, and display charm, then click [SET-UP]
2. Click the network icon.
3. Select 『aterm-...』 from the list of [Wi-Fi]
4. Check "Connect automatically" and then, click "Connect".
5. The input screen of the network security key is displayed. Input password(13 digit **AES Key**) and click "NEXT".
6. The confirmation screen of sharing setup is displayed. Click "Yes, turn on sharing and connect to devices".
7. If "Already connected" is displayed, the connection is completed.

The connection to Windows7 PC

1. Click the "Wireless Network" icon on the task bar on the lower right of the screen. Select 『aterm-...』 from the list of the displayed wireless network.
2. Check "Connect automatically" and click "Connect".
3. The input screen of the network security key is displayed. Input the password, "13 digit **AES key**". Then, click "OK".
4. The screen of "Setup of network places" is displayed.
5. "Network name" and "place types" which are already set up shall be displayed. Check that the router 『aterm-...』 is contented and click on "CLOSE".
6. The connection is completed.

•A software driver is required to use the router as an external USB modem.

•To install driver, turn on the router and plug it in to your computer's USB port. The driver will install automatically.

•After installation, internet access is available whenever the router is plugged in to your computer.

Step3 The connection is completed. The internet is available.

※NOTE There is 2 types of SSID

ex 『aterm-...g』 and 『aterm-...gw』

Each SSID has different password.

Please choose a SSID of 『aterm-...g』.