



USER GUIDE

PowerGlove Vision Camera Guide

Choose, tune, and troubleshoot a camera without changing gesture recognition.

2026 EDITION / IAIN BENNETT / MIT LICENSE

Your camera is how PowerGlove Vision sees your hand. This guide helps you choose a camera, get a clear and responsive picture, and recover quickly when the camera is disconnected or unavailable.

Begin with the automatic settings. They work with ordinary USB cameras and are the best starting point for most families. The advanced frame-rate, reader, exposure, and gain controls are available when you need to improve a particular camera or investigate performance; they do not change how gestures are learned or mapped to games.

Start here

Use these settings first:

- **Camera:** Automatic
- **Camera frame rate:** Automatic
- **Camera reader:** Compatible - OpenCV
- **Exposure behavior:** Automatic

Connect one ordinary UVC camera, place the whole hand in view, and check the Dashboard. Change advanced settings only to solve a visible problem or compare latency.

Camera selection

Automatic discovers a usable camera when tracking starts. The camera does not need to be attached during installation; it may be connected later. Setup refreshes its camera list while the page is open.

Choose a named camera when more than one camera is connected or Automatic picks the wrong one. A saved camera that is temporarily disconnected stays listed as unavailable so the Controller does not silently switch devices.

Frame rate

- **Automatic** prefers 30 fps and accepts the camera driver's usable rate.
- **30 fps** requests the tested gameplay rate.
- **60 fps** is a comparison option for cameras that support it.

An unsupported rate falls back safely. While tracking is active, Setup reports the actual delivered rate below the camera controls.

Camera reader

- **Compatible - OpenCV** is the portable default.
- **Low latency - Direct V4L2** is an optional Linux path for supported 64-bit, 640x480 MJPEG cameras. It consumes the newest camera buffer and falls back to OpenCV when its requirements are unavailable.

Direct V4L2 does not change MediaPipe recognition, gestures, calibration, or controller mappings.

Exposure and gain

Start with **Automatic**. Brighter images are not always faster: a camera may use a long exposure in dim light and silently reduce its effective frame rate.

- **Automatic - fixed frame rate** asks a camera that advertises the control to preserve frame cadence.
- **Automatic - Razer Kiyo Pro tested** also requests the tested temporary HDR-off setting.
- **Manual exposure and gain** is available only with Direct V4L2 and only when the camera reports safe limits.

Manual values are camera-specific. Unsupported settings fall back to automatic exposure and are reported in Setup. Camera automation is restored when tracking closes. The Razer-specific hardware choice is temporary; repowering the camera restores its own defaults.

Lighting and placement

- Light the hand from the front or side, not from a bright window behind it.
- Keep the entire hand, wrist, and intended movement area inside the frame.
- Avoid motion blur by adding room light before increasing gain.
- Keep the camera and playing position consistent with the saved center and movement reach.

Glove Academy may warn about a dark hand or a much brighter background. These warnings are advisory and do not change camera exposure automatically.

In one matched Kiyo Pro test at manual exposure [78](#) and gain [96](#), reducing a bright window behind the player improved overall hand detection from 98.73% to 99.57% and cut reacquisitions from two to one. Fast-sweep detection was already about 98.8% in both clips, and inference time did not change. Treat this as practical placement guidance rather than a universal camera setting.

The shipped MediaPipe Hands 0.10.35 CPU runtime improves inference and reacquisition timing independently of camera exposure. Better front lighting still gives it clearer evidence and more recovery margin; it does not make the model calculation itself run faster.

Reconnection and recovery

The Controller looks for the saved camera whenever tracking starts. Supported camera settings are reapplied after a reconnect. The optional UNO Q recovery helper can recover a stream that remains wedged even though the camera is still visible to USB. It uses [uhubctl](#) only when that tool lists the exact enrolled hub as supporting per-port power control. In that case, it cycles only the camera's saved port. It never forces an unsupported hub. When port switching is unavailable, the existing identity-checked whole-hub rebind remains the fallback.

Seeing the camera return in USB is not considered successful recovery. The helper reports that the USB action has finished, the Controller restarts vision, and recovery is confirmed only after the worker receives a real video frame. The camera does not need to be attached during installation; its hub and direct port are learned on the first healthy use and updated after a move.

Automatic camera selection is the portable behavior. Per-port cycling depends on the hub hardware; unsupported hubs continue to use the guarded fallback.

Quick troubleshooting

- **Camera not listed:** reconnect it, wait a few seconds, and reload Setup.
- **Camera listed but no picture:** stop and restart controller output; if the hourglass remains, reconnect the camera or its powered hub.
- **Dark or blurry picture:** improve room lighting, then compare fixed-rate automatic exposure.
- **Manual controls unavailable:** return to Automatic or use a camera that exposes the required UVC controls.
- **Tracking jumps at an edge:** check framing, center, and Movement reach before changing exposure.

For symptom-by-symptom recovery, see the [Troubleshooting guide](#). For every stored field and installed path, see the [Configuration reference](#).