

QuarkWave MIDI quick start

For: development testers with an assembled instrument. **Status:** source-reviewed, hardware untested (firmware snapshot: 2026-09-22). Use the connection and listening setup supplied with your build; the physical audio circuit and power arrangement are still being documented.

1. Begin with the listening level low. Power the assembled Pico W controller and Uno R4 synth, and connect the build's audio output to your listening setup. **Expected from source:** the Pico starts on **Warm Pad** on a new unit and can sync its selected patch when the Uno responds. The status does not prove that audio is wired correctly. [Startup behavior](#).
2. Put your computer or phone on the Pico's configured Wi-Fi network. Open `http://quarkwave.local/`; if that name is unavailable, use the Pico IP address supplied by the builder. **Expected:** the panel appears. [Pico HTTP server](#).
3. Wait for **Pico: Connected** and **Uno: Connected · Pico patch**. If you see **Uno: Connected · standalone sound**, an external MIDI input has already been used; its sound is being preserved. [Connection meanings](#).
4. In **Perform**, set **Master volume** low, play a browser key, then raise the listening level carefully. The keyboard **Velocity** starts at 100 and affects new notes. **Expected:** a note begins when pressed and releases when you let go. Audible behavior still needs a hardware check. [Keyboard procedure](#).
5. Choose **Pluck**, **Solid Bass**, or another sound from the [factory patch list](#), then select **Load patch**. Change **Cutoff** or **Morph** in Perform. **Expected:** the controls update and the Uno receives the loaded patch. [Patch behavior](#).
6. To keep your change, enter a name, select **Save As**, choose an empty user slot `0–7`, then select **Save to slot**. Confirm before replacing an occupied slot. Factory sounds remain read-only. [Save procedure](#).

If a note hangs, use **Panic** in the top strip. If the two connection labels differ, use [troubleshooting](#). To play the Uno without the Pico, see [External MIDI controllers](#). Record any result in the [hardware test log](#).