



CABINET CHEAT SHEET

VirtualGlove Quick Reference

Current cabinet addresses, services, controls, and maintenance commands.

2026 EDITION / IAIN BENNETT / MIT LICENSE

Your hand is the controller. Use this page to get ready, play, and get back into a game when something goes wrong.

Open VirtualGlove

Open <http://YOUR-UNO-Q.local/> on your phone or computer and choose **VirtualGlove**. If it is the only installed app, it opens automatically. You can also bookmark <http://YOUR-UNO-Q.local:8100/dashboard>.

Use your UNO Q's name in place of **YOUR-UNO-Q**. If its name does not open, use the IP address printed by the installer or shown by your network router.

Page	Use it for
Dashboard	See your hand, centre it, and start controller output.
Play	Play Rock Paper Scissors in your browser.
Learn	Practise gestures in Glove Academy.
Setup	Pair your console, choose a camera, and edit game filenames.
Apps	Open the app chooser or Controller Router Setup.
Help	Read the guides and find troubleshooting steps.

Before you play

1. Connect the camera and point it at your playing area.
2. Open **Dashboard** and choose your player.
3. Hold your hand comfortably in view. Choose **Centre hand** if this is your first session or your camera or playing position changed.
4. Choose **Start controller**.
5. Launch a registered game on your console. Its game profile activates automatically; you do not need to keep the website open.
6. Rest your hand in the centre once, then try a movement or gesture.

Close local **Play** or **Glove Academy** before playing on the console; these activities pause console input.

Pick the right controls

You want to...	What to use
Play with direction and button gestures	A joystick profile for your game.
Play Super Glove Ball with hand movement	Nestopia (VirtualGlove) on your console.
Practise before starting a game	Learn > Glove Academy.
Check the gestures for a particular game	The Game and Gesture Guide .
Exit a console game	Your physical Player 1 controller's configured hotkey combination.

The glove's Select gesture is a game control. It is not the console's exit hotkey.

Choose players and systems

Open **Apps**, then **Setup** in Controller Router. Select your console.

1. Under **Players**, assign each pad to its player. Keep a physical pad on Player 1 for menus and exit controls.
2. Under **Systems**, choose **Controller Router** or **My existing setup**.
3. Close the game and choose **Save assignments**. The choices apply next time you launch a game.

Buddy's games and VirtualGlove require Controller Router enabled for NES. Other systems can keep your existing controls. Installation and upgrades preserve your saved choices.

Quick recovery

What you see	What to try
No hand detected	Check the camera, lighting, and that your full hand is visible.
Hand detected, but no movement	Choose Start controller , check the game filename, then rest your hand in the centre.
The wrong pad responds	Try another pad; check Router Setup > Players .
A wireless pad sleeps or wakes	Wake it. If Router itself restarted, close and relaunch the game.
The console is not connected	Check its address in Setup and complete pairing if requested.
A gesture is difficult to recognise	Practise it in Learn before changing its settings.

Install, upgrade, or learn more

Use the same installation command for a fresh install and an upgrade. Follow the [Installation Guide](#) for your console and UNO Q.

- [Controller Router](#): players, systems, and pad testing.
- [Camera Guide](#): placement and the camera check.
- [Troubleshooting](#): symptoms and recovery steps.
- [Configuration Reference](#): developer and maintenance details.