Harbour & Pine Outdoor Co. Product Care Guide

Waterproof jackets: wash at 30 degrees Celsius using a technical wash product. Do not use fabric softener, as it damages the waterproof coating. Re-proof your jacket every 12 months.

Tents: make sure the tent is completely dry before packing it away. Packing a damp tent causes mold.

Sleeping bags: store them loose in the large cotton sack provided, not compressed in the stuff sack.