How to change a flat tire Area. and tire iron back in trunk. Find a Safe/Flat area? tire. Tighten them with the tire iron. emergency brake. and replace it with spare tire. compartment in your car. on flat tire. Is the clearance to remove flat tire) find the jack and tire iron? Stay in car and call a tow truck.