REMOVAL/INSTALLATION Page 1 of 1

REMOVAL/INSTALLATION

Remove the following:

- Windscreen socket bolts [1]
- Plastic washers [2]
- Rubber washers [3]
- Windscreen [4]

Remove the well nuts [5] and windscreen bracket cover [6].

Installation is in the reverse order of removal.

TORQUE:

Windscreen socket bolt:

0.54 N·m (0.06 kgf·m, 0.4 lbf·ft)

