REMOVAL/INSTALLATION Page 1 of 1

## **REMOVAL/INSTALLATION**

## Remove the following:

- Socket bolt A [1]
- Socket bolts B [2]
- Socket bolt C [3]
- Washer A [4]
- Washers B [5]
- Grommet A [6]
- Grommet B [7]
- Collar A [8]
- Collars B [9]
- Collar C [10]

Release the boss [11] from the grommet [12]. Remove the under cover [13]. Installation is in the reverse order of removal.

