REMOVAL/INSTALLATION Page 1 of 1

REMOVAL/INSTALLATION

Remove the socket bolt [1] and heel guard [2]. Installation is in the reverse order of removal.

